Set up Raspberry PICO

Raspberry Pico Documentation:

https://www.raspberrypi.com/documentation/microcontrollers/

MicroPython software environment:

1. Drag-and-Drop MicroPython

Download the correct MicroPython UF2 file, then copy it to Pico (with MacOS Ventura 13.0 or 13.1, use terminal below)

```
cp -X ~/Desktop/Pico/rp2-pico-20230426-v1.20.0.uf2 /Volume
s/RPI-RP2
```

Connecting to the MicroPython REPL (readevaluate-print loop), using CoolTerm (baud rate 115200)

```
print("Hello, Pico!")
from machine import Pin
led = Pin("LED", Pin.OUT)
led.value(1)
```

Using an Integrated Development Environment (IDE)
 install Pico-W-Go Visual Studio Code Extension
 open VS Code command palette (using Cmd-Shift-P on a Mac)
 run 'Pico-W-Go > Configure Project'
 then run your code