























```
P1 Jumper settings
1-2 = Battery
3-4 = EXT VDD

Debug Connector
1 GND 2 VDD
3 P2.2/DC 4 P2.1/DD
5 P0.4/SSN 6 P0.5/SCK
7 RESET_N 8 P0.3/MOS1
9 VDD_EXT 10 P0.2/MISO
```



