
station_01 — PASSED
STARTING
APPROACH_STATION
STATION_KEEP
mission centre
World y (m)
World x (m)
position error
position threshold (0.5 m)
heading error
Position / radial error (m)
Heading error (deg)
Simulation time since mission samples (s)
left
right
lateral
Normalized thrust command
Wall time since first observed command (s)