Omni-Sense

User Guide

Step 1. Power Omni-Sense via power switch on right side.

Step 2. Adjust red band for correct neck placement (As shown in picture below)

Step 3. Verify Omni-Sense is operational, as seen in picture below.



Step 3A. When Temperature is above 85 Degrees F or Humidity above 80%, Omni-Sense will give off an audio alert as well as a red light alert.



Step 3B. When Temperature is below 50 Degrees F, Omni-Sense will give off an audio alert as well as a blue light alert.