Acme D-200 tumble dryer - Service Manual

Revision A. For trained service technicians.

1. Safety precautions

Read this section before any repair step. Safety steps always come first.

- Isolate the machine from mains power and apply lockout/tagout before opening any panel.
- Wait 5 minutes after isolation before touching inverter or capacitor terminals.
- Never bypass the door lock switch or the thermal cut-out.
- Steam and hot water lines stay pressurised after shutdown. Let them cool and vent them first.

2. Alarm codes

Code	Meaning	Condition	First action
E1	Airflow restriction	Pressure drop across the exhaust duct above limit.	Clean the lint filter and inspect the exhaust duct.
E2	Exhaust over-temperature	Exhaust air above 85 C.	Check the thermostat and the fan belt.
E3	Heater ignition failure	No flame signal within 10 seconds.	Isolate gas and power, then inspect the ignition electrode.
E4	Drum drive overload	Drive motor current above limit.	Isolate power and check the drum bearings and the drive belt tension.
E5	Lint filter blocked	Filter differential pressure above limit.	Empty and clean the lint filter.
E6	Moisture sensor fault	Sensor value constant for 5 minutes.	Clean the sensor bars and check the connector.

3. Troubleshooting procedures

3.1 Alarm E1: Airflow restriction

Safety: isolate the machine and apply lockout/tagout before opening the panel.

Condition: Pressure drop across the exhaust duct above limit.

Procedure: Clean the lint filter and inspect the exhaust duct. If the alarm returns after the check, escalate to the service desk with the alarm code and the cycle step.

3.2 Alarm E2: Exhaust over-temperature

Safety: isolate the machine and apply lockout/tagout before opening the panel.

Condition: Exhaust air above 85 C.

Procedure: Check the thermostat and the fan belt. If the alarm returns after the check, escalate to the service desk with the alarm code and the cycle step.

3.3 Alarm E3: Heater ignition failure

Safety: isolate the machine and apply lockout/tagout before opening the panel.

Condition: No flame signal within 10 seconds.

Procedure: Isolate gas and power, then inspect the ignition electrode. If the alarm returns after the check, escalate to the service desk with the alarm code and the cycle step.

3.4 Alarm E4: Drum drive overload

Safety: isolate the machine and apply lockout/tagout before opening the panel.

Condition: Drive motor current above limit.

Procedure: Isolate power and check the drum bearings and the drive belt tension. If the alarm returns after the check, escalate to the service desk with the alarm code and the cycle step.

4. Maintenance schedule

Interval	Task
Daily	Clean door seal and filters
Monthly	Inspect belts and drain filter
Yearly	Test safety switches and thermal cut-outs