# **ITMO**

Mathematic modelling of mechanical systems dynamic

Sergey Lovlin, Galina Demidova, Aleksandr Mamatov Faculty of Control System and Robotics

#### **Outline**



1. Introduction






- 2. Lumped mass method
- 3. Basic dynamic elements of mechanical systems
- 4. Dynamical models of mechanical systems

#### Introduction






#### Introduction




Mechanical systems are modelled, basically, as systems with lumped-parameter elements;

- ☐ From the energy point of view mechanical systems can be described with dissipative elements, potential energy storage elements, kinetic energy storage elements;
- Forces and moments which drive mechanical system are typically applied by actuators but might represent other loads applied by the environment.



Translational movement



Rotational movement

## **Lumped mass method**

elements.



- ☐ Display of physical properties in a dynamic model as a collection of discrete

- ☐ All elements are simple. Each relates to only one physical property.
- ☐ The state of a simple element is characterized by one phase variable of the flow type and one variable of the potential type.
- ☐ A component equation is an equation that describes the physical property of an element in the form of a relationship between phase variables.

## **Lumped mass method**



☐ The main physical properties of technical objects of any physical nature:



- ✓ inertial;
- ✓ elastic;
- ✓ dissipative.

☐ Friction and transformer elements display specific properties that are not characteristic of all technical objects. Those elements should be considered separately

# **Lumped mass method – Component equations**



☐ Approximation of models.



An example of replacing partial derivatives of phase variables with respect to spatial coordinates by ratios of finite differences:

$$\frac{\partial \varphi}{\partial x} = \frac{\varphi_1 - \varphi_2}{l_x}$$

☐ Obtaining equations based on physical laws:

$$\varphi_J = J \frac{d\Phi_J}{dt}$$

$$\varphi_D = D\Phi_D$$

$$\varphi_E = E \int \Phi_E dt$$

# Lumped mass method – Topological equations



**□** Equilibrium condition:

**Continuity condition:** 

$$\sum_{k} \Phi_{k} = 0$$

☐ The form of component and topological equations is the same for systems of different physical nature.

# **Lumped mass method – Topological equations**



☐ Translational movement:

☐ Rotational movement:



✓ linear speed v;

 $\checkmark$  angular velocity  $\omega$ ;

✓ force F.

- ✓ torque T.
- $\Box$  Flow type phase variables ( $\Phi$ ):
- ✓ force F;
- ✓ torque T.
- $\Box$  Phase variables of potential type ( $\phi$ ):
- ✓ linear speed v;
- $\checkmark$  angular velocity  $\omega$ .

## Dynamic equation of motion




Consider that a driving force  $F_M$  acts on an object of mass m, so that the object moves at a speed v.



From Newton's second law: 
$$F_M - F_L = \frac{d}{dt}(mv) = m\frac{dv}{dt} + v\frac{dm}{dt}$$

If the mass m of the load is constant:  $F_M - F_L = m \frac{dv}{dt} = ma$ 



# Dynamic equation of motion




For a rotational motion:



$$T_{M} - T_{L} = \frac{d}{dt}(J\omega) = J\frac{d\omega}{dt} + \omega\frac{dJ}{dt}$$

If the inertia *J* assumed to be constant:

$$T_{M} - T_{L} = J \frac{d\omega}{dt} = J\varepsilon$$



We can see that if  $T_M > T_L$ , then the object will accelerate, and if  $T_M > T_L$ , then it will decelerate.

In the case of  $T_M=T_L$ , the speed will not be changed.

### Dynamic equation of motion



From the motor's viewpoint, a mechanical load can be seen as a load torque T<sub>L</sub> connected to its shaft. The equation of motion of a motor drive system:






$$T_{M} = (J_{M} + J_{L}) \frac{d\omega}{dt} + T_{L}$$

When the motor is driving a mechanical load, the torque required to run the load is the load torque  $T_L$ , which varies with the type of load. When a load begins to move and is in motion, a friction force occurs, resisting the motion. The equation of motion needs to include the friction force  $T_{\scriptscriptstyle E}$  as

$$T_{M} = (J_{M} + J_{L}) \frac{d\omega}{dt} + T_{L} + T_{F}$$

This equation is also known one-mass model of mechanical subsystem



# Combination system of translational motion and rotational motion




Many motions in the industry such as an elevator, a conveyor, or electric vehicles are a combination of translational motion and rotational motion. In this case, we need to convert the load parameters such as load inertia to the motor shaft.



The expression for the translational motion:

$$F_{M} - F_{L} = m \frac{dv}{dt}$$



The relationships between force and torque, and velocity and angular velocity are:

$$T_M = rF_M$$
  $T_L = rF_L$   $\omega = \frac{v}{r}$ 

Resulting equation from the motor's point of view:

$$T_{M} - T_{L} = mr^{2} \frac{d\omega}{dt} = J_{e} \frac{d\omega}{dt}$$

 $T_{M} - T_{L} = mr^{2} \frac{d\omega}{dt} = J_{e} \frac{d\omega}{dt}$  where J<sub>e</sub> represents the equivalent moment of inertia, which is reflected to the motor shaft side of the mass m in translational motion.

## System with gears or pulleys



Often, the speed required by the load is too low compared to the nominal speed of the motor. Gears or pulleys between the motor and the load being driven are most often used to change the speed. In this case, we need to know how the load will be seen through the gears or pulleys at the motor side.






The equation of motion at the load side:

$$T_L = J_L \frac{d\omega_L}{dt}$$

Because the two gears will travel at an equal distance, we have:

$$\omega_L = \omega_M \, \frac{N_1}{N_2}$$

where  $N_1$  and  $N_2$  are the number of teeth on the gears of the motor and load sides, respectively.



# System with gears or pulleys



When neglecting friction and losses of the gears, the power is the same at the input and at the output of the gear, i.e.:



Load

$$P = T_L \omega_L = T_M \omega_M \quad \rightarrow \quad T_L = \frac{N_2}{N_1} T_M$$

The equation of motion at the motor side is given by:

$$T_{M} = J_{L} \left(\frac{N_{1}}{N_{2}}\right)^{2} \frac{d\omega_{M}}{dt} + J_{M} \frac{d\omega_{M}}{dt} = \left(J_{L} \left(\frac{N_{1}}{N_{2}}\right)^{2} + J_{M}\right) \frac{d\omega_{M}}{dt}$$

$$J_{M}$$
Motor
$$J_{M}$$

$$J_{M}$$


# Basic dynamic elements of mechanical systems




Mechanical systems consist **three** basic elements:



- ☐ Inertia elements
- ☐ Spring elements (elastic)
- ☐ Damper elements (dissipative)



Translational movement




Rotational movement


#### **Inertia elements**



#### **Inertia elements:**

- ☐ Mass for translational movement
- ☐ Rotational inertia for rotational movement
- ☐ Each inertia element with independent motion needs its own differential equation
- ☐ Inertia elements store kinetic energy







Rotational movement

#### **Inertia elements**









Rotational movement

Mass, m, [kg]



Element



Rotational inertia, J,  $[kg \cdot m^2]$ 

Newton 2<sup>nd</sup> law

 $\sum F = ma$ 



Force (torque) equation



Euler 2<sup>nd</sup> law

$$\sum T = J\varepsilon$$

$$E = \frac{1}{2}mv^2$$



Kinetic energy



$$E = \frac{1}{2}J\omega^2$$

#### **Inertia elements**





Point mass at radius r

$$J = mr^2$$



Cylindrical shell about axis c-c (inner radius r)





Rod or bar about centroid

$$J = \frac{mL^2}{12}$$



If outer radius is R, and not thin shell,


 $J = mr^2$ 

$$J = \frac{1}{2}m(R^2 + r^2)$$



Cylinder about axis c-c (radius r)

$$J = \frac{1}{2}mr^2$$



Short bar about pivot

$$J = \frac{m}{12} \left( d^2 + 4l^2 \right)$$


Slender bar case, *d*=0


## **Spring elements**



#### **Spring elements:**


- ☐ Force (torque) is generated to resist deflection
- ☐ Examples: translational and rotational springs. Even steel rod has stiffness
- ☐ Spring elements store potential energy







# **Spring elements**









Rotational movement

Translational movement

Stiffness, k, [N/m]



Element



Stiffness, K, [N·m/rad]

$$F = k(x_1 - x_2)$$



Force (torque) equation



$$T = K(\theta_1 - \theta_2)$$

$$E = \frac{1}{2}kx^2$$




Potential energy




$$E = \frac{1}{2}K\theta^2$$

# **Spring elements**





Translational movement



Rotational movement


$$F = k(x_1 - x_2)$$





Force (torque) equation



$$T = K(\theta_1 - \theta_2)$$









# **Connection of spring elements**





$$k_1 x + k_2 x = F = k_{eq} x$$
$$k_{eq} = k_1 + k_2$$



$$k_{1}y = F k_{2}(x - y) = F$$

$$k_{2}\left(x - \frac{F}{k_{1}}\right) = F$$

$$k_{1} = \frac{1}{k_{1}}$$









#### **Damper elements:**


- ☐ Force (torque) is generated to resist motion
- ☐ Examples: dashpots, friction, wind drag
- ☐ Damper elements dissipate energy






Rotational movement







Translational movement

Rotational movement

Damping, b,  $[N\cdot s/m]$ 



Element



Damping, b, [N·m·s/rad]

 $F = b(\dot{x}_1 - \dot{x}_2)$ 



Force (torque) equation



$$T = b(\dot{\theta}_1 - \dot{\theta}_2)$$

 $E = bV^2$ 




Dissipated energy



 $E = b\omega^2$ 





Translational movement




]

Force (torque) equation




$$T = b(\dot{\theta}_1 - \dot{\theta}_2)$$

Rotational movement




 $F = b(\dot{x}_1 - \dot{x}_2)$ 




# **iTMO**

#### Linear damping:



 $F = b\dot{x}$ 


#### Coulomb friction:



 $F = b \cdot \operatorname{sgn}(\dot{x})$ 








$$F = b\dot{x}^2$$




Real friction function combines aspects of multiple model types





# **Connection of damper elements**





$$F = b_1(\dot{y} - \dot{x}) + b_2(\dot{y} - \dot{x}) =$$

$$= (b_1 + b_2)(\dot{y} - \dot{x})$$

$$F = b_{eq} (\dot{y} - \dot{x})$$
$$b_{eq} = b_1 + b_2$$

$$F = b_1(\dot{z} - \dot{x}) = b_2(\dot{y} - \dot{z})$$

$$\dot{z} = \frac{1}{b_1 + b_2} \left( b_2 \dot{y} + b_1 \dot{y} \right)$$

$$F = b_{eq} (\dot{y} - \dot{x}) = b_2 \left[ \dot{y} - \frac{1}{b_1 + b_2} (b_2 \dot{y} + b_1 \dot{y}) \right] = \frac{b_1 b_2}{b_1 + b_2} (\dot{y} - \dot{x})$$

$$b_{eq} = \frac{b_1 b_2}{b_1 + b_2} = \frac{1}{\frac{1}{b_1} + \frac{1}{b_2}}$$










Consider the spring-mass-dashpot system mounted on a massless cart. Let us obtain mathematical models of this system by assuming that the cart is standing still for t < 0 and the spring-mass-dashpot system on the cart is also standing still for t < 0. In this system, u(t) is the displacement of the cart and is the input to the system. At t=0, the cart is moved at a constant speed, or constant. The displacement y(t) of the mass is the output. In this system, m denotes the mass, m denotes the viscous-friction coefficient, and m denotes the spring constant.



For translational systems, Newton's second law states that:  $\sum F = ma$ 

$$m\frac{d^2y}{dt^2} = -b\left(\frac{dy}{dt} - \frac{du}{dt}\right) - k(y - u)$$

$$m\frac{d^2y}{dt^2} + b\frac{dy}{dt} + ky = b\frac{du}{dt} + ku$$






This equation represents a mathematical model of the system considered. Taking the Laplace transform of this last equation, assuming zero initial condition, gives:

$$(ms^2 + bs + k)Y(s) = (bs + k)U(s)$$

$$G(s) = \frac{Y(s)}{U(s)} = \frac{bs + k}{ms^2 + bs + k}$$

Such a transfer-function representation of a mathematical model is used very frequently in control engineering.





Next, we shall obtain a state-space model of this system. We shall first compare the differential equation for this system:






$$\ddot{y} + \frac{b}{m}\dot{y} + \frac{k}{m}y = \frac{b}{m}\dot{u} + \frac{k}{m}u$$

with the standard form

$$\ddot{y} + a_1 \dot{y} + a_2 y = b_0 \ddot{u} + b_1 \dot{u} + b_2 u$$

and identify  $a_1$ ,  $a_2$ ,  $b_0$ ,  $b_1$ , and  $b_2$  as follows:

$$a_1 = \frac{b}{m}$$
  $a_2 = \frac{k}{m}$   $b_0 = 0$   $b_1 = \frac{b}{m}$   $b_2 = \frac{k}{m}$ 





Then, we can obtain state space model using the follows technique





$$\beta_0 = b_0 = 0$$

$$\beta_1 = b_1 - a_1 \beta_0 = \frac{b}{m}$$

$$\beta_2 = b_2 - a_1 \beta_1 - a_2 \beta_0 = \frac{k}{m} - \left(\frac{b}{m}\right)^2$$

$$\dot{x}_1 = x_2 + \beta_1 u = x_2 + \frac{b}{m} u$$

$$\dot{x}_2 = -a_2 x_1 - a_1 x_2 + \beta_2 u = -\frac{k}{m} x_1 - \frac{b}{m} x_2 + \left[ \frac{k}{m} - \left( \frac{b}{m} \right)^2 \right] u$$

$$x_2 = \dot{x}_1 - \beta_1 u = \dot{x}_1 - \frac{b}{m}u$$

 $x_1 = y - \beta_0 u = y$ 

$$y = x_1$$




#### Vector-matrix representation



$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ -\frac{k}{m} & -\frac{b}{m} \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} \frac{b}{m} \\ \frac{k}{m} - \left(\frac{b}{m}\right)^2 \end{bmatrix} u$$

$$y = \begin{bmatrix} 1 & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix}$$





Consider the mechanical system shown in Figure and find transfer functions  $X_1(s)/U(s)$  and  $X_2(s)/U(s)$ .






The equations of motion for the system:

$$m_1 \ddot{x}_1 = -k_1 x_1 - k_2 (x_1 - x_2) - b(\dot{x}_1 - \dot{x}_2) + u$$
  

$$m_2 \ddot{x}_2 = -k_3 x_2 - k_2 (x_2 - x_1) - b(\dot{x}_2 - \dot{x}_1)$$

Simplifying, we obtain:

$$m_1\ddot{x}_1 + b\dot{x}_1 + (k_1 + k_2)x_1 = b\dot{x}_2 + k_2x_2 + u$$
  
 $m_2\ddot{x}_2 + b\dot{x}_2 + (k_2 + k_3)x_2 = b\dot{x}_1 + k_2x_1$ 





Taking the Laplace transforms of these two equations, assuming zero initial conditions, we obtain:



$$(m_1 s^2 + bs + (k_1 + k_2)) X_1(s) = (bs + k_2) X_2(s) + U(s)$$
$$(m_2 s^2 + bs + (k_2 + k_3)) X_2(s) = (bs + k_2) X_1(s)$$

Transfer functions:

$$\frac{X_1(s)}{U(s)} = \frac{m_2 s^2 + b s + k_2 + k_3}{\left(m_1 s^2 + b s + k_1 + k_2\right) \left(m_2 s^2 + b s + k_2 + k_3\right) - \left(b s + k_2\right)^2}$$

$$\frac{X_2(s)}{U(s)} = \frac{b s + k_2}{\left(m_1 s^2 + b s + k_1 + k_2\right) \left(m_2 s^2 + b s + k_2 + k_3\right) - \left(b s + k_2\right)^2}$$

#### **Examples**




Figure (a) shows a schematic diagram of an automobile suspension system.

As the car moves along the road, the vertical displacements at the tires act as the motion excitation to the auto mobile suspension system.

The motion of this system consists of a translational motion of the center of mass and a rotational motion about the center of mass.

Mathematical modeling of the complete system is quite complicated.




#### **Examples**



A very simplified version of the suspension system is shown in Figure (b).

Assuming that the motion  $x_i$  at point P is the input to the system and the vertical motion  $x_o$  of the body is the output, obtain the transfer function  $X_o(s)/X_i(s)$ . (Consider the motion of the body only in the vertical direction.)

Displacement  $x_o$  is measured from the equilibrium position in the absence of input  $x_i$ .



#### **Examples**





The equation of motion for the system shown in (b) is

$$m\ddot{x}_o + b(\dot{x}_o - \dot{x}_i) + k(\dot{x}_o - \dot{x}_i) = 0$$

Taking the Laplace transform of this last equation, assuming zero initial conditions, we obtain:

$$(ms^{2} + bs + k)X_{o}(s) = (bs + k)X_{i}(s)$$
$$\frac{X_{o}(s)}{X_{i}(s)} = \frac{bs + k}{ms^{2} + bs + k}$$





(b)

# Dynamical models of rotating mechanical systems




Basic kinematic diagrams for electromechanical systems:






One-mass system




Two-mass system



 $T_M$  – motor torque

T<sub>1</sub> – load torque

Three-mass system




 $T_S$  – spring torque

T<sub>D</sub> – damper torque



#### One-mass system



$$\begin{cases} J_{\Sigma} \frac{d\omega_{1}(t)}{dt} = T(t) - T_{L}(t), \\ J_{\Sigma} = J_{1} + J_{2} \end{cases}$$



$$W_{mech2}(s) = \frac{\omega_1(s)}{T(s)} = \frac{1}{J_1 + J_2} \cdot \frac{1}{s}.$$



#### Two-mass system

$$T_{M}$$
,  $-T_{L1}$ ,  $-T_{S12}$ ,  $-T_{D12}$   $-T_{L2}$ ,  $T_{S12}$ ,  $T_{D12}$ 

$$\begin{array}{c|ccccc}
 & K_{12} & & & & & & \\
 & J_1 & & & & & & & \\
 & \omega_1 & & & & & & & \\
 & \theta_2 & & & & \theta_2
\end{array}$$

#### Sensor is installed on the first inertia mass

$$W_{mech2}(s) = \frac{\omega_1(s)}{T(s)} = \frac{1}{J_1 + J_2} \cdot \frac{\frac{J_2}{K_{12}} s^2 + \frac{b_{12}}{K_{12}} s + 1}{s(\frac{J_1 J_2}{K_{12} + J_2}) s^2 + \frac{b_{12}}{K_{12}} s + 1}.$$

Sensor is installed on the second inertia mass


$$W_{mech2}(s) = \frac{\omega_{1}(s)}{T(s)} = \frac{1}{J_{1} + J_{2}} \cdot \frac{\frac{J_{2}}{K_{12}}s^{2} + \frac{b_{12}}{K_{12}}s + 1}{s(\frac{J_{1}J_{2}}{K_{12}(J_{1} + J_{2})}s^{2} + \frac{b_{12}}{K_{12}}s + 1)} \cdot W_{mech3}(s) = \frac{\omega_{2}(s)}{T(s)} = \frac{1}{J_{1} + J_{2}} \cdot \frac{\frac{b_{12}}{K_{12}}s + 1}{s(\frac{J_{1}J_{2}}{K_{12}(J_{1} + J_{2})}s^{2} + \frac{b_{12}}{K_{12}}s + 1)}.$$



#### Three-mass system







$$\begin{cases} J_{1} \frac{d\omega_{1}(t)}{dt} = T(t) - T_{s12}(t) - b_{12} \left(\omega_{1}(t) - \omega_{2}(t)\right) - T_{L1}(t), \\ \frac{dT_{s12}(t)}{dt} = K_{12}(\omega_{1}(t) - \omega_{2}(t)), \\ J_{2} \frac{d\omega_{2}(t)}{dt} = T_{s12}(t) + b_{12} \left(\omega_{1}(t) - \omega_{2}(t)\right) - T_{s23}(t) - b_{23} \left(\omega_{2}(t) - \omega_{3}(t)\right) - T_{L2}(t), \\ \frac{dT_{s23}(t)}{dt} = K_{23}(\omega_{2}(t) - \omega_{3}(t)), \\ J_{3} \frac{d\omega_{3}(t)}{dt} = T_{s23}(t) + b_{23} \left(\omega_{2}(t) - \omega_{3}(t)\right) - T_{L3}(t). \end{cases}$$



#### Multi-mass system

$$\begin{cases} J_{1} \frac{d\omega_{1}(t)}{dt} = T(t) - T_{s12}(t) - b_{12} \left(\omega_{1}(t) - \omega_{2}(t)\right) - T_{L1}(t), \\ \frac{dT_{s12}(t)}{dt} = K_{12}(\omega_{1}(t) - \omega_{2}(t)), \\ J_{2} \frac{d\omega_{2}(t)}{dt} = T_{s12}(t) + b_{12} \left(\omega_{1}(t) - \omega_{2}(t)\right) - T_{s23}(t) - b_{23} \left(\omega_{2}(t) - \omega_{3}(t)\right) - T_{L2}(t), \\ \frac{dT_{s23}(t)}{dt} = K_{23}(\omega_{2}(t) - \omega_{3}(t)), \\ \dots \\ J_{n-1} \frac{d\omega_{n-1}(t)}{dt} = T_{sn-2n-1}(t) + b_{n-2n-1} \left(\omega_{n-2}(t) - \omega_{n-1}(t)\right) - T_{sn-1n}(t) - b_{n-1n} \left(\omega_{n-1}(t) - \omega_{n}(t)\right) - T_{Ln-1}(t), \\ \frac{dT_{sn-1n}(t)}{dt} = K_{n-1n}(\omega_{n-1}(t) - \omega_{n}(t)), \\ J_{n} \frac{d\omega_{n}(t)}{dt} = T_{sn-1n}(t) + b_{n-1n} \left(\omega_{n-1}(t) - \omega_{n}(t)\right) - T_{Ln}(t), \end{cases}$$





# If the sensor is installed on the first inertia mass:

$$W_{mech}(s) = \frac{\omega_1(s)}{T(s)} = \frac{K_{\omega} \prod_{i=2,4,6,...}^{n} T_i^2 s^2 + 2\nu T_i s + 1}{s \prod_{i=1}^{n-1} T_i^2 s^2 + 2\varsigma T_j s + 1},$$


$$K_{\infty} = \frac{1}{J_1 + J_2 + \ldots + J_n} = \frac{1}{J_{\Sigma}}.$$




Three-mass mechanical system is considered









Assume 
$$T_{L1} = T_{L2} = T_{L3} = 0$$
,  $B_{12} = B_{23} = 0$ 



 $J_3 \frac{d\omega_3(t)}{dt} = T_{s23}(t).$ 











$$s^{4} + \left[J_{1}K_{23}(J_{2} + J_{3}) + K_{12}J_{3}(J_{1} + J_{2})\right]s^{2} + K_{12}K_{23}(J_{1} + J_{2} + J_{3})).$$

Characteristic polynomial:

$$D(s) = s(J_1J_2J_3s^4 + \lceil J_1K_{23}(J_2 + J_3) + K_{12}J_3(J_1 + J_2) \rceil s^2 + K_{12}K_{23}(J_1 + J_2 + J_3)).$$



#### Characteristic equation:





$$D(s) = s(J_1J_2J_3s^4 + \lceil J_1K_{23}(J_2 + J_3) + K_{12}J_3(J_1 + J_2)\rceil s^2 + K_{12}K_{23}(J_1 + J_2 + J_3)) = 0.$$

Poles of the transfer function:

$$s_1 = 0;$$

$$s_{2,3} = \pm j \sqrt{\frac{a}{2} \left( 1 - \sqrt{1 - \frac{4b}{a^2}} \right)} = \pm j \omega_{R1};$$


$$s_{4,5} = \pm j \sqrt{\frac{a}{2} \left( 1 + \sqrt{1 - \frac{4b}{a^2}} \right)} = \pm j \omega_{R2}.$$

$$a = \frac{J_3 K_{12} (J_1 + J_2) + J_1 K_{23} (J_2 + J_3)}{J_1 J_2 J_3};$$

$$b = \frac{K_{12}K_{23}(J_1 + J_2 + J_3)}{J_1J_2J_3}.$$

 $\omega_{R1}$ , - resonant frequencies of the three-mass system









Two-mass mechanical system is considered







Assume  $T_{L1} = T_{L2} = 0$ ,  $B_{12} = 0$ 





$$\begin{cases} J_{1} \frac{d\omega_{1}(t)}{dt} = T(t) - T_{s12}(t), \\ \frac{dT_{s12}(t)}{dt} = K_{12}(\omega_{1}(t) - \omega_{2}(t)), \\ J_{2} \frac{d\omega_{2}(t)}{dt} = T_{s12}(t) \end{cases}$$

$$\begin{bmatrix} \mathbf{T}_{\mathsf{M'}} & -\mathbf{T}_{\mathsf{S}12} & & & \\ & \mathbf{J}_{\mathsf{1}} & & & & \\ & & \mathbf{J}_{\mathsf{2}} & & & \\ & & & \mathbf{D}_{\mathsf{2}} & & \\ & & & & \mathbf{D}_{\mathsf{2}} & \\ & & & & & \mathbf{D}_{\mathsf{2}} & \\ \end{bmatrix}$$

$$W_{mech2}(s) = \frac{\omega_1(s)}{T(s)} = \frac{\frac{J_2}{K_{12}}s^2 + 1}{\left(J_1 + J_2\right)s\left(\frac{J_1J_2}{K_{12}\left(J_1 + J_2\right)}s^2 + 1\right)}.$$

Characteristic polynomial:

$$D(s) = (J_1 + J_2)s \left( \frac{J_1 J_2}{K_{12} (J_1 + J_2)} s^2 + 1 \right).$$







#### Characteristic equation:

$$D(s) = (J_1 + J_2)s \left( \frac{J_1 J_2}{K_{12} (J_1 + J_2)} s^2 + 1 \right) = 0.$$



Poles of the transfer function:

$$s_1 = 0;$$


$$s_{2,3} = \pm j \sqrt{\frac{K_{12}(J_1 + J_2)}{J_1 J_2}} = \pm j \omega_{R1};$$


$$\omega_{\it R1}$$
. - resonant frequency of the two-mass system


$$\omega_{R1} = \sqrt{\frac{K_{12} \left(J_1 + J_2\right)}{J_1 J_2}} = \sqrt{\frac{K_{12} \gamma}{J_2}}$$

$$\gamma = \frac{J_1 + J_2}{J_1} \quad \text{- mass ratio}$$













Transformation of the three-mass system into two-mass system








Assume  $K_{23} = \infty$ ,  $J_{2}' = J_{2} + J_{3}$ 




#### Case 1






#### Case 2








Transformation is irrelevant



$$\begin{split} & \omega_{R1} = \sqrt{\frac{K_{12} \left(J_1 + J_2\right)}{J_1 J_2}} = \sqrt{\frac{K_{12} \gamma}{J_2}} \\ & \gamma = \frac{J_1 + J_2}{J_1} \quad \text{- mass ratio} \end{split}$$

- At  $\gamma > 3$  mass ratio has no effect on resonant frequency;
- At  $\gamma$  < 1.5 the value of the resonant frequency increases extremely.






If  $J_1 >> J_2$  elastic joint has little effect on dynamical properties of the mechanical system




Transformation of the two-mass system into one-mass system









Assume  $K_{12} = \infty$ ,  $J_{1}' = J_{1} + J_{2}$ 



#### Case 1









#### Step response









Transformation is relevant

#### Case 2

100

-200


-300


-400 10<sup>-1</sup>

10<sup>0</sup>

Magnitude (dB)









10<sup>2</sup>

Frequency (rad/s)


10<sup>3</sup>











Transformation is irrelevant

# THANK YOU FOR YOUR TIME!

ITSMOre than a UNIVERSITY