6.2 Lubrication

Lubricate the machine with oil regularly according to the table below.

	Section	Term
(a)	Chuck table pad slide shaft	1 year
(b)	Linear guide for applying / peeling section	1 year
(c)	Ball screw for applying / peeling section	1 year





