## 9.5 Peeling speed adjustment

You can adjust the peeling speed with the controller at the lower rear part.

- PEELING UNIT SLOW DOWN (VR00708): Adjusts the peeling unit moving speed

Standard setting value: 0.38

- PEELING ROLL SLOW DOWN (VR00715): Adjusts the peeling roller moving speed. Adjust it

according to the procedure below.

Fig. 1 is for T3 mode peeling movement

Fig. 1: The appropriate setting speed of the peeling unit and peeling roller.






Fig.2: The peeling roller speed is slower than the peeling unit speed. The peeling tape has sag.

Fig.3: The peeling roller speed is faster than the peeling unit speed. The peeling tape has tension (red arrow)





<Speed adjustment procedure>

- 1. Set the speed so that the peeling roller speed is slower than the peeling unit speed, and make the tape sag as shown in Fig. 2.
- 2. Adjust the PEELING ROLL SLOW DOWN (VR00708) to speed up until the condition as shown in Fig.1.