

8.11 Robot teaching exit operation




(1) Press [SET] key on "INDIVIDUAL OPERATION SCREEN". MAIN SCREEN is displayed.



(2) Press [RESET] key on the teach pendant. The robot moves to the original point. The robot teaching mode is canceled.

(3) Press [MAINTENANCE] key on the teach pendant.



(4) Press [TEACH MODE] key on the MAIN SCREEN. Disconnect the teach pendant.