SOP-52-SAFE: Lockout / Tagout Standard Procedure

Step 1: Notification & Preparation

Notify the shift supervisor and DCS control room operator prior to applying lockout padlocks.

Step 2: Electrical Isolation

Open primary air circuit breaker ACB-Y52 on 3.3kV feeder bus. Discharge residual capacitor bank before entry.

Step 3: Hydraulic Pressure Depressurization

Open manual ball valve V-HYD-99 to release accumulator pressure until gauge reading reaches 0.0 MPa. Verify tag Y52-OIL-PRS01 returns to atmospheric reference.