

CSI API ETABS v1

cPointObj Interface

Namespace: [ETABSv1](#)**Assembly:** ETABSv1 (in ETABSv1.dll) Version: 1.0.0.0 (1.24.0.0)

▲Syntax

C# **VB** **C++** **F#**[Copy](#)

```
Public Interface cPointObj  
  
Dim instance As cPointObj
```

The [cPointObj](#) type exposes the following members.

▲Methods

	Name	Description
	AddCartesian	Adds a point object to a model. The added point object will be tagged as a Special Point except if it was merged with another point object. Special points are allowed to exist in the model with no objects connected to them.
	ChangeName	
	Count	
	CountLoadDispl	
	CountLoadForce	
	CountPanelZone	
	CountRestraint	
	CountSpring	
	DeleteLoadDispl	Deletes all ground displacement load assignments, for the specified load pattern, from the specified point object(s).

	DeleteLoadForce	Deletes all point force load assignments, for the specified load pattern, from the specified point object(s).
	DeleteMass	
	DeletePanelZone	
	DeleteRestraint	Deletes all restraint assignments from the specified point object(s).
	DeleteSpecialPoint	Deletes special point objects that have no other objects connected to them.
	DeleteSpring	Deletes all point spring assignments from the specified point object(s).
	GetAllPoints	Retrieves selected data for all point objects in the model
	GetCommonTo	
	GetConnectivity	Retrieves a list of objects connected to a specified point object
	GetCoordCartesian	Retrieves the x, y and z coordinates of the specified point object in the Present Units.
	GetCoordCylindrical	
	GetCoordSpherical	
	GetDiaphragm	Retrieves the diaphragm for a specified point object
	GetElm	
	GetGroupAssign	Retrieves the groups to which a point object is assigned.
	GetGUID	Retrieves the GUID for specified point object.
	GetLabelFromName	Retrieves the label and story for a unique point object name
	GetLabelNameList	Retrieves the names and labels of all defined point objects.

	GetLoadDispl	Retrieves the ground displacement load assignments to point objects.
	GetLoadForce	Retrieves the joint force load assignments to point objects.
	GetLocalAxes	Retrieves the local axis angles for a point object.
	GetMass	
	GetNameFromLabel	Retrieves the unique name of a point object, given the label and story level
	GetNameList	Retrieves the names of all defined point objects.
	GetNameListOnStory	Retrieves the names of the defined point objects on a given story.
	GetPanelZone	
	GetRestraint	Retrieves the restraint assignments for a point object. The restraint assignments are always returned in the point local coordinate system.
	GetSelected	
	GetSpecialPoint	
	GetSpring	Retrieves uncoupled spring stiffness assignments for a point object, that is, it retrieves the diagonal terms in the 6x6 spring matrix for the point object.
	GetSpringAssignment	Retrieves the named point spring property assignment for a point object
	GetSpringCoupled	
	GetTransformationMatrix	
	IsSpringCoupled	
	SetDiaphragm	Assigns a diaphragm to a point object
	SetGroupAssign	Adds or removes point objects from a specified group.

	SetGUID	Sets the GUID for specified point object. If the GUID is passed in as a blank string, the program automatically creates a GUID for the object.
	SetLoadDispl	Makes ground displacement load assignments to point objects.
	SetLoadForce	Makes point force load assignments to point objects.
	SetMass	
	SetMassByVolume	
	SetMassByWeight	
	SetPanelZone	
	SetRestraint	Assigns the restraint assignments for a point object. The restraint assignments are always set in the point local coordinate system.
	SetSelected	Sets the selected status for a point object.
	SetSpecialPoint	Sets the special point status for a point object.
	SetSpring	Assigns coupled springs to a point object.
	SetSpringAssignment	Assigns an existing named point spring property to point objects
	SetSpringCoupled	

[Top](#)

See Also

Reference

[ETABSv1 Namespace](#)

ETABS®, SAP2000® and CSiBridge® are registered trademarks of Computers and Structures, Inc. Copyright © Computers and Structures, Inc. 2022. All rights reserved.

Send comments on this topic to support@csiamerica.com