PWM Drawer


Content

► Types of Displays


► Graphical LCD

► PWM generator

Types of Displays



Graphical LCD



Graphical LCD

Initialization

- To initialize the display, we need to do the below steps,
- Send Display OFF command i.e. 0x3E
- ▶ Send Y address e.g. here 0x40 (Start address).
- ▶ Send X address (Page) e.g. here 0xB8 (Page0).
- Send Z address (Start line) e.g. here 0xC0 (from 0th line).
- ▶ Now send Display ON command i.e. 0x3F

PWM DRAWER

- ▶ We use the following:
- Graphical LCD
- PWM generator
- External interrupt
- Timer 0

Thank you