


TYPES OF NANOMATERIALS

Dr Rajeshkumar Mohanraman

Assistant Professor Grade 1 School of Advanced Sciences VIT Vellore

Methods of preparing nanomaterials



Chemical methods (most powerful)

React a metal salt with an alcohol or some other reducing agent

Metal compound along with a reagent in a boiling solvent (sealed vessel)

Under this condition, many kinds of nano-particles are formed



Hydrothermal and solvothermal methods

Water used as a boiling solvent - Hydrothermal

Organic boiling solvent like a hydrocarbon - solvothermal

For example, if we take a metal acetate and heat in a boiling hydrocarbon, we get metal or metal oxide nanoparticles

Today we have reached a level where can make nanomaterial of any compound in any shape we desired


Nanostructured materials

- 3D: Bulk material
- 2D: Quantum well, Thin films
- •1D: Quantum wires, nanowires
- •0D: Quantum dots


Quantum Confinement

Quantum Confinement is the spatial confinement of electron-hole pairs (excitons) in one or more dimensions within a material.


1D confinement: Quantum Wells 2D confinement: Quantum Wire 3D confinement: Quantum Dot




2D-Graphene Nanosheet



1D- ZnO Nanowire





0D- Carbon quantum dots

Quantum Confinement in Nanostructures: Overview

Electrons Confined in 1 Direction: Quantum Wells (thin films): ⇒ Electrons can easily move in 2 Dimensions! 1 Dimensional Electrons Confined in 2 Directions: Quantization! Quantum Wires: ⇒ Electrons can easily move in 1 Dimension! 2 Dimensional Quantization! Electrons Confined in 3 Directions: Quantum Dots: 3 Dimensional ⇒ Electrons can easily move in Quantization! 0 Dimensions!

- Density of states (dn/dE) is a function of dimensionality.
- Disceretness increases for lower dimensions of particles.


Dimensionality

Zero-dimensional (quantum dots) in which the movement of electrons is confined in all three dimensions.

one-dimensional (quantum wires) in which the electrons can only move freely in the X-direction.

Two-dimensional (quantum wells) in which case the free electron can move in the X-Y plane.

Three dimensional (nanostructured material built of nanoparticles as building blocks) in which the free electron can move in the X, Y and Z directions.



Quantum well


- •It is a two-dimensional system
- •The electron can move in two directions and restricted in one direction.


Quantum Wire

- •It is a one-dimensional system
- •The electron can move in one direction and restricted in two directions.

Quantum dot

- •It is a zero-dimensional system
- •The electron movement was restricted in entire three dimensions





Quantum confinement is more prominent in semiconductors because they have an energy gap in their electronic band structure.

Metals do not have a bandgap, so quantum size effects are less prevalent. Quantum confinement is only observed at dimensions below 2 nm.

STRUCTURE	SPATIAL DIMENSION	CONFINEMENT DIMENSION
Bulk	3	0
Surface/ Film (Quantum Well)	2	1
Nanotubes, -wires (Quantum wire)	1	2
Nano-particles, clusters (Quantum dots)	0	3



