Introduction to FreeRTOS Part 1

Characteristics of freeRTOS (Operating System)

- FreeRTOS is a "Embedded Operating System" for Embedded MicroController
- Software that provides multitasking facilities.
- FreeRTOS allows to run multiple tasks
- and has a simple scheduler to switch between tasks.


FreeRTOS features:

- Priority-based multitasking capability
- Queues to communicate between multiple tasks
- Semaphores to manage resource sharing between multiple tasks
- Utilities to view CPU utilization, stack utilization etc.

Supported CPUs (Ports):


http://www.freertos.org/RTOS_ports.html

FreeRTOS is supplied as a set of C source files. Some of the source files are common to all ports, while others are specific to a port.



FreeRTOS is supplied as a set of C source files. Some of the source files are common to all ports, while others are specific to a port.

FreeRTOSConfig.h: configure FreeRTOS.



Building FreeRTOS

tasks.c and list.c: FreeRTOS source code common to all the FreeRTOS ports and they are located directly in the FreeRTOS/Source directory

In addition to these two files, the following source files are located in the same directory: **queue.c and timer.c**

queue.c provides both queue and semaphore services. queue.c is nearly always required.

timers.c provides software timer functionality. It need only be included in the build if software timers are actually going to be used

Repository (Library) for freeRTOS

- A stand-alone board support package (BSP) is a library generated by the Xilinx SDK that is specific to a hardware design.
- It contains initialization code for bringing up the ARM CPUs in ZYNQ and also contains software drivers for all available ZYNQ peripherals.

The freeRTOS Repository

- The FreeRTOS port extends the stand-alone BSP to also include FreeRTOS source files
- After using this port in a Xilinx SDK environment, the user gets all the FreeRTOS source files in a FreeRTOS BSP library.
- This library uses the Xilinx SDK generated stand-alone BSP library.

Header Files

A source file that uses the FreeRTOS API must include 'FreeRTOS.h', followed by the header file that contains the prototype for the API function being used —

'task.h', 'queue.h', 'semphr.h', 'timers.h' or 'event_groups.h'.

A Task

- Simple C Function
- A pointer to parameters (void*) as input
- Creates a forever loop (while (1))
- The tasks are controlled by the Scheduler (freeRTOS internal function)


Each task has his own Stack:

- Every variable you declare or memory allocate uses memory on the stack.
- The stack size of a task depends on the memory consumed by its local variables and function call depth.
- Please note that if your task (or function) uses printf, it consumes around 1024 bytes of stack.
- At minimum however, you would need at least 256 bytes + your estimated stack space above.
- If you don't allocate enough stack space, your CPU will run to an exception and/or freeze

A Task

```
void myTask (void *pvParameters){
   /* variables declaration */
   Int IvariableExample = 0;
   /* Task implemented as a infinite loop */
   for (;;)
       /* Task Code here */
   /* Function vTaskDelete () delete itself passing NULL parameter */
   vTaskDelete ( NULL );
```

Top Level Task States



Creating a Task

The Task function itself:

```
void ATaskFunction( void *pvParameters)
{
    // do initilisation
    while (1)
    {
    // Task execution code
    }
}
```

Install the Task (in main.c):

Return pdPASS or pdFAIL (when insufficient heap memory)

Example

```
void hello_world_task (void* p)
{
    while(1)
    {
        Printf(" Hello World!");
        vTaskDelay(1000);
    }
}

void main(void)
{
    XtaskCreate (hello_world_task, "TestTask", 512, NULL, 1, NULL);
    vTaskStartScheduler();
    // never comes here
}
```

The main function in FreeRTOS based projects creates tasks. FreeRTOS will let you multi-task based on your tasks and their priority.

Data Types

two port specific data types:

TickType_t and **BaseType_t** (both in portmacro.h).

TickType_t: FreeRTOS configures a periodic interrupt called the tick interrupt. The time between two tick interrupts is called the tick period. Times are specified as multiples of tick periods.

BaseType_t: is generally used for return types that can take only a very limited range of values, and for pdTRUE/pdFALSE type Booleans.

Function Names


Functions are prefixed with both the type they return, and the file they are defined within. For example:

- vTaskPrioritySet() returns a void and is defined within task.c.
- xQueueReceive() returns a **variable** of type BaseType_t and is defined within queue.c.
- pvTimerGetTimerID() returns a pointer to void and is defined within timers.c.


Task running with the same priority

```
void vTaskFunction( void *pvParameters )
    char *pcTaskName;
    volatile uint32 t ul;
/*The string to print out is passed in via the parameter.*/
    pcTaskName = ( char * ) pvParameters;
/* As per most tasks, this task is implemented in an infiniteloop. */
    For( ;; )
         vPrintString( pcTaskName );/* Print out the name of this task. */
         for(ul = 0; ul < mainDELAY LOOP COUNT; ul++)/*Delay for a period. */
/* main function */
Static const char *pcTextForTask1 = "Task 1 is running\r\n";
static const char *pcTextForTask2 = "Task 2 is running\r\n";
int main(void)
/* Create one of the two tasks. */
    xTaskCreate(vTaskFunction, "Task 1", 1000, (void*)pcTextForTask1, 1, NULL);
/* Create the second task from the SAME task implementation (vTaskFunction). Only the value
passed in the parameter is different. */
    xTaskCreate(vTaskFunction, "Task 2", 1000, (void*)pcTextForTask2, 1, NULL);
/* Start the scheduler so the tasks start executing. */
    vTaskStartScheduler();
    for(;;);
```

Task running with the same priority



Task running with the same priority



To select the next task to run, the scheduler itself must execute at each periodic interrupt, called 'tick interrupt'.

Tick interrupt frequency, is configured by the application-defined configTICK_RATE_HZ contant (copilation time) within FreeRTOSConfig.h.


100Hz typical value

Time slice= 10ms

Task running with different priorities


```
void vTaskFunction( void *pvParameters )
    char *pcTaskName;
    volatile uint32 t ul;
/*The string to print out is passed in via the parameter.*/
    pcTaskName = ( char * ) pvParameters;
/* As per most tasks, this task is implemented in an infiniteloop. */
    For( ;; )
         vPrintString( pcTaskName );/* Print out the name of this task. */
         for(ul = 0; ul < mainDELAY LOOP COUNT; ul++)/*Delay for a period. */
/* main function */
Static const char *pcTextForTask1 = "Task 1 is running\r\n";
static const char *pcTextForTask2 = "Task 2 is running\r\n";
int main(void)
/* Create one of the two tasks. */
    xTaskCreate(vTaskFunction, "Task 1", 1000, (void*)pcTextForTask1, 1, NULL);
/* Create the second task with higher priority*/
    xTaskCreate(vTaskFunction, "Task 2", 1000, (void*)pcTextForTask2, 2, NULL);
/* Start the scheduler so the tasks start executing. */
    vTaskStartScheduler();
    for(;;);
```


Task running with different priorities



Task 2 with higher priority than task 1


Task running with different priorities





To make the tasks useful they must be re-written to be **event-driven**.

A task is triggered when an event occurs, and is not able to enter the Running state before that event has occurred.



When a task is waiting for an event is Blocked

To types of events

Temporal - Delays


Synchronization – Waiting for data in a queue

```
void vTaskFunction( void *pvParameters )
{
    char *pcTaskName;
    const TickType_t xDelay250ms = pdMs_TO_TICKS( 250 );
    volatile uint32_t ul;
/*The string to print out is passed in via the parameter.*/
    pcTaskName = ( char * ) pvParameters;
/* As per most tasks, this task is implemented in an infiniteloop. */
    For( ;; )
    {
        vPrintString( pcTaskName );/* Print out the name of this task. */
        vTaskDelay(xDelay250ms);
    }
}
```

vTaskDelay() places the task into the Blocked state until the delay period has expired.


void vTaskDelay(portTickType xTicksToDelay);

Expanding the 'Not Running' State




Expanding the 'Not Running' State

```
/* main function */
Static const char *pcTextForTask1 ="Task 1 is running\r\n";
static const char *pcTextForTask2 ="Task 2 is running\r\n";
int main(void)
{
    xTaskCreate(vTaskFunction, "Task 1",1000, (void*)pcTextForTask1,1,NULL);
    xTaskCreate(vTaskFunction, "Task 2",1000, (void*)pcTextForTask2,2,NULL);
    vTaskStartScheduler();
    for(;;);
}
```





Expanding the 'Not Running' State



More efficient implementation of tasks

Less use of processor time





The Suspended State is also a sub-state of Not Running.


Tasks in the Suspended state are not available to the scheduler.

vTaskSuspend()API

vTaskResume() or xTaskResumeFromISR() API functions.


Most applications do not use the Suspended state.

Expanding the 'Not Running' State



More efficient implementation of tasks

Less use of processor time




Executing periodic tasks

```
const TickType_t xDelay250ms = pdMs_TO_TICKS( 250 );


vTaskDelay(xDelay250ms);

number of tick interrupts that the calling task will remain in the Blocked state
```


Using vTaskDelay() does not guarantee that the frequency at which they run is fixed,



Executing periodic tasks




The parameters to vTaskDelayUntil() specify the exact tick count value at which the calling task should be moved from the Blocked state into the Ready state.



Executing periodic tasks


```
void vTaskFunction( void *pvParameters ) {
    char *pcTaskName;
    TickType_t xLastWakeTime;
    pcTaskName = ( char * ) pvParameters;
    xLastWakeTime = xTaskGetTickCount();/* current tickcount.*/
    for( ;; ) {/* Print out the name of this task. */
        vPrintString( pcTaskName );
    /*This task should execute every 250 milliseconds exactly.*/
        vTaskDelayUntil( &xLastWakeTime, pdMS_TO_TICKS( 250 ));
    }
}
```



Combining blocking and non-blocking tasks

```
void vContinuousFunction( void *pvParameters )
     char *pcTaskName;
     volatile uint32 t ul;
    pcTaskName = ( char * ) pvParameters;
     For(;;)
         vPrintString( pcTaskName ); /* Print out the name of this task. */
void vPeriodicFunction( void *pvParameters ) {
     char *pcTaskName;
     TickType_t xLastWakeTime;
     pcTaskName = ( char * ) pvParameters;
     xLastWakeTime = xTaskGetTickCount();/* current tickcount.*/
     for(;;) {/* Print out the name of this task. */
          vPrintString( pcTaskName );
         vTaskDelayUntil( &xLastWakeTime, pdMS_TO_TICKS( 250 ));
/* main function */
Static const char *pcTextForTask1 = "Continuous task 1 running\r\n";
static const char *pcTextForTask2 = "Continuous task 2 running\r\n";
static const char *pcTextforperiodic = "Periodic task is running\r\n";
int main(void)
     xTaskCreate(vContinuousFunction, "Task 1", 1000, (void*)pcTextForTask1, 1, NULL);
     xTaskCreate(vContinuousFunction, "Task 2", 1000, (void*)pcTextForTask2, 1, NULL);
     xTaskCreate(vPeriodicFunction, "Task periodic", 1000, (void*)pcTextforperiodic, 2, NULL);
     vTaskStartScheduler();
     for(;;);
```

Combining blocking and non-blocking tasks



Other task related functions

- void vTaskPrioritySet(TaskHandle_t pxTask, UbaseType_t uxNewPriority);
 - pxTask: The handle of the task (last parameter of taskCreate function)
 - uxNewPriority: New priority to be set
- UbaseType_t uxTaskPriorityGet(TaskHandle_t pxTask);
- void vTaskDelete(TaskHandle_t pxTaskToDelete);
 - pxTaskToDelete: The handle of the task

Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
 - Fixed priority: Do not change prorities assigned to tasks
 - Pre-emptive: Pre-empt immediately the running task if a task of hgher priority enters to Ready state
 - Time slicing: is used to share processing time between tasks of equal priority - Time between two RTOS tick interrupts

Configured in FreeRTOSConfig.h


- configUSE PREEMPTION 1
- configUSE_TIME_SLICING 1

Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
 - Fixed priority: Do not change prorities assigned to tasks
 - Pre-emptive: Pre-empt immediately the running task if a task of hgher priority enters to Ready state
 - Time slicing: is used to share processing time between tasks of equal priority - Time between two RTOS tick interrupts

Configured in FreeRTOSConfig.h

- configUSE PREEMPTION 1
- configUSE TIME SLICING 1




Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
 - Fixed priority: Do not change prorities assigned to tasks
 - Pre-emptive: Pre-empt immediately the running task if a task of hgher priority enters to Ready state
 - Time slicing: is used to share processing time between tasks of equal priority - Time between two RTOS tick interrupts

Configured in FreeRTOSConfig.h

- configUSE PREEMPTION 1
- configUSE_TIME_SLICING
 1




Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
 - Fixed priority: Do not change prorities assigned to tasks
 - Pre-emptive: Pre-empt immediately the running task if a task of higher priority enters to Ready state
 - Time slicing: is used to share processing time between tasks of equal priority - Time between two RTOS tick interrupts

Configured in FreeRTOSConfig.h

- configUSE PREEMPTION 1
- configUSE TIME SLICING
- configIDLE_SHOULD_YIELD 1



Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
- Fixed Priority Pre-emptive Scheduling without Time Slicing

Configured in FreeRTOSConfig.h

- configUSE_PREEMPTION
- configUSE_TIME_SLICING
 0


Scheduling Algorithms

- Round Robin Scheduling
- Fixed Priority Pre-emptive Scheduling with Time Slicing
- Fixed Priority Pre-emptive Scheduling without Time Slicing
- Co-operative Scheduling

Configured in FreeRTOSConfig.h

- configUSE_PREEMPTION
 0
- configUSE_TIME_SLICING
 any

Running state call taskYIELD() function to re-schedule



Heap Memory Management

The dynamic memory allocation is used by FreeRTOS each time a kernel object is created, and the memory is released when the kernel object is deleted.

The FreeRTOS equivalent functions for malloc() and free() are

PvPortMalloc() and vPortFree()

Heap allocation schemes indicated in files heap_1.c, heap_2.c, heap_3.c, heap_4.c and heap_5

Heap_1

The heap_1 allocation scheme subdivides a simple array into smaller blocks, as calls to pvPortMalloc() are made. The array is called the FreeRTOS heap.


Small embedded dedicated systems that create task before the scheduler run. In the case the memory is dynamically allocated by the kernel befor the application start, and remain allocated until application finish.

The total memory array size is defined in FreeRTOSConfig.h file with

configTOTAL_HEAP_SIZE

Heap allocation schemes

Heap_1




TCB: Task control block

Source:Mastering the FreeRTOS™ Real Time Kernel A Hands-On Tutorial Guide- Richard Barry

Heap allocation schemes

Heap 2 Not recommended for new designs – Instead use Heap 4 scheme

It works dividing the memory heap array using the best fit algorithm to allocate memory when pvPortMalloc() function is called. The best fit algorithm ensure that the pvPortMalloc() will use the memory space that best fit with the requirements of the task.



Source:Mastering the FreeRTOS™ Real Time Kernel A Hands-On Tutorial Guide- Richard Barry

Heap Memory Management

Heap allocation schemes

Heap_3: configTOTAL_HEAP_SIZE has no effect in this mode.


It uses malloc() and free() functions to manage the memory and the size of the heap is defined by the linker.

Heap allocation schemes

Heap_4: Divides the array in smaller blocks, the total size is configured with configTOTAL_HEAP_SIZE.

Use best fit algorithm to allocate memory.

It combine advacent blocks to reduce fragmentation.



Source:Mastering the FreeRTOS™ Real Time Kernel A Hands-On Tutorial Guide- Richard Barry

Heap Memory Management

Heap allocation schemes

Heap_5: Can allocate memory from multiple and separated memory spaces.

Use best fit algorithm to allocate memory.

It combine advacent blocks to reduce fragmentation.

Must be explicitly initialized before pvPortMalloc() can be called. Heap_5 is initialized using the vPortDefineHeapRegions() API function.

This function defines the start address and the size of each separate portion of memory.

void **vPortDefineHeapRegions**(const HeapRegion_t * const pxHeapRegions);

Source:Mastering the FreeRTOS™ Real Time Kernel A Hands-On Tutorial Guide- Richard Barry

Queue Management

'Queues' provide a task-to-task, task-to-interrupt, and interrupt-to-task communication mechanism.


- Queues hold a finite number of fixed size data items
- Queues are normally used as First In First Out (FIFO) buffers

FreeRTOS use queue by copy method.

- Stack variable can be sent directly to a queue.
- Data can be sent to a queue without first allocating a buffer.
- The sending task and the receiving task are completely decoupled.
- The RTOS takes complete responsibility for allocating the memory used to store data.

But still you can use queue by reference

Queue Management



Queue Management

Creating a queue

A queue must be explicitly created before it can be used.

QueueHandle_t xQueueCreate(UBaseType_t uxQueueLength, UbaseType_t uxItemSize);

- UxQueueLength: The maximum number of items that the queue being created can hold at any one time.
- UxItemSize: The size in bytes of each data item that can be stored in the queue.

Queue Management

Using a queue (writing)

TickType t xTicksToWait):

xQueue: The handle of the queue

pvltemToQueue: A pointer to the data to be copied into the queue

• xTicksToWait: The maximum amount of time the task should remain in the

Blocked state to wait for space to become available on the

queue

Return:

• pdPASS – OK

• errQUEUE_FULL — Error, queue full

Queue Management

Using a queue (reading)

```
BaseType_t xQueueReceive( QueueHandle_t xQueue, void * const pvBuffer, TickType_t xTicksToWait );
```

• xQueue: The handle of the queue

pBuffer: A pointer to the memory into which the data will be copied
 xTicksToWait: The maximum amount of time the task should remain in the

Blocked state to wait for a data to become available on the

queue

Return:

• pdPASS – OK

• errQUEUE_EMPTY - Error, queue full

Queue Management

Receiving from multiples queues

FreeRTOS allows you to create a set of queues to manage different events from different sources to block a task (waiting) on read operation from multiple queues

The corresponding API is

QueueSetHandle_t xQueueCreateSet(const UBaseType_t uxEventQueueLength);

The set of queue can be formed by several queues of different sizes and with different size of elements, bynary semaphores or counting semaphores.

The length of the queue is calculated from the sum of each queue size.

The constant configUSE_QUEUE_SETS in FreeRTOSConfig.h must be 1 to allow queue set creation

Queue Management

Adding elements to a set of queues

BaseType_t **xQueueAddToSet**(QueueSetMemberHandle_t xQueueOrSemaphore, QueueSetHandle_t xQueueSet);

In main()

First create the set, then create the queues to be added and finally add queues to the set.

Removing elements from a set of queues

BaseType_t **xQueueRemoveFromSet**(QueueSetMemberHandle_t xQueueOrSemaphore, QueueSetHandle_t xQueueSet);

Queue Management

Selecting elements from a set of queues

QueueSetMemberHandle_t **xQueueSelectFromSet**(QueueSetHandle_t xQueueSet, const TickType t xTicksToWait);

Keep the corresponding task blocked (waiting) until time defined is finished or until an event arrives to the queueset

Queue Management (example)

```
/* Define the lengths of the queues that will be added to the queue set. */
#define QUEUE LENGTH 1 10
#define QUEUE LENGTH 2
                       1.0
/* Binary semaphores have an effective length of 1. */
#define BINARY SEMAPHORE LENGTH
/* Define the size of the item to be held by gueues */
#define ITEM SIZE QUEUE 1 sizeof( uint32 t )
#define ITEM_SIZE_QUEUE_2 sizeof( uint8_t )
/* define the total length of the gueue set*/
#define COMBINED LENGTH ( QUEUE LENGTH 1 + QUEUE LENGTH 2 + BINARY SEMAPHORE LENGTH )
void vAFunction( void ) {
     static OueueSetHandle t xOueueSet;
    QueueHandle_t xQueue1, xQueue2, xSemaphore;
    QueueSetMemberHandle t xActivatedMember;
    uint32 t xReceivedFromOueue1;
    uint8 t xReceivedFromOueue2;
/* Create a gueue set large enough to hold an event for every added gueue*/
    xQueueSet = xQueueCreateSet( COMBINED LENGTH );
/* Create the queues and semaphores that will be contained in the set. */
    xQueue1 = xQueueCreate( QUEUE_LENGTH_1, ITEM_SIZE_QUEUE_1 );
    xQueue2 = xQueueCreate( QUEUE_LENGTH_2, ITEM_SIZE_QUEUE_2 );
/* Create the semaphore that is being added to the set. */
    xSemaphore = xSemaphoreCreateBinary();
/* Take the semaphore, so it starts empty. A block time of zero can be used
as the semaphore is guaranteed to be available - it has just been created. */
    xSemaphoreTake(xSemaphore, 0);
/* Add the gueues and semaphores to the set. */
    xQueueAddToSet( xQueue1, xQueueSet );
    xQueueAddToSet( xQueue2, xQueueSet );
    xQueueAddToSet( xSemaphore, xQueueSet );
/* CONTINUED ON NEXT PAGE */
```

Queue Management (example)

```
/* CONTINUED FROM PREVIOUS PAGE */
    for(;;) {
/* Block to wait for something to be available from the gueues or semaphore
that have been added to the set. Don't block longer than 200ms. */
         xActivatedMember = xQueueSelectFromSet( xQueueSet, pdMS_TO_TICKS( 200 ) );
/* Which set member was selected? */
         if( xActivatedMember == xOueue1 ) {
             xOueueReceive(xActivatedMember, &xReceivedFromOueue1, 0);
/*Receives/takes can use a block time of zero as they are guaranteed to pass because
xQueueSelectFromSet() only returned the handle when something was available. */
             vProcessValueFromQueue1( xReceivedFromQueue1);
         else if( xActivatedOueue == xOueue2 ) {
             xQueueReceive(xActivatedMember, &xReceivedFromQueue2, 0);
             vProcessValueFromOueue2( &xReceivedFromOueue2 );
         else if( xActivatedQueue == xSemaphore ) {
/* Take the semaphore to make sure it can be "given" again. */
             xSemaphoreTake(xActivatedMember, 0);
             vProcessEventNotifiedBySemaphore();
             break:
         else {
/* The 200ms block time expired without event*/
```

Queue Management

Other queue management functions

```
void vQueueDelete( TaskHandle t pxQueueToDelete );
QueueHandle t xQueueCreateStatic( UBaseType t uxQueueLength,
                                       UBaseType t uxItemSize,
                                       uint8 t *pucQueueStorageBuffer,
                                       StaticQueue t *pxQueueBuffer );
UBaseType t uxQueueMessagesWaiting(const QueueHandle t xQueue);
BaseType t xQueueOverwrite( QueueHandle txQueue,
                                  const void *pvItemToOueue ):
BaseType t xQueuePeek( QueueHandle txQueue,
                              void *pvBuffer,
                              TickType t XTicksTc...ait);
BaseType t xQueueReset(QueueHandle txQueue);
```

Software Timer Management

The Software Timer schedules the execution of a function at a set time in the future, or periodically with a fixed frequency. (Implemented and managed by the kernel).

The function executed by the software timer is called the software timer's callback function.

Software timer callback functions execute from start to finish, and exit in the normal way. They should be kept short, and must not enter the Blocked state.

To use it:

Add **timers.h** to your design Set **configUSE_TIMERS** to **1** in FreeRTOSConfig.h

Software Timer Management

Timer is created, with a period, Type (oneshot/autoreload), the TimerID, and the name of the callback function).

The **period** is the amount of ticks until the callback function starts.

Onseshot: timer is executed only one tyme and the callback function start when period is finished and it is executed only once.

Autoreload: the timer restart after period is finished. The callback function is executed every time that period is finished.

The format to create Software Timer Callback Function is

void ATimerCallback(TimerHandle_t xTimer);

Software Timer Management

The Software timer callback function is executed when the scheduler start, then a timer service from the kernel is executed (daemon).

Daemon priority and stack size are set by the **configTIMER_TASK_PRIORITY** and **configTIMER_TASK_STACK_DEPTH** constants in FreeRTOSConfig.h file.

The Software Timing Callback Function send commands (start, stop, reset) to the kernel daemon task through a timer command queue.

The length of the timer command queue is set using **configTIMER_QUEUE_LENGTH**

Software Timer Management

Two states Dormant and Running

Once the Timer has been created remains in the Dormant state until **xTimerStart()** or **xTimerReset()** function is called.

Once running, timer stop when **xTimerStop()** function is called or when Timer expire (Oneshot mode)

TimerHandle_t xTimerStart(TimerHandle_t xTimer, TickType_t xTicksToWait);

Return pdPASS if ok or pdFALSE if the timer command queue is full.

Software Timer Management (Example)

```
pdMS TO TICKS (500) /* Define Period */
#define myTimer period
int main(void) {
     TimerHandle t myTimer;
     BaseType_t
                   xmyTimerStarted;
     /*Create myTimer*/
    myTimer xTimerCreate("mytimer", /*for debug */
                              myTimer period,
                              PdFalse, /*oneshot mode*/
                              prvmyTymerCallback);
     if (myTymer !=NULL) {
          xmyTimerStarted= xTimerStart(myTymer,0);
          if (xmyTimerStarted=pdPASS) {
              vtaskStartScheduler();
/* As always, this line should not be reached. */
for(;;);
/* Implementation of the myTimer callback function"*/
static void prvmyTimerCallback(TimerHandle_t xTimer) {
     TickType t xTimeNow;
     /* Obtain the current tick count. */
     xTimeNow = xTaskGetTickCount();
/* Output a string to show the time at which the callback was executed. */
     vPrintStringAndNumber( "One-shot timer callback executing", xTimeNow );
```

QUESTIONS?