MIPS Introduction

Read: Chapter 2 and Appendix A (5th edition); Chapter 2 and Appendix B (4th edition)


The appendix is available as http://pages.cs.wisc.edu/~larus/HP AppA.pdf from spim website.

Note: The on-line version is named Appendix A. It is the same as the 4th edition's Appendix B.

- Language of the Machine.
- More primitive than higher level languages.
 - E.g., no sophisticated control flow such as for and while.
 - Only simple branch, jump, and jump subroutine.
- Very restrictive.
 - E.g., MIPS Arithmetic Instructions have: two operands, one result.
 - Can do in one instruction: a = b + c
 - Cannot do in one instruction: a = b + c * d e
- We will be working with the MIPS-32 instruction set architecture.
 - Similar to other architectures developed since the 1980's.
 - Used by (at various times) NEC, Nintendo, SGI (formerly Silicon Graphics Inc.), Sony
- Design goals of MIPS:
 - Maximize performance and minimize cost.
 - Reduce design time.

Basic CPU Organization:

• Simplified picture of a computer:



- Three components:
 - Processor (or <u>Central Processing Unit or CPU or "core"</u>); MIPS in our case. Intel, PowerPC, UltraSparc, ...
 - Memory contains the program instructions to execute and the data for the program.
 - I/O Devices how the computer communicates to the outside world. Keyboard, mouse, monitor, printer, game controller, tablet, etc.
- CPU contains three components:
 - Registers hold data values for the CPU to manipulate.
 - Arithmetic Logic Unit (ALU) performs arithmetic and logic functions. Takes values from and returns values to the registers.
 - Control Determines what operation to perform, directs data flow to/from memory, directs data flow between registers and ALU.
 - Actions are determined by the current Instruction.

Memory Organization:

- Viewed as a large, one-dimensional array, with an address for each element — byte — of the array.
- A memory address is an index into the array.
- "Byte addressing" the index points to a byte, 8 bits in today's computers, of memory.
- MIPS addresses (up to) 4 Gigabytes of memory:
 - Bytes are numbered from 0 to 2^{32} 1; or 0 to 4,294,967,295.
- Bytes are nice, but most data items use larger "words".

0	8 bits of data
1	8 bits of data
2	8 bits of data
3	8 bits of data
4	8 bits of data
5	8 bits of data
6	8 bits of data
•••	8 bits of data
,294,967,293	8 bits of data
,294,967,294	8 bits of data
,294,967,295	8 bits of data

Memory Organization (continued):

- For MIPS, a "word" is 32 bits, or 4 bytes.
 - Each register in the CPU holds 32 bits.
 - Not just a coincidence!
- 2^{32} bytes with byte addresses from 0 to 2^{32} 1.
- 2³⁰ words. The words are at addresses:

$$0, 4, 8, 12, 16, 20, 24, 28, ..., 2^{32} - 4$$
 (in decimal)

0, 4, 8, C, 10, 14, 18, 1C, 20, 24, 28, 2C, ... (in hexadecimal)

- Words are "aligned".
 - Each word starts on an address that is divisible by 4.
 - What are the least 2 significant bits of a word address in binary?
- Notes: If you have not already memorized these:

•
$$2^{10} = 1,024_{ten} = 1 \text{ Kilo} = 1 \text{ K}$$

- $2^{20} = 1 \text{ Mega} = 1 \text{ M}$
- $2^{30} = 1 \text{ Giga} = 1 \text{ G}$
- $2^{40} = 1 \text{ Tera} = 1 \text{ T}$

0	32 bits, 4 bytes, of data
4	32 bits, 4 bytes, of data
8	32 bits, 4 bytes, of data
12	32 bits, 4 bytes, of data
•••	32 bits, 4 bytes, of data
4,294,967,284	32 bits, 4 bytes, of data
4,294,967,288	32 bits, 4 bytes, of data
4,294,967,292	32 bits, 4 bytes, of data

0	32 bits, 4 bytes, of data
4	32 bits, 4 bytes, of data
8	32 bits, 4 bytes, of data
C	32 bits, 4 bytes, of data
	32 bits, 4 bytes, of data
FF FF FF F4	32 bits, 4 bytes, of data
FF FF FF F8	32 bits, 4 bytes, of data
FF FF FF FC	32 bits, 4 bytes, of data

Registers vs. Memory:

- Registers can be thought of as a type of memory. They are inside the CPU; thus, they are the "closest" memory.
- Registers provide a place to hold values inside the CPU, and allow a large set of operations to be performed on their values. I.e., add, subtract, compare, etc.
- Principal advantages of registers vs. memory:
 - Fast access.
 - Fast access.
 - Fast access.
- Principal advantages of memory vs. registers:
 - Lower cost.
 - Lower cost.
 - Lower cost.
- An intermediate type of memory: Cache.
 - Different "flavors" depending on size and physical location.
 - Level 1 cache "closest" to the CPU.
 - Usually installed on the chip as part of the CPU.
 - Typically small: 32K, 64K
 - Level 2 cache between the CPU and the memory.
 - Not part of one processor core, but is present on the chip. Shared by all processor cores (or not).
 - Typically a few Megabytes.
 - We will come back to the topic of cache later in the semester.

Registers vs. Memory (continued):

• Register Organization. (See also the SPIM Appendix, page 24).

Name	Register number	Usage	Preserved on call?
\$zero	0	the constant value 0	n.a.
\$at	1	reserved for the assembler	n.a.
\$v0-\$v1	2-3	values for results & expression evaluation	no
\$a0-\$a3	4-7	arguments	yes
\$t0-\$t7	8-15	"temporary"; used for almost anything	no
\$s0-\$s7	16-23	"saved"; used for almost anything	yes
\$t8-\$t9	24-25	"temporary"; used for almost anything	no
\$gp	28	global pointer	yes
\$sp	29	stack pointer	yes
\$fp	30	frame pointer	yes
\$ra	31	return address	yes

- These are the "General Registers". MIPS also has:
 - PC (program counter) register, Status register.
 - Floating-point registers.

Registers vs. Memory (continued):

- For now (programs 1, 2, 3, and 4) we will use:
 - \$zero, \$s0-\$s7, \$t0-\$t9 for writing programs.
 - \$zero always has the value 0; you cannot change its contents.
 - \$s0-\$s7 and \$t0-\$t9 can be used interchangeably in programs.
 - This will change later when we start using functions.
 - \$a0 and \$v0 for printing.
 - Only for printing!
 - Both \$a0 and \$v0 have other uses that will show up in functions.
 - Do NOT use any of the other registers:
 - \$at
 - \$v1
 - \$a1-\$a3
 - \$gp, \$sp, \$fp, \$ra
- Some of the above will change when we start using functions.

MIPS Arithmetic:

- All arithmetic instructions have at most 3 operands.
- All arithmetic is done in registers!
 - Can not, for example, add a number directly to a value stored in memory. In MIPS, this requires 3 steps:
 - Load the value from memory into a register.
 - Add the number to the register.
 - Store the result in memory.
 - Thus, MIPS is a "<u>load-store</u>" architecture. All work other than loading and storing is done <u>only</u> in registers.
- Operand order is fixed.
 - Destination operand is first.
- Example:
 - C or Java code:

$$xray = yoke + zebra;$$
 $$t0 = $t1 + $t2$

• MIPS code:

• adds contents of \$\mathbf{\$\mathbf{t}}\mathbf{1}\ and \$\mathbf{\$\mathbf{t}}\mathbf{2}\, placing the result in \$\mathbf{t}\mathbf{0}\.

\$s1 has papa

\$s2 has sierra

MIPS Arithmetic (continued):

\$s3 has tango

• Longer expressions require more instructions:

\$s5 has foxtrot

• C or Java code (assume all variables are of type int):

Note: **sub** instruction for subtract. Same format as **add** instruction.

```
oscar = papa + sierra + tango;
foxtrot = foxtrot - oscar;
```

• MIPS version:

```
add $t0, $s1, $s2  # $t0 = papa + sierra; put result "temporarily" in $t0 add $s0, $t0, $s3  # oscar = $t0 + tango; use the "temporary" result from $t0 sub $s5, $s5, $s0  # $s5 = foxtrot - oscar
```

- Note: use of **\$t0** to hold "temporary" result.
- Note: # marks the beginning of a comment that runs until the end of the current line
- Note: operands <u>must</u> be registers.
- We did not use variable names in the MIPS version, just register names.
 - Programmer has to "remember" which registers hold which variables.
 - Useful to have comments that say this!

add \$s3, \$s3, \$s3

• Essential if you want a good grade on the programs.

MIPS Arithmetic (continued):

- Registers vs. Memory:
 - Arithmetic instructions operands must be registers.
 - There are only 32 registers available.
 - Compiler for a language, such as C, will associate variables with registers automatically.
- What about programs with more variables than there are registers?
 - This covers just about every program!
 - Must move the values of the variables between memory and registers.

Load and Store Instructions:

- MIPS uses load instructions to copy a value from memory to a register. There are three versions, depending on the amount of data being copied:
 - **lw** will copy a word (32-bits).
 - **lh** will copy half a word (16-bits).
 - **lb** will copy one byte (8-bits).
- MIPS uses store instructions to copy a value from a register to a memory location.
 - sw will copy a word (32-bits).
 - **sh** will copy half a word (16-bits).
 - **sb** will copy one byte (8-bits).

- MIPS allows us to use symbolic names for memory locations.
 - Saves having to use binary or hexadecimal addresses.
 - bats is easier to remember and understand than the memory address 0x1000 0010, for example.
 - In a MIPS assembly program, we can assign symbolic names to <u>memory</u> locations using .word, .half, and .byte, as appropriate:

```
bats: .word 17  # creates a 32-bit integer w/ the initial value 17, named bats balls: .word 3  # creates a 32-bit integer w/ the initial value 3, named balls
```

• We can create as many variables, with initial values, as we need for a program. I.e.,

bats: .word 17
balls: .word 3
gloves: .word 10
bases: .word 4

- Suppose we want to perform some arithmetic on these values? To take a specific example:
 - Want to find the total of the bats + balls + gloves.
- To do arithmetic, we have to get the values from memory into registers. Thus, we need to put the values for bats, balls, and gloves into three registers.
- Where in memory?
 - The names bats, balls, etc. above are symbolic names that represent <u>locations</u> in memory.
 - Note: **bats** is a **location**, not a value.
 - To load a value from a location, we use the **1w** instruction (<u>load word</u>). **1w** has the form:

```
lw destination-register, offset(register-with-address)
```

- The destination-register can be any of \$s0-\$s7, \$t0-\$t9.
- The register-with-address can also be any of these registers.
- How does the register-with-address get its value?

- Getting an address into a register:
 - The la instruction (load address) will put the address associated with a symbolic name into a register. I.e.,

```
la $t0, bats # puts the address of the bats memory location into register $t0
```

• Once the address is in a register, we can use that register for the register-with-address part of an **1w** instruction.

```
lw $s0, 0($t0) # gets value located at address stored in $t0 & puts it into $s0
```

- These two instructions (la and lw) together will put the number stored at location bats into register \$50.
- For now, we will use of for the offset every time.
- Now, we can write the code to find the sum: bats + balls + gloves:

```
$t0, bats
                     # $t0 now contains the address of the bats memory location
la
lw
    $s0, 0($t0)
                     # $s0 now contains the number of bats
     $t0, balls
                     # $t0 now contains the address of the balls memory location
la
                     # $s1 now contains the number of balls
    $s1, 0($t0)
lw
     $t0, gloves
                     # $t0 now contains the address of the gloves memory location
la
                     # $s2 now contains the number of gloves
    $s2, 0($t0)
lw
add $s3, $s0, $s1
                     # $s3 now contains the number of bats + balls
add $s3, $s3, $s2
                     # $s3 now contains the number of bats + balls + gloves
```

- Our answer is now in register \$s3.
- How do we get the answer from register \$s3 into a memory location?

- Copying a value from a register to a memory location is done with store (from slide #11):
 - sw will copy a word (32-bits).
 - **sh** will copy half a word (16-bits).
 - **sb** will copy one byte (8-bits).
- Concentrating on sw for now.
- sw has a similar format to the 1w command:

```
sw source-register, offset(register-with-address)
```

- Again, we need an address (a location) in memory. We get this using the la command.
- Need to declare a location to put our result. Will add this to the memory declarations for bats, balls, etc.
- Two step process to save a value:
 - Get the address of the location (using la).
 - Save the value into that location (using sw).

• A short (not yet complete) MIPS program, named bats1.s, to find: sum = bats + balls + gloves

```
.data ←
bats:
        .word 17
                                                     -.data marks a part of the program
balls:
                 3
        .word
                                                     that defines memory locations.
gloves: .word 10
bases:
        .word
                0
                      # Create a place to put our answer
        .word
sum:
                                                           .text marks a part of the program that
.text ←
                                                           contains assembly instructions (the program).
main:
             $t0, bats
                              # $t0 has the address of the bats memory location
        la
             $s0, 0($t0)
                              # $s0 now holds the number of bats
             $t0, balls
                              # $t0 has the address of the balls memory location
             $s1, 0($t0)
                              # $s1 now holds the number of balls
             $t0, gloves
                              # $t0 has the address of the gloves memory location
        la
             $s2, 0($t0)
                              # $s2 now holds the number of gloves
             $s3, $s0, $s1
                              # $s3 now holds the number of bats+balls
             $s3, $s3, $s2
                              # $s3 now holds the number of bats+balls+gloves
        add
             $t0, sum
                              # $t0 has the address of the sum memory location
        la
             $s3, 0($t0)
                              # sum now holds the number of bats+balls+gloves
        SW
 main: is a required label to tell the spim
 simulator where to begin executing.
```

• bats2.s: A complete version of the bats program. main is now a <u>function</u> that includes the proper way to start and end a function. For now, just put these lines into <u>every</u> main that you write, with the body of main inbetween. We will cover later what these lines are actually doing, and why they are needed.

```
.data
bats:
        .word 17
        .word
balls:
gloves:
        .word 10
bases:
        .word
                     # Create a place to put our answer
        .word
                0
sum:
.text
main:
        # Function prologue -- even main has one
        addiu $sp, $sp, -24 # allocate stack space -- default of 24 here
              $fp, 0($sp) # save caller's frame pointer
        SW
              $ra, 4($sp) # save return address
        SW
        addiu $fp, $sp, 20
                             # setup main's frame pointer
              $t0, bats
                             # $t0 has address of the bats memory location
        la
              $s0, 0($t0)
                             # $s0 now holds the number of bats
        lw
        la $t0, balls
                             # $t0 has address of the balls memory location
        lw $s1, 0($t0)
                             # $s1 now holds the number of balls
        la $t0, gloves
                             # $t0 has address of the gloves memory location
              $s2, 0($t0)
                             # $s2 now holds the number of gloves
        lw
        add $s3, $s0, $s1 # $s3 now holds the number of bats+balls
              $s3, $s3, $s2
        add
                             # $s3 now holds the number of bats+balls+gloves
```

• bats2.s, continued:

```
la $t0, sum # $t0 has address of the sum memory location sw $s3, 0($t0) # sum now holds the number of bats+balls+gloves

done: # Epilogue for main -- restore stack & frame pointers and return lw $ra, 4($sp) # get return address from stack lw $fp, 0($sp) # restore the caller's frame pointer addiu $sp, $sp, 24 # restore the caller's stack pointer jr $ra # return to caller's code
```

- You can find the bats1.s and bats2.s examples from the previous 3 slides on D2L
 - We will be adding to this list of examples!
 - You can execute this program using:
 - QtSpim
 - Your own Windows/Linux/MacOSX machine.
 - lectura, Ubuntu machines in GS-930 and Mac's in GS-228.
- You will find, when you execute either program, that it runs to completion.
 - From **bats1.s**, you get an error:



- Neither version prints anything!
 - We put the answer in a register and in memory.
 - We did not print it!

QtSpim and spim

- Reading: Textbook, Appendix B (4th edition), Appendix A (5th edition and from the Spim web page).
 - Appendix B in the 4th edition, and Appendix A from the spim web site <u>are the same</u>.
 - I refer to this as the "Spim Appendix".
 - Especially read section 9, pages 40 to 45.
 - Appendix A can also be found on the web at: http://www.cs.wisc.edu/~larus/HP_AppA.pdf
 - There is a link to this on-line version on the 252 class web page and in D2L.
- There are "Getting Started" guides for the command-line version of spim:
 - spim: http://www.cs.wisc.edu/~larus/spim.pdf
 - spim Command Line: http://www.cs.wisc.edu/~larus/SPIM_command-line.pdf
- You can also find these links on the <u>252 D2L page</u>. Click on "Useful web links" under Content.

QtSpim and spim (continued):

- spim is a command-line tool usable on a UNIX system (Linux/OS X, among others).
- QtSpim is a GUI interface to spim that is usable on Windows/Linux/OSX.
- QtSpim displays:
 - Text, a scrollable window showing your code.
 - In Regs[16]: A scrollable window that shows:
 - Program Counter (PC) and status registers, among others.
 - General Registers: The 32 general-purpose registers.
 - Data: A scrollable window that shows:
 - User data segment (useful now).
 - User stack (will use this later).
 - FP Regs: A scrollable window that shows:
 - Floating Point Registers, both single- and double-precision registers

PC = 400020OtSpim and spim (continued): EPC = 0Cause Register Display: BadVAddr = 0= 3000ff10Status • After *bats2.s* program has finished. HI LO = 0All register contents are displayed in <u>hexadecimal</u>. RO [r0] = 0[at] = 10010000 [v0] = a [v1] = 0\$t0 has the hex [a0] = 1R4 address of sum = 7ffffe3c [a2] = 7ffffe44 [a3] [t0] = 10010010\$s0 has bats [t1] R10 [t2] [t3] \$s1 has balls \$s2 has gloves R16 [s0] R17 [s1] R18 [s2] = a\$s3 has bats+balls+gloves R19 [s3] = 1eR20 [s4] = 0R21 [s5] = 0R22 [s6] = 0

QtSpim and spim (continued):

- Text Segment:
 - Displays the program code.

Address of instruction hexadecimal

MIPS machine language 32-bit, hexadecimal

Line number from your .s file

```
[00400024] 27bdffe8
                     addiu $29, $29, -24
                                               ; 13: addiu $sp, $sp, -24 # allocate stack space -- default of 24 here
[00400028] afbe0000
                     sw $30, 0($29)
                                               ; 14: sw $fp, 0($sp) # save caller's frame pointer
                                               ; 15: sw $ra, 4($sp) # save return address
[0040002c] afbf0004
                     sw $31, 4($29)
                                              ; 16: addiu $fp, $sp, 20 # setup main's frame pointer
[00400030] 27be0014
                    addiu $30, $29, 20
                                               ; 18: la $t0, bats # $t0 has address of the bats memory location
[00400034] 3c081001
                     lui $8, 4097 [bats]
                                              ; 19: lw $s0, 0($t0) # $s0 now holds the number of bats
[00400038] 8d100000
                    lw $16, 0($8)
                                              ; 20: la $t0, balls # $t0 has address of the balls memory location
[0040003c] 3c011001
                    lui $1, 4097 [balls]
                    ori $8, $1, 4 [balls]
[00400040] 34280004
[00400044] 8d110000
                    lw $17, 0($8)
                                               ; 21: lw $s1, 0($t0) # $s1 now holds the number of balls
                    lui $1, 4097 [gloves]
[00400048] 3c011001
                                              ; 22: la $t0, gloves # $t0 has address of the gloves memory location
[0040004c] 34280008
                    ori $8, $1, 8 [gloves]
[00400050] 8d120000
                                              ; 23: lw $s2, 0($t0) # $s2 now holds the number of gloves
                     lw $18, 0($8)
                                              ; 24: add $s3, $s0, $s1 # $s3 now holds the number of bats+balls
[00400054] 02119820
                    add $19, $16, $17
[00400058] 02729820
                    add $19, $19, $18
                                              ; 25: add $s3, $s3, $s2 # $s3 now holds the number of bats+balls+glove
                    lui $1, 4097 [sum]
[0040005c] 3c011001
                                              ; 27: la $t0, sum # $t0 has address of the sum memory location
[00400060] 34280010
                    ori $8, $1, 16 [sum]
[00400064] ad130000
                    sw $19, 0($8)
                                              ; 28: sw $s3, 0($t0) # sum now holds the number of bats+balls+gloves
                    lw $31, 4($29)
                                              ; 31: lw $ra, 4($sp) # get return address from stack
[00400068] 8fbf0004
                                              ; 32: lw $fp, 0($sp) # restore the caller's frame pointer
[0040006c] 8fbe0000
                     lw $30, 0($29)
                                              ; 33: addiu $sp, $sp, 24 # restore the caller's stack pointer
                    addiu $29, $29, 24
[00400070] 27bd0018
                                              ; 34: jr $ra # return to caller's code
[004000741 03e00008
                    jr $31
                                                   Assembly language instruction,
```


Assembly language instruction, after assembly

from your .s file,

<u>before</u> assembly

QtSpim and spim (continued):

- Data Segment:
 - Shows the contents of memory. This snapshot was taken after *bats2.s* stopped executing.



Printing in QtSpim and spim:

- Need to connect to an outside device ("outside" the CPU).
- The simulator provides this for us via the System Call mechanism.
- There are 17 system calls. See Figure 9.1 on page 44 of the SPIM Appendix for the complete list.
- Here are <u>some</u> of the more useful ones (there are others you will need; look them up!):

Service	System call code	Arguments	Result
print_int	1	\$a0 = integer	
print_float	2	\$f12 = float	
print_double	3	\$f12 = double	
print_string	4	\$a0 = string	
read_int	5		integer (in \$v0)
read_float	6		float (in \$f0)
read_double	7		double (in \$f0)
read_string	8	a0 = buffer, a1 = length	

Printing Strings:

- We can declare character <u>arrays</u> using .ascii.
 - This is done in the .data section.
 - For example,

```
myChars: .ascii "abc7 d8-#$stuff8y wi"
gibberish: .ascii "982(*&$junk(*&stuff"
words: .ascii "the of and or nor a an alphabet Zulu"
```

- A *string* is a character array with an additional character on the end. This last character is always the **nul** character (ascii value zero).
 - Declare a string using .asciiz. Examples:

```
myName: .asciiz "Patrick T. Homer"
morning: .asciiz "Good morning"
week: .asciiz "Su Mo Tu We Th Fr Sa"
```

Printing Strings (continued):

• Declare one (or more) strings in the .data segment using .asciiz:

```
morning: .asciiz "Good morning"
myName: .asciiz "Patrick T. Homer"
week: .asciiz "Su Mo Tu We Th Fr Sa"
```

• Load the <u>address</u> of the string into **\$a0**:

```
la $a0, myName # put the address of my name in register $a0
```

- Put the system call number for **print_string** into **\$v0**.
 - Need a new instruction: add immediate:
 - Like **add**, but 3rd register is replaced with a positive or negative integer:

```
addi $v0, $zero, 4 # put system call number 4 into register $v0
```

• Call system:

syscall # spim will now print the string that has my name

• HelloWorld1.s

```
# Print the Hello World phrase.
# Here we load the base address of the string
# into register $a0, and use the print string
# syscall to print the phrase.
.data
hello: .asciiz "Hello World\n"
.text
main:
        # Function prologue -- even main has one
        addiu $sp, $sp, -24 # allocate stack space -- default of 24 here
              $fp, 0($sp) # save caller's frame pointer
        SW
              $ra, 4($sp) # save return address
        SW
        addiu $fp, $sp, 20  # setup main's frame pointer
        # set up $a0 to hold address of the hello world string
        # then print the string
                $a0, hello # Point to the string
        la
                $v0, $zero, 4 # syscall value for print string
        addi
        syscall
        # Epiloque for main -- restore stack & frame pointers and return
done:
              $ra, 4($sp) # get return address from stack
        lw
              $fp, 0($sp)
                              # restore the caller's frame pointer
        lw
        addiu $sp, $sp, 24  # restore the caller's stack pointer
        jr
              $ra
                              # return to caller's code
```

• HelloWorld1.s: Use the step command to advance to the syscall on line 25.

```
PC
               = 40003c
     EPC
               = 0
     Cause
               = 0
     BadVAddr = 0
     Status
               = 3000ff10
     HI
               = 0
     LO
               = 0
                                       print str system call
         [r0] = 0
     R0
     R1
              = 0
         [at]
     R2
          [ v0 ]
     R3
              = 0
          [v1]
     R4
         [a0] = 10010000
              = 7ffffe3c
          [a1]
         [a2] = 7ffffe44
     R7
          [a3] = 0
     R8
         [t0] = 0
     R9 [t1] = 0
     R10 [t2] = 0
                                             Address of hello string
User data segment [10000000]..[10040000]
[10000000]..[10010000] 00000000[10010000]
                                                6c6c6548
                                                          6f57206f
                                                                    0a646c72
                                                                               000000000 HelloWorld
[10010010]..[10040000]
                        00000000
User Stack [7ffffe38]..[80000000]
                                                                       \n d l r nul
                                                            o W
[7ffffe38]
                        7ffffe76
              00000001
                                                            0
[7ffffe40]
              00000000
                         7fffffdd
                                   7fffffa4
[7ffffe50]
              7fffff80
                        7ffffff73
                                   7fffff63
```

• *HelloWorld2.s*: Can break the string into multiple parts:

```
.data
                                            Note: The prologue and epilogue of main are missing
        .asciiz "Hello"
hello:
                                            here. They are present in the HelloWorld2.s example
space: .asciiz " "
                                            that is on D2L.
world: .asciiz "World"
newline: .asciiz "\n"
.text
         # set up and print the string "Hello"
                $a0, hello # Point to the string
         la
                 $v0, $zero, 4 # syscall value for print string
         addi
         syscall
         # set up and print the string " "
         la
                 $a0, space # Point to the string
         addi
                 $v0, $zero, 4 # syscall value for print string
         syscall
         # set up and print the string "World"
                $a0, world # Point to the string
         la
                 $v0, $zero, 4 # syscall value for print string
         addi
         syscall
         # set up and print the string "\n"
                 $a0, newline # Point to the string
         la
                 $v0, $zero, 4 # syscall value for print string
         addi
         syscall
```

• *HelloWorld2.s*: Can break the string into multiple parts:

```
.data
         hello:
                    .asciiz "Hello"
                   .asciiz " "
         space:
         world:
                    .asciiz "World"
         newline: .asciiz "\n"
User data segment [10000000]..[10040000]
                                                      0020006f
[10000000]..[10010000] 00000000[10010000]
                                                                          000a0064 Hello
[10010010]..[10040000]
                       00000000
User Stack [7ffffe38]..[80000000]
[7ffffe38]
             00000001 7ffffe76
[7ffffe40]
             00000000
                       7fffffdd 7fffffa4
[7ffffe50]
             7fffff80
                      7ffffff73 7fffff63
```

Program Flow Control

- Assembly language supports a much smaller set of flow control instructions compared to high-level programming languages:
 - What assembly language does not have:
 - for, while, do...while, switch
 - What assembly language does have:
 - Unconditional branch.
 - Conditional branch.
 - Function calls.

Unconditional branch.

The jump instruction:

- j label
- Example:

```
add $t0, $s1, $s2
j toThere
add $t0, $t0, $s1 # This instruction is skipped
add $s1, $s2, $s2 # This instruction is skipped
toThere: add $s7, $s1, $s3
```

Conditional branch.

- Chooses between two control flows. Either
 - Execute the next instruction, or
 - Jump to a different instruction.
- MIPS has two conditional branch instructions:
 - Branch if equal:
 - beq register, register, Label
 - Branch if not equal:
 - bne register, register, Label
- Example:

```
if ( i == j )
    h = i + j;
z = h + h;
bne $s0, $s1, downThere # if (i != j)
add $s3, $s0, $s1 # h = i + j

downThere: add $s4, $s3, $s3 # z = h + h
```

- Note: reversal of the condition from equality to inequality!
 - This is a common technique.

Conditional branch (continued):

• Example, version 1:

```
bne $s4, $s5, Lab1 # compare i, j
 if ( i != j )
                           j Lab2
                                                # skip true part
  h = i + j;
                     Lab1:
                           add $s3, $s4, $s5
                                               \# h = i + j
                                                # skip false part
                            j Lab3
else
                     Lab2:
  h = i - j;
                           sub $s3, $s4, $s5 # h = i - j
k = h + i;
                     Lab3:
                           add \$s6, \$s3, \$4 # k = h + i
```

- The statement labeled **Lab1**: is executed <u>only</u> when \$s4 is <u>not</u> equal to \$s5.
- The statement labeled **Lab2**: is executed only when \$s4 is equal to \$s5.
- The statement labeled **Lab3**: is executed <u>always</u>.
- Need to "skip the true part" if the bne is false; hence the need for j Lab2.
- Confusing structure, prone to errors.

Conditional branch (continued):

• Example, version 2:

```
if ( i != j )
    h = i + j;
    dd $s3, $s4, $s5 # h = i + j
    j Lab2 # skip false part

else
    h = i - j;
    sub $s3, $s4, $s5 # h = i - j

k = h + i;
    Lab2:
    add $s6, $s3, $s4 # k = h + i
```

- The reversed condition makes this easier to read, and less prone to errors.
 - Allows the assembly code to more closely follow the pattern from the higher-level language.
- The statement labeled **Lab1**: is executed <u>only</u> when \$s4 is equal to \$s5.
- The statement labeled **Lab2**: is executed <u>always</u>.

Conditional branch (continued):

- Comparisons other than equal or not equal?
- New instruction: **Set Less Than**.
 - Compares two registers and puts the result in the destination register:

- First operand, \$\displain \text{in this case, is the destination of the result of the comparison.}
 - Note: this follows the pattern of all the MIPS arithmetic instructions.
- Second and third operands are compared: \$s4 < \$s5
- Result is 1 if the comparison is true.
- Result is **o** if the comparison is false.
- Example:

```
# Basic idea:
# if ( $s3 ?? $s5 ) goto Athos
slt $t0, ___, ___,
b__ $t0, $zero, Athos
# less than:
# if ($s5 < $t7) goto otherPlace</pre>
slt $t0, <u>$s5</u>, <u>$t7</u>
bne $t0, $zero, otherPlace
# greater than:
# reverse the order
# if ( $s4 > $s1 ) goto Batman
# becomes
# if ( $s1 < $s4 ) goto Batman
slt $t2, <u>$s1</u>, <u>$s4</u>
bne $t2, $zero, Batman
```

```
# Alternative approach when ='s is present:
# Basic idea:
                                              # if ( $s3 <= $s2 ) goto Zorro
# if ( $s3 ?? $s5 ) goto Athos
      $t0, ____, ___
b__ $t0, $zero, Athos
                                              # Two parts:
                                              # First: if ( $s3 == $s2 ) goto Zorro
                                              beq $s3, $s2, Zorro
                                              # Second: if ($s3 < $s2) goto Zorro
# less than or equal to:
                                              slt $t2, $s3, $s2
    reverse the meaning, use greater than
                                              bne $t2, $zero, Zorro
# if ( $s3 <= $s2 ) goto Zorro
# becomes:
# if (!($s3 > $s2)) goto Zorro
                                              # if ( $s3 >= $s5 ) goto Porthos
                                              # First part, take care of ='s
# need to reverse the order to remove !
                                              beq $s3, $s5, Porthos
# if ( $s2 < $s3 ) goto Zorro
                                              # Then, we have:
slt $t1, $s2, $s3
                                              # if ( $s3 > $s5 ) goto Porthos
bne $t1, $zero, Zorro
                                              # reverse the order to get
                                              # if ( $s5 < $s3 ) goto Porthos
# Can use a similar approach for >=
                                              slt $t0, $s5, $s3
# But, this can be confusing(!!)
                                              bne $t0, $zero, Porthos
# and prone to errors
```

• MIPS Instruction summary to date:

Instruction	Meaning
add \$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3
sub \$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3
addi \$t0, \$s3, Number	add immediate: $$t0 = $s3 + Number$
la \$s2, label	\$s2 = address of label, pseudo-instruction
lw \$s1, 0(\$s2)	\$s1 = Memory[\$s2], load word in Memory at position \$s2 into \$s1
sw \$s1, 0(\$s2)	Memory[\$s2] = \$s1, store word in $$s1$ into $Memory$ at position $$s2$
slt \$t0, \$s3, \$s4	\$t0 = \$s3 < \$s4, put 1 in \$t0 if true, else put 0 in \$t0
bne \$s4, \$s5, aLabel	Next instruction executed is at aLabel if \$s4 ≠ \$s5
beq \$s4, \$s5, bLabel	Next instruction executed is at bLabel if \$s4 == \$s5
j cLabel	Next instruction executed is at cLabel

For Loops.

• C (or Java) code:

```
sum = 0;
for (i = 0; i < y; i++)
sum = sum + x;</pre>
```

- MIPS:
 - Assume: \$s0 has x, \$s1 has y, and \$s2 (will have) sum.
 - Will use **\$t0** for **i**.

```
initialize
                  add $s2, $zero, $zero # sum = 0
                \rightarrow addi $t0, $zero, 0  # i = 0, initial value set before loop begins
loop index
          LoopBegin:
                  # for loop does comparison at beginning of each iteration
 condition -
                  slt $t2, $t0, $s1  # is i < y ??
                  beq $t2, $zero, LoopEnd # branch below end of loop if done
                  # loop body
                  add $s2, $s2, $s0
                                           \# sum = sum + x
                  # increment loop index
 increment
                🝌 addi $t0, $t0, 1
                                           # i++
                       LoopBegin
          LoopEnd:
                  # rest of program goes here...
```

• Complete MIPS program: for loop example. Available as *for1*.s on D2L.

```
.data
        .word 42
x:
        .word
y:
        .word 0
sum:
answer: .asciiz "The sum is "
newline: .asciiz "\n"
.text
main:
        # Function prologue -- even main has one
        addiu $sp, $sp, -24 # allocate stack space -- default of 24 here
             $fp, 0($sp) # save caller's frame pointer
        SW
                              # save return address
            $ra, 4($sp)
        addiu $fp, $sp, 20
                              # setup main's frame pointer
        # Put x into $s0
             $t0, x
        la
             $s0, 0($t0)
        lw
        # Put y into $s1
        la $t0, y
        lw $s1, 0($t0)
        add $s2, $zero, $zero # sum = 0
        add $t0, $zero, $zero
                                 \# i = 0
```

```
LoopBegin:
        # for loop does comparison at beginning of each iteration
                                 # is i < y ??
        slt $t2, $t0, $s1
        beq $t2, $zero, LoopEnd # branch below end of loop if done
        # loop body
        add $s2, $s2, $s0 # sum = sum + x
        # increment loop index
        addi $t0, $t0, 1
                             # i++
              LoopBegin
LoopEnd:
        # Print message
              $a0, answer
        addi $v0, $zero, 4
        syscall
        # Print the sum
        add $a0, $s2, $zero
        addi $v0, $zero, 1
        syscall
        # Print newline
            $a0, newline
        la
        addi $v0, $zero, 4
        syscall
```

```
done: # Epilogue for main -- restore stack & frame pointers and return lw $ra, 4($sp) # get return address from stack lw $fp, 0($sp) # restore the caller's frame pointer addiu $sp, $sp, 24 # restore the caller's stack pointer jr $ra # return to caller's code
```

- Print the integers in an array where the number of elements in the array is known.
- First problem to understand: How to represent an array in MIPS?
 - Handled by declaring memory in the .data section.
 - The label **numElements** tells us how many values are stored in the array.
 - The array has only one label, which is the name of the array.
 - The label identifies the beginning of the array.
 - Example:
 - .data
 numElements:
 - .word 7
 - elements:
- .word 55
- .word 77
- .word 0
- .word -16
- .word -19
- .word 82

- Arrays in assembly differ from arrays inJava in two very important ways:
 - Nothing marks the end of an array.
 - Nothing indicates how many elements are in the array.

- Sets up an array:
 - Named elements.
 - 7 locations, each of size 4 bytes (a word).
 - Each position has an initial value.

- We need:
 - A register to hold the loop index, i.
 - A register to hold the number of elements in the array.
 - A register to hold the starting address of the array.

```
addi $$1, $zero, 0  # $$1 = i = 0

la $$t0, numElements
lw $$2, 0($t0)  # $$2 = numElements

la $$t0, elements  # $$t0 = address of elements[0]
```

- To get one element of the array:
 - Compute the offset (number of bytes) from the beginning of the array to the desired integer.
 - Each integer is 4 bytes (one word).
 - Can multiply i by 4, then add to the starting address of the array:

```
add $t1, $s1, $s1
add $t1, $t1, $t1 # $t1 = 4 * i
add $t2, $t0, $t1 # $t2 = address of elements[i]
lw $a0, 0($t2) # $a0 = elements[i]
```

• Note: it is faster to do two add's than to do one multiply.

• Complete MIPS program: array print example. Available as for 2.s on D2L. # Print the values of an array using a for loop. .data numElements: .word 7 elements: \$t0, elements .word 55 # lw \$t7, 0(\$t0) .word 66 # lw \$t7, 4(\$t0) # lw \$t6, 8(\$t0) .word 77 .word 0 .word -16 .word -19.word 82 newline: .asciiz "\n" .text main: # Function prologue -- even main has one subu \$sp, \$sp, 24 # allocate stack space -- default of 24 here \$fp, 0(\$sp) # save caller's frame pointer SW \$ra, 4(\$sp) # save return address

addiu \$fp, \$sp, 20 # setup main's frame pointer

• Complete MIPS program: array print example. Available as for 2.s on examples from class web page and D2L.

```
\# for ( i = 0; i < numElements; i++ )
             print elements[i]
                                                          Write a pseudo-code version of your algorithm.
                $s1, $zero, 0
        addi
                                 \# i = 0
                                                          Then, put it in your code as comments.
                $t0, numElements
        la
                                                          We will look for these in your programs.
                $s2, 0($t0) # $s2 = numElements
        1w
                $t0, elements # $t0 = address of elements[0]
        la
loopBegin:
        # test if for loop is done
        slt
                $t1, $s1, $s2
                                 # $t1 = i < numElements</pre>
                $t1, $zero, loopEnd
        beq
        # Compute address of elements[i]
                $t1, $s1, $s1
        add
                $t1, $t1, $t1 # $t1 = 4 * i
        add
                $t2, $t0, $t1  # $t2 = address of elements[i]
        add
                $a0, 0($t2)
                               # $a0 = elements[i]
        lw
                $v0, $zero, 1
        addi
        syscall
        # print newline
                $a0, newline
        la
        addi
                $v0, $zero, 4
        syscall
```

• *for2.s* continued:

```
addi $s1, $s1, 1 # i++
j loopBegin
```

loopEnd:

```
done: # Epilogue for main -- restore stack & frame pointers and return
lw $ra, 4($sp)  # get return address from stack
lw $fp, 0($sp)  # restore the caller's frame pointer
addiu $sp, $sp, 24  # restore the caller's stack pointer
jr $ra  # return to caller's code
```

While Loops:

• Consider the while loop:

```
while ( save[i] != -2 ) Stop the loop when we find a -2
  if ( save[i] == k ) How many elements in the array save are equal to k?
    count += 1;
  i = i + 1;
```

• Here is a complete MIPS program to solve this problem. Available as while 1.s on the class web page and D2L.

.data

```
\# save[0] = 19
          .word
                  19
save:
                                 \# save[1] = 42
                  42
          .word
                                 \# save[2] = 42
          .word
                  42
                                 \# save[3] = 42
          .word
                                 \# save[4] = 42
                  42
          .word
                                 \# save[5] = 42
          .word
                  42
                                 \# save[6] = 42
          .word
                  42
                                 \# save[7] = 93
          .word
                  93
                                 \# save[8] = -2
          .word
                  -2
                                 # number within save that we are looking for
k:
          .word
         .asciiz "The final value of count = "
str:
newline: .asciiz "\n"
```

While loops (continued):

```
.text
main:
       # Function prologue -- even main has one
       addiu $sp, $sp, -24  # allocate stack space -- default of 24 here
sw $fp, 0($sp)  # save caller's frame pointer
            $ra, 4($sp) # save return address
       SW
       addiu $fp, $sp, 20  # setup main's frame pointer
            la
            $s3, $zero, $zero # initial value of i is 0
       add
           $t0, k
       la
          lw
       addi $s1, $zero, -2 # Put ending value of -2 into $s1
       add $s2, $zero, $zero # $s2 = count = 0; start count at zero
LoopBegin:
       # Loop Test, stop loop when we find a -2 in save[i]
       add $t1, $s3, $s3
                           # quadruple i to get offset for save[i]
       add $t1, $t1, $t1
       add $t1, $t1, $s6 # compute address of save[i]
       beq $t0, $s1, LoopEnd # end loop if save[i] == -2
```

```
While loops (continued):
          # Loop body
```

Note: The code for the if statement is <u>entirely</u> contained within the body of the loop. Do **not** jump outside the loop!

```
# if ( save[i] == k )
          count++
              $t0, $s5, afterIncrement # if ( save[i] != k )
                                 # count += 1
        addi $s2, $s2, 1
afterIncrement:
        addi $s3, $s3, 1
                                 # i++
        j
              LoopBegin
                                # back to start of loop
LoopEnd:
        # Print count with a label
                                # $a0 = address of start of string
              $a0, str
         la
        addi $v0, $zero, 4
        syscall
              $a0, $s2, $zero
                                # $a0 = value of count
         add
        addi $v0, $zero, 1
        syscall
              $a0, newline
                                # $a0 = address of newline string
         la
        addi $v0, $zero, 4
```

syscall

While loops (continued): The WRONG way to do an if statement that is inside a loop

```
# Loop body
         # if ( save[i] == k )
                                                                     if ( x .lt. y ) goto 53
             count++
               $t0, $s5, increment # if ( save[i] != k )
                                                                     if (x) 42, 93, 16
afterIncrement:
               $s3, $s3, 1
         addi
                                  # back to start of loop
               LoopBegin
LoopEnd:
         # Print count with a label
               $a0, str
                                  # $a0 = address of start of string
         la
         addi $v0, $zero, 4
         syscall/
               $a0, $s2, $zero
                                 # $a0 = value of count
         add
         addi/ $v0, $zero, 1
         syscall
               $a0, newline
                                 # $a0 = address of newline string
         addi \ $v0, $zero, 4
         syscall
             done
                                                                         done:
                                                                         on next
             addi $s2, $s2, 1
                                     # count += 1
increment:
         j
             afterIncrement
                                                                         page
```

While loops (continued):

```
done: # Epilogue for main -- restore stack & frame pointers and return
lw $ra, 4($sp)  # get return address from stack
lw $fp, 0($sp)  # restore the caller's frame pointer
addiu $sp, $sp, 24  # restore the caller's stack pointer
jr $ra  # return to caller's code
```

Other conditions for branching:

- So far, we have **beq** and **bne** for branching, and we have **slt** for comparing (without branching).
- What about other possibilities? Branch on less than, branch on greater than, branch on less than or equal, etc?
- Can have an assembly language that provides all of these options.
 - MIPS does not! (I am not counting pseudo-instructions.)
- Can use slt with bne or beg to build the missing branch instructions.
- Example:
 - Branch if greater than (assume x is in \$s1, and y is in \$s2):

- Note: The order of the comparison was reversed.
 - The question becomes: Is not(y < x)? If so, the branch goes to the else clause.
 - Reversing the meaning of the comparison is a common technique!

Constant or Immediate Operands:

- Many times, one operand of an arithmetic instruction is a small constant integer.
 - Can occur in 50% or more of the MIPS instructions in some programs!
- Possible solutions:
 - Put typical constants in memory and load them into a register when needed. .text
 - Can be quite slow to perform the 1w operation so many times in a program! 1a \$t0, twenty
 - Hard-wire some of the registers to hold the most commonly used constants. lw \$s3, 0(\$t0)
 - The \$zero register in MIPS.
 - Difficult in general to decide which constants (other than zero) are most needed.
- MIPS Solution (and something similar is done in many other assembly languages):
 - Add "a few" instructions that allow one operand (of the three) to be stored in the instruction itself.
 - addi
 - slti
 - Have already been using addi.

- add \$zero, \$s7, \$s2
- addi \$s7, \$s2, -17
- slti \$t0, \$s2, 20
- -32,768 to 32,767
- slti \$t0, 20, \$s2 # does NOT work!!

.data

twenty: .word 20

slt \$t0, \$s2, \$s3

Constant or Immediate Operands (continued):

• Examples:

```
addi $t1, $s3, 4  # $t1 = $s3 + 4  
addi $t7, $s2, -27  # $t7 = $s2 + (-27)  
slti $t2, $s4, -8  # $t2 = $s4 < -8, $t2 == 0 if false, $t2 == 1 if true
```

- The immediate operand in all these cases is a 16-bit, signed, two's complement integer.
 - Thus, the range for the immediate operand is: -32,768 to +32,767.
- Note: there is no **subi** instruction. Why?
- la is a pseudo-instruction. It will accept an argument as large as a 32-bit, signed, two's complement integer.
 - The argument is assumed to be a label.
 - The address associated with the label is put in the specified register.
 - The assembler (spim in our case) will substitute one or two instructions for the la.
 - How many instructions are substituted depends on the address of the label.

la \$t3, numbers

• MIPS Instruction summary to date:

Category	Instruction		Example	Meaning	Comments
	add	add	\$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3	3 operands; data in reg
Arithmetic	add immediate	addi	\$s1, \$s2, 17	\$s1 = \$s2 + 17	3 operands; data in reg
	subtract	sub	\$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3	3 operands; data in reg
Data transfer	load word	lw	\$s1, 0(\$s2)	\$s1 = Memory[\$s2]	Data fm memory to reg
Data transfer	store word	sw	\$s3, 0(\$t5)	Memory[\$t5] = \$s3	Data fm reg to memory
	branch on equal	beq	\$s1,\$s2,Label	if (\$s1 == \$s2) goto Label	Equal test and branch
Conditional	branch on not equal	bne	\$s1,\$s2,Label	if (\$s1 ≠ \$s2) goto Label	Not equal test & branch
branch	set on less than	slt	\$s1, \$s2, \$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than
	set on less than imm	slti	\$s1, \$s2, num	if (\$s2 < num) \$s1 = 1; else \$s1 = 0	Compare less than w/ immediate operand
Unconditional branch	jump	j	Label	goto Label	Branch to target address

Machine Language

Reading: Section 2.5 (4th edition).

- Instructions have to be stored in memory. It is a design choice as to how to represent the instructions.
- MIPS makes the choice to use a 32-bit value to represent instructions.
 - This choice could be different.
 - Some instruction sets use different sizes for different instructions.
 - Can result in multiple reads from memory to get one instruction into the CPU.
 - Example: The Motorola 68000 chip uses instruction sizes that vary in length from 16 to 80 bits.

- Repeating Slide #23:
- Text Segment:
 - Displays the program code.

Line number from your .s file MIPS machine language Address of instruction 32-bit, hexadecimal hexadecimal [00400024] 27bdffe8 addiu \$29, \$29, -24 ; 13: addiu \$sp, \$sp, -24 # allocate stack space -- default o [00400028] afbe0000 sw \$30, 0(\$29) sw \$31, 4(\$29) [00400030] 27be0014 addiu \$30, \$29, 20 lui \$8, 4097 [bats]

; 14: sw \$fp, 0(\$sp) # save caller's frame pointer ; 15: sw \$ra, 4(\$sp) # save return address [0040002c] afbf0004 ; 16: addiu \$fp, \$sp, 20 # setup main's frame pointer ; 18: la \$t0, bats # \$t0 has address of the bats memory locat [00400034] 3c081001 [00400038] 8d100000 ; 19: lw \$s0, 0(\$t0) # \$s0 now holds the number of bats lw \$16, 0(\$8) [0040003c] 3c011001 lui \$1, 4097 [balls] ; 20: la \$t0, balls # \$t0 has address of the balls memory loc ori \$8, \$1, 4 [balls] [00400040] 34280004 [00400044] 8d110000 lw \$17, 0(\$8) ; 21: lw \$s1, 0(\$t0) # \$s1 now holds the number of balls [00400048] 3c011001 lui \$1, 4097 [gloves] ; 22: la \$t0, gloves # \$t0 has address of the gloves memory 1 [0040004c] 34280008 ori \$8, \$1, 8 [gloves] ; 23: lw \$s2, 0(\$t0) # \$s2 now holds the number of gloves [00400050] 8d120000 lw \$18, 0(\$8) add \$19, \$16, \$17 [00400054] 02119820 ; 24: add \$s3, \$s0, \$s1 # \$s3 now holds the number of bats+ba [00400058] 02729820 ; 25: add \$s3, \$s3, \$s2 # \$s3 now holds the number of bats+ba add \$19, \$19, \$18 [0040005c] 3c011001 lui \$1, 4097 [sum] ; 27: la \$t0, sum # \$t0 has address of the sum memory locatio [00400060] 34280010 ori \$8, \$1, 16 [sum] ; 28: sw \$s3, 0(\$t0) # sum now holds the number of bats+balls [00400064] ad130000 sw \$19, 0(\$8) ; 31: lw \$ra, 4(\$sp) # get return address from stack [00400068] 8fbf0004 lw \$31, 4(\$29) ; 32: lw \$fp, 0(\$sp) # restore the caller's frame pointer [0040006c] 8fbe0000 lw \$30, 0(\$29) [00400070] 27bd0018 addiu \$29, \$29, 24 ; 33: addiu \$sp, \$sp, 24 # restore the caller's stack pointer [00400074] 03e00008 jr \$31 ; 34: jr \$ra # return to caller's code

Assembly language

instruction, after assembly


Assembly language instruction, from your .s file,

before assembly

3 — MIPS Introduction


• For example:

- Registers are represented in the machine instruction as numbers in the range 0..31.
 - \$t1 is register 9; \$s1 is register 17; \$s2 is register 18



- Field abbreviations: SPIM Appendix section 10.2, page 50.
 - op basic operation of the instruction, the *operation code* or <u>opcode</u>.
 - **rs** first <u>register source</u> operand.
 - **rt** second <u>register source</u> operand.
 - \bullet rd register destination operand; the result of the operation goes into this register.
 - shamt shift amount (we will see the use of this field later, for now it will always be zero).
 - **funct** <u>function</u>. Selects the specific variant of the opcode. (Figure 10.2, page 50 in SPIM Appendix).

• Other points to notice about the layout:




- It is no accident that there are 16 bits with three fields in each half of the format.
- The Most Significant Bit (MSB) is on the **opcode** end of the instruction.
- The Least Significant Bit (LSB) is on the **funct** end of the instruction.
- This instruction format is called <u>R-type</u>.
- This format is used for most of the arithmetic instructions.
 - The main exception are the arithmetic instructions that take immediate operands.

- More R-format instruction examples:
- Set-Less-Than:

- Register \$\ddot\dot\omega\$ is \$\ddot\dot\omega\$; Register \$\ddot\dot\dot\omega\$ is \$\ddot\dot\omega\$.
- The <u>opcode</u> is 0 (again); the <u>funct</u> field is different from the **add**.
 - This is the only way to tell it is an slt rather than an add.

op	rs	rt	rd	shamt	funct
000000	01001	01010	01000	00000	101010
0 _{ten}	9 _{ten}	10 _{ten}	8 _{ten}	0 _{ten}	42 _{ten}

- Subtract:
 - There are two versions of subtract:
 - **sub** assumes the values in the registers are <u>signed</u> numbers.
 - **subu** assumes the values in the registers are <u>unsigned</u> numbers.



subu \$s1, \$t3, \$t4

\$s1 is \$17; \$t3 is \$11; \$t4 is \$12

op	rs	rt	rd	shamt	funct
000000	01011	01100	10001	00000/	100011
0 _{ten}	11 _{ten}	12 _{ten}	17 _{ten}	0_{ten}	35_{ten}

Arithmetic instructions with <u>Immediate</u> operands:

- Major difference: Each instruction has two registers and an immediate value (signed, 16-bit, 2's complement integer).
- Need 16 bits (out of a total of 32 bits) for the immediate operand:
 - We can make use of the shamt field: 5 bits.
 - We only need two registers, not three. This gains: 5 bits.
 - Total so far: 10 bits. But we need 16...
- Solution: Use a different opcode for each immediate instruction.
 - Gains the funct field: 6 bits.
 - Total is now: 16 bits.
- This is the I-format instruction.
- Puts the immediate operand in the second half (right half) of the instruction:


addi	\$s7, \$	t0, 321	# \$s7 is \$23; \$t0 is	\$8
op	rs	rt	16 bit number	
001000	01000	10111	0000 0001 0100 0001	
8 _{ten}	8 _{ten}	23 _{ten}	321 _{ten}	

More I-format instructions:

- Conditional branch statements need to include an address.
- Addresses are 32-bit values in MIPS.
- Dilemma: How to fit the opcode, two registers, and an address into a 32-bit MIPS instruction?
 - Use <u>PC-relative addressing</u>.
 - Address specified in the conditional branch is relative to the current value of the Program Counter.
 - Use the specified address as a 16-bit, two's complement value. Add this to the current value of the program counter.
 - Allows forward or backward branching.
 - Can not branch to locations that are "too far away."
 - Optimization:
 - All MIPS instructions are 32-bit. They are all word-aligned (start on an address divisible by 4).
 - Let the offset in the conditional branch instruction be an "instruction" offset, rather than a byte offset. That is, the offset is multiplied by 4 before being added to the Program Counter.

More I-format instructions:

• Example of conditional branch in I-format:



- The Program Counter contains the address of the <u>next</u> instruction.
- Thus, to branch to the label **toThere** we add two instructions: PC + 2 * (size of a MIPS instruction).

More I-format instructions — 1w and sw:

- The 1w and sw instructions use only two registers (similar to bne and beq in this respect).
- They also use a 16-bit, two's complement number; the offset.
- Unlike beq, the offset for 1w and sw is a count of bytes, not words.

lw \$s7, 0(\$s2) # \$s7 is \$23; \$s2 is \$18

op	rs	rt	16 bit number		
100011	10010	10111	0000 0000 0000 0000		
35 _{ten}	18 _{ten}	23 _{ten}	0 _{ten}		

sw \$s3, 168(\$s1) # \$s3 is \$19; \$s1 is \$17

op	rs	rt	16 bit number		
101011	10001	10011	0000 0000 1010 1000		
43 _{ten}	17 _{ten}	19 _{ten}	168 _{ten}		

Unconditional branch and the J-Format:

- The jump instruction takes a single argument, which is the address of an instruction.
- The instruction has to fit within 32-bits (as do all MIPS instructions).
 - Need an opcode: 6 bits.
 - Need an address: 32 bits.
 - That's 38 bits(!!)
 - Can not use a 32-bit address.
- The address of an instruction is always a multiple of 4.
 - Addresses that are multiplies of 4 always have two binary zeroes on the right.
 - Don't store the two zeroes.
- Now:
 - Need an opcode: 6 bits.
 - Need an address: 30 bits.
 - That's 36 bits; closer, but not quite there yet.

Unconditional branch and the J-Format (continued):

• So far:


j $0x0040\ 0240$ $0x0040\ 0240 = 0000\ 0000\ 0100\ 0000\ 0010\ 0100\ 0000_{two}$

• Take the left-most 4 bits from the PC:

j 0x0040 0240

 $0x0040\ 0240 = 0000\ 0000\ 0100\ 0000\ 0010\ 0100\ 0000$

From the PC+4



- Allows a j instruction to go to any instruction that has the same high-order 4 bits as the PC.
 - Divides the 4GB address space into 16 segments, each containing (how many?) bytes.

Dropped

Logical Operations

Reading: Section 2.6 (4th edition), 2.5 (3rd edition).

• AND:

and \$t0, \$s1, \$s2

una (co, (si, (si

• Performs a <u>bit-wise</u> AND operation:

 $$s1 = 0010 \ 0110 \ 0110 \ 1111 \ 1111 \ 0000 \ 1010$

 $$s2 = 1111 \ 0000 \ 0000 \ 0000 \ 1111 \ 0000 \ 1111 \ 1111$

\$s1 AND \$s2 = 0010 0000 0000 0000 1111 0000 0000 1010

- For Java and C, this operation is done with &
 - Example:

$$x = y \& z;$$

op	rs	rt	rd	shamt	funct
000000	10001	10010	01000	00000	100100
0 _{ten}	17 _{ten}	18 _{ten}	8 _{ten}	0 _{ten}	36 _{ten}

a	b	c = a AND b
0	0	0
0	1	0
1	0	0
1	1	1

• OR:

• Performs a <u>bit-wise</u> OR operation:

$$$s1 = 0010 \ 0110 \ 0110 \ 0111 \ 1111 \ 1111 \ 0000 \ 1010$$

$$$s2 = 1111 0000 0000 0000 1111 0000 1111 1111$$

- For Java and C, this operation is done with |
 - Example:

$$x = y \mid z;$$

op	rs	rt	rd	shamt	funct
000000	10001	10010	01000	00000	100101
0 _{ten}	17 _{ten}	18 _{ten}	8 _{ten}	0 _{ten}	37 _{ten}

a	b	c = a OR b
0	0	0
0	1	1
1	0	1
1	1	1

• NOR, Not OR:

- Performs a <u>bit-wise</u> NOT OR operation.
- The NOT OR operation takes the OR of the two operands, then reverses (NOT's) the result:

$$$s1 = 0010 \ 0110 \ 0110 \ 0111 \ 1111 \ 1111 \ 0000 \ 1010$$

$$$s2 = 1111 \ 0000 \ 0000 \ 0000 \ 1111 \ 0000 \ 1111 \ 1111$$

• There is <u>not</u> an operator for this operation in Java or C

op	rs	rt	rd	shamt	funct
000000	10001	10010	01000	00000	100111
0 _{ten}	17 _{ten}	18 _{ten}	8 _{ten}	0 _{ten}	39 _{ten}

a	b	c = a NOR b
0	0	1
0	1	0
1	0	0
1	1	0

- NOT:
 - The bit-wise NOT operation simply reverses each bit: 0 becomes 1; 1 becomes 0.

$$\$s1 = 0010 \ 0110 \ 0110 \ 0111 \ 1111 \ 1111 \ 0000 \ 1010$$
NOT $\$s1 = 1101 \ 1001 \ 1001 \ 1001 \ 0000 \ 0000 \ 1111 \ 0101$

- MIPS does not have a NOT operation.
- Instead, we can use NOR with \$zero as one of the registers. For example, to apply the NOT operation to \$s1, do the following:

- There is a NOT operator in C and Java for doing a bit-wise NOT operation:
 - The tilde operator:

$$x = \sim y;$$

a	NOT a
0	1
1	0

• XOR, Exclusive-OR:

- Performs a <u>bit-wise</u> XOR operation. Exclusive-OR has the answer 0 when both operands are 1.
- XOR

$$$s1 = 0010 \ 0110 \ 0110 \ 0111 \ 1111 \ 1111 \ 0000 \ 1010$$

$$$s2 = 1111 0000 0000 0000 1111 0000 1111 1111$$

- For Java and C, this operation is done with ^
 - Example:

$$x = y ^ z;$$

op	rs	rt	rd	shamt	funct
000000	10001	10010	01000	00000	100110
0 _{ten}	17 _{ten}	18 _{ten}	8 _{ten}	0 _{ten}	38 _{ten}

a	ь	c = a XOR b
0	0	0
0	1	1
1	0	1
1	1	0

• XOR, Exclusive-OR:

```
xor $t0, $s1, $s2
```

- Performs a <u>bit-wise</u> XOR operation. Exclusive-OR has the answer 0 when both operands are 1.
- XOR

```
$s1 = 0010 0110 0110 0110 1111 1111 0000 1010 the key

$s2 = 1111 0000 0000 0000 1111 0000 1111 1111 the message

$s1 XOR $s2 = 1101 0110 0110 0110 0000 1111 1111 0101 the encrypted message

$s1 XOR $s2 = 1101 0110 0110 0110 0000 1111 1111 0101 the encrypted message

$s1 = 0010 0110 0110 0110 1111 1111 0000 1010 the key

1111 0000 0000 0000 1111 0000 1111 1111 the message
```

- and \$t1, \$s5, \$zero
- or \$t2, \$s5, \$zero

- Immediate versions of AND, OR, XOR. These are named: andi, ori, xori.
 - They each have a 16-bit, signed, two's complement number for the immediate operand.
 - The immediate value is <u>zero</u>-extended to create a 32-bit number. Then the operation is applied.

andi \$t0, \$s1, 0x74 A2 andi \$t0, \$s1, 0x74A2 andi \$t3, \$s4, 17 \$s1 = 0010 0110 0110 0110 1111 1111 0000 1010 and 0x74A2 = 0000 0000 0000 0000 0111 0100 1010 0010

76

0000 0000 0000 0000 0111 0100 0000 0010

op	rs	rt	16 bit number	
001100	10001	10010	0111 0100 1010 0010	
12 _{ten}	17 _{ten}	18 _{ten}	29858 _{ten}	

op	rs	rt	16 bit number	
001101	10001	10010	1001 0100 1010 0010	
13 _{ten}	17 _{ten}	18 _{ten}	-27486 _{ten}	

Shifting:

• Logical shifts:

$$$s1 = 1001 \ 1100 \ 0100 \ 0000 \ 1111 \ 0101 \ 1100 \ 0011$$

• Move the bits in the register.

$$$t0 = 1000 0000 0000 0000 0000 0000 0000$$

• Bits "fall off" the end of the register.

$$$11$$
 $$t0, $s1, 0$ $$t0 = $s0 shifted left 4 bits$

 $$s1 = 1001 \ 1100 \ 0100 \ 0000 \ 1111 \ 0101 \ 1100 \ 0011$

\$t0 = 1001 1100 0100 0000 1111 0101 1100 0011

• Shift Left Logical: **s11**

$$$11$$
 \$t0, \$s1, 4 # \$t0 = \$s0 shifted left 4 bits

$$$s1 = 1001 1100 0100 0000 1111 0101 1100 0011$$

- For Java and C, this operation is done with <<
 - Example:

$$x = y << 4;$$
 $x <<= 5;$

- rs field is ignored (not used) since we only have two registers in the instruction.
- shamt field is now being used.

shamt funct
00100 000000
-
4 _{ten} 0 _{ten}

• Shift Right Logical: srl

• For C, this operation is done with >>

• Example: $x = y \gg 4$;

• For Java, this operation is done with >>>

• Example: x = y >>> 4;

op	rs	rt	rd	shamt	funct
000000	00000	10001	01000	00100	000010
0 _{ten}	0 _{ten}	17 _{ten}	8 _{ten}	4 _{ten}	2 _{ten}

- Notes on using Logical shifts:
 - The **shamt** field has 5 bits; enough to shift from 0 to 31 positions.
 - We can use a logical shift left by two places to multiply by 4:
 - Useful in computing array offsets. Use one s11 instead of using two add instructions.
 - Can think of shift left logical as a multiply by a power of two.

• Shift Right Arithmetic

```
sra $t0, $s1, 6  # $t0 = $s0 shifted right 6 bits
$s1 = 1001 1100 0100 0000 1111 0101 1100 0011
$t0 = 1111 1110 0111 0001 0000 0011 1101 0111
```

- The arithmetic shift will copy the sign bit on the left.
 - If the number is positive, 0's are shifted into the left side.
 - If the number is negative, 1's are shifted into the left side (as in the example above).
- For Java, this operation is done with >>

Ор	rs	rı	ra	snami	Tunct
000000	00000	10001	01000	00110	000011
00000	00000	10001	01000	00110	000011
		17	0	6	2
Uten	0 _{ten}	17 _{ten}	8 _{ten}	oten	³ ten

• Example:

$$x = y >> 6;$$

- For C, the definition of >> is an implementation-dependent feature. That is, a compiler may choose to implement >> as a <u>logical</u> shift, <u>or</u> as an <u>arithmetic</u> shift.
 - Example:

$$x = y >> 6;$$

- For an unsigned int, this gives shift right logical.
- For a signed int, the result is implementation-dependent!

Category	Instruction	Example	Meaning	Comments
	add	add \$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3	3 operands; data in reg
Arithmetic	add immediate	addi \$s1, \$s2, 17	\$s1 = \$s2 + 17	3 operands; data in reg
	subtract	sub \$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3	3 operands; data in reg
Data tuan afan	load word	lw \$s1, 0(\$s2)	\$s1 = Memory[\$s2]	Data fm memory to reg
Data transfer	store word	sw \$s3, 0(\$t5)	Memory[\$t5] = \$s3	Data fm reg to memory
	and	and \$t0, \$s1, \$s2	\$t0 = \$s1 & \$s2	bit-wise AND
	and immediate	andi \$t0,\$s1,0x00A	\$ \$t0 = \$s1 & 0x00A3	bit-wise AND immediate
	or	or \$t0, \$s1, \$s2	\$t0 = \$s1 \$s2	bit-wise OR
	or immediate	ori \$t0,\$s1,0x00A	\$ \$t0 = \$s1 0x00A3	bit-wise OR immediate
	nor	nor \$t0, \$s1, \$s2	\$t0 = \$s1 NOR \$s2	bit-wise NOR
Logical	xor	xor \$t0, \$s1, \$s2	\$t0 = \$s1 ^ \$s2	bit-wise XOR
	xor immediate	xori \$t0,\$s1,0x00A	\$ \$t0 = \$s1 ^ 0x00A3	bit-wise XOR immediate
	shift left logical	sll \$t0, \$s1, 3	\$t0 = \$s1 << 3	shift \$s1 left 3 bits
	shift right logical	srl \$t0, \$s1, 3	\$t0 = \$s1 >>> 3	shift \$s1 right 3 bits, fill on left with 0's
	shift right arithmetic	sra \$t0, \$s1, 3	\$t0 = \$s1 >> 3	shift \$s1 right 3 bits, fill on left with sign bit

Category	Instruction		Example	Meaning	Comments
	branch on equal	beq	\$s1,\$s2,Label	if (\$s1 == \$s2) goto Label	Equal test and branch
Conditional branch	branch on not equal	bne	\$s1,\$s2,Label	if (\$s1 ≠ \$s2) goto Label	Not equal test & branch
	set on less than	slt	\$s1, \$s2, \$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than
Unconditional branch	jump	j	Label	goto Label	Branch to target address

81