

☆ PROJECT ASSEMBLY GALLERY VIDEO DOWNLOAD COMMUNITY BLOG FORUM NEWS

Rotational Wrist

Building of the rotational wrist part.




After printing you should have five parts.



Remove with pliers the support. Fix in the bracket the servo MG995. Use the Arduino to set it to 0 degree.





HELP ME EXPERIMENT



SEARCH

search here...

MEMBER ACTIVITIES



Dwayne Williams uploaded a new picture: opencv_fd_1.jpg
17 hours. 56 minutes ago



standing proud as a test bot for Grog. He is very

pleased to be a part of enhancing the Inmoov Nation.



Fred uploaded a new picture: Possible spring for...
1 day, 16 hours ago



Maybe a possible spring for tendons?



Use on shouldr 0

Like

0

g+1


Tweet

are actuator from your servo. Cut it and fix it to the small gear as shown. It led.




Grease the big gear before setting in "rotawrist2"





Drill and tight fit the gear to "rotawrist3" through "rotawrist2".



Use hot glue gun to position and fix "cableholderwrist1" to the top of the servo. This will help to



Jack Phillips posted an update 2 days, 11 hours ago

Head Connect to Torso. Using EZ Robot for programing interface for now. Printing arms and hands next. Not sure how to post video so here is the link.

https://www.youtube.com/wat ch?

v=czMIEDz9804&feature=c4overview&list=UUNwIfeOZcu4UbOx3bcqJHQ



Gael Langevin posted an update 2 days, 16 hours ago

To Fred and others:

https://groups.google.com/gro up/inmoov/attach/151d3d256 a4108f0/spring%20tensioner1.j pg?part=4&authuser=0

This is how I see a spring added to the retraction tendon. In this set up we avoid forcing on the servo either way of rotation and it also avoid losing tension in the tendons.



Fred uploaded a new picture: 69.jpg 3 days, 17 hours ago





Fred uploaded a new picture: 71.jpg 3 days, 17 hours ago



FOLLOW ME


gael langevin
1 circle
413 followers

RECENT POSTS


InMoov prosthetic hand almost ready InMoov in Moscow, Geek Picnic InMoov on the New Yorker Wow InMoov Santa! guide the rods into the center hole.



Close the whole thing and tight the 3 screws on perimeter. Make a test run with your Aduino. This is the position you should have when your servo is at 180° for the left hand



Now it's time to glue "rotawrist1" to "robpart2V2". Once glued detach "rotawrist1" from "rotawrist2". Start running the rods from your servos up to each finger. (Use the Arduino to set your servos at 0 Degrees) Don't twist the rods and make sure the upper rods run through the upper parts of the fingers, run the lower rods through the lower parts of the fingers.



This is where you are going to test your patience and skills. I use twisers for to do the job.

Share and Enjoy

Like { 0





Share

• Ctim

New wiring design for the hand

RECENT COMMENTS

Gael Langevin on Hand and Forarm

Tom on Hand and Forarm

InMoov » InMoov prosthetic hand almost ready on Default Hardware Map

Gael Langevin on Hand and Forarm

Tom on Hand and Forarm

ARCHIVES

March 2014

February 2014

January 2014

December 2013

November 2013

October 2013

September 2013

August 2013

July 2013

May 2013

April 2013

March 2013

February 2013

January 2013

December 2012

November 2012

October 2012

September 2012

August 2012

July 2012

June 2012

May 2012

CATEGORIES

Select Category

http://www.inmoov.fr/rotational-wrist/

Leave a comment

You must be logged in to post a comment.

Copyright © 2014 In Moov Proudly powered by WordPress. BACK TO TOP ↑