



Asset Inspection 1-Pager Overview

1




To begin, locate the **Asset Inspection** tab on the home screen and select it.

2




Select the **Inspect** button on the Asset Inspection page.

3



You will be directed to the **Inspection** page where all inspection items are listed and can be selected if any defects are found.





Select the type of inspection you will be conducting: **Pre-Trip, In-Trip or Post-Trip**.


In this scenario, **Pre-Trip** will be selected as an example.

Asset Inspection 1-Pager Overview

4




5



For **Inspection Location** scroll down the inspection list to locate the inspection location section.

This will automatically be selected by the system.


If required, select the **Edit** button to manually update the location.



If there is any additional information you would like to note that is not directly related to the inspection, use the **Remarks** section.

Once done, click on the **Green Tab** if no defects found.

6



When you submit the inspection, the system will ask you to **sign** the inspection.

Click on **Yes** to sign and submit.

The system will automatically return you to the home screen.

You may now proceed to your destination where you have to hook a trailer.