



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Cutlist for Door Sizes (Campbell IE002 Door)

Door Sizes				
Quan	Width	Height	Part	Room# Cab# (Quan)
(1)	34 9/16	30	{Door Size}	R1:8
(2)	17 27/32	49 3/8	{Door Size}	R1:12(2)
(4)	17 27/32	35 3/4	{Door Size}	R1:7(2),12(2)
(2)	17 27/32	17 3/4	{Door Size}	R1:10(2)
(1)	17 13/16	35 3/4	{Door Size}	R1:9
(2)	16 25/32	29 3/4	{Door Size}	R1:2(2)
(2)	16 5/8	30	{Door Size}	R1:N27,N28
(2)	16 3/8	29 7/8	{Door Size}	R1:N25,N26
(2)	14 27/32	49 3/8	{Door Size}	R1:6(2)
(2)	14 27/32	35 3/4	{Door Size}	R1:6(2)
(6)	14 27/32	29 3/4	{Door Size}	R1:18(2),19(2),20(2)
(1)	14 13/16	29 3/4	{Door Size}	R1:1
(27)	Doors	(Total)		
105.6	Sq.Ft.	(Total)		



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Cutlist for Door Sizes (Campbell IE002 Drawer)

Door Sizes				
Quan	Width	Height	Part	Room# Cab# (Quan)
(2)	35 13/16	11 3/4	{Drawer Front Size}	R1:3(2)
(1)	35 13/16	10 1/8	{Drawer Front Size}	R3:1
(1)	35 13/16	10	{Drawer Front Size}	R3:1
(1)	35 13/16	6	{Drawer Front Size}	R1:3
(1)	26 13/16	12 3/4	{Drawer Front Size}	R1:16
(2)	20 13/16	11 3/4	{Drawer Front Size}	R1:4(2)
(1)	20 13/16	6	{Drawer Front Size}	R1:4
(2)	17 13/16	12 3/4	{Drawer Front Size}	R1:15,17
(2)	17 13/16	10 3/4	{Drawer Front Size}	R1:15,17
(2)	17 13/16	6	{Drawer Front Size}	R1:15,17
(15)	Doors	(Total)		
26.3	Sq.Ft.	(Total)		



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Cutlist for Door Sizes (Shaker 90 - Drawer Front)

Door Sizes				
Quan	Width	Height	Part	Room# Cab# (Quan)
(2)	17 13/16	10 1/16	{Drawer Front Size}	R2:2(2)
(1)	14 13/16	39 1/2	{Drawer Front Size}	R2:4
(2)	14 13/16	6	{Drawer Front Size}	R2:4(2)
(5)	Doors	(Total)		
7.8	Sq.Ft.	(Total)		



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence

Cutlist for Door Sizes (Shaker 90 Door)

Door Sizes				
Quan	Width	Height	Part	Room# Cab# (Quan)
(4)	13 11/32	20 1/4	{Door Size}	R2:1(2),3(2)
(4)	Doors	(Total)		
7.5	Sq.Ft.	(Total)		



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Cutlist for Dwr Box/Tray Sizes (Tray-Blind Dado 6 Piece)

Dwr Box/Tray Sizes					
Quan	Width	Height	Depth	Part	Room# Cab# (Quan)
(4)	26 11/32	4	18	Tray	R1:6(4)
(2)	12 11/32	4	18	Tray	R1:1(2)
(6)	Boxes	(Total)			



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Cutlist for Dwr Box/Tray Sizes (Drawer-Blind Dado Box)

Dwr Box/Tray Sizes					
Quan	Width	Height	Depth	Part	Room# Cab# (Quan)
(1)	34 11/32	8	18	Drawer Box	R3:1
(1)	34 5/16	10	21	Drawer Box	R1:3
(1)	34 5/16	8	21	Drawer Box	R1:3
(1)	34 5/16	4	21	Drawer Box	R1:3
(1)	25 11/32	10	21	Drawer Box	R1:16
(1)	19 5/16	10	21	Drawer Box	R1:4
(1)	19 5/16	8	21	Drawer Box	R1:4
(1)	19 5/16	4	21	Drawer Box	R1:4
(1)	16 11/32	10	21	Drawer Box	R1:17
(1)	16 11/32	8	21	Drawer Box	R1:17
(1)	16 11/32	4	21	Drawer Box	R1:17
(1)	16 5/16	10	21	Drawer Box	R1:15
(1)	16 5/16	8	21	Drawer Box	R1:15
(1)	16 5/16	4	21	Drawer Box	R1:15
(2)	16 5/32	8	18	Drawer Box	R2:2(2)
(1)	13 3/32	12	12	Drawer Box	R2:4
(2)	13 3/32	4	12	Drawer Box	R2:4(2)
(19)	Boxes	(Total)			



Left Coast Cabinets

09/15/2026

Job: Modern Cabinetry - Spigener Residence
Hardware List

Hardware			
Quan	Part	Room# Cab# (Quan)	Other
30	Blum TANDEM 563H (USA) Spacers	R1C1(6), R1C6(24)	
465	Conformat	R1C1(24), R1C2(21), R1C3(20), R1C4(18), R1C6(35), R1C7(13), R1C8(6), R1C9(11), R1C10(22), R1C12(36), R1C14(24), R1C15(18), R1C16(33), R1C17(32), R1C18(15), R1C19(24), R1C20(15), R2C1(24), R2C2(22), R2C3(24), R2C4(4), R3C1(24)	
5	Drawer Front Adjuster	R2C2(2), R2C4(3)	
4	None	R2C1(2), R2C3(2)	
5	Recessed Pull	R2C2(2), R2C4(3)	
36	Wire Pull	R1C1(1), R1C2(2), R1C3(3), R1C4(3), R1C6(4), R1C7(2), R1C9(1), R1C10(2), R1C12(4), R1C15(3), R1C16(1), R1C17(3), R1C18(2), R1C19(2), R1C20(2), R3C1(1)	
56	Euro Frameless	R1C1(2), R1C2(4), R1C6(10), R1C7(4), R1C9(2), R1C10(4), R1C12(10), R1C18(4), R1C19(4), R1C20(4), R2C1(4), R2C3(4)	
6	Blum TANDEM 563H (USA) - TANDEM 563H3050B	R2C4(6)	
18	Blum TANDEM 563H (USA) - TANDEM 563H4570B	R1C1(4), R1C6(8), R2C2(4), R3C1(2)	
26	Blum TANDEM 563H (USA) - TANDEM 563H5330B	R1C3(6), R1C4(6), R1C15(6), R1C16(2), R1C17(6)	
52	Flat Metal Pin 5mm	R1C6(4), R1C7(8), R1C9(8), R1C10(4), R1C12(12), R1C14(4), R1C18(4), R1C19(4), R1C20(4)	