

CompTia A+ Assessment

Section A - Concept Application

Scenario 1:

Step 1: Start with the CPU — It Drives Every Other Decision

For an office workstation running productivity/office applications, you don't need high-end gaming performance — a mid-range CPU is sufficient. Choose between:

- **Intel** (e.g., Core i5, current generation) or **AMD** (e.g., Ryzen 5)

Why start here: The CPU determines the socket type, which immediately narrows down which motherboards are even physically compatible.

Step 2: Select a Compatible Motherboard

- **Match the socket type exactly** to the chosen CPU (e.g., Intel LGA 1700 or AMD AM5) — this is non-negotiable.
- **Choose the form factor** based on the office case/desk space — **Micro-ATX** is a sensible choice for office workstations, since it's compact and cost-effective while still offering enough expansion for basic needs.
- **Check chipset support** — confirm the specific chipset (e.g., Intel B760, AMD B650) officially supports your chosen CPU generation, since even matching sockets can sometimes require a BIOS update for newer CPUs on older chipsets.

Step 3: Select Compatible RAM

- **Match RAM generation** to what the motherboard supports (DDR4 or DDR5 — check the motherboard's specification sheet)
- **Check maximum supported speed (MHz)** — buying faster RAM than the board supports means it will simply run at the board's maximum, not the RAM's rated speed
- For office use, **16GB (2x8GB) in dual-channel** is typically sufficient — dual-channel (two matched sticks) improves performance over a single stick.

Step 4: Select Compatible Storage

- **SSD over HDD** is the clear choice for office workstations — as covered earlier, SSDs offer faster boot/load times and better reliability, both of which reduce downtime and improve day-to-day productivity.
- **Check available connectors on the motherboard:** M.2 NVMe slot (fastest) or SATA (more common, still very fast for office use).
- A **256GB–512GB SSD** is typically sufficient for an office workstation's OS and productivity software.

How to Confirm Everything Will Work Together

1. **Cross-check the CPU socket** against the motherboard's official specification sheet or manufacturer compatibility list.
2. **Check the motherboard's QVL (Qualified Vendor List)** — most manufacturers publish a list of specific RAM kits tested and confirmed compatible with that exact board.
3. **Use a compatibility tool** like PCPartPicker, which automatically flags mismatches (wrong socket, unsupported RAM type, etc.) when building a parts list.
4. **Confirm BIOS support** — if using a newer CPU on an older motherboard revision, check the manufacturer's CPU support list to see if a BIOS update is required before the system will even boot.
5. **Verify storage connector match** — confirm the motherboard has the specific M.2 slot or SATA ports you're planning to use.

Scenario 2:

	HDD	SSD	NVMe
Technology	Spinning magnetic disks with a mechanical read/write head	Flash memory chips, no moving parts	Flash memory chips, no moving parts
Interface	SATA	SATA	PCI
Speed	80-160 MB/s	500-550 MB/s	2000-7000+ MB/s
Latency	High	Low	Very low
Power Consumption	Higher	Lower	Lowest
Typical Use Case	Bulk storage, backups	General computing, office use	Gaming. Video editing

For a workforce mainly running office and productivity applications, a standard **SATA SSD** is the most suitable and cost-effective choice. Here's the technical reasoning:

Office workloads are not I/O-intensive — applications like Word, Excel, and Outlook don't demand the extreme sequential/random read-write throughput that NVMe provides; the performance difference between SATA SSD and NVMe would be largely unnoticeable in daily use for these tasks.

SATA SSD already solves the real bottleneck — the biggest performance jump for office use comes from **eliminating mechanical seek time** (HDD → SSD), which drastically improves boot times, application launches, and file access.

Cost efficiency at scale — when equipping many workstations for a business, the price premium of NVMe over SATA SSD isn't justified by workload demands; that budget is better spent on adequate RAM or a slightly better CPU.

Reliability matches the use case — SATA SSDs still offer strong durability (no moving parts) and are well-proven for years of everyday office use.

Scenario 3:

GPU: Handles the parallel processing needed for rendering viewports, previews, and hardware-accelerated effects in design software — tasks the CPU alone would handle far slower. For "mildly" intensive work, a mid-range dedicated GPU is enough; integrated graphics would likely struggle over a full workday.

Cooling system: Since the workload runs for several hours daily, sustained heat becomes the real risk. Without adequate cooling (case airflow, GPU/CPU coolers sized for the load), the system will hit thermal throttling — automatically slowing down to protect itself, causing lag and stutter right when consistent performance is needed. Poor cooling over time also increases wear and crash risk, which could mean lost work in unsaved files.

Scenario 4:

Why Hardware Compatibility Matters

When components come from **different vendors**, nothing guarantees they were designed with each other in mind — each manufacturer builds to open standards (like PCIe, DDR, ATX), but implementation details, supported

features, and firmware requirements can still vary. Compatibility matters because:

- **Physical fit** — components must literally connect (socket types, connector pin-outs, physical dimensions).
- **Electrical/signal compatibility** — components must operate within compatible voltage, power draw, and signaling standards.
- **Firmware/protocol support** — the motherboard's BIOS must recognize and properly initialize whatever CPU, RAM, or storage is installed.

Without confirming compatibility across vendors, you risk a system that **won't boot at all**, runs unstably, or **silently underperforms** without any obvious error.

Component Mismatch	Resulting Issues
CPU socket $\neq$ motherboard socket	CPU physically won't fit; build is impossible
CPU generation not supported by motherboard's current BIOS	System won't POST until a BIOS update is applied — sometimes requiring an older, compatible CPU just to perform the update
RAM type mismatch (DDR4 vs DDR5)	RAM physically won't fit the slot at all
RAM speed exceeds motherboard's supported limit	RAM runs at a lower speed than rated, or system fails to boot/is unstable
PSU connector type mismatch e.g., older PSU without PCIe power connectors for a modern GPU	GPU can't receive power; can't be used at a
Storage interface mismatch (e.g., M.2 slot key type, or no NVMe support)	Drive can't be installed or won't be detected

Scenario 5:

Choosing an Appropriately Rated PSU

Step 1: Calculate total power draw

Add up the estimated wattage of every major component:

- CPU (check manufacturer's TDP rating)
- GPU (check manufacturer's rated power draw)

- Motherboard, RAM, storage devices, fans (smaller but still additive draws)

Step 2: Add headroom (20–30%)

Don't select a PSU rated exactly at your calculated total — add a **20-30% buffer** above that number.

Step 3: Check efficiency rating

Look for an **80 PLUS certification** (Bronze, Gold, Platinum) — higher ratings mean less wasted energy as heat, and better stability under sustained load.

Step 4: Confirm connector availability

Verify the PSU includes the specific connectors your build needs:

- 24-pin ATX (motherboard)
- 4/8-pin CPU Connector
- PCIe 6/8-pin (GPU)
- SATA power (storage devices)

Safety and Connection Checks Before Powering On

1. **Ensure the PSU is unplugged during all connections** - Keep the PSU unplugged from the wall throughout every connection step, to eliminate any risk of shock or short-circuiting while connecting cables.
2. **Check the motherboard's main power connector** - Verify the 24-pin ATX connector is fully inserted into the motherboard with the retention clip audibly clicked into place — a loose connection here is a common cause of failure to boot.
3. **Check the CPU power connector** - Confirm the 4-pin or 8-pin EPS connector near the CPU socket is firmly seated. This delivers dedicated power to the processor and is easy to overlook since it's separate from the main 24-pin connector.
4. **Check GPU power connectors** - Verify all required PCIe power cables are plugged directly into the GPU, matching exactly what the card requires (6-pin, 8-pin, or both). An underpowered GPU connection can cause instability or prevent the system from posting.
5. **Check storage power connections** - Confirm SATA power connectors are firmly and correctly seated (keyed, so they only fit one way) into each storage drive.

6. **Check for loose hardware or stray metal** - Visually inspect the case interior for loose screws, stray wires, or any metal that could accidentally touch the motherboard and cause a short circuit.
7. **Verify the PSU voltage switch (if present)** - If the PSU has a manual voltage selector switch, confirm it matches your region's mains voltage — an incorrect setting can cause serious damage when powered on.
8. **Power on and observe first boot** - Only after all the above checks are complete, plug the PSU into the wall outlet, switch the PSU's rear power switch to 'On', and then press the case power button to boot for the first time.

Scenario 6:

Confirming the System Passes POST Successfully

1. Listen and watch for boot indicators

- Listen for a **single confirmation beep** (standard AMI/Award BIOS success pattern) — any other beep pattern (like the 3-beep RAM failure code) indicates a specific hardware fault.
- Watch for the motherboard's **diagnostic LEDs** (if present) to show no active error state — many modern boards have dedicated CPU/RAM/GPU/Boot LEDs that light up sequentially and then turn off once each stage passes.

2. Confirm visual output

- Verify the monitor displays the manufacturer's splash screen or BIOS/UEFI boot logo — confirms the GPU (or integrated graphics) initialized correctly and is communicating properly.

3. Enter BIOS/UEFI setup and verify hardware detection

- Confirm the **CPU** is correctly identified (model, correct clock speed).
- Confirm **RAM capacity** matches what was physically installed (e.g., 16GB shows as 16GB, not less).
- Confirm all **storage devices** appear in the storage/boot device list with correct capacities.

4. Confirm successful boot into the OS

- Let the system proceed past POST into the installed operating system, confirming a full, stable boot — not just POST success in isolation.

5. Basic functional checks


- Confirm peripherals (keyboard, mouse) respond.
- Confirm network connectivity (Ethernet/Wi-Fi) is detected.
- Run a brief stability check under light load to confirm no immediate crashes or thermal issues.

If POST Does Not Pass:

1. **Identify the failure point via beep code or LED** - Listen carefully to the beep pattern or read the motherboard's diagnostic LED/error code. Cross-reference it against the motherboard manufacturer's beep code chart to identify which specific component is flagged (CPU, RAM, GPU, or storage).
2. **Reseat RAM and GPU** - Power off, unplug the PSU, and reseat the RAM modules and GPU firmly in their slots — the most common cause of POST failure is a component that isn't fully seated, not an actual hardware defect.
3. **Verify all power connections** - Confirm the 24-pin ATX and CPU power connectors are fully clipped in, and that GPU PCIe power cables are properly connected — as covered in the PSU connection checks.
4. **Test with a minimal configuration** - If reseating doesn't resolve it, disconnect all non-essential components (GPU, extra RAM sticks, extra storage) and attempt to boot with just the CPU and a single RAM stick installed, to isolate which specific component is causing the failure.
5. **Swap suspected faulty components if spares are available** - Swap in a known-working spare component (RAM stick, GPU) if available, to confirm whether the original part is actually defective or if the issue lies elsewhere (motherboard, PSU).
6. **Escalate to PSU/motherboard testing if issue persists** - If POST still fails after isolating and testing individual components, the issue likely points to a defective motherboard or PSU — at this point, further diagnosis with a multimeter or replacement of the suspected part is the next step before handover.

Section B - Practical Coding Tasks

Task 1



Cooling FAN



Storage Devices (SATA SSD)

Make/Model of each component:

1. Motherboard - Gigabyte GA-H61M-DS2
2. CPU - Intel, Socket LGA 1155
3. RAM - One DDR3 DIMM installed (single-channel)
4. GPU - Dedicated Card Slot
5. Storage - WD Green SATA SSD, 120GB
6. Cooling System - Intel stock cooler


Functions:

1. **Motherboard** - The main circuit board connecting and enabling communication between every other component — CPU, RAM, storage, GPU, and peripherals.
2. **CPU** - Executes instructions and performs calculations; acts as the primary processing unit ("brain") of the system.
3. **RAM** - Provides temporary, high-speed memory for data and programs actively in use - cleared when the system powers off.
4. **GPU** - Handles graphics rendering and parallel processing tasks - critical for display output and any graphics-intensive workloads.
5. **Storage device** - Provides long-term, non-volatile storage for the operating system, applications, and files.
6. **Cooling System** - Dissipates heat generated by the CPU/GPU during operation, preventing thermal throttling and maintaining stable performance.

Task 2


CPU Socket type - **LGA 1155**

CPU compatible with LGA 1155 Socket are: **2nd and 3rd Gen Core i3/i5/i7, Pentium, and Celeron CPUs.**




1. 24-Pin ATX Power Connector
2. RAM Slot
3. CPU Socket
4. 4-Pin CPU Connector
5. PCIe x16 Slot (GPU slot)
6. PCIe x1 Slot (Expansion cards)
7. SATA Ports
8. CPU Fan Connector
9. Rear I/O Ports
10. Front Panel header

Task 3



RAM Module



SATA SSD

Both components detected correctly after reinstallation.

Task 4

Full Desktop PC Assembly

Step 1 - Prepare the Cabinet and Components

Placed the cabinet on a stable surface and organized all removed components and screws before starting reassembly. This helps avoid missing parts and improves efficiency.

Step 2 - Install the Power Supply Unit (PSU)

Inserted the PSU into its mounting position and secured it with screws at the rear of the cabinet.

Step 3 - Install the Motherboard

Carefully aligned the motherboard with the cabinet standoffs and I/O shield, then secured it using motherboard screws.

Step 4 - Connect Motherboard Power Cables

Connected:

- 24-pin ATX power connector
 - CPU power connector
- from the PSU to the motherboard.




Step 5 - Install the CPU Fans

Mounted the CPU cooler and connected the fan cable to the CPU FAN header on the motherboard.



Step 6 - Install the RAM

Aligned the RAM stick with the RAM slots and pressed them in until the side clips locked.



Step 7 - Install HDD / SSD Storage Drives

Mounted the HDD/SSD into the drive bay and connected:

- SATA data cable to motherboard
- SATA power cable from PSU



Step 8 - Install the GPU

Inserted the graphics card into the PCIe x16 slot and secured it with screws.



Step 9 - Connect Front Panel and Internal Cables

Connected:

- power switch
- reset switch
- front USB headers
- front audio headers

Step 11 - Close the Side Panel

Reattached the side panel and tightened the screws securely.

Step 12 - Connect External Devices

Connected:

- monitor
- keyboard
- mouse
- power cable
- Ethernet cable

Step 13 - Power On and Test the System

Turned on the PC and verified:

- fans spinning,
- display output,
- BIOS/OS boot,
- proper hardware detection.

This confirms successful reassembly of the desktop PC.



Section C - Mini Capstone Project

Workstation Deployment & Boot-Failure Diagnosis Report

1. Three Components to Check First When a PC Fails to Boot

RAM - The single most common cause of a no-boot/no-POST condition. A stick that isn't fully seated prevents the system from completing memory initialization, and BIOS will halt before display output even initializes.

Power connections (24-pin ATX + CPU 4-pin) - The 24-pin ATX connector sits along the bottom edge and the 4-pin sits near the CPU socket. A loose or partially-seated connector here is indistinguishable from a "dead" system at first glance, but is the easiest and cheapest fix.

GPU seating — A GPU that isn't fully seated in its PCIe x16 slot can cause symptoms ranging from no display output at all to intermittent crashes, even though the system otherwise powers on normally. Reseating the GPU firmly, confirming the retention clip is engaged, and verifying the PCIe power connectors (6/8-pin) are properly attached is a quick, high-value check before moving on to more invasive troubleshooting.

2. Motherboard-CPU Compatibility

The inspected Gigabyte GA-H61M-DS2 uses an LGA 1155 socket paired with the Intel H61 chipset. This directly constrains what CPU can be installed and how it functions:

- Only **2nd/3rd Gen Intel Core (i3/i5/i7), Pentium, or Celeron** CPUs are physically and electrically compatible - a CPU using any other socket (e.g., LGA 1200, AM4) simply cannot be installed.
- The **H61 chipset specifically lacks overclocking support**, meaning even an unlocked "K"-series CPU would run at stock speeds only - a compatibility limitation at the chipset level, not just the socket.
- If a 3rd Gen CPU were installed on a motherboard still running an outdated factory BIOS built only for 2nd Gen support, the system would **fail to POST entirely** until a BIOS update is applied — this is a realistic cause of "hardware detection error" symptoms matching ABC Solutions reported issue, since the system may power on (fans, LEDs active) but never complete POST or display output.

3. Verifying RAM and Storage Installation

RAM verification:

- Physically confirm both retention clips are fully engaged with no visible gap on either side of the module.
- On this board's single populated DIMM slot, boot into BIOS and check that the **detected memory capacity matches the physical module's rated capacity** (e.g., an 8GB stick should show as 8192MB, not a partial/incorrect value).
- A capacity mismatch or the RAM not appearing at all in BIOS confirms either a seating issue or a genuinely faulty module.

Storage verification:

- Confirm the SATA data cable and SATA power cable are both firmly connected to the drive.
- In BIOS's storage/boot configuration menu, confirm the drive appears with the correct model name and capacity(should read "WD Green SSD, 120GB") - if absent, this points to a cable/connection fault rather than a drive failure, since SATA SSDs rarely fail silently at first boot.

What POST should confirm overall: A successful POST sequence should show correct CPU identification, the full installed RAM capacity, and the storage device listed in the boot order — all before the system proceeds to OS boot. Any of these being absent or incorrect identifies exactly which component needs reseating or replacement.

4. Hardware-Installation Checklist (Prevent Future Failures)

1. **Verify CPU socket and chipset compatibility** against the motherboard's official CPU support list before installation - including checking whether a BIOS update is needed for newer CPU generations.
2. **Confirm every power connector is fully seated and clipped** (24-pin ATX, CPU 4/8-pin, SATA power) - visually and physically check each one, not just visually.
3. **Reseat RAM with visible confirmation of both retention clips locked**, and verify detected capacity in BIOS before finalizing the build.

4. **Test boot with a minimal configuration first** (CPU + single RAM stick, no unnecessary peripherals) before adding all components, to catch failures early and in isolation.
5. **Document each system's BIOS POST screen** (CPU, RAM, storage detected) as a baseline reference before handover, so future troubleshooting has a known-good state to compare against.

5. SSD vs. HDD

For a **computer lab environment** - where systems are used by multiple students/staff throughout the day, powered on and off frequently, and need to boot quickly between class sessions - an **SSD is clearly the better choice** over an HDD, for specific technical reasons:

- **Faster boot and application load times** - directly reduces downtime between lab sessions, which matters when class periods are time-constrained.
- **No moving parts** - SSDs are significantly more resistant to physical shock and vibration, an important factor in a shared lab environment where systems may be bumped, moved, or handled by many different users.
- **Lower failure rate under frequent power cycling** - lab PCs are powered on/off far more often than a typical single-user workstation; HDDs mechanical spin-up/spin-down cycles accumulate wear faster under this usage pattern than flash-based SSDs.
- **Confirmed in the inspected system** - the WD Green SSD installed in this workstation exemplifies this choice already being applied correctly, supporting fast, reliable boot performance suited to the lab's repeated-use context.

Section D - AI-Augmented Learning

The exact prompt I gave to the AI tool :

I am a junior technician and I have been given a task to diagnose a desktop PC that fails to boot immediately after assembly. Provide me with a simple step by step guide to help resolve the issue. Also maintain the correct priority order to check each components of the PC.

AI's original checklist

1. **Apply ESD precautions first** - Before touching anything, put on an anti-static wrist strap or regularly touch a grounded metal surface. This protects sensitive components from static discharge during the entire troubleshooting process.
2. **Check the power source** - Confirm the wall outlet has power, the PSU's rear switch is set to 'On', and the PSU voltage selector (if present) matches your region's mains voltage.
3. **Verify main power connectors Power off and unplug the PSU** - Verify the 24-pin ATX connector and the CPU 4/8-pin connector are both fully seated and clipped into the motherboard — this is the single most common cause of a fresh build failing to boot.
4. **Check RAM seating** - Reseat each RAM module firmly, ensuring both retention clips click into place with no visible gap. If multiple sticks are installed, test with a single stick first to rule out a faulty or poorly seated module. **This is the step most likely to have caught the reported issue at ABC Solutions.**
5. **Check GPU seating and power** - If a dedicated GPU is installed, confirm it's fully seated in the PCIe x16 slot with the retention clip engaged, and that its PCIe power connector are plugged in.
6. **Check storage connections** - Confirm SATA/NVMe storage devices have both data and power cables properly connected. A missing storage connection usually still allows POST, but won't let the system boot into an OS.
7. **Read POST beep codes or diagnostic LEDs** - Listen for beep codes or check the motherboard's diagnostic LED/display. Cross-reference the code against the motherboard manufacturer's manual to identify exactly which component is flagged.
8. **Test with a minimal configuration** - If the system still fails, disconnect all non-essential components (GPU, extra RAM sticks, extra storage) and attempt to boot with just the CPU and a single

RAM stick. This isolates whether the fault lies with a specific component or the motherboard/PSU itself.

My Corrected Version

1. Apply ESD precautions first
2. Check power source
3. Verify main power connectors
4. **Listen for POST beep codes or check diagnostic LEDs (moved up) — do this immediately after confirming power, before physically reseating anything.**
5. Check RAM seating (prioritized based on beep code, if one was heard)
6. Check GPU seating and power
7. Check storage connections
8. Test with a minimal configuration

The AI's original checklist placed POST beep codes at step 7 - after the technician had already manually reseated RAM, the GPU, and storage. This is inefficient and out of order: beep codes (or diagnostic LEDs) cost nothing to check and can immediately point to the specific failing component, making the earlier manual reseating steps unnecessary busywork if the beep code already identifies, say, a RAM fault. I moved this step to immediately after confirming power, so the technician diagnoses before physically intervening — a more logical, time-efficient order for an on-site technician.