MorseMicro first install checklist

Steps to take on your computer	Steps to take on your radio
 Download the AREDN® sysupgrade.bin file for your MorseMicro device from arednmesh.org Cable your computer's Ethernet port to the router's LAN port and power on the router Verify that your computer received an IP address from the device's DHCP service Open a web browser and navigate to the device's web interface 	
	 Login and navigate to System → Backup/Flash Firmware and go to Flash new firmware image Uncheck the Keep Settings checkbox Click Choose File to select the AREDN® sysupgrade.bin file you downloaded Click Flash image to upload the new image, then verify the file checksum and click Proceed After the firmware image is loaded, the device will reboot to the AREDN® firmware (this process takes several minutes)
 □ Verify that your computer is assigned a new IP address automatically using DHCP. You may need to disconnect & reconnect the Ethernet interface to ensure the new IP address assignment. Verify that your computer can ping the radio at 192.168.1.1. □ Open a web browser and enter either http://192.168.1.1 or http://localnode.local.mesh to configure your new node 	