

SEHH2238: Computer Networking

Main Topics

Ch 3. Physical Layer

- **∞** 3.2 Periodic Analogue Signals
- **№ 3.3 Digital Signals**
- **尽 3.4 Transmission Impairment**
- **≈ 3.6 Performance**

Ch 4. Digital Transmission

SEHH2238 Lecture 2

SEHH2238: Computer Networking

Physical layer





Figure 3.1: Communication at the physical layer

SEHH2238: Computer Networking

3.1 Data and Signal

Transformation of Information to Signals


 To be transmitted, data must be transformed to electromagnetic signals



WCB/McGraw-Hill SEHH2238 Lecture 2

Analog and Digital

- Analog signals can have any value in a range (continuous values)
- Digital signals can have only a limited number of values (discrete values)



SEHH2238 Lecture 2


3.2 Periodic Analogue Signals

SEHH2238: Computer Networking

Periodic Analog Signals

The sine wave is the most fundamental form of a periodic signal

 A periodic signal can be decomposed into a set of sine waves




- Characteristics of a sine wave:
 - Amplitude − the instantaneous height
 - □ Frequency the no. of cycles per second (Hz)
 - ♦ Frequency and period are the inverse of each other $f = \frac{1}{T}$ and $T = \frac{1}{f}$
 - Phase the shift of the wave along the time axis (relative to time zero) measured in degrees or radians

SEHH2238: Computer Networking

WCB/McGraw-Hill


SEHH2238: Computer Networking

Different Amplitudes




a. A signal with high peak amplitude

WCB/McGraw-Hill




Different Frequencies

© The McGraw-Hill Companies, Inc.,




a. A signal with a frequency of 12 Hz



b. A signal with a frequency of 6 Hz

SEHH2238: Computer Networking

Different Phases



SEHH2238: Computer Networking

Time and Frequency Domains

- A time-domain graph plots amplitude as a function of time
- A frequency-domain graph plots each sine wave's peak amplitude against its frequency


SEHH2238 Lecture 2

10

SEHH2238: Computer Networking

WCB/McGraw-Hill

Time and Frequency Domain




SEHH2238: Computer Networking **Examples** Time Frequency domain domain a. Frequency Time 1 second Frequency Time 1 second 16 Frequency SEHH2238 Lecture 2 12 WCB/McGraw-Hill

SEHH2238 Lecture 2 11


Composite Signals

- * Periodic signal can be decomposed into a set of sine waves (called **components**)
 - call each has its own amplitude, frequency, and phase




SEHH2238: Computer Networking

Decomposition of the signal



a. Time-domain decomposition of a composite signal




b. Frequency-domain decomposition of the composite signal


SEHH2238 Lecture 2

SEHH2238: Computer Networking

Bandwidth of a Signal

The bandwidth of a composite signal is the difference between the highest and the lowest frequencies contained in that signal.






13

15


SEHH2238: Computer Networking

Bandwidth of periodic and aperiodic signals

Periodic Signal contains discrete frequencies



Aperiodic Signal with continuous frequencies



SEHH2238 Lecture 2

SEHH2238 Lecture 2

Example

If a periodic signal is decomposed into five sine waves with frequencies of 100, 300, 500, 700, and 900 Hz, what is its bandwidth? Draw the spectrum, assuming all components have a maximum amplitude of 10 V.

Solution

Let f_h be the highest frequency, f_l the lowest frequency, and B the bandwidth. Then

 $B = f_h - f_l = 900 - 100 = 800 \text{ Hz}$ Amplitude

The spectrum has only five spikes, at 100, 300, 500, 700, and 900 Hz | 000 = 800 Hz | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 | 000 |


3.3 Digital Signals

- In addition to being represented by an analog signal, information can also be represented by a digital signal
- For example, a 1 can be encoded as a positive voltage and a 0 as zero voltage. A digital signal can have more than two levels. In this case, we can send more than 1 bit for each level.


SEHH2238 Lecture 2

40

SEHH2238: Computer Networking



Digital signal can have more than two levels, in this case, more bits can be sent in each level.



b. A digital signal with four levels

SEHH2238: Computer Networking

SEHH2238: Computer Networking

Example

A digital signal has eight levels. How many bits are needed per level?

Solution

We calculate the number of bits from the formula


Number of bits per level = $log_2 8 = 3$

Each signal level is represented by 3 bits.

3.4 TRANSMISSION IMPAIRMENT

- Signals travel through transmission media, which are not perfect. The imperfection causes signal impairment.
- **❖** The signal at the beginning of the medium is not the same as the signal at the end of the medium.
 - **™** What is sent is not what is received.
- ***** Three causes of impairment are
 - **Attenuation**
 - **Distortion**
 - **Noise**

SEHH2238 Lecture 2



* Attenuation means a loss of energy.

* Measured by **decibel** (**dB**) =
$$10 \log_{10} \frac{P_2}{P_1}$$

SEHH2238 Lecture 2 22

SEHH2238: Computer Networking

Example

Suppose a signal travels through a transmission medium and its power is reduced to one-half. This means that P_2 is $(1/2)P_1$. In this case, the attenuation (loss of power) can be calculated as

$$10 \log_{10} \frac{P_2}{P_1} = 10 \log_{10} \frac{0.5P_1}{P_1} = 10 \log_{10} 0.5 = 10(-0.3) = -3 \text{ dB}$$


A loss of 3 dB (-3 dB) is equivalent to losing one-half the power.

SEHH2238: Computer Networking

Reason for using dB

Decibel numbers can be added (or subtracted) when we are measuring several points (cascading) instead of just two.


Example: A signal travels from point 1 to point 4. In this case, the decibel value can be calculated as




SEHH2238 Lecture 2 23 SEHH2238 Lecture 2 24

Distortion

- Distortion means that the signal changes its form or shape.
- Main cause: Difference in delay of different frequency components.






SEHH2238 Lecture 2

25

27




 Noise includes thermal noise, induced noise, crosstalk, and impulse noise, etc.


Measured by Signal-to-noise ratio (SNR):

26

SEHH2238: Computer Networking

Two cases of SNR: a high SNR and a low SNR





SEHH2238 Lecture 2

SEHH2238: Computer Networking

The power of a signal is 10 mW and the power of the noise is 1 μ W. What are the values of SNR and SNR_{dR}?

Solution

Example

The values of SNR and SNR_{dB} can be calculated as follows:

$$SNR = \frac{10,000 \ \mu\text{W}}{1 \ \mu\text{W}} = 10,000$$
$$SNR_{dB} = 10 \log_{10} 10,000 = 10 \log_{10} 10^4 = 40$$

SEHH2238 Lecture 2 28

3.5 DATA RATE LIMITS

A very important consideration in data communications is how fast we can send data, in bits per second, over a channel.

Data rate depends on three factors:

- 1. The bandwidth available
- 2. The level of the signals we use
- 3. The quality of the channel (the level of noise)

SEHH2238 Lecture 2

29

SEHH2238: Computer Networking

Noiseless Channel: Nyquist Bit Rate

For a noiseless Channel, the Nyquist bit rate formula defines the theoretical maximum bit rate:

BitRate = $2 \times \text{bandwidth} \times \log_2 L$



Increasing the levels of a signal may reduce the reliability of the system.

· Receiver becomes difficult to distinguish different levels

SEHH2238 Lecture 2

SEHH2238: Computer Networking

Examples on Nyquist Bit Rate

Consider a noiseless channel with a bandwidth of 3000 Hz transmitting a signal with two signal levels. The maximum bit rate can be calculated as

BitRate =
$$2 \times 3000 \times \log_2 2 = 6000$$
 bps

Consider the same noiseless channel transmitting a signal with four signal levels (for each level, we send 2 bits). The maximum bit rate can be calculated as

BitRate = $2 \times 3000 \times \log_2 4 = 12,000$ bps

SEHH2238: Computer Networking

Noisy Channel: Shannon Capacity

- In reality, we cannot have a noiseless channel; the channel is always noisy. In 1944, Claude Shannon introduced a formula, called the Shannon capacity.
- The theoretical maximum data rate of a noisy channel is related to SNR

 $C = B \log_2 (1 + SNR) bps$

- B − bandwidth of the channel (in Hz)
- Actual data rate usually is smaller
- Regardless to number of signal levels

SEHH2238 Lecture 2 31 SEHH2238 Lecture 2 32

Example on Shannon Capacity

We can calculate the theoretical highest bit rate of a regular telephone line. A telephone line normally has a bandwidth of 3000. The signal-to-noise ratio is usually 3162. For this channel the capacity is calculated as

$$C = B \log_2 (1 + \text{SNR}) = 3000 \log_2 (1 + 3162) = 3000 \log_2 3163$$

= 3000 × 11.62 = 34,860 bps

This means that the highest bit rate for a telephone line is 34.860 kbps. If we want to send data faster than this, we can either increase the bandwidth of the line or improve the signal-to-noise ratio.

SEHH2238 Lecture 2

33

SEHH2238: Computer Networking

Throughput Example

A network with bandwidth of 10 Mbps can pass only an average of 12,000 frames per minute with each frame carrying an average of 10,000 bits. What is the throughput of this network?

Solution

We can calculate the throughput as

Throughput = $(12,000 \times 10,000) / 60 = 2$ Mbps

The throughput is almost one-fifth of the bandwidth in this case.

SEHualan: Computer Networking

3.6. Performance Throughput

- The *throughput* is a measure of how fast we can actually send data through a network.
- Although, at first glance, bandwidth in bits per second and throughput seem the same, they are different.
- A link may have a bandwidth of B bps, but we can only send T bps, but

T always less than B.

1.34

SEHH2238: Computer Networking

Latency or Delay

- The latency or delay defines how long it takes for an entire message to completely arrive at the destination from the time the first bit is sent out from the source.
- We can say that latency is made of four components:
 - propagation time,
 - transmission time,
 - queuing time, and
 - processing delay.

Latency = propagation time + transmission time + queuing time + processing delay

Propagation Time and Transmission Time

- Propagation Time
 - Measures the time required for a bit to travel from the source to the destination. The propagation time is calculated by dividing distance by the propagation speed.

Propagation Time = Distance / (Propagation Speed)

- We will use Tp as the short form for Propagation Time.
- Transmission Time
 - Measures the time between the first bit and the last bit leaving the sender. The Transmission time depends on the size of the message and the bandwidth of the channel.

Transmission Time = (Message Size) / Bandwidth

We will use Tx as the short form for Transmission Time.

SEHH2238 Lecture 2

37

Example 3.45

Propagation time Example

What is the propagation time if the distance between the two points is 12,000 km? Assume the propagation speed to be 2.4×10^8 m/s in cable.

Solution

We can calculate the propagation time as

Propagation time =
$$(12,000 \times 1,000) / (2.4 \times 10^8) = 50 \text{ ms}$$

The example shows that a bit can go over the Atlantic Ocean in only 50 ms if there is a direct cable between the source and the destination.

38

Example 3.46

What are the propagation time and the transmission time for a 2.5-KB (kilobyte) message if the bandwidth of the network is 1 Gbps? Assume that the distance between the sender and the receiver is 12,000 km and that light travels at 2.4×10^8 m/s.

Solution

We can calculate the propagation and transmission time as

Propagation time =
$$(12,000 \times 1000) / (2.4 \times 10^8) = 50$$
 ms
Transmission time = $(2500 \times 8) / 10^9 = 0.020$ ms

Note that in this case, because the message is short and the bandwidth is high, the dominant factor is the propagation time, not the transmission time.

Example 3.47

Assume that the distance between the sender and the receiver is 12,000 km and that light travels at $2.4 \times 10^8 \text{ m/s}$. What are the propagation time and the transmission time for a 5-MB (megabyte) message (an image) if the bandwidth of the network is 1 Mbps?

Solution

We can calculate the propagation and transmission times as

Propagation time =
$$(12,000 \times 1000) / (2.4 \times 10^8) = 50$$
 ms
Transmission time = $(5,000,000 \times 8) / 10^6 = 40$ s

The dominant factor is transmission time now.


4. Analog-to-digital Conversion

- Nowadays systems process digital data
- However, we may receive analog signal Microphone, Camera, etc.
- ❖ Convert analog signal to digital data
 □ Pulse Code Modulation (PCM)

SEHH2238 Lecture 2

SEHH2238: Computer Networking

Components of PCM encoder




SEHH2238 Lecture 2 42

SEHH2238: Computer Networking

Sampling - Pulse Amplitude Modulation (PAM)

- ❖ Analog signal is sampled every T_s
 - α T_s is the sample interval
 - $R_s = 1/T_s$ is the sampling rate (or sampling frequency)



SEHH2238: Computer Networking




Note: How many samples are sufficient?

According to the Nyquist theorem, the sampling rate must be at least 2 times the highest frequency contained in the signal

Nyquist rate =
$$2 \times f_{max}$$

(to ensure the accurate reproduction of the original signal)


Undersampling will reproduce another signal with lower frequency



SEHH2238: Computer Networking

Quantization

- Assign quantized values to quantization levels
- Approximate the sample amplitude to the quantized values




SEHH2238: Computer Networking

Represent the quantized samples by bits

How many bits are required per sample?

 $\alpha n_b = \log_2 L$ (L is the number of quantization levels)



SEHH2238 Lecture 2

48

SEHH2238: Computer Networking


Quantization Error

- Quantization is an approximation process.
- The value of the difference of the actual value and the quantized value is the quantization error.
- This error is regarded as a noise.
- * The signal-to-noise (in dB) ratio depends on the number of bits per sample (n_b) , which is calculated in the following formula:

$$SNR_{dB} = 6.02n_b + 1.76 dB$$

SEHH2238: Computer Networking

Quantization and encoding of a sampled signal



SEHH2238 Lecture 2 47 SEHH2238 Lecture 2

Example

What is the quantization error (SNR_{dB}) in the previous slide?

Solution

We can use the formula to find the quantization. We have eight levels and 3 bits per sample, so

$$SNR_{dB} = 6.02(3) + 1.76 = 19.82 \ dB$$

Increasing the number of levels increases the SNR.

SEHH2238 Lecture 2 49

SEHH2238: Computer Networking

Example

We want to digitize the human voice. Assuming 8 bits per sample, what is the bit rate?

Solution

The human voice normally contains frequencies from 0 to 4000 Hz.

Sampling rate = $2 \times 4000 = 8000$ samples/s

Bit rate = sampling rate x number of bits per sample = $8000 \times 8 = 64,000 \text{ bps} = 64 \text{ Kbps}$

SEHH2238 Lecture 2 50

SEHH2238: Computer Networking

Summary

- Analog Signal and Digital Signal

 - □ Time domain and frequency domain
- Transmission Impairment
 - Attenuation, Distortion, Noise
- Data rate limit
 - Nyquist bit rate (for noiseless channel)
 - **⊗** Shannon capacity (for noisy channel)
- Analog-to-digital Conversion (PCM)
 - **⋈** Sampling, quantization
- Revision Quiz
 - http://highered.mheducation.com/sites/0073376221/student_view0/chapte r3/quizzes.html

SEHH2238 Lecture 2