

CONNECTIVITY STATE / REACHABILITY

Connectivity state tells HouseMaster what is known about the path; it does not by itself establish physical or engineering condition.

PROPOSED HOUSEMASTER INTEGRATION STATES ≠ BEELINE INTERNAL NETWORK STATES

ZONE B • HOUSEMASTER CONNECTIVITY-STATE VOCABULARY • 7 SEMANTIC PEERS • NO ORDER / NO TRANSITIONS / NO SEVERITY SCALE

UNKNOWN No connectivity information has ever been received for this device/profile.	PROVISIONED A connectivity profile is conceptually associated with a device; reachability not yet confirmed.	REACHABLE Connectivity path currently confirmed responsive.	UNREACHABLE Connectivity path currently not responding; cause not yet classified.	DEGRADED Connectivity path responsive but reduced quality, such as delayed delivery, without being fully unreachable.	SUSPENDED Connectivity intentionally paused by administrative action. NOT A FAULT.	DECOMMISSIONED Device/connectivity profile retired and no longer expected to report.
---	--	---	---	---	--	--

ZONE C • REACHABILITY / KNOWLEDGE MATRIX • TRANSPORT EVIDENCE ≠ ENGINEERING-CONDITION DETERMINATION

CONDITION	OBSERVATION STATE	HOUSEMASTER MAY KNOW	HOUSEMASTER MUST NOT INFER
01 NO ENGINEERING OBSERVATION RECEIVED	No new data since last known state	No update has arrived	Underlying engineering condition is unchanged, healthy or failed
02 DEVICE UNREACHABLE	Connectivity path not responding	Connectivity path is down	Physical device or engineering component has failed
03 DEVICE REACHABLE BUT NO ENGINEERING EVENT	Connectivity confirmed responsive, but no telemetry/event content	Transport path itself is functioning	Absence of an event necessarily means normal. Event-driven: silence may be expected. Continuous/periodic: silence may indicate an unclassified device/interface issue.
04 DEVICE REACHABLE AND OBSERVATION DELIVERED	Connectivity and content both confirmed	Reported value/event is available for domain interpretation	Delivered value is automatically a verified engineering fact. Preserve: Observation → Symptom → Defect gating.

ZONE D • RESPONSIBILITY BOUNDARY

HOUSEMASTER — integration-state vocabulary; permitted-knowledge semantics; domain interpretation; evidence gating.
BEELINE — connectivity / transport domain.

HOUSEMASTER CONNECTIVITY STATES ≠ BEELINE INTERNAL NETWORK STATES
No Beeline state mapping is inferred.

ZONE E • OPEN / TBD — 4

EC03-05-TBD-01 Joint validation of seven-state HouseMaster vocabulary
EC03-05-TBD-02 Heartbeat interval = NOT DEFINED
EC03-05-TBD-03 Timeout value = NOT DEFINED
EC03-05-TBD-04 Polling frequency = NOT DEFINED
No value is inferred or supplied.

ZONE F • GUARDRAILS — 6

HOUSEMASTER CONNECTIVITY STATES ≠ BEELINE INTERNAL NETWORK STATES	NO UPDATE ≠ UNCHANGED / HEALTHY / FAILED ENGINEERING CONDITION	UNREACHABLE CONNECTIVITY PATH ≠ FAILED PHYSICAL DEVICE OR ENGINEERING COMPONENT
REACHABLE WITH NO EVENT ≠ NECESSARILY NORMAL	DELIVERED OBSERVATION ≠ VERIFIED ENGINEERING FACT	NO HEARTBEAT INTERVAL / TIMEOUT / POLLING FREQUENCY IS DEFINED

PROVENANCE ANCHOR ONLY • SEM-MCD-001 — Semey, Shakarima 13A • No installed-device, SIM, gateway, availability, heartbeat-behavior, or site-condition inference