Mechatronics 3DX4

Slides 5: Time Response

Dr. O. Onaizah

Department of Computing and Software McMaster University

Material based on lecture notes by P. Taylor and M. Lawford, and Control Systems Engineering by N. Nise.

©2006-2012 R.J. Leduc

Introduction

- Once we have obtained a mathematical representation of a system, our next step is to analyze its transient and steady-state response.
- ► In this section, we will focus on how to analyze a system's transient response.
- We already know how to determine the output response by solving differential equations, or taking inverse Laplace transforms.
- These methods are laborous and time consuming.
- We want to develop a technique where we can get the desired information about a system's transient and steady-state response, basically by inspection.
- Our first topic will be how to analyze poles and zeros to determine a system's response.

Poles and Zeros

Consider:

$$G(s) = \frac{b_{n-1}s^{n-1} + b_{n-2}s^{n-2} + \dots + b_0}{s^n + a_{n-1}s^{n-1} + \dots + a_0} = \frac{N(s)}{D(s)}$$

- ▶ Poles of G(s) are the roots of D(s).
- **Zeros** of G(s) are the roots of N(s).
- ▶ Generally, at poles $G(s) = \infty$ unless the pole is cancelled by a matching zero.
- At zeros, G(s)=0 unless the zero is cancelled by a matching pole.

Poles and Zeros of First Order System eg.

- ▶ A system's output response contains two parts:
 - 1. Forced or steady state response: this is caused by the poles of the input function, R(s).
 - 2. Natural or homogeneous response: this is caused by the poles of the transfer function, G(s).
- ▶ In example below, our transfer function is $G(s) = \frac{s+2}{s+5}$, and our input is $R(s) = \frac{1}{s}$.





Figure 4.1.

Poles and Zeros of First Order System eg. - II






Figure 4.1.

Poles and Zeros of First Order System eg. - III

- 1. Pole of input function generated forced response, u(t).
- 2. Pole of transfer function generated natural response, e^{-5t} .

The above is not affected at all by the zero.

3. Pole on real axis, say at $-\alpha$, generates an exponential response, $e^{-\alpha t}$.

Farther to the left on negative axis, the faster the response decays.

4. Both the poles and zeros contribute to the amplitude of the response (ie. the $\frac{2}{5}$ and $\frac{3}{5}$ factors).




Figure 4.2.

Evaluating Response using Poles eg.

Consider system shown below.




Figure 4.3.

From inspection, we can immediately determine:

$$C(s) \equiv \underbrace{\frac{K_1}{s}}_{\text{Forced}} + \underbrace{\frac{K_2}{s+2} + \frac{K_3}{s+4} + \frac{K_4}{s+5}}_{\text{Natural}}$$

▶ Using $\mathcal{L}\{\frac{1}{s+\alpha}\}=e^{-\alpha t}$ gives:

$$c(t) \equiv \underbrace{K_1}_{\text{Forced}} + \underbrace{K_2 e^{-2t} + K_3 e^{-4t} + K_4 e^{-5t}}_{\text{Natural}}$$

First Order Systems

- We will now examine first order systems without zeros so we can define performance specifications.
- ▶ We use systems of the form $G(s) = \frac{a}{s+a}$ as our base form for our definitions.
- ▶ If our input is the step function, $R(s) = \frac{1}{s}$, we get

$$c(t) = c_f(t) + c_n(t) = 1 - e^{-at}$$




Figure 4.4.


Time Constant

- We will now examine first order systems without zeros so we can define performance specifications.
- Our first specification is the system's time constant, $\tau = \frac{1}{a}$.
- ► The time constant is the time required for step response to rise to 63% percent of its final value.

$$c(\tau) = 1 - e^{-a\tau} = 1 - e^{-a \cdot \frac{1}{a}} = 1 - e^{-1} \approx 1 - 0.37 = 0.63$$

- As $\frac{dc(t)}{dt} = ae^{-at}$, we thus have a equal to the slope at t=0.
- We call a the exponential frequency.

Figure 4.5




Rise and Settling Time

- ▶ Rise time, T_r , is the time for the output to go from 10% to 90% of its final value.
- ▶ Can show that $T_r = \frac{2.2}{a}$.
- ▶ Settling time, T_s , is time required for the output to reach 98% of its final value.

▶ Setting $c(T_s) = 0.98$, we find that $T_s = \frac{4}{a}$.

Figure 4.5



Using Testing to Determine Transfer Function

- It is quite often not possible or practical to determine a system's transfer function by analytical means.
- ▶ In general, gain of system at s = 0 (D.C. gain) is not unity.
- A more general model would be $G(s) = \frac{K}{s+a}$.
- ► Step response is thus

$$C(s) = \frac{K}{s(s+a)} = \frac{\frac{K}{a}}{s} - \frac{\frac{K}{a}}{s+a}$$

▶ We thus have

$$c(t) = \frac{K}{a}(1 - e^{-at})$$

▶ How can we experimentally determine the values of K and a?

Using Testing to Determine Transfer Function - II

- ► For system to be a first-order system, its unit step response should have *no overshoot* and should have a *nonzero initial slope*, as in diagram below.
- From diagram, we can see the final value is about 0.72, thus 63% of that is $0.63 \times 0.72 = 0.45$.
- From diagram, the output reaches 0.45 at about $\tau = 0.13$ (time constant).
- (time constant). We thus have $a=\frac{1}{\tau}=7.7.$
- We next note that $c(\infty) = \frac{K}{a}(1 e^{-at})|_{t \to \infty} = \frac{K}{a}$
- Thus $K = a \cdot c(\infty) = (7.7)(0.72) = 5.54$
- ▶ Thus $G(s) = \frac{5.54}{s + 7.7}$




Figure 4.6

Second-Order Systems

- ► For first order systems, varying the systems parameters only changed the speed of the response.
- Form of a second order system we will analyze is $G(s) = \frac{b}{s^2 + as + b}$.
- Changes in these parameters can actually change the form of the system's response.
- May see responses similar to first-order system, damped oscillations, or undamped oscillations.

©2006-2012 R.J. Leduc

Second-Order System Examples




Figure 4.7.

Second-Order System Examples -II




Figure 4.7.

► Like for first-order system, we want to determine information about system's steady state and transient response by examination.

©2006-2012 R.J. Leduc 15

Overdamped Response

- ► For overdamped response, we have a system with two non equal real poles.
- The unit step response to system below is

$$C(s) = \frac{9}{s(s^2 + 9s + 9)} = \frac{9}{s(s + 7.854)(s + 1.146)}$$

From inspection of poles, we know form of system's response will be:

$$c(t) = K_1 + K_2 e^{-\sigma_1 t} + K_3 e^{-\sigma_2 t}$$

where $-\sigma_1 = -7.854$ and $-\sigma_2 = -1.146$, are our two real poles.




Figure 4.7.

Critically Damped Response

- ► For critically damped response, we have a system with two equal real poles.
- ▶ The unit step response to system below is

$$C(s) = \frac{9}{s(s^2 + 6s + 9)} = \frac{9}{s(s+3)^2} = \frac{K_1}{s} + \frac{K_2}{(s+3)} + \frac{K_3}{(s+3)^2}$$

From inspection of poles, we know form of system's response will be:

$$c(t) = K_1 + K_2 e^{-\sigma_1 t} + K_3 t e^{-\sigma_1 t}$$

where $-\sigma_1 = -3$ is our pole location.




Figure 4.7.

Underdamped Response

- For underdamped response, we have a system with two complex conjugate poles (non zero real and imaginary parts).
- The unit step response to system below is

$$C(s) = \frac{9}{s(s^2 + 2s + 9)} = \frac{9}{s(s + 1 + j\sqrt{8})(s + 1 - j\sqrt{8})}$$
$$= \frac{K_1}{s} + \frac{\alpha + j\beta}{s + 1 + j\sqrt{8}} + \frac{\alpha - j\beta}{s + 1 - j\sqrt{8}}$$

► Thus the form of system's response will be:

$$c(t) = K_1 + e^{-\sigma_d t} [2\alpha \cos \omega_d t + 2\beta \sin \omega_d t]$$
 where $-\sigma_d \pm i\omega_d = -1 \pm i\sqrt{8}$.




Figure 4.7.

Underdamped Response - II

- ▶ For system with poles at $s = -\sigma_d \pm j\omega_d$, the real part (σ_d) determines the exponential frequency (decay rate) for the exponential envelope.
- The imaginary part, ω_d , determines the oscillation frequency of the sinusoids, and is called the damped frequency of oscillation.
- Can show that

$$e^{-\sigma_d t} [2\alpha \cos \omega_d t + 2\beta \sin \omega_d t]$$

= $K_4 e^{-\sigma_d t} \cos(\omega_d t - \phi)$

where
$$\phi = \tan^{-1}(\frac{\beta}{\alpha})$$
 and $K_4 = \sqrt{(2\alpha)^2 + (2\beta)^2}$




Figure 4.8

©2006-2012 R.J. Leduc

Undamped Response

- For undamped response, we have a system with two imaginary poles (zero real part).
- The unit step response to system below is

$$C(s) = \frac{9}{s(s^2+9)} = \frac{9}{s(s+j3)(s-j3)} = \frac{K_1}{s} + \frac{\alpha+j\beta}{s+j3} + \frac{\alpha-j\beta}{s-j3}$$


Thus the form of system's response will be:


$$c(t) = K_1 + e^{-(0)t} [2\alpha \cos \omega_d t + 2\beta \sin \omega_d t]$$

= $K_1 + 2\alpha \cos \omega_d t + 2\beta \sin \omega_d t$
= $K_1 + K_4 \cos(\omega_d t - \phi)$

where $\pm i\omega_d = \pm i3.$


Figure 4.7





Second-order System's Step Responses

- Critically damped case represents the transition between the underdamped and overdamped cases.
- Critically damped case is the fastest response without overshoot.



General Second-Order Systems

- We now generalize our discussion of second-order systems and develop specifications to describe the response of the system.
- 1. The **natural frequency**, ω_n , of a second-order system is the frequency of oscillation of the system with damping removed.
- The damping ratio of a second-order system is a way to describe a system's damped oscillation, independent of time scale.

We define *damping ratio*, ζ , to be

$$\zeta = \frac{\mathsf{Exponential\ decay\ frequency}}{\mathsf{Natural\ frequency(rad/sec)}}$$

©2006-2012 R.J. Leduc

Deriving Parameters - ω_n

 \blacktriangleright We want to rewrite the second-order system shown below in terms of ω_n and ζ

$$G(s) = \frac{b}{s^2 + as + b} \tag{1}$$

▶ The quadratic equation tells us the poles are:

$$s_{1,2} = \frac{-a \pm \sqrt{a^2 - 4b}}{2} = \frac{-a}{2} \pm \frac{\sqrt{a^2 - 4b}}{2} \tag{2}$$

- ▶ To determine ω_n , we need an undamped system; thus a=0, $G(s)=\frac{b}{s^2+b}.$
- ▶ Our poles are thus $s_{1,2} = \pm j \sqrt{b}$, giving $\omega_n = \sqrt{b}$ and $b = \omega_n^2$.

Deriving Parameters - ζ

$$G(s) = \frac{b}{s^2 + as + b}$$
 $s_{1,2} = \frac{-a}{2} \pm \frac{\sqrt{a^2 - 4b}}{2}$

- For an underdamped system, the poles must have a real part, $\sigma = \frac{-a}{2}$.
- The exponential decay frequency is equal to the absolute value of σ .

$$\zeta = \frac{\text{Exponential decay frequency}}{\text{Natural frequency(rad/sec)}} = \frac{|\sigma|}{\omega_n} = \frac{a/2}{\omega_n}$$
 (3)

► We thus have:

$$a = 2\zeta\omega_n\tag{4}$$


▶ We can now rewrite our system as

$$G(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{5}$$


Relating Parameters to Poles

Substituting into the poles equation gives:

$$s_{1,2} = \frac{-a}{2} \pm \frac{\sqrt{a^2 - 4b}}{2} = \frac{-(2\zeta\omega_n)}{2} \pm \frac{\sqrt{(2\zeta\omega_n)^2 - 4\omega_n^2}}{2}$$
$$= -\zeta\omega_n \pm \omega_n\sqrt{\zeta^2 - 1}$$
(6)



Relating Parameters to Poles - II



Underdamped Second-order Systems

- ▶ We are mostly interested in underdamped systems as they give us the fastest response.
- ▶ Need to examine behavior more closely for analysis and design.
- ▶ Will now define transient specifications for underdamped responses.
- The step response is:

$$C(s) = \frac{\omega_n^2}{s(s^2 + 2\zeta\omega_n s + \omega_n^2)} = \frac{K_1}{s} + \frac{K_2 s + K_3}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$
 (7)

Assuming $\zeta < 1$ (ie. underdamped case), partial fractions gives:

$$C(s) = \frac{1}{s} - \frac{(s + \zeta\omega_n) + \frac{\zeta}{\sqrt{1 - \zeta^2}}\omega_n\sqrt{1 - \zeta^2}}{(s + \zeta\omega_n)^2 + \omega_n^2(1 - \zeta^2)}$$
(8)

©2006-2012 R.J. Leduc 27

Underdamped Second-order Systems - II

$$C(s) = \frac{1}{s} - \frac{(s + \zeta\omega_n) + \frac{\zeta}{\sqrt{1 - \zeta^2}}\omega_n\sqrt{1 - \zeta^2}}{(s + \zeta\omega_n)^2 + \omega_n^2(1 - \zeta^2)}$$

We can now use the inverse Laplace transform below that we derived earlier

$$\mathcal{L}\{K_1e^{-at}\cos\omega t + K_2e^{-at}\sin\omega t\} = \frac{K_1(s+a) + K_2\omega}{(s+a)^2 + \omega^2}$$

This gives:

$$c(t) = 1 - e^{-\zeta \omega_n t} (\cos \omega_n \sqrt{1 - \zeta^2} t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_n \sqrt{1 - \zeta^2} t)$$
$$= 1 - \frac{1}{\sqrt{1 - \zeta^2}} e^{-\zeta \omega_n t} \cos(\omega_n \sqrt{1 - \zeta^2} t - \phi) \tag{9}$$


where $\phi = \tan^{-1}(\frac{\zeta}{\sqrt{1-\zeta^2}})$.

Underdamped Second-order Systems - III

$$c(t) = 1 - \frac{1}{\sqrt{1 - \zeta^2}} e^{-\zeta \omega_n t} \cos(\omega_n \sqrt{1 - \zeta^2} t - \phi)$$

where
$$\phi = \tan^{-1}(\frac{\zeta}{\sqrt{1-\zeta^2}})$$
.

▶ We can now plot the output with the time axis normalized to the natural frequency.



Underdamped Response Specifications


Let $c_{final} = \lim_{t \to \infty} c(t)$.

- 1. Rise time, T_r , is the time for the output to go from 10% $(0.1c_{final})$ to 90% $(0.9c_{final})$ of its final value.
- 2. Peak time, T_p , is the time required to reach the first and largest peak, c_{max} .
- 3. Percent overshoot, %OS, is the percentage that the output overshoots the final value at $t=T_p$.

$$\% \mathrm{OS} = \frac{c_{max} - c_{final}}{c_{final}} \times 100\%$$

4. Settling time, T_s , is time required for the output to reach and stay within $\pm 2\%$ of c_{final} .





Calculating Peak time

We can determine T_p by differentiating c(t) in equation 9 and finding the first time it equals zero after t=0.

$$\mathcal{L}\{\dot{c}(t)\} = sC(s) = \frac{\omega_n^2}{(s^2 + 2\zeta\omega_n s + \omega_n^2)}$$
(10)

As we want in form of $\mathcal{L}\{sinwt\}$, we complete the square for the denominator giving

$$\mathcal{L}\{\dot{c}(t)\} = sC(s) = \frac{\omega_n^2}{(s + \zeta\omega_n)^2 + \omega_n^2 (1 - \zeta^2)}$$

$$= \frac{\frac{\omega_n}{\sqrt{1 - \zeta^2}} \omega_n \sqrt{1 - \zeta^2}}{(s + \zeta\omega_n)^2 + \omega_n^2 (1 - \zeta^2)}$$
(11)

We thus have

$$\dot{c}(t) = \frac{\omega_n}{\sqrt{1-\zeta^2}} e^{-\zeta\omega_n t} \sin(\omega_n \sqrt{1-\zeta^2} t)$$
 (12)

Calculating Peak time - II

▶ Setting $\dot{c}(t) = 0$ gives

$$\omega_n \sqrt{1 - \zeta^2} \, t = n\pi$$

thus

$$t = \frac{n\pi}{\omega_n \sqrt{1 - \zeta^2}} \tag{13}$$

At n=1, we get first time derivative equals zero after t=0. We thus have:

$$T_p = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}} \tag{14}$$

Calculating %OS

- ▶ Percent overshoot is: $\%OS = \frac{c_{max} c_{final}}{c_{final}} \times 100\%$ ▶ To determine c_{max} , we need to evaluate $c(T_p)$ by substituting equation (14) into equation (9) reproduced below:

$$c(t) = 1 - e^{-\zeta \omega_n t} (\cos \omega_n \sqrt{1 - \zeta^2} t + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \omega_n \sqrt{1 - \zeta^2} t)$$

$$c(T_p) = 1 - e^{-\zeta \pi / \sqrt{1 - \zeta^2}} (\cos \pi + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin \pi)$$

$$= 1 + e^{-\zeta \pi / \sqrt{1 - \zeta^2}}$$
(15)

- From equation 9, it is easy to see that $c(\infty) = c_{final} = 1$.
- Substituting into the %OS formula gives:

$$\%OS = \frac{1 + e^{-\zeta \pi / \sqrt{1 - \zeta^2}} - 1}{1} \times 100\%$$


$$\%OS = e^{-\zeta \pi / \sqrt{1 - \zeta^2}} \times 100\%$$
(16)

33

Calculating %OS -II

%OS =
$$e^{-\zeta \pi / \sqrt{1 - \zeta^2}} \times 100\%$$

- ▶ However, what if we knew which %OS we wanted?
- We can use the equation above to solve for ζ in terms of %OS. This gives:



Calculating 2% Settling Time

- ➤ Settling time is when the ouput reaches and stays within 2% of its final value.
- ► This occurs at latest when the exponential envelope of equation 9 reaches the value of 0.02. This gives:

$$\frac{1}{\sqrt{1-\zeta^2}}e^{-\zeta\omega_n t} = 0.02\tag{18}$$

► Solving for *t* gives:

$$e^{-\zeta\omega_n t} = 0.02\sqrt{1-\zeta^2}$$

$$-\zeta\omega_n t = \ln(0.02\sqrt{1-\zeta^2})$$


$$T_s = \frac{-\ln(0.02\sqrt{1-\zeta^2})}{\zeta\omega_n}$$
(19)

$$T_s \approx \frac{4}{\zeta \omega_n}$$
 (20)

©2006-2012 R.J. Leduc 35


Calculating Rise Time

- There does not exist a precise relationship between rise time and damping ratio.
- Instead, we use a computer and equation 9 to solve for $c(\omega_n t_1) = 0.1 c_{final}$ and $c(\omega_n t_2) = 0.9 c_{final}$, normalizing for the natural frequency.
- We then calculate the normalized rize time, $\omega_n T_r$, as $\omega_n T_r = (\omega_n t_2) (\omega_n t_1)$
- Then, we can use charts below to solve for T_r given a specific ζ and ω_n .



System Response with Additional Poles

- ▶ In last section, we analyzed second-order systems.
- ► The formulas we have derived for percent overshoot, settling time, and peak time are only directly valid for systems with two complex poles and no zeros.
- However, sometimes we can approximate a higher-order system as a second-order system containing the dominant poles.
- ▶ The dominant poles are the two poles farthest to the right.



System Response with Additional Poles - II

- How far away do the additional poles have to be?.
- Depends on the accuracy you want.
- Text assumes that if a pole is five times more to the left than the dominant poles, then system is represented by the dominant poles.
- If above met, you would design using the second-order approximation, then simulate final system to make sure it satisfies the design specifications such as %OS, and T_s etc.

©2006-2012 R.J. Leduc

Example Three Pole Systems

Compare step responses of systems below:

$$T_1(s) = \frac{24.542}{s^2 + 4s + 24.542}$$

$$T_2(s) = \frac{10 \times 24.542}{(s+10)(s^2 + 4s + 24.542)}$$

$$T_3(s) = \frac{3 \times 24.542}{(s+3)(s^2 + 4s + 24.542)}$$




Figure 4.24.

Justification for Ignoring Nondominant Poles

- As long as the nondominant pole is far enough to the left, then its contribution to the output will be negligible.
- ► Easy to see that this will cause it to decay quickly, but what about its amplitude?
- Consider the third order system below

$$C(s) = \frac{bc}{s(s^2 + as + b)(s + c)} = \frac{A}{s} + \frac{Bs + C}{s^2 + as + b} + \frac{D}{s + c}$$

If we assume steady state response is unity, and that the nondominant pole is at s=-c, we can then solve for the following constants using partial fractions:

$$A = 1; B = \frac{ca - c^2}{c^2 + b - ca}$$

$$C = \frac{ca^2 - c^2a - bc}{c^2 + b - ca}; D = \frac{-b}{c^2 + b - ca} (21)$$

Justification for Ignoring Nondominant Poles - II

$$A = 1;$$
 $B = \frac{ca - c^2}{c^2 + b - ca}$ $C = \frac{ca^2 - c^2a - bc}{c^2 + b - ca};$ $D = \frac{-b}{c^2 + b - ca}$

▶ If we let $c \to \infty$, we find:

$$A = 1;$$
 $B = -1$ $C = -a;$ $D = 0.$ (22)

System Response with Zeros

- We now examine systems with Zeros.
- As we saw before, zeros don't change the type of system, but can affect the constants found during partial fraction expansion.
- Consider the system below

$$G(s) = \frac{(s+a)}{(s+b)(s+c)} = \frac{A}{s+b} + \frac{B}{s+c}$$

where by partial fractions we have:

$$A = \frac{-b+a}{-b+c}; \qquad B = \frac{-c+a}{-c+b} \tag{23}$$

42

System Response with Zeros -II

$$A = \frac{-b+a}{-b+c}; \qquad B = \frac{-c+a}{-c+b}$$

► When the zero is far to the left, it will be much larger than the poles, thus:

$$A \approx \frac{a}{-b+c};$$
 $B \approx \frac{a}{-c+b}$

Our system then becomes

$$G(s) \approx a \left[\frac{\frac{1}{-b+c}}{s+b} + \frac{\frac{1}{-c+b}}{s+c} \right] = \frac{a}{(s+b)(s+c)}$$

Nonminium-Phase System

- ▶ What if the zero is in the right half plane (ie. a < 0)?
- ▶ If C(s) is the response of a system, then after adding zero at -a, we get:

$$(s+a)C(s) = sC(s) + aC(s)$$

- ▶ If the derivative term sC(s) is larger than the scaled response aC(s), the system will initially follow the derivative in the wrong direction!
- If we take r(t) = -u(t) as our input, we could get a system like the one below.




Figure 4.26.

Pole Zero Cancellations

Consider the system below:

$$G(s) = \frac{K(s+z_1)}{(s+p_1)(s^2+as+b)}$$
(24)

If z_1 and p_1 are close enough to each other, they can effectively cancel each other even though they are not exactly equal.

$$C(s) = \frac{26.25(s+4)}{s(s+4.01)(s+5)(s+6)}$$
 (25)

$$= \frac{0.87}{s} - \frac{5.3}{s+5} + \frac{4.4}{s+6} + \frac{-0.033}{s+4.01}$$
 (26)


$$\approx \frac{0.87}{s} - \frac{5.3}{s+5} + \frac{4.4}{s+6} \tag{27}$$

© 2006-2012 R.J. Leduc 45

Analysis and Design of Feedback Systems

- Using the block diagram algebra we developed earlier, we can now apply our second-order system results to feedback systems.
- ► Applying feedback reduction, we find that the equivalent closed-loop transfer function of system on right is

$$T(s) = \frac{K}{s^2 + as + K} \tag{28}$$



Figures 5.6 and 4.14.

Analysis and Design of Feedback Systems - II


$$T(s) = \frac{K}{s^2 + as + K}$$

As we increase K from zero, the poles of the system will go from overdamped $(0 \le K < \frac{a^2}{4})$, critically damped $(K = \frac{a^2}{4})$, to underdamped $(K > \frac{a^2}{4})$.

$$s_{1,2} = \frac{-a}{2} \pm \frac{\sqrt{a^2 - 4K}}{2} \ s_{1,2} = \frac{-a}{2} \ s_{1,2} = \frac{-a}{2} \pm \frac{j\sqrt{4K - a^2}}{2}$$

Gain Design for Transient Response

- ▶ Design the value for system gain, K, such that the system response has 10% overshoot.
- Applying feedback reduction, our closed-loop transfer function becomes



Matlab solution to the problem

```
₁ a=5
_{2} G=zpk([],[0 -a],1)
3 pos=10
4 zeta=-\log(pos/100)/sqrt(pi^2+\log(pos/100)^2)
5 K=a^2/(4*zeta^2)
6 Wn=sqrt(K)
7
  rlocus (G)
  sgrid (zeta ,Wn)
  pause
10
11
  Gcl=K*G/(1+K*G)
13 step (Gcl)
14 [y,t]=step(Gcl);
15 max(y)
```