ADC Lab

Example1:

we want to display the corresponding ADC values in the Serial Monitor. Connect potentiometer of the kit as the following:

- Connect Pin1 to 5V of Arduino
- Connect Pin3 to GND of Arduino
- Connect Pin2 to PC0

Then display on serial monitor ADC results

Serial.begin(9600) used to open UART and set baud rate to 9600.

Serial.println(reading) to print ADC on serial monitor

Steps:

- 1. Initialize adc:
 - ✓ Make ADC Ref=VCC (AREF = AVcc)
 - ✓ Enable ADC
 - ✓ Set prescaler by 128 so $Feq_{ADC} = \frac{16000000}{128} = 125000$
- 2. ADC Read function:
 - ✓ Select the corresponding channel 0~7.
 - ✓ Start single conversion by write '1' to ADSC.
 - ✓ Wait for conversion to complete.
 - ✓ Return ADC read value.
- 3. Main:
 - 1. Initialize ADC.
 - 2. Read adc value at PA0.

Example2:

Do the same above using interrupt