Petrophysics Lecture 4: Advanced Archie Log Evaluation

Well Log Interpretation & Pickett Plots

Department / Year: Petroleum Geosciences Department - 2nd Year

Lecture Key Outlines & Core Competencies:

- 1. Pickett Plot Technique for Rw and m determination
- 2. Hingle Plot Method for Quick-Look Saturation
- 3. Case Study: Gulf of Suez Clastic Reservoir

Academic Notice & Verification:

This official academic document is distributed through the PETROGEO learning platform.

All rights reserved. Designed and developed by Eng. Abdelrahman Mohamed.

Support: abdelrahmanelbortogaly@gmail.com | Integrated with Chrome PDF Viewer

Section 2: Practical Calculations, Laboratory Equations & Exercises

Core Equations & Petrophysical / Geological Relations:

Equation 1: Phi_total = (V_bulk - V_grain) / V_bulk * 100%

Equation 2: Q = (k * A * delta_P) / (mu * L) [Darcy Law 1D]

Equation 3: Sw = ((a / Phi^m) * (Rw / Rt))^(1 / n) [Archie Saturation]

Equation 4: V_shale = (GR_log - GR_clean) / (GR_shale - GR_clean) [Linear Index]

Laboratory Work Checklist & Submission:

[OK] Step 1: Calibrate electronic calipers and weigh dry clean core plugs.

[OK] Step 2: Record helium injection pressure and stabilization chamber readings.

[OK] Step 3: Plot data on semi-log scale graph and determine trend line slopes.

[OK] Step 4: Upload your lab report directly via PETROGEO Admin & Student portal.