## Hardware Implementation of GPS Tracking System Using SIM808 module

## Instructions for the project:

- 1. Connect Ac adaptor with a power source.
- 2. Press the power button placed on the module for 3 seconds.
- 3. Then release the button when the power led is turned on.
- 4. Wait until **ready message**<sup>1</sup> is sent to the **admin number** <sup>2</sup> selected in program .
- 5. Now the project is ready to use and waiting for new messages or calls .
- 6. To communicate with the project, you can either send SMS message or dial the GSM mobile number.<sup>3</sup>
- 7. To get GPS data you can either call the GSM Mobile Number or Send The **Password Keyword**<sup>4</sup> and **GPS Data Flag**<sup>5</sup> in SMS message To GSM Mobile Number.
- 8. If you call The GSM Mobile Number it waits for 2 seconds and then hangs up the call. Then the module send SMS message with GPS data to this mobile number.
- 9. Also, you can perform any AT commands like **Power On GPS** <sup>6</sup>, **Power OFF GPS** <sup>7</sup>or **Check GPS Status** <sup>8</sup> with the same way as previous instruction.
- 10. You can also Get GPS data and perform an AT Command in the same Message.
- 11. Finally, There is an **emergency message**<sup>9</sup> which is not required to send password flag with it. When the module receives an emergency message, it calls the admin number.

<sup>&</sup>lt;sup>1</sup> SIM808 is ready to use :)

<sup>&</sup>lt;sup>2</sup> 01270989676

<sup>&</sup>lt;sup>3</sup> 01500377147

<sup>4</sup> weeka

<sup>&</sup>lt;sup>5</sup> GET GPS

<sup>&</sup>lt;sup>6</sup> AT+CGPSPWR=1

<sup>&</sup>lt;sup>7</sup> AT+CGPSPWR=0

<sup>8</sup> AT+CGPSSTATUS?

<sup>9</sup> help