

THE LAYOUT BORDER SETUP ROUTINE ALLOWS A CHOICE OF:
- BORDER SIZE
- MODEL SPACE DRAWING SCALE
- ADDITION OF OFFICE LAYERS
- ADDITION OF OFFICE TEXT STYLES
- ADDITION OF OFFICE DIMENSION STYLES

IN ADDITION TO THOSE ITEMS, THE ROUTINE ALSO:
- INSERTS OR X–REFS THE SELECTED BORDER IN THE LAYOUT TAB
- CREATES A "DRAWING AREA" WINDOW IN THE MODEL TAB
- CREATES VIEWPORT IN THE LAYOUT TAB AND ZOOMS TO SCALE
- IMPORTS THE PAGE SETUP(S) INFORMATION FROM THE BORDER SELECTED

ALL BORDERS CREATED ON LAYER 0 WITH COLORS ASSIGNED.

PROJECT NUMBER 000000 WILL PROVIDE FOR A DEFAULT OFFICE BORDER OF THE SIZE SELECTED.

VALID PROJECT NUMBERS WILL EXTERNALLY REFERENCE THE PROJECT BORDER FROM THE PROJECT DIRECTORY AND INSERT A BLOCK OF ATTRIBUTES.

BORDERS WITH TIGHT ATTRIBUTE SPACING OR SPECIAL JUSTIFICATIONS HAVE DYNAMIC ADJUSTMENTS ADDED.



THE MODEL SPACE BORDER SETUP ROUTINE ALLOWS A CHOICE OF:
- BORDER SIZE
- MODEL SPACE DRAWING SCALE
- ADDITION OF OFFICE LAYERS
- ADDITION OF OFFICE TEXT STYLES
- ADDITION OF OFFICE DIMENSION STYLES

IN ADDITION TO THOSE ITEMS, THE ROUTINE ALSO:
- INSERTS OR X–REFS THE SELECTED BORDER IN THE MODEL TAB AT SPECIFIED SCALE
- IMPORTS THE PAGE SETUP(S) INFORMATION FROM THE BORDER SELECTED

ALL BORDERS CREATED ON LAYER 0 WITH COLORS ASSIGNED.

PROJECT NUMBER 000000 WILL PROVIDE FOR A DEFAULT OFFICE BORDER OF THE SIZE SELECTED.

VALID PROJECT NUMBERS WILL EXTERNALLY REFERENCE THE PROJECT BORDER FROM THE PROJECT DIRECTORY AND INSERT A BLOCK OF ATTRIBUTES.

BORDERS WITH TIGHT ATTRIBUTE SPACING OR SPECIAL JUSTIFICATIONS HAVE DYNAMIC ADJUSTMENTS ADDED.



REVISION SKETCH BORDERS ARE SET UP TO CREATE SEPERATE TABS FOR EACH REVISION SKETCH. THE TABS ARE LINKED TO THE ATTRIBUTES IN THE BORDERS.

REVISION SKETCH BORDERS DO NOT ALTER DRAWING SETTINGS



THE REVISION SKETCH BORDER ROUTINE ALLOWS A CHOICE OF:
- BORDER SIZE
- LAYOUT TAB NAME

IN ADDITION TO THOSE ITEMS, THE ROUTINE ALSO:
- INSERTS OR X–REFS THE SELECTED BORDER IN THE LAYOUT TAB
- CREATES VIEWPORT IN THE LAYOUT TAB AND ZOOMS EXTENTS
- IMPORTS THE PAGE SETUP(S) INFORMATION FROM THE BORDER SELECTED

CREATING PROJECT REVISION BORDERS AT PROJECT INCEPTION CAN PROVIDE SIGNIFICANT SAVINGS AND SHORTEN RESPONSE TIME. THESE DRAWING IMAGES WERE CREATED FROM AUTOCAD DRAWINGS USING THE REVISION SKETCH SETUP.

ALL BORDERS CREATED ON LAYER 0 WITH COLORS ASSIGNED.

PROJECT NUMBER 000000 WILL PROVIDE FOR A DEFAULT OFFICE BORDER OF THE SIZE SELECTED.

VALID PROJECT NUMBERS WILL EXTERNALLY REFERENCE THE PROJECT BORDER FROM THE PROJECT DIRECTORY AND INSERT A BLOCK OF ATTRIBUTES.

BORDERS WITH TIGHT ATTRIBUTE SPACING OR SPECIAL JUSTIFICATIONS HAVE DYNAMIC ADJUSTMENTS ADDED.





THE TILT PANEL BORDER SETUP IS MORE OF A TEMPLATE AND DEMONSTRATION OF SOME OF THE OTHER FEATURES AVAILABLE IN A SETUP ROUTINE.

THIS ROUTINE FUNCTIONS LIKE THE REVISION SETUP.

tHE ADDITIONAL FEATURES ARE NOTED ABOVE

ALL BORDERS CREATED ON LAYER 0 WITH COLORS ASSIGNED.

PROJECT NUMBER 000000 WILL PROVIDE FOR A DEFAULT OFFICE BORDER OF THE SIZE SELECTED.

VALID PROJECT NUMBERS WILL EXTERNALLY REFERENCE THE PROJECT BORDER FROM THE PROJECT DIRECTORY AND INSERT A BLOCK OF ATTRIBUTES.

BORDERS WITH TIGHT ATTRIBUTE SPACING OR SPECIAL JUSTIFICATIONS HAVE DYNAMIC ADJUSTMENTS ADDED.



THE QUICK SKETCH BORDER ROUTINE ALLOWS ONLY A CHOICE OF BORDER SIZE

IN ADDITION TO THAT, THE ROUTINE ALSO:

INSERTS OR X–REFS THE SELECTED BORDER IN THE CURRENT TAB AT THE CURRENT DIMSCALE SETTING

IMPORTS THE PAGE SETUP(S) INFORMATION FROM THE BORDER SELECTED

QUICK SKETCH BORDERS ALLOW PROFESSIONAL FRAMING OF IDEAS IN SECONDS

ALL BORDERS CREATED ON LAYER 0 WITH COLORS ASSIGNED.

PROJECT NUMBER 000000 WILL PROVIDE FOR A DEFAULT OFFICE BORDER OF THE SIZE SELECTED.

VALID PROJECT NUMBERS WILL EXTERNALLY REFERENCE THE PROJECT BORDER FROM THE PROJECT DIRECTORY AND INSERT A BLOCK OF ATTRIBUTES.

BORDERS WITH TIGHT ATTRIBUTE SPACING OR SPECIAL JUSTIFICATIONS HAVE DYNAMIC ADJUSTMENTS ADDED.

MORE IMPORTANT THAN WHAT THE LAYERS ARE IS HOW THEY ARE PERCIEVED BY THE CREATOR OF THIS PACKAGE. LAYERS ARE FIRST AND FORMOST THE DRAFTER'S TOOL. A LAYERING SYSTEM SHOULD IDEALY BE DESIGNED TO ACCOMPLISH MORE BUT MUST FIRST FACILLITATE THE DRAFTING EFFORT.

THE LAYERS IN THIS SYSTEM SORT DRAWING ELEMENTS BY TYPE OF OBJECT. THIS PACKAGE ALSO MAKES USE OF THE SPECIAL CHARACTERISTICS OF LAYER 0 AND ASSIGNING COLOR AND/OR LINETYPE "BYBLOCK". A SIMPLE ADJUSTMENT TO THE SPECIFIC BLOCK WILL TUNE THIS TO THE CLIENT'S PREFERENCES.

ALL OF THE ITEMS WILL SELF ASSIGN LAYERS IF THE MENU OR TOOLBAR COMMAND IS USED. THE SEQUENCE OF DECISION IS AS FOLLOWS:

1. CHECK FOR THE LAYER THE OBJECT WILL BE ASSIGNED TO
2. IF THE LAYER EXISTS, SWITCH TO IT TEMPORARILY FOR THE COMING OPERATION.
3. IF THE LAYER DOES NOT EXIST, PERFORM THE COMING OPERATION ON THE CURRENT LAYER.

THIS PROCESS ALLOWS THE COMPANY TOOLS TO BE USED IN OTHER CAD STANDARDS WITHOUT LAYER CREATION. tHE FULL LIST OF LAYERS USED IS:

0	BLOCK CREATION LAYER, BORDER INSERTION LAYER, NOT USED FOR GENERAL DRAFTING
DEFPOINTS	USED BY AUTOCAD FOR DIMENSION DEFINITION POINTS, DOES NOT PLOT--USED FOR GUIDELINES & VIEWPORTS
S-ABLT	BOLTS, ANCHORS AND FASTENERS OF ALL TYPES
S-ARCH	ARCHITECTURAL (BACKGROUND) LINEWORK
S-BLDG	BUILDING OUTLINE
S-BRDG	JOIST BRIDGING
S-BRIK	BRICK
S-CMUW	CMU WALLS
S-CONC	CONCRETE EDGES ON PLAN
S-CONC-BEAM	CONCRETE BEAMS ON PLAN
S-CONC-COLS	CONCRETE COLUMNS ON PLAN
S-CONC-JOIS	CONCRETE JOISTS ON PLAN
S-DECK	STEEL DECK
S-DIMS	DIMENSIONS
S-EXST	LAYER FOR MINIMAL EXISTING STRUCTURE
S-EXST-XXXX	LAYERS FOR DRAWING EXISTING STRUCTURE WITH SHADED PENS AND VARIED LINEWIDTH
S-GRID	CENTERLINES
S-HTCH	HATCHING AND SHADING
S-MESH	WELDED WIRE FABRIC
S-MTCH	MATCH LINES
S-MECH	MECHANICAL EQUIPMENT OUTLINES
S-OPNG	OPENINGS
S-PIER	PIERS AND FOOTINGS
S-RBAR	REINFORCING BARS, WATERSTOPS
S-REVS	REVISION CLOUDS
S-REV_	REVISION DELTA GENERATED LAYERS
S-SECT-CONC	CONCRETE EDGES IN SECTION
S-SECT-STEL	STEEL ON SECTIONS
S-SLAB-JNTS	SLAB CONTROL JOINTS ON PLAN
S-STEL-BEAM	STEEL BEAMS AND GIRDERS ON PLAN
S-STEL-COLS	STEEL COLUMNS ON PLAN
S-STEL-JOIS	OPEN WEB STEEL JOISTS ON PLAN (CHANGE LAYER LINETYPE FOR SECTIONS)
S-TAGS	CROSS REFERENCE, TITLES, SYMBOLS AND CODED NOTES
S-TEXT	GENERAL DRAWING TEXT, TEXT-LIKE BLOCKS
S-WALL	WALLS OF VARIOUS DESCRIPTION
S-WELD	WELDING SYMBOLS
S-WOOD	WOOD, LIGHT GAGE STEEL, ACCESSORIES

"RESTORING" LAYERS TO OFFICE STANDARD OVERWRITES ANY ADJUSTMENTS TO LAYERS THAT MAY HAVE BEEN MADE PREVIOUSLY.

"ADDING" LAYERS NOT EXISTING DO NOT ALTER ANY LAYERS ALREADY PRESENT IN THE DRAWING.

"ADDING EXISTING" LAYERS WILL ADD OFFICE OBJECT LAYERS PRECEDED BY "S-EXST" INSTEAD OF "S-". THIS PROCESS DOES NOT ALTER ANY OBJECT'S LAYER STATE. THE NUMBERS FOR THE LAYERS WERE SELECTED TO MIRROR THE BLOCK OF NUMBERS ACTIVELY USED BUT WITH A 50% SCREENING APPLIED. THIS ALLOWS SHADED OBJECTS TO HAVE LINE WIDTH AND MAKES THE CONVERSION TO FOLLOW WORK EFFICIENTLY WITH MINIMAL ADDITIONAL EDITING TO THE DRAWING (EXCEPT ERASING).

"CONVERTING LINEWORK" TO EXISTING LAYERS IS A PROCESS BY WHICH A DRAWING DONE WITH STANDARD OFFICE LAYERING IS CONVERTED TO A BACKGROUND DRAWING FOR ADDITIONS OR RENOVATION. EACH OFFICE OBJECT LAYER WILL HAVE IT'S CORRESPONDING EXISTING LAYER CREATED AND ALL OF IT'S OBJECTS TRANSFERRED TO IT. THIS PROCEDURE IGNORES "NON-OBJECT" LAYERS SUCH AS GRID, TEXT AND TAG LAYERS AND ASSUMES ANY HATCHING WILL BE ROMOVED AND IGNORES IT AS WELL. ANY OBJECTS WITH COLORS ASSIGNED MUST BE HANDLED INDIVIDUALLY. THIS PROCEDURE ALSO WORKS WELL WHEN EXTENSIVE DRAWINGS OF EXISTING STRUCTURES MUST BE CREATED. THE BUILDING CAN BE DRAWN AS USUAL AND BE CONVERTED PRIOR TO ADDING NEW STRUCTURE. THE ROUTINE WILL NOT WORK IF EXISTING LAYERS ALREADY EXIST.

A FULL SET OF DIMENSION STYLES CAN BE CREATED TO USER SPECIFICATIONS FOR ANY DIMENSIONING METHOD. INTUICAD'S ENHANCED DIMENSIONING BENEFITS CONSISTS SOLELY OF HAVING A BUTTON CAPABLE OF RESTORING THEM TO A PREDETERMINED STATE WHEN NECESSARY. THE STYLE NAME "STANDARD" HAS SPECIAL FUNCTIONAL CAPABILITIES TO AUTOCAD.

THERE ARE TWO TEXT STYLES IN THE SYSTEM, "STANDARD" AND "TITLE". THE "STANDARD" NAME IN THIS CASE ALLOWS THE BLOCK ATTRIBUTES TO ADAPT TO ALTERNATE FONTS. THE "TITLE" ALLOWS FOR A SECOND FONT (IF DESIRED) IN TITLES AND SCHEDULES.