

Before entering a site, confirm the address, access instructions, hazard notes, and named contact. Stop

At closeout, explain completed work in plain language, record materials actually used, and ask the contractor to sign the record of work.