

Raspberry Pi GPU Audio Video Programming



Raspberry Pi GPU Audio Video Programming

Jan Newmarch

Raspberry Pi GPU Audio Video Programming

Jan Newmarch Oakleigh, Victoria Australia

DOI 10.1007/978-1-4842-2472-4

Library of Congress Control Number: 2016961518

Copyright © 2017 by Jan Newmarch

This work is subject to copyright. All rights are reserved by the Publisher, whether the whole or part of the material is concerned, specifically the rights of translation, reprinting, reuse of illustrations, recitation, broadcasting, reproduction on microfilms or in any other physical way, and transmission or information storage and retrieval, electronic adaptation, computer software, or by similar or dissimilar methodology now known or hereafter developed.

Trademarked names, logos, and images may appear in this book. Rather than use a trademark symbol with every occurrence of a trademarked name, logo, or image we use the names, logos, and images only in an editorial fashion and to the benefit of the trademark owner, with no intention of infringement of the trademark.

The use in this publication of trade names, trademarks, service marks, and similar terms, even if they are not identified as such, is not to be taken as an expression of opinion as to whether or not they are subject to proprietary rights.

While the advice and information in this book are believed to be true and accurate at the date of publication, neither the authors nor the editors nor the publisher can accept any legal responsibility for any errors or omissions that may be made. The publisher makes no warranty, express or implied, with respect to the material contained herein.

Managing Director: Welmoed Spahr

Lead Editor: Steve Anglin

Technical Reviewer: Chaim Krause

Editorial Board: Steve Anglin, Pramila Balan, Laura Berendson, Aaron Black, Louise Corrigan, Jonathan Gennick, Robert Hutchinson, Celestin Suresh John, Nikhil Karkal, James Markham, Susan McDermott, Matthew Moodie, Natalie Pao, Gwenan Spearing

Coordinating Editor: Mark Powers

Copy Editor: Kim Wimpsett Compositor: SPi Global Indexer: SPi Global Artist: SPi Global

Distributed to the book trade worldwide by Springer Science+Business Media New York, 233 Spring Street, 6th Floor, New York, NY 10013. Phone 1-800-SPRINGER, fax (201) 348-4505, e-mail orders-ny@springer-sbm.com, or visit www.springeronline.com. Apress Media, LLC is a California LLC and the sole member (owner) is Springer Science + Business Media Finance Inc (SSBM Finance Inc). SSBM Finance Inc is a **Delaware** corporation.

For information on translations, please e-mail rights@apress.com, or visit www.apress.com.

Apress and friends of ED books may be purchased in bulk for academic, corporate, or promotional use. eBook versions and licenses are also available for most titles. For more information, reference our Special Bulk Sales–eBook Licensing web page at www.apress.com/bulk-sales.

Any source code or other supplementary materials referenced by the author in this text are available to readers at www.apress.com. For detailed information about how to locate your book's source code, go to www.apress.com/source-code/. Readers can also access source code at SpringerLink in the Supplementary Material section for each chapter.

Printed on acid-free paper

To my wife, Linda Cai, and my daughter, Kathryn, who let me play with my computing toys without complaint.

Contents at a Glance

About the Author	xvi
About the Technical Reviewer	ti
Acknowledgments	хх
Introduction	xxii
■Chapter 1: Introduction to the Raspberry Pi	1
Chapter 2: Khronos Group	7
■Chapter 3: Compiling Programs for the Raspberry Pi	9
■Chapter 4: Dispmanx on the Raspberry Pi	21
■Chapter 5: EGL on the Raspberry Pi	27
■Chapter 6: OpenGL ES on the Raspberry Pi	41
■Chapter 7: OpenMAX on the Raspberry Pi Concepts	79
■Chapter 8: OpenMAX Components on the Raspberry Pi	83
■Chapter 9: OpenMAX on the Raspberry Pi State	113
■Chapter 10: OpenMAX IL Client Library on the Raspberry Pi	129
■Chapter 11: OpenMAX Buffers on the Raspberry Pi	137
■Chapter 12: Image Processing on the Raspberry Pi	153
■Chapter 13: OpenMAX Video Processing on the Raspberry Pi	181
■Chapter 14: OpenMAX Audio on the Raspberry Pi	203
■Chapter 15: Rendering OpenMAX to OpenGL on the Raspberry Pi	245

CONTENTS AT A GLANCE

■Chapter 16: Playing Multimedia Files on the Raspberry Pi	261
■Chapter 17: Basic OpenVG on the Raspberry Pi	325
■Chapter 18: Text Processing in OpenVG on the Raspberry Pi	349
■Chapter 19: Overlays on the Raspberry Pi	375
Index	435

Contents

About the Author	xvi
About the Technical Reviewer	xix
Acknowledgments	xx
Introduction	xxiii
■Chapter 1: Introduction to the Raspberry Pi	1
Introduction	1
Programming Style	5
Conclusion	6
Resources	6
■Chapter 2: Khronos Group	7
Role of Khronos	7
OpenGL ES	7
OpenVG	8
EGL	8
OpenMAX	8
Conclusion	8
Resources	8
■Chapter 3: Compiling Programs for the Raspberry Pi	g
Generic Information	g
Versions of gcc	10
C99 or C11 Compilers	10
gcc Compile Flags	11

CONTENTS

includes	14
Dispmanx	14
EGL	14
OpenMAX	14
OpenGL ES	15
OpenVG	15
Libraries	15
Dispmanx	15
EGL	15
OpenMAX	15
OpenGL ES	16
OpenVG	16
Sample Makefiles	16
Dispmanx	16
EGL	17
OpenMAX	17
OpenVG	18
Using pkg-config	18
Conclusion	19
Chapter 4: Dispmanx on the Raspberry Pi	. 21
Building Programs	21
Accessing the GPU	21
Garbage Collection	24
Screen Capture	25
Conclusion	25
Onoldolon	ZJ
Resources	
Resources	25
Resources Chapter 5: EGL on the Raspberry Pi	25 27
Resources	25 27

	Initializing EGL	. 28
	Creating a Rendering Context	. 30
	Creating an EGL Drawing Surface with Dispmanx	. 33
	Garbage Collection	. 37
	Conclusion	. 39
	Resources	. 39
i	Chapter 6: OpenGL ES on the Raspberry Pi	. 41
	Building Programs	
	OpenGL ES	. 42
	The esUtil Functions	. 43
	Vertices	. 46
	Shaders	. 47
	Minimal Vertex Shader	48
	Minimal Fragment Shader	48
	Loading the Shaders	49
	Creating the Program Object	. 50
	Drawing Something	. 51
	Putting It Together	. 53
	Drawing an Opaque Red Triangle	. 53
	A Colored Triangle	. 57
	Varyings	57
	Passing Multiple Attributes to the Vertex Shader	58
	Drawing Squares and Other Shapes	. 59
	Which to Choose?	62
	Textures	. 62
	TGA Files	
	Mipmaps	
	Creating a Texture Object	63

■ CONTENTS

Texture Attributes and the Shaders	63
Drawing the Texture	65
Complete Code for Drawing an Image	67
Animation: Rotating an Image	71
Matrices	71
esUtil	71
Invoking Animation	72
Uniform Parameters: The Rotation Matrix	72
Conclusion	78
Resources	78
■Chapter 7: OpenMAX on the Raspberry Pi Concepts	79
OpenMAX Overview	79
OpenMAX Concepts	80
Conclusion	81
Resources	81
Chapter 8: OpenMAX Components on the Raspberry PiPi	83
OpenMAX IL Components OpenMAX IL Components	
	83
OpenMAX IL Components Getting a List of Components	83 84
OpenMAX IL Components	83 84 87
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component	83 84 87 88
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information	83 84 87 88
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters	
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information	
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information Getting Information About Specific Types of Port	
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information Getting Information About Specific Types of Port Detailed Audio Port Information	
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information Getting Information About Specific Types of Port Detailed Audio Port Information Conclusion Resources	
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information Getting Information About Specific Types of Port Detailed Audio Port Information Conclusion Resources Chapter 9: OpenMAX on the Raspberry Pi State	838487899091111111
OpenMAX IL Components Getting a List of Components Getting a Handle to a Component Port Information Getting and Setting Parameters Getting Port Information Getting Information About Specific Types of Port Detailed Audio Port Information Conclusion Resources	838487909293111111

Loaded to Idle	115
A Nonworking Program	115
What's Wrong with It?	118
Idle to Executing	122
When Do State Changes Occur?	122
What to Do When a State Change Occurs?	127
Conclusion	128
Resources	128
■Chapter 10: OpenMAX IL Client Library on the Raspberry Pi	129
Building Programs	129
Public Functions	130
Creating a Client	131
Changing Component State	132
Waiting for Events	135
Debugging Clients	135
Conclusion	136
Resources	136
■Chapter 11: OpenMAX Buffers on the Raspberry Pi	137
Building Programs	137
Buffers	137
OpenMAX Buffer Allocation	138
The IL Client Library	138
Writing to and Reading from Buffers	142
Sequence of Actions	143
The EOS Flag	144
A Hiccup: Port Settings Changed	145
Example Image Decoding	146
Conclusion	152
Resources	152

CONTENTS

Chapter 12: Image Processing on the Raspberry Pi	153
Building Programs	. 153
Image Components	. 153
Image Formats	. 154
Decoding a JPEG Image	. 157
Tunneling	. 158
Rendering an Image Using Tunnelling	. 162
Rendering an Image Without Tunneling	. 168
Conclusion	. 180
Resources	. 180
Chapter 13: OpenMAX Video Processing on the Raspberry Pi Pi	181
Building Programs	. 181
Video Components	. 181
Video Formats	. 182
Decoding an H.264 File	. 186
Rendering an H.264 Video	. 193
Going Full-Screen	. 201
Conclusion	. 201
Resources	. 201
Chapter 14: OpenMAX Audio on the Raspberry Pi Pi	203
Building Programs	
Audio Components	. 204
Audio Formats	. 204
Decoding an Audio File Using audio_decode	. 213
Rendering PCM Data	. 213
PCM Data	
Choosing an Output Device	214
Setting PCM Format	215

Decoding an MP3 File Using FFmpeg or Avconv	221
Rendering MP3 Using FFmpeg or LibAV and OpenMAX	226
Rendering MP3 with ID3 Extensions Using FFmpeg or LibAV and OpenMAX	234
Conclusion	244
Resources	244
Chapter 15: Rendering OpenMAX to OpenGL on the Raspberry Pi	245
EGLImage	245
OpenMAX	245
OpenGL	246
eglCreatelmageKHR	246
Broadcom GPU	246
Components	247
Threads	247
Rendering a Video into an OpenGL ES Texture	247
Conclusion	259
Resources	259
■Chapter 16: Playing Multimedia Files on the Raspberry PiPi	261
Desperate Debugging	261
Multimedia Files	261
Demuxing Multimedia Files	263
Decoding the Audio Stream Using LibAV	263
Rendering an Audio Stream	266
Rendering the Video Stream (at Full Speed)	275
Rendering the Video Stream (with Scheduling)	277
Rendering Both Audio and Video	299
Use the Audio Decoder?	
Conclusion	324
Resources	324

CONTENTS

■Chapter 17: Basic OpenVG on the Raspberry PiPi	325
Building Programs	. 325
Introduction	. 325
Dispmanx and EGL	. 326
OpenVG Pipeline	. 330
Drawing a Pink Triangle	. 331
Drawing Standard Shapes	. 337
Images	. 341
Creating a VGImage from Memory Data	342
Drawing an Image	342
Drawing an Image Using OpenVG Calls	344
Conclusion	. 348
Resources	. 348
Chapter 18: Text Processing in OpenVG on the Raspberry Pi	349
Building Programs	. 349
Drawing Text	350
Drawing Text Using Cairo	. 350
Drawing Text Using Pango	. 355
FreeType	. 361
Font Faces	361
Paths and Glyphs	362
Drawing a FreeType Outline	. 363
Drawing a FreeType Bitmap	. 367
VGFonts and Multiple Characters	. 368
VGDrawGlyph	368
vgDrawGlyphs	371
Glyph Metrics	371
Conclusion	. 373
Resources	373

Chapter 19: Overlays on the Raspberry Pi	375
Introduction	375
Dispmanx Layers	375
Drawing OpenGL ESon Top of an OpenMAX Image	376
Drawing OpenGL ES on Top of an OpenMAX Video	387
Drawing OpenVG on Top of an OpenMAX Image	398
Drawing OpenVG on Top of an OpenMAX Video	408
Drawing Text on Top of an OpenMAX Video Using Pango	419
Conclusion	433
ndex	435

About the Author



Jan Newmarch is the head of the ICT (Higher Education) at Box Hill Institute, an adjunct professor at Canberra University, and an adjunct lecturer in the School of Information Technology, Computing, and Mathematics at Charles Sturt University. He is interested in more aspects of computing than he has time to pursue, but the major thrust over the last few years has developed from user interfaces under Unix into Java, to the Web, and then into general distributed systems. Jan has developed a number of publicly available software systems in these areas. For the last few years, he has been looking at sound for Linux systems and programming the Raspberry Pi's GPU. He is now exploring aspects of the IoT. He lives in Melbourne, Australia, and enjoys the food and culture there but is not so impressed by the weather.

About the Technical Reviewer



Chaim Krause currently lives in Leavenworth, Kansas, where the U.S. Army employs him as a simulation specialist. In his spare time, he likes to play PC games and occasionally develops his own. He has recently taken up the sport of golf to spend more time with his significant other, Ivana. Although he holds a bachelor's of science degree in political science from the University of Chicago, Chaim is an autodidact when it comes to computers, programming, and electronics. He wrote his first computer game in BASIC on a Tandy Model I Level I and stored the program on a cassette tape. Amateur radio introduced him to electronics, while the Arduino and the Raspberry Pi provided a medium to combine computing, programming, and electronics into one hobby.

Acknowledgments

This book was written with the aid of the extensive documentation on all topics related to computing and the helpful nature of the many thousands of programmers contributing to the Web as a knowledge source. The book is based on the engineering and development work of those behind the Raspberry Pi and of course of the organizations creating the hardware, the software, and the APIs to run programs on GPUs.

Introduction

The Raspberry Pi was created to meet a need to help younger people become involved in the IT field. As a low-cost computer, it can be used, experimented with, broken, and replaced. Initially expected to sell perhaps a few thousand, it has now sold more than 10 million units, and it is used for all sorts of activities, right up to building supercomputers held together with LEGO blocks.

A surprising and early development was to use the Raspberry Pi as a media center, where the GPU was used by software such as omxplayer to render 1080p movies to HDMI screens. This has led to software such as Kodi and OpenElec. My partner is Chinese, so for entertainment we sing karaoke. We have several karaoke players, and they all have different features. I wanted to combine all these features into a single application running on low-cost hardware, and the Raspberry Pi was a natural choice. But it turned out to be really, really *hard*. Some documentation about programming the Raspberry Pi's GPU was available but very inaccessible. So, as I explored what the GPU was capable of, I documented it all, and it turned into this book.

Who This Book Is For

This book is aimed at programmers familiar with C programming who want to write programs using the Raspberry Pi's GPU. It does not assume a prior background in graphics programming, but it does assume that you understand enough about the Unix/Linux programming environment to install and build software from source using tools such as make. Of course, it assumes you have a Raspberry Pi and are comfortable setting it up and installing software packages.

What This Book Covers

There are a multitude of APIs and programming styles for programming graphics systems. The Raspberry Pi supports a few of these: OpenGL ES for 3D programming, OpenVG for 2D vector graphics programming, and OpenMAX for video and audio. This book attempts to deal with all of these. The book deals with the basic concepts of each style of programming and illustrates them with many complete, working programs. You are fortunate in that although the Raspberry Pi has been through a number of hardware revisions, the GPU has remained the same, so the programs run unchanged on all versions of the hardware.

OpenGL ES is a well-documented API. I deal with it here in only enough depth to give simple programs showing the basic concepts of working on the Raspberry Pi. Then you can move on to other resources. The OpenMAX and OpenVG systems have not been documented anywhere outside of formal specifications and multiple PowerPoint presentations. Describing those systems form the major part of the book. In particular, the boundaries between CPU and GPU programming are discussed in detail, such as where text handling or audio decoding should occur.

The final chapter looks at the interplay between these different APIs: drawing dynamic text using OpenVG on top of a video played by OpenMAX, for example.

By the end of this book, you will be familiar with the current APIs using the Raspberry Pi's GPU. Source code for all the programs is accessible via the book's Apress.com product page, which is at www.apress.com/9781484224717.

CHAPTER 1

Introduction to the Raspberry Pi

The Raspberry Pi (RPi) is a low-cost Linux computer developed with the intention of improving the background of students entering university computer science courses by giving them a good, cheap environment in which to play. And it does! In fact, I've got a bunch of colleagues at work, well into middle age, who have leapt upon it to play with. So far their kids haven't found out, though....

Introduction

The RPi is a small, single-board computer developed originally for the purpose of teaching computer science in schools. It uses a system on a chip (SoC) and is characterized by a small form factor, low power, not much RAM, limited inputs and outputs, and disk storage provided either by an SD card or by external storage using a USB port.

There is a growing ecosystem of such computers, and sites such as Element14 Single Board Computers Line Card (https://www.element14.com/community/docs/DOC-55875?ICID=sbc-featured-products) and Wikipedia (http://en.wikipedia.org/wiki/Single-board computer) list many of them.

Now this doesn't seem very exciting, but nevertheless the RPi has captured the imagination (and the pockets!), with more than ten million sold. In fact, Amazon lists more than 1,000 books related to the RPi.

So, what is it? Well, it is a single-board computer, about the size of a credit card. There are a series of models beginning with the Raspberry Pi 1 released in 2012 to the Model 3 Model B released in 2016 and the Pi Zero.

The Model B has 512 MB RAM, two USB ports, and an Ethernet port. It has HDMI and analog audio and video outputs. The RPi FAQ states that the models currently available are the Pi 2 Model B, the Pi 3 Model B, the Pi Zero, and the Pi 1 Model B+ and A+. The following is from the FAQ at www.raspberrypi.org/faqs:

The Model A+ is the low-cost variant of the Raspberry Pi. It has 256 MB RAM, one USB port, 40 GPIO pins, and no Ethernet port. The Model B+ is the final revision of the original Raspberry Pi. It has 512 MB RAM (twice as much as the A+), four USB ports, 40 GPIO pins, and an Ethernet port. In February 2015, it was superseded by the Pi 2 Model B, the second generation of the Raspberry Pi. The Pi 2 shares many specs with the Pi 1 B+, but it uses a 900 MHz quad-core ARM Cortex-A7 CPU and has 1 GB RAM. The Pi 2 is completely compatible with first-generation boards and is the model we recommend for use in schools, due to its flexibility for the learner. The Pi 3 Model B was launched in February 2016; it uses a 1.2 GHz 64-bit quad-core ARM Cortex-A53 CPU, has 1 GB RAM, integrated 802.11n wireless LAN, and Bluetooth 4.1. Finally, the Pi Zero is half the size of a Model A+, with a 1 GHz single-core CPU and 512 MB RAM, and mini-HDMI and USB On-the-Go ports.

Electronic supplementary material The online version of this chapter (doi:10.1007/978-1-4842-2472-4_1) contains supplementary material, which is available to authorized users.

© Jan Newmarch 2017

Figure 1-1 shows what the RPi looks like graphically, and Figure 1-2 shows what it looks like in real life.




Figure 1-1. Raspberry Pi Model 3B (https://www.element14.com/community)

For its target audience, this is a wonderful computer. Its price point means that if it breaks, well, you just get another one. It runs a full-blown Linux system (the RPi 3B can run a very stripped down version "IoT" version of Windows) and can be used in a huge variety of situations (including as an array of RPis to build a supercomputer or hooked up to sensors as a participant in the Internet of Things). But if you want to use a single RPi for heavy-duty computation, well, it sucks. The following is from Wikipedia:

On the CPU level the performance of the RPi 2 is similar to a 300 MHz Pentium II of 1997–1999. The RPi 3 is substantially better but still not a world-shaker.

The GPU, on the other hand, is quite reasonable. The following is from the RPi FAQ:

The GPU is capable of 1 Gpixel/s, 1.5 Gtexel/s, or 24 GFLOPs of general-purpose compute and features a bunch of texture filtering and DMA infrastructure.

The GPU provides Open GL ES 2.0, hardware-accelerated OpenVG, and 1080p30 H.264 high-profile encode and decode.

Now this isn't top-of-the-range GPU performance. A review of the NVidia GTX 980 gave 72 gigapixels per second, but then that single graphics card is ten times the cost of the whole RPi!

From the point of view of this book, an important factor is that while the CPU has changed in the different models, the GPU has remained the same. That means programs written to the GPU will run unchanged across all the different models.

A number of Linux images are available from the Raspberry Pi site, and others are being developed elsewhere. I use the Debian-based Raspbian image, which essentially comes in two forms: with or without a GUI. It doesn't matter which one you use since in this book you will write directly to the GPU and bypass any running window system.

ELinux.org maintains a list of RPi distributions. There are many standard Linux distros included, such as Fedora, Debian, Arch, SUSE, Gentoo, and others. The RPi has gained traction as a media center based on the XBMC media center, and this is represented by distros such as OSMC (formerly Raspbmc) and OpenElec.

It doesn't really matter which distro you use or even whether you use the X Window System or a command line. You will be bypassing those for this book.

There don't seem to be any books that go into detail about the Broadcom VideoCore GPU used on the RPi, besides several tutorials and a set of examples from Broadcom. I bumped into a need to do this kind of programming while trying to turn the RPi into a karaoke machine: with the CPU busting its gut rendering MIDI files, there was nothing left for showing images such as karaoke lyrics except for the GPU, and nothing really to tell me how to do it.

This book scratches my itch. Since I've had to learn a lot about RPi GPU programming, I might as well share it. Let's be honest: much of this is about sharing the pain. What started as a side issue turned into a full-blown project of its own, and this stuff is *hard*.

I will cover OpenGL ES, OpenMAX, and OpenVG. Along the way I will cover some Dispmanx. A version of the full OpenGL has just been released in beta, but this book will not cover that.

If you can't program in C, then go away. If you can't do concurrent programming using threads, then you will probably get glassy-eyed at various points. You need to be able to read formal specifications and pay attention to all the finicky details or your application won't work. And you will need to spend a lot of time experimenting and working through unexplained "features," buggy behavior, and not-yet-implemented core elements. Get used to staring at your screen in a totally bemused fashion, with a debugger running and the specification open on one side and a half-dozen web sites open on the other. I've found that a good bottle of red wine helps, not with the programming but for handling the frustration!

Programming Style

There are many different C programming styles that can be adopted. Regrettably this book uses most of them. I have taken code and specifications from the following places:

- The OpenMAX specification
- The OpenGL ES specification
- The OpenVG specification
- The OpenGL ES Programming Guide
- The Broadcom IL Client library

My preferred brace style for C programming is the "one true brace" with the opening brace on the same line as its conditional statement, as shown here:

```
if (x) {
...
}
```

The IL Client library uses the Allman style (brace on a new line), as shown here:

```
if (x)
{
    ...
}
```

The Programming Guide uses the Whitesmiths style (brace on a new line, indented), as shown here:

```
if (x)
{
    ...
}
```

For variable names, I prefer delimiting words with an underscore (_), as in my_vbl, though after many years of Java programming, I am also happy with CamelCase (myVbl). The IL Client library uses _ separation; the Programming Guide uses CamelCase.

The OpenMAX specification uses a simplified form of Hungarian notation for struct field types such as pNativeRender but prefixes all function calls with OMX_, and the struct names themselves are all uppercase such as OMX AUDIO PORTDEFINITIONTYPE.

The OpenGL ES specification uses CamelCase for its function names, all beginning with ${\tt gl}$ such as ${\tt glValidateProgram}$.

It isn't possible to get one consistent style throughout the book, so I haven't even tried for this edition. Please be tolerant.

Conclusion

This chapter has given you a brief overview of the RPi and what this book will attempt to cover.

Resources

- Raspberry Pi home page: https://www.raspberrypi.org/
- RPi OpenMAX forum: https://www.raspberrypi.org/forums/viewforum.php?f=70
- RPi Graphics forum: https://www.raspberrypi.org/forums/viewforum.php?f=67
- RPi OpenGL ES forum: https://www.raspberrypi.org/forums/viewforum. php?f=68
- Raspberry Pi VideoCore APIs: http://elinux.org/Raspberry Pi VideoCore APIs
- Linux Gizmos reports on many SoCs including the RPi: http://hackerboards.com/
- Tutorial: VLC with hardware acceleration on Raspberry Pi: http://intensecode.blogspot.com.au/2013/10/tutorial-vlc-with-hardware-acceleration.html
- How to draw 2D images using OpenGL, in SDL: http://gamedev.stackexchange.com/questions/46640/how-to-draw-2d-images-using-opengl-in-sdl
- Hardware Accelerated Qt Multimedia Backend for Raspberry Pi and OpenGL Shaders on Video: http://thebugfreeblog.blogspot.com.au/2013/04/hardware-accelerated-qtmultimedia.html
- Decoding and Rendering Compressed Images with OpenMAX on Raspberry Pi: http://thebugfreeblog.blogspot.com.au/2012/12/decoding-and-rendering-compressed.html

CHAPTER 2



According to its web site, "The Khronos Group is a not-for-profit industry consortium creating open standards for the authoring and acceleration of parallel computing, graphics, dynamic media, computer vision, and sensor processing on a wide variety of platforms and devices."

Role of Khronos

The Khronos Group is concerned with devising and setting standards for graphics and video processing, among other things. The standards it is involved in include the following:

- OpenGL
- OpenGL ES
- OpenMAX
- EGL
- OpenVG
- OpenCL

What relevance does this have to the RPi? Well, the RPi supports OpenGL ES, OpenVG, and OpenMAX, and, by the structure of the standards, EGL. So, this is the primary source site for information about the video and graphics programming APIs used by the RPi. Having said that, it may not be the best site to learn what these APIs are. You can read this book instead.

OpenGL ES

According to its web site, "OpenGL ES is a royalty-free, cross-platform API for full-function 2D and 3D graphics on embedded systems, including consoles, phones, appliances, and vehicles. It consists of well-defined subsets of desktop OpenGL, creating a flexible and powerful low-level interface between software and graphics acceleration. OpenGL ES includes profiles for floating-point and fixed-point systems and the EGL specification for portably binding to native windowing systems. OpenGL ES 1.X: fixed function hardware offering acceleration, image quality, and performance. OpenGL ES 2.X: enables full programmable 3D graphics."

What distinguishes OpenGL ES from OpenGL is its emphasis on low-capability embedded systems, and the RPi falls into this category, although it is not necessarily embedded. OpenGL ES is a simplified and tidied-up form of OpenGL but still has the same capabilities as OpenGL. The emphasis with this API is on 2D and 3D graphics, suitable for games programming and other high-demand graphics applications.

© Jan Newmarch 2017 7

It will work in cooperation with other windowing systems, such as the X Window System or Wayland, or where no other windowing system is running.

OpenVG

According to its web site, "OpenVG is a royalty-free, cross-platform API that provides a low-level hardware acceleration interface for vector graphics libraries such as Flash and SVG. OpenVG is targeted primarily at handheld devices that require portable acceleration of high-quality vector graphics for compelling user interfaces and text on small-screen devices, while enabling hardware acceleration to provide fluidly interactive performance at very low power levels."

OpenVG is an alternative approach to graphics to OpenGL. While OpenGL renders onto textures, OpenVG is more concerned with drawing lines to form shapes and then rendering within those shapes.

EGL

According to its web site, "EGL is an interface between Khronos-rendering APIs such as OpenGL ES or OpenVG and the underlying native platform window system. It handles graphics context management, surface/buffer binding, and rendering synchronization and enables high-performance, accelerated, mixed-mode 2D and 3D rendering using other Khronos APIs."

EGL is the "glue" layer between the higher-level APIs and the hardware. It isn't used extensively by the application programmer, just enough to give the higher level the hooks into the lower level. Both OpenGL ES and OpenVG sit above EGL.

OpenMAX

According to its web site, "OpenMAX" is a royalty-free, cross-platform API that provides comprehensive streaming media codec and application portability by enabling accelerated multimedia components to be developed, integrated, and programmed across multiple operating systems and silicon platforms. The OpenMAX API will be shipped with processors to enable library and codec implementers to rapidly and effectively make use of the full acceleration potential of new silicon, regardless of the underlying hardware architecture."

This is a bit more market-speak. But this API is designed for streaming media such as movies and music. Again, it will work with other windowing systems.

Conclusion

Khronos is the standards organization responsible for many of the graphics standards. This chapter has briefly introduced those relevant to the RPi.

Resources

• Khronos Group: www.khronos.org/

CHAPTER 3

Compiling Programs for the Raspberry Pi

Every system has its own quirks when it comes to compilation. The RPi is no exception. This chapter looks at the process of compiling C code for the RPi.

Generic Information

Here is some general information:

- The command arch gives the Linux idea of the CPU. On the RPi 2, it gives armv7l.
 According to the Arch Linux ARM (http://archlinuxarm.org/platforms/armv7/broadcom/raspberry-pi-2), this means "ARMv7l Cortex-A7 quad-core. [...] The SoC is a Broadcom BCM2836."
- The file /etc/issue contains the information Raspbian GNU/Linux 7.
- The file /etc/os-release contains general information about your operating system.

```
PRETTY_NAME="Raspbian GNU/Linux 7 (wheezy)"
NAME="Raspbian GNU/Linux"
VERSION_ID="7"
VERSION="7 (wheezy)"
ID=raspbian
ID_LIKE=debian
ANSI_COLOR="1;31"
HOME_URL="http://www.raspbian.org/"
SUPPORT_URL="http://www.raspbian.org/RaspbianForums"
BUG_REPORT_URL="http://www.raspbian.org/RaspbianBugs"
```

At the time of this writing, the RPi 3 gives a similar report, although the CPU is actually a different one, an ARMv8 Cortex A53. Apparently this is because of the current lack of a 64-bit version of Raspbian, so it reports the same as the 32-bit version for backward compatibility.

© Jan Newmarch 2017

Versions of gcc

Near the end of 2016, the Raspbian distros give gcc 4.8 as the default C compiler. This is fine. If you have an older version, say 4.6, you will want to upgrade your distro or gcc.

C99 or C11 Compilers

Based on language standards supported by gcc, gcc by default does not use the latest C standards. It uses a sort-of 1990 standard, using the default flag -std=gnu90. You can set it to use the C99 standard with the flag -std=c99 and to use C11 with the flag -std=c11.

But there is a problem. EGL, which forms the basis for OpenGL ES and OpenVG, does not support C99. If you try to use the C99 flag, then just including <EGL/egl.h> will throw a host of errors, mainly because it doesn't like the declaration of the function clock_gettime, even though the appropriate header <time.h> is included.

```
In file included from /opt/vc/include/interface/vcos/vcos.h:116:0,
                 from /opt/vc/include/interface/vmcs host/vc dispmanx.h:33,
                 from /opt/vc/include/EGL/eglplatform.h:110,
                 from /opt/vc/include/EGL/egl.h:36,
                 from tiny.c:2:
/opt/vc/include/interface/vcos/pthreads/vcos platform.h: In function
'vcos semaphore wait timeout':
/opt/vc/include/interface/vcos/pthreads/vcos platform.h:297:4: warning:
implicit declaration of function 'clock gettime' [-Wimplicit-function-declaration]
    if (clock gettime(CLOCK REALTIME, &ts) == -1)
/opt/vc/include/interface/vcos/pthreads/vcos platform.h:297:22: error:
'CLOCK REALTIME' undeclared (first use in this function)
    if (clock gettime(CLOCK REALTIME, &ts) == -1)
    You can work around this by using the flag -std=gnu99 instead, but this still generates lots of warnings.
In file included from /opt/vc/include/interface/vcos/vcos.h:185:0,
                 from /opt/vc/include/interface/vmcs host/vc dispmanx.h:33,
                 from /opt/vc/include/EGL/eglplatform.h:110,
                 from /opt/vc/include/EGL/egl.h:36,
                 from tiny.c:2:
/opt/vc/include/interface/vcos/vcos_timer.h:112:6: warning: inline function
'vcos timer delete' declared but never defined [enabled by default]
void vcos timer delete(VCOS TIMER T *timer);
/opt/vc/include/interface/vcos/vcos timer.h:109:6: warning: inline function
'vcos timer reset' declared but never defined [enabled by default]
void vcos_timer_reset(VCOS_TIMER_T *timer, VCOS_UNSIGNED delay);
```

This will compile nevertheless. Do you want to put up with the warnings or just use the default gcc mode?

gcc Compile Flags

The command

```
gcc -mcpu=native -march=native -Q --help=target
```

prints lots of interesting stuff on what gcc figures out. On the RPi 2 with gcc 4.8, it gives the following:

```
The following options are target specific:
                                          aapcs-linux
-mabi=
-mabort-on-noreturn
                                          [disabled]
-mandroid
                                          [disabled]
-mapcs
                                          [disabled]
-mapcs-float
                                          [disabled]
-mapcs-frame
                                          [disabled]
-mapcs-reentrant
                                          [disabled]
-mapcs-stack-check
                                          [disabled]
-march=
                                          armv7-a
-marm
                                          [enabled]
-mbig-endian
                                          [disabled]
-mbionic
                                          [disabled]
-mcallee-super-interworking
                                          [disabled]
-mcaller-super-interworking
                                          [disabled]
                                          cortex-a7
-mcpu=
-mfix-cortex-m3-ldrd
                                          [enabled]
-mfloat-abi=
                                          hard
-mfp16-format=
                                          none
-mfpu=
                                          vfp
-mglibc
                                          [enabled]
-mhard-float
-mlittle-endian
                                          [enabled]
-mlong-calls
                                          [disabled]
-mpic-register=
-mpoke-function-name
                                          [disabled]
-msched-prolog
                                          [enabled]
-msingle-pic-base
                                          [disabled]
-msoft-float
-mstructure-size-boundary=
                                          0x20
-mthumb
                                          [disabled]
-mthumb-interwork
                                          [enabled]
-mtls-dialect=
                                          gnu
-mtp=
                                          auto
-mtpcs-frame
                                          [disabled]
-mtpcs-leaf-frame
                                          [disabled]
-mtune=
                                          [default]
-muclibc
                                          [disabled]
-munaligned-access
                                          [enabled]
-mvectorize-with-neon-double
                                          [disabled]
                                          [enabled]
-mvectorize-with-neon-quad
-mword-relocations
                                          [disabled]
-mwords-little-endian
                                          [disabled]
```

```
Known ARM ABIs (for use with the -mabi= option):
aapcs aapcs-linux apcs-gnu atpcs iwmmxt
Known ARM architectures (for use with the -march= option):
armv2 armv2a armv3 armv3m armv4 armv4t armv5 armv5e armv5t armv5te armv6
armv6-m armv6j armv6k armv6s-m armv6t2 armv6zk armv7 armv7-a armv7-m
armv7-r armv7e-m armv8-a iwmmxt iwmmxt2 native
Known fp16 formats (for use with the -mfp16-format= option):
alternative ieee none
Known ARM FPUs (for use with the -mfpu= option):
crypto-neon-fp-armv8 fp-armv8 fpv4-sp-d16 neon neon-fp-armv8 neon-fp16
neon-vfpv4 vfp vfp3 vfpv3 vfpv3-d16 vfpv3-d16-fp16 vfpv3-fp16 vfpv3xd
vfpv3xd-fp16 vfpv4 vfpv4-d16
Valid arguments to -mtp=:
auto cp15 soft
Known floating-point ABIs (for use with the -mfloat-abi= option):
hard soft softfp
Known ARM CPUs (for use with the -mcpu= and -mtune= options):
arm1020e arm1020t arm1022e arm1026ej-s arm10e arm10tdmi arm1136j-s
arm1136jf-s arm1156t2-s arm1156t2f-s arm1176jz-s arm1176jzf-s arm2 arm250
arm3 arm6 arm600 arm600 arm610 arm620 arm7 arm70 arm700 arm700i arm710
arm7100 arm710c arm710t arm720 arm720t arm740t arm7500 arm7500fe arm7d
arm7di arm7dm arm7dmi arm7m arm7tdmi arm7tdmi-s arm8 arm810 arm9 arm920
arm920t arm922t arm926ej-s arm940t arm946e-s arm966e-s arm968e-s arm9e
arm9tdmi cortex-a15 cortex-a5 cortex-a7 cortex-a8 cortex-a9 cortex-m0
cortex-mOplus cortex-m1 cortex-m3 cortex-m4 cortex-r4 cortex-r4f cortex-r5
ep9312 fa526 fa606te fa626 fa626te fa726te fmp626 generic-armv7-a iwmmxt
iwmmxt2 marvell-pj4 mpcore mpcorenovfp native strongarm strongarm110
strongarm1100 strongarm1110 xscale
TLS dialect to use:
gnu gnu2
```

If you want to find out what this all means, look at the GCC Option Summary at https://gcc.gnu.org/onlinedocs/gcc/Option-Summary.html.

I built up an impressive set of options, basically by chucking in everything I saw in other people's code. They are now as follows:

```
-mfloat-abi=hard -mcpu=arm1176jzf-s -fomit-frame-pointer -mabi=aapcs-linux
-mtune=arm1176jzf-s -mfpu=vfp -Wno-psabi -mno-apcs-stack-check -mstructure-size-boundary=32
-mno-sched-prolog -march=armv6zk
```

Some of these are specific to the RPi version 1, and some are redundant. They are discussed here:

• -mabi=aapcs-linux: This generates code for the specified ABI. Possible values are apcs-gnu, atpcs, aapcs, aapcs-linux, and iwmmxt.

This seems to be primarily for linking to C++ libraries. For C only, can it be omitted?

- -mfloat-abi=hard: This specifies which floating-point ABI to use. Possible values
 are soft, softfp, and hard. For decent performance on the RPi, you will use the hard
 floating-point distro and use this flag in compilations. This seems to be the default
 anyway.
- arch, cpu, and mtune: These give information about the CPU. On later versions of gcc, it can be left as native, with one wrinkle. If all are left as native with gcc 4.6, you get the following:

warning: switch -mcpu=cortex-a7 conflicts with -march=armv7-a switch

and then the following:

```
Assembler messages:
Error: unknown cpu `native'
Error: unrecognized option -mcpu=native
cc1: error: bad value (native) for -mcpu switch
cc1: error: bad value (native) for -march switch
```

The following is according to Richard Earnshaw, at https://gcc.gnu.org/bugzilla/show_bug.cgi?id=58869:

If you specify -mcpu, you don't need to also specify the architecture; the compiler can work that out from the CPU.

At a technical level, Cortex-A7 implements the ARMv7ve variant of ARMv7, which is why you get conflict messages (v7ve having the integer divide instructions); the diagnostic is telling you that the architecture derived from the CPU option is at variance with that coming from the -march option.

If you really want to generate strict ARMv7 code that is tuned for cortex-a7, then use -march=armv7-a -mtune=cortex-a7.

But then the value of cortex-a7 isn't recognized by the assembler.

```
Assembler messages:
Error: unknown architecture `cortex-a7'

Error: unrecognized option -march=cortex-a7

cc1: error: bad value (cortex-a7) for -mtune switch

cc1: error: bad value (cortex-a7) for -march switch
```

This seems to be using the gcc version 4.6 assembler and is OK under the 4.8 version. The values of arm1176jzf-s and armv6zk are for the RPi 1.

- -fomit-frame-pointer: This is an optimization flag and may mess up debugging by omitting useful information.
- -mfpu=vfp: This specifies the floating-point h/w. This value is the default, so it could be omitted.
- -mno-apcs-stack-check: This is disabled anyway.

- -mstructure-size-boundary=32: This looks important; I got bitten once by assuming 64-bit architecture.
- -mno-sched-prolog: The default is enabled; maybe this is useful for debugging?

In summary, this looks reasonable:

```
-mabi=aapcs-linux -mtune=cortex-a7 -march=armv7-a -mfpu=vfp -mstructure-size-boundary=32 -mno-sched-prolog
```

This looks OK for some optimization while still allowing debugging.

Includes

The following are the includes.

Dispmanx

The Dispmanx include files are not organized very nicely. Ideally, only the top-level directory /opt/vc/include should be needed. Unfortunately, this includes files that don't have a base relative to this file. The following set may be needed:

EGL

This adds no new directories.

OpenMAX

I use both the OpenMAX API and the wrapper from Broadcom, the IL Client library. The IL Client library is intended for wider use than just the RPi, so it contains some conditional execution flags. The main one is to choose between 32- and 64-bit architectures since time to OpenMAX is 64 bits and on a 32-bit machine, that needs to be managed in a struct, not a simple type. This flag is OMX SKIP64BIT.

I also use the define RASPBERRY_PI in my code where appropriate. There doesn't seem to be a default RPI define flag.

The appropriate includes and cflags are as follows:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/
include/interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
OMX_ILCLIENT_INC = -I/opt/vc/src/hello pi/libs/ilclient
```

```
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)
CFLAGS = -DOMX SKIP64BIT -DRASPBERRY PI $(INCLUDES)
```

OpenGL ES

I am using the esUtils utility from the OpenGL ES book by Munshi et al., and their files are in the subdirectory Common of my code. The includes reflect this, as shown here:

OpenVG

There are no additional include directories.

Libraries

The following are the libraries.

Dispmanx

The libraries required are as follows:

```
DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
LDFLAGS = $(DMX_LIBS)
```

EGL

This pulls in the Dispmanx and EGL libraries. Unfortunately, it also requires the OpenGL ES library.

```
DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
LDFLAGS = $(DMX_LIBS) $(EGL_LIBS)
```

OpenMAX

The libraries are both the standard OpenMAX libraries and the IL Client libraries.

```
DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL
OMX_LIBS = -lopenmaxil
OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient
LDFLAGS = $(DMX LIBS) $(EGL LIBS) $(OMX LIBS) $(OMX ILCLIENT LIBS)
```

OpenGL ES

In addition to the Munshi objects, the math library has to be added. The EGL_LIBS library already has the GLESv2 library.

```
DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
LDFLAGS = $(DMX_LIBS) $(EGL_LIBS) \
Common/esUtil.o Common/esShader.o Common/esTransform.o\
-lm
```

OpenVG

There is just one additional OpenVG library.

```
DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OPENVG LIBS = -lOpenVG
```

Sample Makefiles

The following are the makefiles.

Dispmanx

This Makefile is for the directory OpenMAX/Components with the C file info.c. The preprocessor flags are for the RPi 2.

```
DMX_INC = -I/opt/vc/include -I/opt/vc/include/interface/vmcs_host/ -I/opt/vc/
include/interface/vcos/pthreads -I/opt/vc/include/interface/vmcs host/linux
```

```
INCLUDES = $(DMX_INC)

CFLAGS = $(INCLUDES)

CPPFLAGS = -march=armv7-a -mtune=cortex-a7

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
LDFLAGS = $(DMX_LIBS)

all: info
```

Running the command make will build all the executables.

EGL

This Makefile is for the directory OpenMAX/Components with the C files info.c, context, and window.c. The preprocessor flags are for the RPi 2.

Running the command make will build all the executables.

OpenMAX

This Makefile is for the directory OpenMAX/Components with the C files info.c, listcomponents.c, and portinfo.c. The preprocessor flags are for the RPi 2.

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/
-I/opt/vc/include/interface/vcos/pthreads
-I/opt/vc/include/interface/vmcs_host/linux

EGL_INC =
    OMX_INC = -I /opt/vc/include/IL
    OMX_ILCLIENT_INC = -I/opt/vc/src/hello_pi/libs/ilclient
    INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS = -march=armv7-a -mtune=cortex-a7

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
    EGL_LIBS = -L/opt/vc/lib/ -lEGL -IGLESv2
    OMX_LIBS = -lopenmaxil
    OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient

LDFLAGS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS) $(OMX_ILCLIENT_LIBS)

all: info listcomponents portinfo
```

Running the command make will build all the executables.

OpenVG

This Makefile is for the directory OpenVG with the C files simple_shape.c and ellipse.c. The preprocessor flags are for the RPi 2.

Using pkg-config

The tool pkg-config is useful for simplifying include and library options. For example, if you want to also use the Glib libraries, then rather than track down all of the include files and library files, you can use the following:

```
$(pkg-config --cflags glib-2.0)
$(pkg-config --libs glib-2.0)
```

These then expand into the following:

```
-I/usr/include/glib-2.0 -I/usr/lib/x86_64-linux-gnu/glib-2.0/include-lglib-2.0 \,
```

These work for nearly all the packages installed using a Debian package manager such as apt-get. (Red Hat systems use pkgconfig.)

The relevant package for the Raspberry Pi GPU include files and libraries is libraspberrypi-dev. Many package-related commands work fine for this package. For example, to show all the files in the package, dpkg-query -L libraspberrypi-dev lists the 241 files in the package. Unfortunately, pkg-config does *not* work, as the creators of this package neglected to include the file libraspberrypi-dev.pc, which would be required by pkg-config.

Heiher (https://github.com/heiher) includes a Git package called raspberrypi-firmware-pkgconfig that fills that gap. This includes these files:

```
bcm_host.pc
egl.pc
glesv2.pc
vg.pc
```

There is, however, a nuisance problem in using these files as they are given: the Mesa project also has the configuration files egl.pc and glesv2.pc, which are installed if you have installed the Mesa package libegl1-mesa or libgles2-mesa. Mesa has not followed the expected naming conventions (the EGL package descriptor should have been libegl1-mesa.pc, for example).

Download the package and copy the .pc files to /usr/share/pkgconfig. The different includes/ libraries are then managed in Makefiles with the following:

• Dispmanx:

```
CFLAGS = $(shell pkg-config --cflags bcm_host)
LDLIBS = $(shell pkg-config --libs bcm_host)
```

• EGL:

```
CFLAGS = $(shell pkg-config --cflags egl-vc)
LDLIBS = $(shell pkg-config --libs egl-vc)
```

• OpenGL ES:

```
CFLAGS = $(shell pkg-config --cflags glesv2-vc)
LDLIBS = $(shell pkg-config --libs glesv2-vc)
```

OpenVG:

```
CFLAGS = $(shell pkg-config --cflags vg-vc)
LDLIBS = $(shell pkg-config --libs vg-vc)
```

• OpenMAX:

```
CFLAGS = $(shell pkg-config --cflags openmax-vc)
LDLIBS = $(shell pkg-config --libs openmax-vc)
```

• OpenMAX with IL client library:

```
CFLAGS = $(shell pkg-config --cflags openmax--il-vc)
LDLIBS = $(shell pkg-config --libs openmax-il-vc)
```

Conclusion

This chapter is perhaps premature but summarizes the build process for the RPi.

CHAPTER 4



Dispmanx is the lowest level of programming for the RPi's GPU. I don't go very deeply into it in this chapter, but you'll learn enough to get a native window for use by other toolkits.

Building Programs

The following is a Makefile to build the program in this chapter:

```
DMX_INC = -I/opt/vc/include -I/opt/vc/include/interface/vmcs_host/
-I/opt/vc/include/interface/vcos/pthreads
-I/opt/vc/include/interface/vmcs_host/linux

INCLUDES = $(DMX_INC)

CFLAGS = $(INCLUDES)

CPPFLAGS = -march=armv7-a -mtune=cortex-a7

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
LDFLAGS = $(DMX_LIBS)

all: info
```

You can use it by running make in the same directory as the Makefile and source file info.c.

Accessing the GPU

The lowest level of accessing the GPU seems to be by an API called Dispmanx. Now, people don't write their graphics applications using Dispmanx. Instead, they use Dispmanx to get a window that is then used by a framework such as EGL and from there by OpenGLES.

Just to give you a total lack of encouragement from using Dispmanx, there are hardly any examples and no serious documentation. However, that hasn't stopped AndrewFromMelbourne from developing a set of programs that can draw Mandelbrot figures, animate triangles, and so on. I'm not going to delve deeply into his programs; you can download them from raspidmx (https://github.com/AndrewFromMelbourne/raspidmx) if you want.

You just use Dispmanx to get some information about the display size and then to create a window that takes up the full screen. You won't do anything else in this chapter; this is just a building block on the way to using the Dispmanx window within a higher-level API. Again, if you want, explore AndrewFromMelbourne's examples.

© Jan Newmarch 2017

The following are the relevant Dispmanx calls to build a window:

```
DISPMANX ELEMENT HANDLE T dispman element;
 DISPMANX_DISPLAY_HANDLE_T dispman_display;
DISPMANX UPDATE HANDLE T dispman update;
VC RECT T dst rect;
VC_RECT_T src_rect;
success = graphics get display size(0 /* LCD */,
          &screen width, &screen height);
assert( success >= 0 );
dst rect.x = 0;
 dst rect.y = 0;
 dst rect.width = screen width;
 dst rect.height = screen height;
 src rect.x = 0;
 src rect.y = 0;
 src_rect.width = screen width << 16;</pre>
 src rect.height = screen height << 16;</pre>
 dispman display = vc dispmanx display open( 0 /* LCD */);
 dispman update = vc dispmanx update start( 0 );
 dispman element =
     vc dispmanx element add(dispman update, dispman display,
                             0/*layer*/, &dst rect, 0/*src*/,
                             &src rect, DISPMANX PROTECTION NONE,
                             0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
```

At the end of this, you have a window stored in dispman_element that can be used as a native window object later.

The complete program is info.c and just prints the size of the screen, as shown here:

```
/*
 * code stolen from openGL-RPi-tutorial-master/encode_OGL/
 */

#include <stdio.h>
#include <bcm_host.h>

typedef struct
{
    uint32_t screen_width;
    uint32_t screen_height;
    DISPMANX_DISPLAY_HANDLE_T dispman_display;
} DISPMANX_STATE_T;

DISPMANX_STATE_T state, *p_state = &state;
```

```
void init dispmanx(DISPMANX STATE T *state) {
    int32 t success = 0;
    bcm_host_init();
   DISPMANX ELEMENT HANDLE T dispman element;
   DISPMANX UPDATE HANDLE T dispman update;
   VC RECT T dst rect;
   VC_RECT_T src_rect;
    success = graphics get display size(0 /* LCD */,
                                        &state->screen_width,
                                        &state->screen height);
    assert( success >= 0 );
   printf("Screen height %d, width %d\n",
           state->screen height, state->screen width);
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = state->screen width;
    dst rect.height = state->screen height;
    src rect.x = 0;
    src rect.y = 0;
    src rect.width = state->screen width << 16;</pre>
    src rect.height = state->screen height << 16;</pre>
    state->dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
        vc_dispmanx_element_add(dispman_update, state->dispman_display,
                                0/*layer*/, &dst rect, 0/*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    /* Now we have created a native Dispmanx window
    * Toolkits such as OpenGL ES will use this for
    * their own 'native window' type, with code like this:
    static EGL_DISPMANX_WINDOW_T nativewindow;
    nativewindow.element = dispman element;
    nativewindow.width = state->screen_width;
    nativewindow.height = state->screen height;
   vc dispmanx update submit sync( dispman update );
    assert(vc dispmanx element remove(dispman update, dispman element) == 0);
```

}

```
int
main(int argc, char *argv[])
{
    init_dispmanx(p_state);
    assert( vc_dispmanx_display_close(p_state->dispman_display) == 0);
    return 0;
}
    It can then be run easily by the following:
./info
    The output on my RPi is as follows:
    Screen height 1080, width 1920
```

Garbage Collection

C does not have automatic garbage collection like Java or other languages have. You need to do it yourself. This program does little else apart from opening a display. This can be closed by vc_dispmanx_display_close(p state->dispman display). It doesn't actually seem to make a difference but is tidier.

Showing the free memory in RAM used by the CPU is common; tools such as top give a good idea of this, with ps drilling down deeper. Showing the memory used by the GPU is trickier, and there is a Broadcom tool vcdbg to show that. Even if nothing has been run, it shows some memory usage (with 512 MB of RAM devoted to the GPU).

```
$/opt/vc/lib /opt/vc/bin/vcdbg reloc
Relocatable heap version 4 found at 0x1f000000
total space allocated is 492M, with 492M relocatable, 0 legacy and 0 offline
O legacy blocks of size 2359296
free list at 0x3d886520
489M free memory in 1 free block(s)
largest free block is 489M bytes
0x1f000000: free 489M
   4] 0x3d886540: used 576 (refcount 1 lock count 0, size 512, align
                                                                             4, data
0x3d886560, d0rual) 'ILCS VC buffer pool'
   3] 0x3d886780: used 3.5M (refcount 1 lock count 8, size 3618816, align 4096, data
0x3d887000, d1rual) 'ARM FB'
   2] Ox3dbfafaO: used 16K (refcount 1 lock count 0, size 16384, align
                                                                            32, data
0x3dbfafc0, d0ruAl) 'audioplus_tmp_buf'
    1] Ox3dbfefe0: used 4.0K (refcount 1 lock count 0, size 0, align 4096, data
0x3dbff000, d1rual) 'camera fast alloc arena'
small allocs not requested
```

This program is useful for showing what is going on when you haven't been doing garbage collection!

Screen Capture

AndrewFromMelbourne has written a program using Dispmanx called raspi2png to capture the RPi screen and save it as a PNG file. The source code demonstrates additional Dispmanx calls.

Conclusion

Dispmanx is the layer between EGL and the Broadcom GPU. You just looked at enough to supply that bridge.

Resources

- raspidmx by AndrewFromMelbourne: https://github.com/AndrewFromMelbourne/ raspi2png
- cherry: A GPU accelerated slide show daemon for Raspberry Pi: https://sanje2v.wordpress.com/tag/dispmanx/

CHAPTER 5



EGL provides a base for graphics programming, common to many systems such as OpenCL, OpenGL, OpenGL ES, and OpenVG. It is system neutral and for the RPi is the layer above Dispmanx.

Building Programs

The following is a Makefile to build these programs:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
INCLUDES = $(DMX_INC) $(EGL_INC)

CFLAGS = $(INCLUDES)
CPPFLAGS = -march=armv7-a -mtune=cortex-a7

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib -lEGL -lGLESv2

LDFLAGS = $(DMX_LIBS) $(EGL_LIBS)

all: context info window
```

Overview

According to the EGL specification at www.khronos.org/registry/egl/specs/eglspec.1.5.pdf, "EGL [is] an interface between rendering APIs such as OpenCL, OpenGL, OpenGL ES, or OpenVG (referred to collectively as client APIs) and one or more underlying platforms (typically window systems such as X11)." It is not intended that application programmers write directly to EGL; instead, they should use one of the APIs such as OpenGL.

© Jan Newmarch 2017 27

Each underlying platform will have a means of rendering EGL surfaces. In this chapter, you will look at how EGL surfaces are linked to Dispmanx surfaces and how windows are built. You won't actually draw into any windows because that is best done using, for example, OpenGL. You will do that in Chapter 6.

Why EGL? The following is from the Wayland FAQ at http://wayland.freedesktop.org/faq.html#heading toc j 12:

EGL is the only GL binding API that lets us avoid dependencies on existing window systems, in particular X. GLX obviously pulls in X dependencies and only lets us set up GL on X drawables. The alternative is to write a Wayland-specific GL binding API, say, WaylandGL.

A more subtle point is that libGL.so includes the GLX symbols, so linking to that library will pull in all the X dependencies. This means that we can't link to full GL without pulling in the client side of X, so we're using GLES2 for now. Longer term, we'll need a way to use full GL under Wayland.

From the RPi viewpoint, EGL forms the link between native Dispmanx windows and the OpenGL ES API.

Initializing EGL

EGL has a display that it writes on. The display is built on a native display and is obtained by the call eglGetDisplay. The EGL platform is then initialized using eglInitialize.

Typically an EGL display will support a number of configurations. For example, a pixel may be 16 bits (5 red, 5 blue, and 6 green), 24 bits (8 red, 8 green, and 8 blue), or 32 bits (8 extra bits for alpha transparency). An application will specify certain parameters, such as the minimum size of a red pixel, and can then access the array of matching configurations using eglChooseConfig. The attributes of a configuration can be queried using eglGetConfigAttrib. One configuration should be chosen before proceeding.

The program info.c lists the possible configurations that are available to EGL.

```
/*
  * code stolen from openGL-RPi-tutorial-master/encode_OGL/
  */
#include <stdio.h>
#include <assert.h>
#include <math.h>
#include <unistd.h>

#include <EGL/egl.h>
#include <EGL/eglext.h>

typedef struct
{
    uint32_t screen_width;
    uint32_t screen_height;
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
```

```
EGLConfig config;
} EGL_STATE_T;
EGL_STATE_T state, *p_state = &state;
void printConfigInfo(int n, EGLDisplay display, EGLConfig *config) {
    int size;
    printf("Configuration %d is\n", n);
    eglGetConfigAttrib(display,
                       *config, EGL RED SIZE, &size);
    printf(" Red size is %d\n", size);
    eglGetConfigAttrib(display,
                       *config, EGL BLUE SIZE, &size);
    printf(" Blue size is %d\n", size);
    eglGetConfigAttrib(display,
                       *config, EGL GREEN SIZE, &size);
    printf(" Green size is %d\n", size);
    eglGetConfigAttrib(display,
                       *config, EGL BUFFER SIZE, &size);
    printf(" Buffer size is %d\n", size);
   eglGetConfigAttrib(display,
                       *config, EGL_BIND_TO_TEXTURE_RGB , &size);
   if (size == EGL TRUE)
       printf(" Can be bound to RGB texture\n");
   else
       printf(" Can't be bound to RGB texture\n");
   eglGetConfigAttrib(display,
                       *config, EGL BIND TO TEXTURE RGBA , &size);
   if (size == EGL TRUE)
       printf(" Can be bound to RGBA texture\n");
   else
       printf(" Can't be bound to RGBA texture\n");
}
void init egl(EGL STATE T *state)
    EGLBoolean result;
    EGLint num configs;
    EGLConfig *configs;
    // get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    if (result == EGL FALSE) {
```

```
fprintf(stderr, "Can't initialise EGL\n");
        exit(1);
    }
    eglGetConfigs(state->display, NULL, 0, &num_configs);
    printf("EGL has %d configs\n", num configs);
    configs = calloc(num configs, sizeof *configs);
    eglGetConfigs(state->display, configs, num configs, &num configs);
    int i:
    for (i = 0; i < num configs; i++) {
        printConfigInfo(i, state->display, &configs[i]);
}
int
main(int argc, char *argv[])
{
    init egl(p state);
    return 0;
}
    The program is run by info.
    The following is a portion of the output:
EGL has 28 configs
Configuration 0 is
  Red size is 8
  Blue size is 8
  Green size is 8
  Buffer size is 32
  Can't be bound to RGB texture
  Can be bound to RGBA texture
Configuration 1 is
  Red size is 8
  Blue size is 8
  Green size is 8
  Buffer size is 24
  Can be bound to RGB texture
  Can be bound to RGBA texture
```

Creating a Rendering Context

Each configuration will support one or more client APIs such as OpenGL. The API is usually requested through the configuration attribute EGL_RENDERABLE_TYPE, which should have a value such as EGL_OPENGL_ES2_BIT.

In addition to a configuration, each application needs one or more *contexts*. Each context defines a level of the API that will be used for rendering. Examples typically use a level of 2, and a context is created using eglCreateContext.

The following is typical code to perform these steps:

```
init_egl() {
    EGLint major, minor, count, n, size;
    EGLConfig *configs;
    EGLint config_attribs[] = {
        EGL_SURFACE_TYPE, EGL_WINDOW_BIT,
        EGL RED SIZE, 8,
        EGL_GREEN_SIZE, 8,
        EGL BLUE SIZE, 8,
        EGL RENDERABLE TYPE, EGL OPENGL ES2 BIT,
        EGL NONE
    };
    static const EGLint context attribs[] = {
        EGL CONTEXT CLIENT VERSION, 2,
        EGL NONE
    };
    display->context =
        eglCreateContext(display->display,
                          display->config,
                          EGL NO CONTEXT, context attribs);
}
    The program context.c takes the first available configuration and then creates a context.
 * code stolen from openGL-RPi-tutorial-master/encode OGL/
#include <stdio.h>
#include <assert.h>
#include <math.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
typedef struct
    uint32 t screen width;
    uint32_t screen_height;
```

```
EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
EGL_STATE_T state, *p_state = &state;
void init egl(EGL STATE T *state)
    EGLBoolean result;
    EGLint num configs;
    static const EGLint attribute list[] =
        {
            EGL RED SIZE, 8,
            EGL GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL NONE
        };
    EGLConfig *configs;
    // get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    eglGetConfigs(state->display, NULL, 0, &num configs);
    printf("EGL has %d configs\n", num configs);
    configs = calloc(num configs, sizeof *configs);
    eglGetConfigs(state->display, configs, num configs, &num configs);
    // get an appropriate EGL configuration - just use the first available
    result = eglChooseConfig(state->display, attribute list,
                             &state->config, 1, &num_configs);
    assert(EGL FALSE != result);
    // Choose the OpenGL ES API
    result = eglBindAPI(EGL OPENGL ES API);
    assert(EGL FALSE != result);
```

Creating an EGL Drawing Surface with Dispmanx

An EGL window needs to be created from a native window or surface. This is different for each system. For the RPi, you use a Dispmanx window, as created in the previous chapter. This is used to create an EGL drawing surface by eglCreateWindowSurface.

You take the EGL context creation from the previous program and the Dispmanx window creation from the previous chapter and build an EGL window surface with the following:

Drawing into this surface is generally done by an API such as OpenGL, and the choice of this has been set in the EGL context. This is set for the drawing surfaces by eglMakeCurrent.

Following this, drawing can take place. For now, you will draw only a big red rectangle occupying the screen. Once the drawing is complete, the EGL layer renders the surface by swapping the drawing buffer using eglSwapBuffers.

The program is window.c.

```
/*
 * code stolen from openGL-RPi-tutorial-master/encode_OGL/
#include <stdio.h>
#include <assert.h>
#include <math.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <bcm_host.h>
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
    EGL_DISPMANX_WINDOW_T nativewindow;
    DISPMANX DISPLAY HANDLE T dispman display;
} EGL STATE T;
EGL STATE T state = {
    .display = EGL NO DISPLAY,
    .surface = EGL_NO_SURFACE,
    .context = EGL NO CONTEXT
EGL_STATE_T *p_state = &state;
void init egl(EGL STATE T *state)
{
    EGLint num_configs;
    EGLBoolean result;
    bcm host init();
    static const EGLint attribute_list[] =
            EGL RED SIZE, 8,
            EGL GREEN_SIZE, 8,
            EGL_BLUE_SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL_SURFACE_TYPE, EGL_WINDOW_BIT,
            EGL NONE
        };
    static const EGLint context attributes[] =
        {
```

```
EGL_CONTEXT_CLIENT_VERSION, 2,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
   result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute list, &state->config, 1,
    &num_configs);
    assert(EGL FALSE != result);
    // Choose the OpenGL ES API
    result = eglBindAPI(EGL OPENGL ES API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                      state->config, EGL_NO_CONTEXT,
                                      context attributes);
   assert(state->context!=EGL NO CONTEXT);
}
void init dispmanx(EGL STATE T *state) {
    EGL DISPMANX WINDOW T *nativewindow = &p state->nativewindow;
    int32 t success = 0;
    uint32 t screen width;
    uint32_t screen_height;
   DISPMANX ELEMENT HANDLE T dispman element;
   DISPMANX_DISPLAY_HANDLE_T dispman_display;
   DISPMANX UPDATE HANDLE T dispman update;
   VC RECT T dst rect;
   VC_RECT_T src_rect;
   bcm host init();
    // create an EGL window surface
    success = graphics_get_display_size(0 /* LCD */,
                                        &screen width,
                                        &screen height);
    assert( success >= 0 );
   dst rect.x = 0;
    dst rect.y = 0;
    dst_rect.width = screen_width;
    dst rect.height = screen height;
```

```
src rect.x = 0;
    src rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    state->dispman display = dispman display;
    dispman element =
        vc dispmanx element add(dispman update, dispman display,
                                0/*layer*/, &dst rect, 0/*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen height;
    vc dispmanx update submit sync(dispman update);
    assert(vc dispmanx element remove(dispman update, dispman element) == 0);
    printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                             state->config,
                                             &p state->nativewindow, NULL );
    assert(state->surface != EGL NO SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL FALSE != result);
}
void cleanup(int s) {
    if (p state->surface != EGL NO SURFACE &&
        eglDestroySurface(p state->display, p state->surface)) {
        printf("Surface destroyed ok\n");
    if (p state->context != EGL NO CONTEXT &&
        eglDestroyContext(p state->display, p state->context)) {
        printf("Main context destroyed ok\n");
    if (p state->display != EGL NO DISPLAY &&
        eglTerminate(p_state->display)) {
        printf("Display terminated ok\n");
    }
```

```
if (eglReleaseThread()) {
        printf("EGL thread resources released ok\n");
    if (vc_dispmanx_display_close(p_state->dispman_display) == 0) {
        printf("Dispmanx display rleased ok\n");
    bcm host deinit();
    exit(s);
}
int
main(int argc, char *argv[])
    signal(SIGINT, cleanup);
    init_egl(p_state);
    init dispmanx(p state);
    egl from dispmanx(p state);
    glClearColor(1.0, 0.0, 0.0, 1.0);
   glClear(GL COLOR BUFFER BIT);
   glFlush();
    eglSwapBuffers(p state->display, p state->surface);
    sleep(4);
    cleanup(0);
    return 0;
}
    The program is run by window and has the following output:
Got a Dispmanx window
Surface destroyed ok
Main context destroyed ok
Display terminated ok
EGL thread resources released ok
Dispmanx display rleased ok
```

Garbage Collection

C does not have automatic garbage collection like Java or other languages have. You have to do it yourself. The function cleanup manages this. It is also attached to a SIG_INT interrupt handler to clean up after Ctrl-C interrupts.

```
void cleanup(int s) {
   if (p state->surface != EGL NO SURFACE &&
```

```
eglDestroySurface(p_state->display, p_state->surface)) {
        printf("Surface destroyed ok\n");
    if (p_state->context != EGL_NO_CONTEXT &&
       eglDestroyContext(p state->display, p state->context)) {
       printf("Main context destroyed ok\n");
    if (p state->display != EGL NO DISPLAY &&
        eglTerminate(p state->display)) {
        printf("Display terminated ok\n");
    if (eglReleaseThread()) {
       printf("EGL thread resources released ok\n");
    if (vc dispmanx display close(p state->dispman display) == 0) {
       printf("Dispmanx display released ok\n");
    bcm host deinit();
    exit(s);
}
    Garbage collection is not complete; there seems to be a number of Khronos calls that don't go away.
$/opt/vc/bin/vcdbg reloc
Relocatable heap version 4 found at 0x1f000000
total space allocated is 492M, with 490M relocatable, 0 legacy and 2.3M offline
O legacy blocks of size 2359296
free list at 0x3bf78d20
461M free memory in 1 free block(s)
largest free block is 461M bytes
0x1f000000: offline 2.3M
0x1f240000: free 461M
[ 31] 0x3bf78d40: used 96K (refcount 1 lock count 1, size 98304, align 256, data
0x3bf78e00, D1rual) 'khrn_hw_bin_mem'
[ 30] 0x3bf90e60: used 96K (refcount 1 lock count 1, size 98304, align 256, data
0x3bf90f00, D1rual) 'khrn hw bin mem'
0x3bf90e60: corrupt trailer (space 98592 != 98593)
[ 29] 0x3bfa8f80: used 96K (refcount 0 lock count 0, size 98304, align 256, data
0x3bfa9000, D1ruAl) 'khrn hw bin mem'
0x3bfc10a0: free 25M
 11] 0x3d885700: used 96 (refcount 0 lock count 0, size 22, align
                                                                              1, data
0x3d885720, d1rual) 'khrn hw null render'
0x3d885760: free 3.5K
   4] 0x3d886540: used 576 (refcount 1 lock count 0, size 512, align
                                                                              4, data
0x3d886560, d0rual) 'ILCS VC buffer pool'
   3] 0x3d886780: used 3.5M (refcount 1 lock count 8, size 3618816, align 4096, data
0x3d887000, d1rual) 'ARM FB'
```

```
[ 2] 0x3dbfafa0: used 16K (refcount 1 lock count 0, size 16384, align 32, data
0x3dbfafc0, d0ruAl) 'audioplus_tmp_buf'
[ 1] 0x3dbfefe0: used 4.0K (refcount 1 lock count 0, size 0, align 4096, data
0x3dbff000, d1rual) 'camera fast alloc arena'
heap corruption detected
small allocs not requested
```

This appears to be a fixed allocation that does not increase over multiple runs of programs.

Conclusion

This chapter has looked at EGL, which is the layer above Dispmanx and the layer below the major APIs of OpenGL ES, OpenVG, and so on.

Resources

- eglIntro—introduction to managing client API rendering through the EGL API: https://www.khronos.org/registry/egl/sdk/docs/man/html/eglIntro.xhtml
- Khronos Native Platform Graphics Interface (EGL Version 1.5): www.khronos.org/registry/egl/specs/eglspec.1.5.pdf

CHAPTER 6



OpenGL ES is one of the means of drawing graphics on the RPi. It is an extremely sophisticated system that I introduce in this chapter but do not attempt to cover in detail. The major contribution of this chapter is to establish how you use Dispmanx to create an EGL surface so you can do OpenGL ES rendering. It describes a version of esUtils.c from the Munshi et al. book adapted to the RPi and gives some examples of its use. This gives the basics of what is required to run OpenGL ES programs on the RPi but is not intended to be more than an introduction to general OpenGL ES programming.

Building Programs

Download Benosteen's OpenGL ES files for the RPi.

```
git clone git://github.com/benosteen/opengles-book-samples.git
```

This will create a directory structure in the current directory, including the RPi files you will use in this chapter in the directory opengles-book-samples/Raspi/Common. For convenience, move this up to the current directory, as shown here:

```
mv opengles-book-samples/Raspi/Common.
```

Add the following Makefile to the directory Common:

```
#
# Raspbery Pi library for building 'OpenGL ES 2.0 Programming Guide' examples
#
LIBES=libRPes2pg.a

DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
GLES_INC =
INCLUDES = $(DMX_INC) $(EGL_INC) $(GLES_INC)
CFLAGS = $(INCLUDES) -DRPI_NO_X -DPI_DISPLAY=4
```

© Jan Newmarch 2017 41

The purpose of this Makefile is to create the library file libRPes2pg.a. Then the programs in this chapter can be built using the Makefile.

```
DMX INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs host/linux
EGL INC =
GLES INC = -ICommon/
INCLUDES = $(DMX INC) $(EGL INC) $(GLES INC)
CFLAGS = $(INCLUDES)
DMX LIBS = -L/opt/vc/lib/ -lbcm host -lvcos -lvchiq arm -lpthread
EGL LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
ESP\ LIBS = -LCommon\ -1RPes2pg
LDLIBS = $(DMX LIBS) $(EGL LIBS) $(ESP LIBS) -1m
SRC = Hello Triangle Hello TriangleColour Simple Image Simple Texture2D Rotate Image Hello
Square
all: $(SRC)
$(SRC): Common/libRPes2pg.a
Common/libRPes2pg.a:
    make -C Common
```

OpenGL ES

In this chapter, you actually get to draw things, using the OpenGL ES API supported by the RPi. OpenGL was first specified in 1992, arising out of earlier systems by Silicon Graphics. Obviously, being so old, it has accreted a certain amount of fluff. OpenGL ES is a simplified form, more suitable to low-profile computers such as the RPi. OpenGL ES is now up to version 3, but the RPi supports only version 2. (Actually, it also supports version 1, but we will ignore that.)

Note that the latest Raspbian image from February 2016 has experimental support for full OpenGL. This book will not discuss this; I would expect its main use would be to build in support for the forthcoming Vulkan graphics system.

OpenGL ES is a significantly complex system; generating 2D and 3D images is an exceedingly nontrivial task! The canonical reference for this API is the *OpenGL ES 2.0 Programming Guide* by Aaftab Munshi, Dan Ginsburg, and Dave Shreiner. It is nearly 500 pages and is packed with information about how to program OpenGL ES.

Obviously, I cannot hope to replicate all the material in that book. Nevertheless, I will address the issues of getting OpenGL ES running on the RPi and show you a number of simple examples.

The esUtil Functions

The Munshi et al. book tries to present a platform-independent view of OpenGL ES programming so that the example programs will run essentially unchanged across multiple platforms, including Linux, Windows, the iPhone, and Android. To do this, it has to abstract above the OS-dependent layers. It does so with a set of functions wrapped in files such as esUtil.c, one version for each OS.

The original book did not contain any version of this file for the RPi (it hadn't been invented then), but authors such as Benosteen have created versions. His version contains code that will run both under the X Window System and as stand-alone; I will cover the stand-alone version.

The esUtil.c file essentially defines four functions.

- esInitContext initializes their framework.
- esCreateWindow creates an EGLContext for drawing.
- esRegisterDrawFunc registers a suitable OpenGL ES drawing function.
- esMainLoop draws things in a loop.

The library uses a struct.

This gives OS-independent information needed for drawing OpenGL ES. The four fields of EGLNativeWindowType, EGLDisplay, EGLContext, and EGLSurface were all covered for the RPi in previous chapters and are defined for the RPi as follows:

```
///
// CreateEGLContext()
//
//
      Creates an EGL rendering context and all associated elements
//
EGLBoolean CreateEGLContext (EGLNativeWindowType hWnd, EGLDisplay* eglDisplay,
                              EGLContext* eglContext, EGLSurface* eglSurface,
                              EGLint attribList[])
{
   EGLint numConfigs;
   EGLint majorVersion;
   EGLint minorVersion;
   EGLDisplay display;
   EGLContext context;
   EGLSurface surface;
```

```
EGLConfig config;
EGLint contextAttribs[] = { EGL_CONTEXT_CLIENT_VERSION, 2, EGL_NONE, EGL_NONE };
// Get Display
display = eglGetDisplay(EGL DEFAULT DISPLAY);
if ( display == EGL NO DISPLAY )
   return EGL FALSE;
}
// Initialize EGL
if ( !eglInitialize(display, &majorVersion, &minorVersion) )
   return EGL FALSE;
}
// Get configs
if (!eglGetConfigs(display, NULL, 0, \u221mConfigs))
   return EGL FALSE;
// Choose config
if (!eglChooseConfig(display, attribList, &config, 1, &numConfigs) )
   return EGL FALSE;
}
// Create a surface
surface = eglCreateWindowSurface(display, config, (EGLNativeWindowType)hWnd, NULL);
if ( surface == EGL NO SURFACE )
   return EGL FALSE;
}
// Create a GL context
context = eglCreateContext(display, config, EGL_NO_CONTEXT, contextAttribs );
if ( context == EGL NO CONTEXT )
   return EGL_FALSE;
}
// Make the context current
if (!eglMakeCurrent(display, surface, surface, context) )
   return EGL_FALSE;
*eglDisplay = display;
*eglSurface = surface;
*eglContext = context;
```

```
return EGL_TRUE;
}
///
// WinCreate()
//
//
        This function initialized the native X11 display and window for EGL
//
EGLBoolean WinCreate(ESContext *esContext, const char *title)
    int32 t success = 0;
    uint32 t screen width;
   uint32_t screen_height;
    EGL DISPMANX WINDOW T *nativewindow = malloc(sizeof(EGL DISPMANX WINDOW T));
   DISPMANX ELEMENT HANDLE T dispman element;
   DISPMANX DISPLAY HANDLE T dispman display;
   DISPMANX UPDATE HANDLE T dispman update;
   VC RECT T dst rect;
   VC RECT T src rect;
    bcm host init();
    // create an EGL window surface
    success = graphics_get_display_size(0 /* LCD */,
                                         &screen width,
                                         &screen height);
    assert( success >= 0 );
   dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst rect.height = screen height;
    src rect.x = 0;
    src rect.y = 0;
    src_rect.width = screen_width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
        vc dispmanx element add(dispman_update, dispman_display,
                                0/*layer*/, &dst rect, 0/*src*/,
                                &src_rect, DISPMANX_PROTECTION_NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL_DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen_height;
```

```
vc_dispmanx_update_submit_sync(dispman_update);
printf("Got a Dispmanx window\n");
esContext->hWnd = (EGLNativeWindowType) nativewindow;
return EGL_TRUE;

These are used in a typical application like this, where UserData is some application-dependent structure:
ESContext esContext;
UserData userData;
esInitContext ( &esContext );
esContext.userData = &userData;
esCreateWindow ( &esContext, "My application", 320, 240, ES_WINDOW_RGB );
```

Vertices

}

A key data structure for drawing is the vertex, which is a point in two- or three-dimensional space. Each vertex may have attributes associated with it such as a color. A line has two vertices, a triangle has three, a square has four, and a circle has as many points around the circumference as are needed to look like a circle.

Using three-dimensional (x, y, z) coordinates, you can specify the vertices of a triangle by doing the following:

Note that the coordinate system (www.matrix44.net/cms/notes/opengl-3d-graphics/coordinate-systems-in-opengl) for OpenGL ES is




Figure 6-1. OpenGL ES coordinate system

so that this triangle is




Figure 6-2. Triangle in the coordinate system

(but note, you haven't given the vertices any color yet, so it isn't going to appear red until you do.)

Shaders

Shaders are programs that run on the GPU rather than on the CPU. There is a communications pipeline from the CPU to the GPU: the CPU sends programs and data to the GPU, which then executes them. There are two types of programs that run on the GPU: vertex shaders and fragment shaders. Simplifying horribly dramatically the relationship between these is




Figure 6-3. Communications path

The vertex shader is handed vertices one at a time and performs some operation such as moving the vertex to a new position. The OpenGL ES pipeline will then work out which pixels should be drawn and hand them one at a time to the fragment shader, which works out the color of the pixel.

How does OpenGL ES know which pixels are to be drawn? Because the application will have said, "Draw triangles incorporating these triplets of vertices and fill them in" (more details soon).

So, what do shaders look like? They are in a C-like language, custom designed for OpenGL ES. The language supports all the operations required for graphics and is quite extensive. I will need to cover some of it in the sequel. The specification is called the OpenGL ES Shading Language (https://www.khronos.org/files/opengles shading language.pdf).

Minimal Vertex Shader

The following is a really simple vertex shader:

```
attribute vec4 vPosition;
void main()
{
    gl_Position = vPosition;
}
```

This takes a parameter called vPosition and assigns it to the variable gl_Position. *Every vertex shader must assign a value to this variable.* This shader is taking an input value for the location of the vertex and assigning the final location of that vertex to the same value.

The data type of $gl_{position}$ is a four-dimensional vector (x, y, z, w). The first three components are the (x, y, z) values of the vertex, while the fourth is typically set to 1.

The shader is *not* C code; it is not compiled by the application. It is passed as a string to the GPU and compiled at runtime by the GPU.

Minimal Fragment Shader

A fragment shader is responsible for setting a color on a pixel. A color is also a four-dimensional vector, of the form (red, green, blue, alpha), with all values between 0 and 1. The alpha value is the amount of "transparency," where 1 means opaque and 0 means transparent.

A minimal fragment shader just sets the pixel to opaque red.

```
void main()
{
    gl_FragColor = vec4 ( 1.0, 0.0, 0.0, 1.0 );
}
```

The variable gl_FragColor *must* be assigned a value.

This also is not compiled by the application but is passed as a string to the GPU, which compiles it at runtime.

Loading the Shaders

}

The shaders are given as source code strings to OpenGL ES. You have to create a shader object, tell it the source code, compile the shader, and check for errors. The code for this is as follows:

```
GLuint LoadShader ( GLenum type, const char *shaderSrc )
  GLuint shader;
  GLint compiled;
   // Create the shader object
   shader = glCreateShader ( type );
   if ( shader == 0 )
        return 0;
   // Load the shader source
   glShaderSource ( shader, 1, &shaderSrc, NULL );
   // Compile the shader
   glCompileShader ( shader );
   // Check the compile status
   glGetShaderiv ( shader, GL_COMPILE_STATUS, &compiled );
   if (!compiled)
      GLint infoLen = 0;
      glGetShaderiv ( shader, GL INFO LOG LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetShaderInfoLog ( shader, infoLen, NULL, infoLog );
         esLogMessage ( "Error compiling shader:\n%s\n", infoLog );
         free ( infoLog );
      }
      glDeleteShader ( shader );
      return 0;
   return shader;
```

Creating the Program Object

The OpenGL ES program to run in the GPU must be created and the shaders attached. This is a bit messy as you have to define the shaders, load the shaders, create the program that will run the shaders, attach the shaders to the program, add the information about the attributes (here vPosition), link the program, and take error correction action if it fails.

The typical code to do this is as follows:

```
int Init ( ESContext *esContext )
   esContext->userData = malloc(sizeof(UserData));
   UserData *userData = esContext->userData;
   GLbvte vShaderStr[] =
      "attribute vec4 vPosition;
                                    \n"
      "void main()
                                    \n"
                                    \n"
          gl Position = vPosition; \n"
                                    \n";
   GLbyte fShaderStr[] =
       "void main()
                                                     \n"
        gl_FragColor = vec4 ( 1.0, 0.0, 0.0, 1.0 );\n"
   GLuint vertexShader;
   GLuint fragmentShader;
   GLuint programObject;
   GLint linked;
   // Load the vertex/fragment shaders
   vertexShader = LoadShader ( GL VERTEX SHADER, vShaderStr );
   fragmentShader = LoadShader ( GL_FRAGMENT_SHADER, fShaderStr );
   // Create the program object
   programObject = glCreateProgram ( );
   if ( programObject == 0 )
      return 0;
   glAttachShader ( programObject, vertexShader );
   glAttachShader ( programObject, fragmentShader );
   // Bind vPosition to attribute 0
   glBindAttribLocation ( programObject, 0, "vPosition" );
   // Link the program
   glLinkProgram ( programObject );
```

```
// Check the link status
  glGetProgramiv ( programObject, GL LINK STATUS, &linked );
   if (!linked)
     GLint infoLen = 0;
     glGetProgramiv ( programObject, GL INFO LOG LENGTH, &infoLen );
     if (infoLen > 1)
        char* infoLog = malloc (sizeof(char) * infoLen );
        glGetProgramInfoLog ( programObject, infoLen, NULL, infoLog );
        esLogMessage ( "Error linking program:\n%s\n", infoLog );
        free ( infoLog );
     glDeleteProgram ( programObject );
     return GL FALSE;
   }
   // Store the program object
   userData->programObject = programObject;
  glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
  return GL_TRUE;
}
```

Drawing Something

That's a lot of code so far, and we still haven't drawn anything! That's the purpose of the next function, which will set up the array of vertices, set a viewport in which to see the drawing, establish the vertices to be drawn, and finally draw them.

Establishing the vertices involves first setting the active program by gluseProgram; multiple programs can exist at any one time, but only one is active for drawing (you have defined only one so far).

The array of vertices given as C code must then be set so that OpenGL ES can hand each vertex to the attribute vPosition. The array is, for example, the set of triangle vertices that you already saw early on.

The attribute that will be set to each vertex in turn is vPosition in the vertex shader. In the C code, you don't use the string vPosition to identify it, but instead use the integer index 0 that you set *once* when creating and linking the program with the following:

```
// Bind vPosition to attribute 0
glBindAttribLocation ( programObject, 0, "vPosition" );
```

The link is made with the following function:

where you specify 0 for the index attribute, 3 for the number of elements in each vertex (for x, y and z), GL_FLOAT for the data type of each array element, GL_FALSE for normalized data, and a stride of 0, meaning that you have only vertex data and nothing else in the vertex array.

```
glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
```

One last little wrinkle and then you can draw: attributes by default are *disabled*, meaning that the C data will not be given to the attribute. The attribute (with index 0) must be enabled with the following:

```
glEnableVertexAttribArray ( 0 );
```

Now you draw using the function glDrawArrays, which takes three parameters: the drawing mode (you will use triangle mode for the single triangle), the initial vertex in the vertex array, and the number of vertices to be drawn.

```
glDrawArrays ( GL TRIANGLES, 0, 3 );
    The draw function is as follows:
void Draw ( ESContext *esContext )
   UserData *userData = esContext->userData;
   GLfloat vVertices[] = { 0.0f, 0.5f, 0.0f,
                           -0.5f, -0.5f, 0.0f,
                            0.5f, -0.5f, 0.0f };
   // Set the viewport
   glViewport ( 0, 0, esContext->width, esContext->height );
   // Clear the color buffer
   glClear ( GL_COLOR_BUFFER_BIT );
   // Use the program object
   glUseProgram ( userData->programObject );
   // Load the vertex data
   glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
   glEnableVertexAttribArray ( 0 );
   glDrawArrays ( GL_TRIANGLES, 0, 3 );
}
```

Putting It Together

The main function brings it all together.

```
int main ( int argc, char *argv[] )
{
    ESContext esContext;
    UserData userData;

    esInitContext ( &esContext );
    esContext.userData = &userData;

    esCreateWindow ( &esContext, "Hello Triangle", 320, 240, ES_WINDOW_RGB );

    if ( !Init ( &esContext ) )
        return 0;

    esRegisterDrawFunc ( &esContext, Draw );

    esMainLoop ( &esContext );
}
```

Drawing an Opaque Red Triangle

If you now take the set of functions from esUtil.c, the convenience functions defined earlier with the special values for arrays and shaders, then you can finally draw a red opaque triangle. The program is Hello_Triangle.c.

```
// Book:
             OpenGL(R) ES 2.0 Programming Guide
// Authors:
             Aaftab Munshi, Dan Ginsburg, Dave Shreiner
// ISBN-10:
             0321502795
             9780321502797
// ISBN-13:
// Publisher: Addison-Wesley Professional
// URLs:
             http://safari.informit.com/9780321563835
//
             http://www.opengles-book.com
//
// Hello Triangle.c
//
//
     This is a simple example that draws a single triangle with
//
     a minimal vertex/fragment shader. The purpose of this
//
     example is to demonstrate the basic concepts of
//
     OpenGL ES 2.0 rendering.
#include <stdlib.h>
#include "esUtil.h"
```

```
typedef struct
   // Handle to a program object
   GLuint programObject;
} UserData;
///
// Create a shader object, load the shader source, and
// compile the shader.
GLuint LoadShader ( GLenum type, const char *shaderSrc )
   GLuint shader;
   GLint compiled;
   // Create the shader object
   shader = glCreateShader ( type );
   if (shader == 0)
        return 0;
   // Load the shader source
   glShaderSource ( shader, 1, &shaderSrc, NULL );
   // Compile the shader
   glCompileShader ( shader );
   // Check the compile status
   glGetShaderiv ( shader, GL COMPILE STATUS, &compiled );
   if (!compiled)
   {
      GLint infoLen = 0;
      glGetShaderiv ( shader, GL_INFO_LOG_LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetShaderInfoLog ( shader, infoLen, NULL, infoLog );
         esLogMessage ( "Error compiling shader:\n%s\n", infoLog );
         free ( infoLog );
      }
      glDeleteShader ( shader );
      return 0;
   }
   return shader;
}
```

```
111
// Initialize the shader and program object
int Init ( ESContext *esContext )
  esContext->userData = malloc(sizeof(UserData));
  UserData *userData = esContext->userData;
   GLbyte vShaderStr[] =
      "attribute vec4 vPosition;
                                    \n"
     "void main()
                                    \n"
                                    \n"
         gl_Position = vPosition; \n"
     "}
                                    \n";
   GLbyte fShaderStr[] =
      "precision mediump float;\n"\
      "void main()
                                                     \n"
                                                     \n"
     " gl_FragColor = vec4 ( 1.0, 0.0, 0.0, 1.0 );\n"
  GLuint vertexShader;
  GLuint fragmentShader;
  GLuint programObject;
  GLint linked;
   // Load the vertex/fragment shaders
   vertexShader = LoadShader ( GL VERTEX SHADER, vShaderStr );
   fragmentShader = LoadShader ( GL FRAGMENT SHADER, fShaderStr );
   // Create the program object
   programObject = glCreateProgram ( );
   if ( programObject == 0 )
     return 0;
   glAttachShader ( programObject, vertexShader );
  glAttachShader ( programObject, fragmentShader );
   // Bind vPosition to attribute 0
  glBindAttribLocation ( programObject, 0, "vPosition" );
   // Link the program
  glLinkProgram ( programObject );
   // Check the link status
  glGetProgramiv ( programObject, GL_LINK STATUS, &linked );
```

```
if (!linked)
      GLint infoLen = 0;
      glGetProgramiv ( programObject, GL_INFO_LOG_LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetProgramInfoLog ( programObject, infoLen, NULL, infoLog );
         esLogMessage ( "Error linking program:\n%s\n", infoLog );
         free ( infoLog );
      }
      glDeleteProgram ( programObject );
      return GL_FALSE;
   }
   // Store the program object
   userData->programObject = programObject;
   glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
   return GL TRUE;
}
///
// Draw a triangle using the shader pair created in Init()
void Draw ( ESContext *esContext )
{
   UserData *userData = esContext->userData;
   GLfloat vVertices[] = { 0.0f, 0.5f, 0.0f,
                           -0.5f, -0.5f, 0.0f,
                            0.5f, -0.5f, 0.0f };
   // Set the viewport
   glViewport ( 0, 0, esContext->width, esContext->height );
   // Clear the color buffer
   glClear ( GL_COLOR_BUFFER_BIT );
   // Use the program object
   glUseProgram ( userData->programObject );
   // Load the vertex data
   glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
   glEnableVertexAttribArray ( 0 );
   glDrawArrays ( GL_TRIANGLES, 0, 3 );
}
```

```
int main ( int argc, char *argv[] )
{
    ESContext esContext;
    UserData userData;

    esInitContext ( &esContext );
    esContext.userData = &userData;

    esCreateWindow ( &esContext, "Hello Triangle", 320, 240, ES_WINDOW_RGB );

    if ( !Init ( &esContext ) )
        return 0;

    esRegisterDrawFunc ( &esContext, Draw );

    esMainLoop ( &esContext );
}
```

The program is run by calling Hello_Triangle and draws a small red triangle.

A Colored Triangle

In the previous example, you drew a triangle with a solid red color. This was done by setting the fragment shader variable fragmentColor to opaque red. But what if you wanted to get a color triangle?



Figure 6-4. Coloured triangle

Do you have to calculate all of the color values yourself?

Varyings

You could do it by yourself, but fortunately OpenGL ES can do the work for you. It has the concept of *varyings*, which are variables with values interpolated from the vertex shader data. For the colored triangle, the interpolated values are calculated using the vertex colors, averaged out based on the distance from each vertex.

To use them, you define a variable to be varying in both the vertex and the fragment shader, with the same name. You set a value in each vertex using a new attribute and then can access the interpolated value in each fragment shader. The vertex shader is as follows:

```
attribute vec4 vPosition;
attribute vec4 vColour;

varying vFragmentColour;

void main()
{
    gl_Position = vPosition;
    vFragmentColour = vColour;
}

    The fragment shader is as follows:

varying vec4 vFragmentColour;

void main()
{
    gl_FragColor = vFragmentColour;
}
```

Passing Multiple Attributes to the Vertex Shader

In the simple triangle program, you passed a set of vertex values to the vertex shader by first setting the index of the attribute to 0 and then calling the vertex attribute pointer function. To add more attributes, the simplest way (but not the most efficient) is to set extra attributes to higher index values (one, two, and so on) and call the vertex attribute pointer function on these as well.

Here are the changes required to set colors for the color attribute:

The program is Hello_TriangleColour.c. It isn't worth including the full code here because only the previous lines differ from the Hello_Triangle.c program. It is run by Hello_TriangleColour.

Drawing Squares and Other Shapes

If you want to draw complex shapes such as squares, cubes, or even circles and spheres, you need to break them down into triangles. Squares and other regular shapes are easy to divide into triangles, but even then there can be many choices (divide on *this* diagonal or on *that* one?).

Far more complex, and more important, is how to label the vertices of these triangles, because that affects how you ask OpenGL ES to draw them. The OpenGL ES specification illustrates this with




Figure 6-5. Possible vertex labelling of figures

Making separate triangles is easiest for the programmer: you just have to cut the polygons into any triangles with any labeling and call glDrawArrays where every three vertices define a separate triangle. But it may cost more in processing time.

A square, for example, can be divided into two separate triangles with a total of six vertices. Doing so would look like this:

Here is the drawing code:

```
glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
glEnableVertexAttribArray ( 0 );
glDrawArrays ( GL_TRIANGLES, 0, 6 );
```

But a square can also be divided into a triangle strip or even a triangle fan with only four vertices. But you have to be more careful. If you want a strip, the first vertex must not be shared with any other triangle and neither can the last. Here is one possibility for a square at $(\pm 1, \pm 1)$:

```
-1.0f, -1.0f, 0.0f,
-1.0f, 1.0f, 0.0f
};
```

The square can then be drawn with the following:

```
glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
glEnableVertexAttribArray ( 0 );
glDrawArrays ( GL_TRIANGLE_STRIP, 0, 4 );
```

An alternative mechanism uses the vertex arrays as shown earlier but draws elements by explicit indexes into this array rather than the implicit indexes caused by the element ordering. This makes use of another array, this time of the indices. The vertex array must be used too, of course.

Even if an index array is used, there are still the choices of drawing individual triangles, strips, or fans. Using triangles, the code is as follows:

(This is usually optimized by reusing some of the vertices as $\{0, 1, 2, 3, 2, 1\}$ and omitting the last two entries of the vertices array.) The square can then be drawn with the following:

The square can then be drawn with the following:

```
glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
glEnableVertexAttribArray ( 0 );
glDrawElements ( GL_TRIANGLE_STRIP, 4, GL_UNSIGNED_BYTE, vIndices );
These possibilities can all be seen in a revised Draw function, where the differ
```

These possibilities can all be seen in a revised Draw function, where the different choices described earlier can be made by setting TRIANGLES and ELEMENTS to 0 or 1:

```
void Draw ( ESContext *esContext )
#define TRIANGLES 1
#define ELEMENTS 1
   UserData *userData = esContext->userData;
  GLfloat vVertices[] = {
                          1.0f, -1.0f, 0.0f,
                          1.0f, 1.0f, 0.0f,
                          -1.0f, -1.0f, 0.0f,
                          -1.0f, 1.0f, 0.0f,
#if TRIANGLES
                          -1.0f, -1.0f, 0.0f,
                          1.0f, 1.0f, 0.0f
#endif
                         };
#if ELEMENTS
   GLubyte vIndices[] = {
                         0, 1, 2,
 if TRIANGLES
                         4, 5
# endif
                        };
#endif
   // Set the viewport
   glViewport ( 0, 0, esContext->width, esContext->height );
   // Clear the color buffer
   glClear ( GL_COLOR_BUFFER_BIT );
   // Use the program object
   glUseProgram ( userData->programObject );
   // Load the vertex data
   glVertexAttribPointer ( 0, 3, GL FLOAT, GL FALSE, 0, vVertices );
   glEnableVertexAttribArray ( 0 );
```

```
#if TRIANGLES
# if ELEMENTS
    glDrawElements ( GL_TRIANGLES, 6, GL_UNSIGNED_BYTE, vIndices );
# else
    glDrawArrays ( GL_TRIANGLES, 0, 6 );
# endif
#else
# if ELEMENTS
    glDrawElements ( GL_TRIANGLE_STRIP, 4, GL_UNSIGNED_BYTE, vIndices );
# else
    glDrawArrays ( GL_TRIANGLE_STRIP, 0, 4 );
# endif
#endif
}
```

The full program is Hello_Square.c and is run by Hello_Square.

Which to Choose?

The choice of triangles, strip, or fan will depend on the geometry of the shape and any semantic context it might have; for example, drawing a wall of rectangles would use a strip, while drawing circles would use a fan. The choice of drawing arrays or elements usually comes down in favor of elements for efficiency.

Textures

Textures are another means of filling triangles. A texture is image data that can be manipulated by the fragment shader. Textures can be two-dimensional rectangular images or the six sides of a cube. In this section, you will look only at two-dimensional images. Textures will typically come from image data stored in files or hard-coded into the program. The Munshi et al. book uses a simple hard-coded 2x2 image. Here you will take a file image.

TGA Files

There are many, many different file formats—some lossy, some lossless, some compressed, some not, some with metadata, some without. In this section, you will just use TGA (www.fileformat.info/format/tga/egff.htm), which is an uncompressed format with enough useful metadata that is simple to load.

TGA files can be created from, for example, JPEG files by using the convert utility from the Gimp drawing system. It is simple to convert a file from JPEG to TGA format. You just give the appropriate file extensions.

```
convert image.jpg image.tga
```

A TGA file has a header section that gives the width and height of the image from which its size can be calculated. The default format will be RGB, as in 24-bit pixels. Reading in such a file is just a matter of locating the dimensions, malloc'ing the right size buffer, skipping to the start of the image data, and reading it all in.

The esUtil.c file includes a function called esLoadTGA that will read in an image, returning the image and its dimensions.

The default is for the origin of the image to be the top-left corner, with the y-axis growing down. OpenGL ES, on the other hand, has the origin in the bottom-left corner with the y-axis growing up. So, the image will be upside down relative to the OpenGL coordinates. This can be fixed by reading the data in differently or by using an OpenGL ES reflection. You will map the texture upside down to give the correct orientation.

Mipmaps

An application may need to render an image in fine detail or, say, if it is far away, in only coarse detail. To avoid GPU load, multiple images can be given for one texture at varying levels of detail. I won't cover that here and will just set one image for all levels of detail.

Creating a Texture Object

Textures are stored in texture objects that have to be created using an image with a known format, dimensions, and pixel values. Assuming you have stored the width, height, and image in the userData field of an esContext, where the format is known to be RGB as unsigned bytes, the code is as follows:

```
GLuint CreateSimpleTexture2D(ESContext *esContext)
   // Texture object handle
   GLuint textureId;
   UserData *userData = esContext->userData;
   char *pixels = userData->image;
   // Use tightly packed data
   glPixelStorei ( GL UNPACK ALIGNMENT, 1 );
   // Generate a texture object
   glGenTextures ( 1, &textureId );
   // Bind the texture object
   glBindTexture ( GL TEXTURE 2D, textureId );
   // Load the texture
   glTexImage2D ( GL TEXTURE 2D, 0, GL RGB,
                  userData->width, userData->height,
                  O, GL RGB, GL UNSIGNED BYTE, pixels );
   // Set the filtering mode
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MIN FILTER, GL NEAREST );
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MAG FILTER, GL NEAREST );
   return textureId;
}
```

Texture Attributes and the Shaders

Two-dimensional textures will only need (x, y) values as coordinates, unlike vertex coordinates that are described by four coordinates (x, y, z, w). The vertices of the 2D texture will need to be fed into the vertex shaders in order that the texture can be properly located within the final rendering. This will need a parameter within the shader of type vec2. The texture coordinates are limited to the square with vertices (0,0),(1,0),(0,1), and (1,1).

The fragment shader will need a varying texture coordinate, which would be initialized by the vertex shader but then interpolated. This will need to be integrated with the image pixel values, and this is done by a fragment shader function texture2D.

The vertex shader program will typically look like this:

```
attribute vec4 a position;
      attribute vec2 a texCoord;
      varying vec2 v texCoord;
      void main()
      {
         gl Position = a position;
         v texCoord = a texCoord;
      }
    The fragment shader will be as follows:
      precision mediump float;
      varying vec2 v texCoord;
      uniform sampler2D s texture;
      void main()
      {
        gl_FragColor = texture2D( s_texture, v_texCoord );
    These are all combined into a revised Init function as follows:
int Init ( ESContext *esContext )
{
    UserData *userData = esContext->userData;
    GLbyte vShaderStr[] =
      "attribute vec4 a_position;
                                      \n"
      "attribute vec2 a texCoord;
                                     \n"
      "varying vec2 v texCoord;
                                     \n"
      "void main()
                                      \n"
      "{
"
                                     \n"
          gl Position = a position; \n"
                                     \n"
          v_texCoord = a_texCoord;
                                      \n";
    GLbyte fShaderStr[] =
      "precision mediump float;
                                                              \n"
      "varying vec2 v_texCoord;
                                                              \n"
      "uniform sampler2D s_texture;
                                                              \n"
      "void main()
                                                              \n"
                                                              \n"
         gl_FragColor = texture2D( s_texture, v_texCoord );\n"
                                                              \n";
   // Load the shaders and get a linked program object
   userData->programObject = esLoadProgram ( vShaderStr, fShaderStr );
```

```
// Get the attribute locations
userData->positionLoc = glGetAttribLocation ( userData->programObject, "a_position" );
userData->texCoordLoc = glGetAttribLocation ( userData->programObject, "a_texCoord" );

// Get the sampler location
userData->samplerLoc = glGetUniformLocation ( userData->programObject, "s_texture" );

// Load the texture
userData->textureId = CreateSimpleTexture2D (esContext);

glClearColor ( 0.of, 0.of, 0.of, 0.of );
return GL_TRUE;
}
```

Drawing the Texture

To draw, you need to pass in the vertex coordinates. You will draw a square for the vertices. For the texture coordinates, you also need to specify their four coordinates. This could be done using two arrays as follows:

More commonly, these arrays would be interleaved as follows:

(Note that you are rendering the texture upside down to compensate for it being upside down relative to OpenGL ES coordinates.)

The question then is how to get—separately—the two sets of vertices. This is where the stride parameter comes into play in the call to glVertexAttribPointer. Basically, you want to say the following:

```
Each vertex co-ordinate occurs in a set of three in every five values,
    starting at index zero
Each texture co-ordinate occurs in a set of two in every five values,
    starting at index three
```

```
The code for this is as follows:
  // Load the vertex position
  glVertexAttribPointer ( userData->positionLoc, 3, GL_FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), &vVertices[0] );
  // Load the texture coordinate
  glVertexAttribPointer ( userData-gt;texCoordLoc, 2, GL FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), &vVertices[3] );
    The drawing code is then as follows:
void Draw ( ESContext *esContext )
  UserData *userData = esContext->userData;
  GLfloat vVertices[] = { -0.5f, 0.5f, 0.0f, // Position 0
                           0.0f, 1.0f, // TexCoord 0
                           -0.5f, -0.5f, 0.0f, // Position 1
                           0.0f, 0.0f,
                                              // TexCoord 1
                           0.5f, -0.5f, 0.0f, // Position 2
                           1.0f, 0.0f, // TexCoord 2
                           0.5f, 0.5f, 0.0f, // Position 3
                           1.0f, 1.0f // TexCoord 3
                        }:
  GLushort indices[] = { 0, 1, 2, 0, 2, 3 };
  // Set the viewport
  glViewport ( 0, 0, esContext->width, esContext->height );
  // Clear the color buffer
  glClear ( GL COLOR BUFFER BIT );
  // Use the program object
  glUseProgram ( userData->programObject );
  // Load the vertex position
  glVertexAttribPointer ( userData->positionLoc, 3, GL FLOAT,
                          GL_FALSE, 5 * sizeof(GLfloat), vVertices );
  // Load the texture coordinate
  glVertexAttribPointer ( userData->texCoordLoc, 2, GL FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), &vVertices[3] );
  glEnableVertexAttribArray ( userData->positionLoc );
  glEnableVertexAttribArray ( userData->texCoordLoc );
  // Bind the texture
  glActiveTexture ( GL_TEXTURE0 );
  glBindTexture ( GL TEXTURE 2D, userData->textureId );
```

```
// Set the sampler texture unit to 0
glUniform1i ( userData->samplerLoc, 0 );
glDrawElements ( GL_TRIANGLES, 6, GL_UNSIGNED_SHORT, indices );
}
```

Complete Code for Drawing an Image

The final code is Simple_Image.c. There appears to be a minor bug in the function esLoadTGA in the Common/esUtil.c file. It gets the colors of the image a little wrong.

```
// Authors: Aaftab Munshi, Dan Ginsburg, Dave Shreiner
// Copyright: the authors and Jan Newmarch
// Simple Image.c
//
//
      This is a simple example that draws an image with a 2D
//
      texture image.
//
#include <stdlib.h>
#include <stdio.h>
#include "esUtil.h"
typedef struct
   // Handle to a program object
  GLuint programObject;
   // Attribute locations
   GLint positionLoc;
   GLint texCoordLoc;
   // Sampler location
   GLint samplerLoc;
   // Texture handle
   GLuint textureId;
   GLubyte *image;
    int width, height;
} UserData;
///
// Create a simple 2x2 texture image with four different colors
GLuint CreateSimpleTexture2D(ESContext *esContext)
   // Texture object handle
   GLuint textureId;
   UserData *userData = esContext->userData;
```

```
GLubyte *pixels = userData->image;
   userData->width = esContext->width;
   userData->height = esContext->height;
   // Use tightly packed data
   glPixelStorei ( GL UNPACK ALIGNMENT, 1 );
   // Generate a texture object
   glGenTextures ( 1, &textureId );
   // Bind the texture object
   glBindTexture ( GL_TEXTURE_2D, textureId );
   // Load the texture
   glTexImage2D ( GL TEXTURE 2D, 0, GL RGB,
                  userData->width, userData->height,
                  0, GL RGB, GL UNSIGNED BYTE, pixels );
   // Set the filtering mode
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MIN FILTER, GL NEAREST );
   glTexParameteri ( GL TEXTURE_2D, GL_TEXTURE_MAG_FILTER, GL_NEAREST );
   return textureId;
}
///
// Initialize the shader and program object
//
int Init ( ESContext *esContext )
    UserData *userData = esContext->userData;
    GLbyte vShaderStr[] =
      "attribute vec4 a_position;
                                     \n"
      "attribute vec2 a texCoord;
                                     \n"
      "varying vec2 v texCoord;
                                     \n"
      "void main()
                                     \n"
      "{
"
                                     \n"
          gl Position = a position; \n"
          v_texCoord = a_texCoord; \n"
                                     \n";
    GLbyte fShaderStr[] =
      "precision mediump float;
                                                            \n"
      "varying vec2 v_texCoord;
                                                            \n"
      "uniform sampler2D s_texture;
                                                             \n"
      "void main()
                                                            \n"
      "{
"
                                                            \n"
         gl_FragColor = texture2D( s_texture, v_texCoord );\n"
```

```
// Load the shaders and get a linked program object
  userData->programObject = esLoadProgram ( vShaderStr, fShaderStr );
  // Get the attribute locations
  userData->positionLoc = glGetAttribLocation ( userData->programObject, "a_position" );
  userData->texCoordLoc = glGetAttribLocation ( userData->programObject, "a texCoord" );
  http://www.netmanners.com/e-mail-etiquette-tips/
  // Get the sampler location
  userData->samplerLoc = glGetUniformLocation ( userData->programObject, "s texture" );
  // Load the texture
  userData->textureId = CreateSimpleTexture2D (esContext);
  glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
  return GL TRUE;
}
// Draw a triangle using the shader pair created in Init()
void Draw ( ESContext *esContext )
  UserData *userData = esContext->userData;
  GLfloat vVertices[] = { -0.5f, 0.5f, 0.0f, // Position 0
                           0.0f, 1.0f, // TexCoord 0
                          -0.5f, -0.5f, 0.0f, // Position 1
                           0.0f, 0.0f,
                                        // TexCoord 1
                           0.5f, -0.5f, 0.0f, // Position 2
                           1.0f, 0.0f, // TexCoord 2
                           0.5f, 0.5f, 0.0f, // Position 3http://www.netmanners.com/
                                                 e-mail-etiquette-tips/
                           1.0f, 1.0f // TexCoord 3
                        };
  GLushort indices[] = { 0, 1, 2, 0, 2, 3 };
  // Set the viewport
  glViewport ( 0, 0, esContext->width, esContext->height );
  // Clear the color buffer
  glClear ( GL_COLOR_BUFFER_BIT );
  // Use the program object
  glUseProgram ( userData->programObject );
  // Load the vertex position
  glVertexAttribPointer ( userData->positionLoc, 3, GL_FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), vVertices );
  // Load the texture coordinate
  glVertexAttribPointer ( userData->texCoordLoc, 2, GL_FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), &vVertices[3] );
```

```
glEnableVertexAttribArray ( userData->positionLoc );
   glEnableVertexAttribArray ( userData->texCoordLoc );
   // Bind the texture
   glActiveTexture ( GL TEXTURE0 );
   glBindTexture ( GL TEXTURE 2D, userData->textureId );
   // Set the sampler texture unit to 0
   glUniform1i ( userData->samplerLoc, 0 );
   glDrawElements ( GL TRIANGLES, 6, GL UNSIGNED SHORT, indices );
}
///
// Cleanup
//
void ShutDown ( ESContext *esContext )
   UserData *userData = esContext->userData;
   // Delete texture object
   glDeleteTextures ( 1, &userData->textureId );
   // Delete program object
   glDeleteProgram ( userData->programObject );
   free(esContext->userData);
}
int main ( int argc, char *argv[] )
{
   ESContext esContext;
   UserData userData;
   int width, height;
   GLubyte *image;
   image = esLoadTGA("jan.tga", &width, &height);
   if (image == NULL) {
       fprintf(stderr, "No such image\n");
      exit(1);
   }
   printf("Width %d height %d\n", width, height);
   userData.image = image;
   userData.width = width;
   userData.height = height;
   esInitContext ( &esContext );
   esContext.userData = &userData;
```

```
esCreateWindow ( &esContext, "Simple Texture 2D", width, height, ES_WINDOW_RGB );
if ( !Init ( &esContext ) )
    return 0;
esRegisterDrawFunc ( &esContext, Draw );
esMainLoop ( &esContext );
ShutDown ( &esContext );
}
```

Run this by Simple Image. The image used is of me since that is possibly more interesting than a wall tile.

Animation: Rotating an Image

In this section, you will take a brief look at some of the issues and techniques in animating the graphics display. As you will have seen from multiple computer games and digital movies, the animations can be amazingly sophisticated and also involve much programmer time, program complexity, and CPU/GPU time. You will do about the simplest: make the image of the previous section rotate around an axis.

Matrices

I cut my teeth on matrices years ago writing programs in Algol 60 to solve simultaneous linear equations. Now it is easier, with libraries to manage most calculations. You will use various ES functions from the Munshi et al. book to simplify things.

There are several primary operations you can carry out on graphic images to fit them into scenes: you can rotate them, move them nearer or further, apply perspective views so that the "parallel lines meet at the horizon," or do any other effects you may choose.

The operations are carried out on vectors such as the (x, y, z, w) coordinates of a vertex. The operations are represented by *matrices* that are square (or rectangular) arrays of numbers. The main operation is to *multiply* a *vector* by a *matrix*. Any book on linear algebra will give details on how to do this.

esUtil

These are the principal functions supplied by the esUtil package:

- Create an identity matrix with esMatrixLoadIdentity
- Multiply two matrices with esMatrixMultiply
- Translate a vector from one point to another with esTranslate
- Rotate a matrix through an angle around an axis with esRotate
- Scale a matrix by a factor with esScale
- Multiply a matrix by a perspective matrix with esPerspective

These may remove the need to explicitly specify actual matrices.

Invoking Animation

You already have a Draw function. You add to this an Update function to make the changes needed for the next Draw:

```
esRegisterDrawFunc ( &esContext, Draw );
esRegisterUpdateFunc ( &esContext, Update );

The Update function for a simple rotation can be as follows:

void Update ( ESContext *esContext, float deltaTime )
{
   UserData *userData = (UserData*) esContext->userData;

   // Compute a rotation angle based on time to rotate the cube userData->angle += ( deltaTime * 40.0f );
   if( userData->angle >= 360.0f )
        userData->angle -= 360.0f;

   // Generate an identity matrix before rotating the square esMatrixLoadIdentity( &userData->rotateMx );

   // Rotate the square about the (1, 0, 1) axis esRotate( &userData->rotateMx, userData->angle, 1.0, 0.0, 1.0 );
}
```

This uses a current rotation angle stored in userData and applies it to an identity matrix about a vector specified here as (x, y, z) = (1.0, 0.0, 1.0).

Uniform Parameters: The Rotation Matrix

If you are rotating an entire image, the rotation has to be applied to every pixel in the drawn image, and it is the same rotation matrix in each case. So, this matrix needs to be constant over all the vertex and fragment shaders. Such a matrix is a *uniform* parameter and is specified as such in both the vertex and fragment shaders.

Working out the value of a uniform parameter is something that needs to be done *once* in each drawing iteration; so, it is done in the application's Update C code, not in the shaders. It is then passed in as a parameter on each draw call by glUniformMatrix4fv.

Extra fields are added to UserData for the rotation angle and rotation matrix. Apart from that and the earlier changes, the standard program structure holds. The program to rotate an image loaded from a TGA file is Rotate_Image.c.

```
//
// Book: OpenGL(R) ES 2.0 Programming Guide
// Authors: Aaftab Munshi, Dan Ginsburg, Dave Shreiner
// ISBN-10: 0321502795
// ISBN-13: 9780321502797
// Publisher: Addison-Wesley Professional
// URLs: http://safari.informit.com/9780321563835
// http://www.opengles-book.com
//
```

```
// Simple_Texture2D.c
//
//
      This is a simple example that draws a quad with a 2D
//
      texture image. The purpose of this example is to demonstrate
      the basics of 2D texturing
//
//
#include <stdlib.h>
#include <stdio.h>
#include "esUtil.h"
typedef struct
   // Handle to a program object
   GLuint programObject;
   // Attribute locations
   GLint positionLoc;
  GLint texCoordLoc;
   // Uniform locations
  GLint rotateLoc;
   // Sampler location
   GLint samplerLoc;
   // Texture handle
   GLuint textureId;
   GLubyte *image;
    int width, height;
   // Rotation angle
   GLfloat angle;
   // rotate matrix
   ESMatrix rotateMx;
} UserData;
///
// Create a simple 2x2 texture image with four different colors
GLuint CreateSimpleTexture2D(ESContext *esContext)
   // Texture object handle
   GLuint textureId;
  UserData *userData = esContext->userData;
   // 2x2 Image, 3 bytes per pixel (R, G, B)
   GLubyte pixels[4 * 3] =
```

```
{
      255, 0, 0, // Red
       0, 255, 0, // Green
       0, 0, 255, // Blue
      255, 255, 0 // Yellow
   userData->width = 2;
   userData->height = 2;
   GLubyte *pixels = userData->image;
   userData->width = esContext->width;
   userData->height = esContext->height;
#endif
   // Use tightly packed data
   glPixelStorei ( GL UNPACK ALIGNMENT, 1 );
   // Generate a texture object
   glGenTextures ( 1, &textureId );
   // Bind the texture object
   glBindTexture ( GL_TEXTURE_2D, textureId );
   // Load the texture
   glTexImage2D ( GL TEXTURE 2D, 0, GL RGB,
                  userData->width, userData->height,
                  0, GL RGB, GL UNSIGNED BYTE, pixels );
   // Set the filtering mode
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MIN FILTER, GL NEAREST );
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MAG FILTER, GL NEAREST );
  return textureId;
}
///
// Initialize the shader and program object
int Init ( ESContext *esContext )
{
    UserData *userData = esContext->userData;
    GLbyte vShaderStr[] =
      "uniform mat4 u rotateMx;
                                                 \n"
      "attribute vec4 a_position;
                                                 \n"
                                                 \n"
      "attribute vec2 a texCoord;
      "varying vec2 v_texCoord;
                                                 \n"
      "void main()
                                                 \n"
      "{
"
                                                 \n"
         gl_Position = u_rotateMx * a_position; \n"
         v_texCoord = a_texCoord;
                                                 \n"
                                                 \n";
```

```
GLbyte fShaderStr[] =
      "precision mediump float;
                                                           \n"
      "varying vec2 v texCoord;
                                                           \n"
      "uniform sampler2D s_texture;
                                                           \n"
     "void main()
                                                           \n"
                                                           \n"
        gl_FragColor = texture2D( s_texture, v_texCoord );\n"
   // Load the shaders and get a linked program object
   userData->programObject = esLoadProgram ( vShaderStr, fShaderStr );
   // Get the attribute locations
   userData->positionLoc = glGetAttribLocation ( userData->programObject, "a position" );
   userData->texCoordLoc = glGetAttribLocation ( userData->programObject, "a texCoord" );
   userData->rotateLoc = glGetUniformLocation( userData->programObject, "u_rotateMx" );
   // Starting rotation angle for the square
   userData->angle = 0.0f;
   // Get the sampler location
   userData->samplerLoc = glGetUniformLocation ( userData->programObject, "s texture" );
   // Load the texture
   userData->textureId = CreateSimpleTexture2D (esContext);
  glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
  return GL_TRUE;
}
111
// Update rotate matrix based on time
void Update ( ESContext *esContext, float deltaTime )
{
  UserData *userData = (UserData*) esContext->userData;
   // Compute a rotation angle based on time to rotate the cube
   userData->angle += ( deltaTime * 40.0f );
   if( userData->angle >= 360.0f )
     userData->angle -= 360.0f;
   // Generate an identity matrix before rotating the square
  esMatrixLoadIdentity( &userData->rotateMx );
  // Rotate the square
  esRotate( &userData->rotateMx, userData->angle, 1.0, 0.0, 1.0);
}
```

```
///
// Draw a triangle using the shader pair created in Init()
void Draw ( ESContext *esContext )
  UserData *userData = esContext->userData;
  GLfloat vVertices[] = \{ -0.5f, 0.5f, 0.0f, // Position 0 \}
                           0.0f, 1.0f,
                                          // TexCoord 0
                          -0.5f, -0.5f, 0.0f, // Position 1
                           0.0f, 0.0f,
                                              // TexCoord 1
                           0.5f, -0.5f, 0.0f, // Position 2
                           1.0f, 0.0f,
                                              // TexCoord 2
                           0.5f, 0.5f, 0.0f, // Position 3
                           1.0f, 1.0f // TexCoord 3
  GLushort indices[] = { 0, 1, 2, 0, 2, 3 };
  // Set the viewport
  glViewport ( 0, 0, esContext->width, esContext->height );
  // Clear the color buffer
  glClear ( GL_COLOR_BUFFER_BIT );
  // Use the program object
  glUseProgram ( userData->programObject );
  // Load the vertex position
  glVertexAttribPointer ( userData->positionLoc, 3, GL_FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), vVertices );
  // Load the texture coordinate
  glVertexAttribPointer ( userData->texCoordLoc, 2, GL FLOAT,
                          GL FALSE, 5 * sizeof(GLfloat), &vVertices[3] );
  glEnableVertexAttribArray ( userData->positionLoc );
  glEnableVertexAttribArray ( userData->texCoordLoc );
  // Load the rotate matrix
  glUniformMatrix4fv( userData->rotateLoc, // userData->mvpLoc,
                      1, GL FALSE, (GLfloat*) &userData->rotateMx.m[0][0] );
  // Bind the texture
  glActiveTexture ( GL TEXTUREO );
  glBindTexture ( GL_TEXTURE_2D, userData->textureId );
  // Set the sampler texture unit to 0
  glUniform1i ( userData->samplerLoc, 0 );
  glDrawElements ( GL TRIANGLES, 6, GL UNSIGNED SHORT, indices );
}
```

```
111
// Cleanup
void ShutDown ( ESContext *esContext )
  UserData *userData = esContext->userData;
  // Delete texture object
  glDeleteTextures ( 1, &userData->textureId );
   // Delete program object
  glDeleteProgram ( userData->programObject );
  free(esContext->userData);
}
int main ( int argc, char *argv[] )
   ESContext esContext;
  UserData userData;
   int width, height;
  GLubyte *image;
   image = esLoadTGA("jan.tga", &width, &height);
   if (image == NULL) {
       fprintf(stderr, "No such image\n");
      exit(1);
  printf("Width %d height %d\n", width, height);
  userData.image = image;
   userData.width = width;
   userData.height = height;
  esInitContext ( &esContext );
  esContext.userData = &userData;
  esCreateWindow ( &esContext, "Simple Texture 2D", width, height, ES WINDOW RGB );
   if ( !Init ( &esContext ) )
     return 0;
  esRegisterDrawFunc ( &esContext, Draw );
  esRegisterUpdateFunc ( &esContext, Update );
  esMainLoop ( &esContext );
   ShutDown ( &esContext );
}
```

Run this by Rotate_Image. It shows the picture of me in a rotating square.

Conclusion

OpenGL ES is an amazingly complex and sophisticated system that I have made a small attempt to explain. This chapter covered drawing on the EGL surface discussed in earlier chapters and showed a number of relatively simple cases. These have been standard OpenGL ES; the only RPi-specific part has been the EGL surface.

Resources

- OpenGL ES Shading Language: https://www.khronos.org/files/opengles_ shading language.pdf
- OpenGLES Specification: https://www.khronos.org/registry/gles/specs/2.0/ es full spec 2.0.25.pdf
- openGL-RPi-tutorial: https://github.com/peepo/openGL-RPi-tutorial
- OpenMAX+GLES2: Decode and render JPEG (with source code): jpeg_gles2: www.raspberrypi.org/forums/viewtopic.php?f=33&t=57721
- Using OpenGL ES 2.0 on the Raspberry Pi without X windows: http://benosteen.wordpress.com/2012/04/27/using-opengl-es-2-0-on-the-raspberry-pi-without-x-windows/
- KHR_image_base describes EGLImageKHR type: www.khronos.org/registry/egl/ extensions/KHR/EGL KHR image base.txt
- OpenGL Programming/Modern OpenGL Tutorial Text Rendering 01: http:// en.wikibooks.org/wiki/OpenGL_Programming/Modern_OpenGL_Tutorial_Text_ Rendering_01
- Using OpenGL ES to Accelerate Apps with Legacy 2D GUIs: https://software.intel.com/en-us/articles/using-opengl-es-to-accelerate-apps-with-legacy-2d-guis
- glEGLImageTargetTexture2DOES: http://e2e.ti.com/support/dsp/omap_applications_processors/f/447/t/81109.aspx
- Raspberry Pi VideoCore APIs: http://elinux.org/Raspberry_Pi_VideoCore_APIs
- OpenGL* ES 2.0 Programming Guide by Aaftab Munshi, Dan Ginsburg and Dave Shreiner: http://opengles-book.com/es2/index.html
- opengles-book-samples: https://code.google.com/p/opengles-book-samples/ source/checkout
- TGA File Format Summary: www.fileformat.info/format/tga/egff.htm
- Raspberry Pi OpenGL ES forum: www.raspberrypi.org/forums/viewforum. php?f=68
- OpenGL ES 2.0 for iOS, Chapter 4 Introducing the Programmable Pipeline: http://iphonedevelopment.blogspot.com.au/2010/11/opengl-es-20-for-ios-chapter-4.html


CHAPTER 7

OpenMAX on the Raspberry Pi Concepts

This chapter gives a brief overview of OpenMAX IL on the Raspberry Pi. It looks at the component model and the processing model. Further details are given in later chapters.

OpenMAX Overview

OpenMAX is designed to play audio and video. It consists of three layers.



OpenMAX Media Portability Library

Figure 7-1. OpenMAX APIs

© Jan Newmarch 2017 79

The preferred programming layer is OpenMAX AL, the application layer. Unfortunately, the RPi does not support OpenMAX AL. What it does support is OpenMAX IL, the integration layer. Now this isn't nice to program to, as the following quotes from GitHub attest:

- According to jamesh, "OpenMAX is a complete and utter nightmare to use btw."
- According to dom, "I have written a fair bit of openmax client code and find it very
 hard. You have to get an awful lot right before you get anything useful out. Just lots
 of OMX_ErrorInvalidState and OMX_ErrorBadParameter messages if you are lucky.
 Nothing happening at all if you are not...."
- According to Twinkletoes, "I'm from a DirectShow background, and I thought that
 was badly documented...then I met OpenMax. Lots of ppts saying lovely things about
 it but no documentation or code examples I can find."

My own experience backs up these quotes, sadly. I've spent hours staring blankly at a screen, with the specification on one side and the debugger open on the other. It's a hard and rocky road ahead.

OpenMAX Concepts

The basic concept is of a *component*, which is an audio/video (or other) processing unit of some type, such as a volume control, a mixer, and an output device. Each component has zero or more input and output *ports*. Each port has a type, such as an audio port, a video port, or a timer port. The type is important: you manipulate different types with different structures. Each port can have one or more *buffers* that carry data either into or out of a component.

OpenMAX IL components use buffers to carry data. A component will usually process data from an input buffer and place it on an output buffer. This processing is not visible to the API, so it allows vendors to implement components in hardware or software, built on top of other A/V components, and so on. OpenMAX IL gives mechanisms for setting and getting parameters of components, for calling standard functions on the components, or for getting data in and out of components.

While some of the OpenMAX IL calls are synchronous, those that require possibly substantial amounts of processing are asynchronous, communicating the results through callback functions. This leads naturally to a multithreaded processing model, although OpenMAX IL does not visibly use any thread libraries and should be agnostic to how an IL client uses threads. The Broadcom examples for the Raspberry Pi use Broadcom's VideoCore OS (VCOS) threads.

There are two mechanisms for getting data into and out of components. The first is where the IL client makes calls on the component. All components are required to support this mechanism. The second is where a *tunnel* is set up between two components for data to flow along a shared buffer. A component is not required to support this mechanism, but the Broadcom ones do.

Once you have everything set up, the typical programming model for OpenMAX is as follows:

- Keep loading input buffers with data.
- Once an input buffer is loaded, ask the component to empty the buffer.
- Whenever a component empties the input buffer, it will call a function in the client, at which point the client can fill it again.
- Internal component processing will occur, and at some stage the component will fill
 one or more of its output buffers.

- When an output buffer is filled, the component will call another function in the client.
- The client will do something with the output buffer data and then return the buffer to the component to fill again.

There is, however, an immense amount of detail to each of these steps. It becomes more complex if a "pipeline" of components is involved, such as a decoder feeding into a format converter feeding into a rendering component. However, the principles are basically unchanged.

Conclusion

This chapter has given a brief overview of the architecture of OpenMAX IL. Later chapters will flesh this out in full detail.

Resources

- Raspberry Pi Video on a Teapot Rendering OpenMAX onto an OpenGL surface: https://www.youtube.com/watch?v=-y3m HFg4Do
- OpenMax rendering onto OpenGL texture: www.raspberrypi.org/forums/ viewtopic.php?t=6577
- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- Decoding and Rendering to Texture H264 with OpenMAX on Raspberry Pi: http:// thebugfreeblog.blogspot.com.au/2012/12/decoding-and-rendering-totexture-h264.html

CHAPTER 8

OpenMAX Components on the Raspberry Pi

OpenMAX uses components as the objects in its processing model. There is a large list of standard components. The Broadcom implementation on the Raspberry Pi has only a subset of these, plus some others. This chapter shows how to list the available components and get some of their properties.

Building Programs

The programs in this chapter can be built using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)
CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OMX_LIBS = -lopenmaxil

LDFLAGS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS)
SRC = info.c listcomponents.c portinfo.c

EXE = info listcomponents portinfo
all: $(EXE)
```

OpenMAX IL Components


OpenMAX IL in 1.1.2 lists a number of standard components, including a decoder, an encoder, a mixer, a reader, a renderer, a writer, a capturer, and a processor. An IL client gets such a component by calling OMX_GetHandle(), passing in the name of the component. This is a problem: the components do not have a standard name. The 1.1.2 specification says the following:

© Jan Newmarch 2017

Since components are requested by name, a naming convention is defined. OpenMAX IL component names are zero-terminated strings with the following format: "OMX.<vendor_name>.<vendor_specified_convention>." For example: OMX.CompanyABC.MP3Decoder. productXYZ.

No standardization among component names is dictated across different vendors.

The Broadcom OpenMAX IL components used on the Raspberry Pi are documented at the VMCS-X OpenMAX IL Components page (http://home.nouwen.name/RaspberryPi/documentation/ilcomponents/index.html). For example, that page shows a visualization component as look like this:



This has two audio ports (green), an input port 140 and an output port 141; a timer port (yellow), number 143; and a video output port (red), number 142. Clicking this component shows further details including the parameters that can be queried or set.

The detail view also shows the name of the component, which is used to look up the component. For the visualization component, its name is OMX.broadcom.visualisation.

Getting a List of Components

There is a simple way of programmatically getting the supported components. First initialize the OpenMAX system with OMX_init() and then make calls to OMX_ComponentNameEnum(). For successive index values, it returns a unique name each time, until it finally returns an error value of OMX_ErrorNoMore.

Each component may support a number of *roles*. These are given by OMX_GetRolesOfComponent. The Broadcom version has zero roles for each component, so it isn't useful for the RPi.

The program is listcomponents.c.

```
#include <stdio.h>
#include <oMX_Core.h>
#include <omx_Core.h>
#include <bcm_host.h>

OMX_ERRORTYPE err;

void listroles(char *name) {
    int n;
    OMX_U32 numRoles;
    OMX_U8 *roles[32];

    /* get the number of roles by passing in a NULL roles param */
    err = OMX_GetRolesOfComponent(name, &numRoles, NULL);
    if (err != OMX_ErrorNone) {
        fprintf(stderr, "Getting roles failed\n", 0);
        exit(1);
    }
}
```

```
printf(" Num roles is %d\n", numRoles);
    if (numRoles > 32) {
        printf("Too many roles to list\n");
        return;
    }
    /* now get the roles */
    for (n = 0; n < numRoles; n++) {
        roles[n] = malloc(OMX MAX STRINGNAME SIZE);
   err = OMX GetRolesOfComponent(name, &numRoles, roles);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Getting roles failed\n", 0);
        exit(1);
    for (n = 0; n < numRoles; n++) {
        printf("
                   role: %s\n", roles[n]);
        free(roles[n]);
    }
    /* This is in version 1.2
   for (i = 0; OMX_ErrorNoMore != err; i++) {
        err = OMX RoleOfComponentEnum(role, name, i);
        if (OMX ErrorNone == err) {
            printf(" Role of omponent is %s\n", role);
        }
    }
    */
}
int main(int argc, char** argv) {
    unsigned char name[OMX MAX STRINGNAME SIZE];
   bcm host init();
   err = OMX Init();
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX_Init() failed\n", 0);
        exit(1);
    }
   err = OMX ErrorNone;
   for (i = 0; OMX ErrorNoMore != err; i++) {
        err = OMX ComponentNameEnum(name, OMX_MAX_STRINGNAME_SIZE, i);
        if (OMX ErrorNone == err) {
            printf("Component is %s\n", name);
            listroles(name);
        }
   printf("No more components\n");
   exit(0);
}
```

The following is the Makefile for the programs in this chapter:

The listcomponents program is run with the following:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2

OMX_LIBS = -lopenmaxil

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS)

SRC = info.c listcomponents.c portinfo.c
EXE = info listcomponents portinfo
all: $(EXE)
```

./listcomponents

The Raspberry Pi reports a large number of components but does not define a role for any of them.

```
Component is OMX.broadcom.audio capture
  Num roles is 0
Component is OMX.broadcom.audio decode
  Num roles is 0
Component is OMX.broadcom.audio encode
  Num roles is 0
Component is OMX.broadcom.audio render
  Num roles is 0
Component is OMX.broadcom.audio_mixer
  Num roles is 0
Component is OMX.broadcom.audio splitter
  Num roles is 0
Component is OMX.broadcom.audio processor
  Num roles is 0
Component is OMX.broadcom.camera
  Num roles is 0
Component is OMX.broadcom.clock
  Num roles is 0
Component is OMX.broadcom.coverage
  Num roles is 0
Component is OMX.broadcom.egl render
  Num roles is 0
Component is OMX.broadcom.image fx
```

```
Num roles is 0
Component is OMX.broadcom.image_decode
 Num roles is 0
Component is OMX.broadcom.image encode
 Num roles is 0
Component is OMX.broadcom.image read
 Num roles is 0
Component is OMX.broadcom.image write
 Num roles is 0
Component is OMX.broadcom.read media
 Num roles is 0
Component is OMX.broadcom.resize
 Num roles is 0
Component is OMX.broadcom.source
 Num roles is 0
Component is OMX.broadcom.text scheduler
 Num roles is 0
Component is OMX.broadcom.transition
 Num roles is 0
Component is OMX.broadcom.video decode
 Num roles is 0
Component is OMX.broadcom.video encode
 Num roles is 0
Component is OMX.broadcom.video render
 Num roles is 0
Component is OMX.broadcom.video scheduler
 Num roles is 0
Component is OMX.broadcom.video splitter
 Num roles is 0
Component is OMX.broadcom.visualisation
 Num roles is 0
Component is OMX.broadcom.write media
 Num roles is 0
Component is OMX.broadcom.write still
 Num roles is 0
No more components
```

Getting a Handle to a Component

Before you can do anything with a component (apart from getting its name earlier), you need to get a *handle* to it. The call OMX_GetHandle takes four parameters.

- A pointer to the handle, which will be filled in by the call.
- The name of the component.
- Application callback data. This is used to pass information from this part of the program to later stages that are called asynchronously through events. Ignore it for now and set it to NULL.
- A pointer to a structure of callback functions. These are used extensively when doing
 event and buffer processing, but you aren't going to do that yet. For now you will set
 it to a struct of NULL functions.

Port Information

Ports are the means by which a component communicates, where clients pass data into a port's input buffers and receive processed data back from a port's output buffers.

OpenMAX uses an OMX_PARAM_PORTDEFINITIONTYPE struct to keep port information. This is a complex structure, found in the OMX_Component.h file and in section 3.1.2.12 of the 1.1.2 specification.

All of the OpenMAX structures, just like this one, have as their first field the size of the structure and as the second field the version of OpenMAX that is being used. Before any struct is used, these must be initialized. It is also a good idea to ensure the structure is zeroed out.

```
struct OMX_PARAM_PORTDEFINITIONTYPE portdef;
memset(&portdef, 0, sizeof(OMX_PARAM_PORTDEFINITIONTYPE));
portdef.nSize = sizeof(OMX_PARAM_PORTDEFINITIONTYPE);
portdef.nVersion.nVersion = OMX_VERSION;
```

The next most important parameter is the index number of the port we are interested in.

One way of finding this is from the documentation mentioned earlier. For example, if you were querying the video port of the visualization component, you would specify this video port with the following:

```
portdef.nPortIndex = 142;
```

There are other ways, which will be discussed later when you look at particular port types. Each port has buffers. Information about these buffers is stored in the next set of fields:

```
OMX_U32 nBufferCountActual; /** The actual number of buffers allocated on this port */
OMX_U32 nBufferCountMin; /** The minimum number of buffers this port requires */
OMX_U32 nBufferSize; /** Size, in bytes, for buffers to be used for this channel
*/
```

Ports have a state flag as to whether they are enabled or disabled. Components also have state. There is interaction between the port state and component state, and it's not nice. This will be dealt with in more detail in a later chapter. For now, you often toggle this between OMX_TRUE and OMX_FALSE.

```
OMX BOOL bEnabled;
```

The last important fields deal with the type of port. First, there is the direction: either $OMX_DirInput$ or $OMX_DirOutput$.

```
OMX DIRTYPE eDir;
```

Next is whether it is an audio (OMX_PortDomainAudio), video (OMX_PortDomainVideo), image (OMX_PortDomainImage), or other (OMX_PortDomainOther) port.

```
OMX PORTDOMAINTYPE eDomain
```

Finally, there is a union corresponding to each of these domains:

```
union {
   OMX_AUDIO_PORTDEFINITIONTYPE audio;
   OMX_VIDEO_PORTDEFINITIONTYPE video;
   OMX_IMAGE_PORTDEFINITIONTYPE image;
   OMX_OTHER_PORTDEFINITIONTYPE other;
} format;
```

Getting and Setting Parameters

OpenMAX has a standard way of getting and setting parameter information for all types such as OMX_PARAM_PORTDEFINITIONTYPE shown earlier. A handle to a component is required; this will have come from a call to OMX_GetHandle() earlier. Then for each type of struct there is a corresponding index value. For OMX_PARAM_PORTDEFINITIONTYPE, the index is OMX_IndexParamPortDefinition, with a similar pattern for other data types. (Strangely, the index OMX_IndexParamPortDefinition doesn't seem to be individually documented in the 1.1.2 specification. Oh well, it works anyway.)

A call to set a parameter value is described in section 3.2.2.8 of the 1.1.2 specification and is as follows:

Setting a parameter is described in section 3.2.2.9 of the 1.1.2 specification and is done with the following:

Getting Port Information

You can now combine the last three sections to allow a program to get the information about a particular port on a component and print it out. The program is portinfo.c, which takes a component name and a port index as parameters.

```
#include <stdio.h>
#include <stdlib.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
OMX ERRORTYPE get port info(OMX HANDLETYPE handle,
                            OMX PARAM PORTDEFINITIONTYPE *portdef) {
    return OMX GetParameter(handle,
                             OMX IndexParamPortDefinition,
                             portdef);
}
void print port info(OMX PARAM PORTDEFINITIONTYPE *portdef) {
    char *domain;
    printf("Port %d\n", portdef->nPortIndex);
    if (portdef->eDir == OMX DirInput) {
        printf(" is input port\n");
    } else {
        printf(" is output port\n");
    switch (portdef->eDomain) {
    case OMX PortDomainAudio: domain = "Audio"; break;
    case OMX PortDomainVideo: domain = "Video"; break;
    case OMX PortDomainImage: domain = "Image"; break;
    case OMX_PortDomainOther: domain = "Other"; break;
    printf(" Domain is %s\n", domain);
    printf(" Buffer count %d\n", portdef->nBufferCountActual);
    printf(" Buffer minimum count %d\n", portdef->nBufferCountMin);
    printf(" Buffer size %d bytes\n", portdef->nBufferSize);
}
OMX CALLBACKTYPE callbacks = { .EventHandler = NULL,
                                .EmptyBufferDone = NULL,
                                .FillBufferDone = NULL
};
```

```
int main(int argc, char** argv) {
    int i;
    char componentName[128]; // min space required see /opt/vc/include/IL/OMX_Core.h
                             // thanks to Peter Maersk-Moller
   OMX ERRORTYPE err;
   OMX HANDLETYPE handle;
   OMX_PARAM_PORTDEFINITIONTYPE portdef;
    OMX VERSIONTYPE specVersion, compVersion;
   OMX UUIDTYPE uid;
    int portindex;
    if (argc < 3) {
        fprintf(stderr, "Usage: %s component-name port-index\n", argv[0]);
       exit(1);
    strncpy(componentName, argv[1], 128);
    portindex = atoi(argv[2]);
    bcm host init();
   err = OMX_Init();
    if(err != OMX ErrorNone) {
        fprintf(stderr, "OMX Init() failed\n", 0);
       exit(1);
    /** Ask the core for a handle to the component
   err = OMX_GetHandle(&handle, componentName,
                        // the next two fields are discussed later
                        NULL, &callbacks);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX GetHandle failed\n", 0);
       exit(1);
    }
    // Get some version info
   err = OMX GetComponentVersion(handle, componentName,
                                  &compVersion, &specVersion,
                                  &uid);
    if (err != OMX_ErrorNone) {
        fprintf(stderr, "OMX GetComponentVersion failed\n", 0);
       exit(1);
    printf("Component name: %s version %d.%d, Spec version %d.%d\n",
           componentName, compVersion.s.nVersionMajor,
           compVersion.s.nVersionMinor,
           specVersion.s.nVersionMajor,
           specVersion.s.nVersionMinor);
```

```
memset(&portdef, 0, sizeof(OMX PARAM PORTDEFINITIONTYPE));
    portdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    portdef.nVersion.nVersion = OMX VERSION;
    portdef.nPortIndex = portindex;
    if (get port info(handle, &portdef) == OMX ErrorNone) {
        print port info(&portdef);
    }
    exit(0);
}
    When this is run, say with the following:
./portinfo OMX.broadcom.image decode 320
    it results in the following:
Component name: OMX.broadcom.image decode:12 version 0.0, Spec version 1.1
Port 320
  is input port
  Domain is Image
  Buffer count 3
  Buffer minimum count 2
  Buffer size 81920 bytes
```

(The component name has an integer field—here 12—that seems to increment by one each time it is run.)

Getting Information About Specific Types of Port

In the previous section, you specified the port of a component explicitly. You aren't likely to sit there with the specification handy just to input port numbers. You want to be able to determine valid port numbers programmatically.

Unfortunately, you can't just ask for a list of valid ports. What you can do is ask for a list of *audio* ports, a list of *video* ports, a list of *image* ports, and a list of valid *other* ports.

Getting such a list is done using a new data structure, the OMX_PORT_PARAM_TYPE. This is described in the file OMX_Core.h and is pretty simple.

This structure is filled using a call to OMX_GetParameter as usual, but with an index appropriate to the port type you want. These are as follows:

- For audio ports, the index is OMX IndexParamAudioInit.
- For video ports, the index is OMX IndexParamVideoInit.

- For image ports, the index is OMX_IndexParamImageInit.
- For other ports, the index is OMX_IndexParamOtherInit.

Here's an example to get the video ports:

Note that within each type of port, the values are consecutive. For example, video_splitter has five video ports starting at 250, so the port numbers are 250 through 254.

Note that all that this does is to get the range of port numbers for a particular type of port. If the number of ports returned is zero, there are no ports of this type. Also, to get actual information about each port, you still have to make a call to the following:

Detailed Audio Port Information

Each type of port (audio, video, image, or other) has a data structure for information specific to that type. For an audio port, the type is OMX_AUDIO_PORTDEFINITIONTYPE and is similar for the other types.

For an audio port, this information is returned as one of the union types in the OMX_PARAM_PORTDEFINITIONTYPE and can be filled in a call to the following, as in the previous program:

The information you want is the audio port information within the general port information. This part of the structure is as follows:

```
portdef.format.audio
```

(Remember, the audio port information is in a union with tag format and field audio.)

The OMX_AUDIO_PORTDEFINITIONTYPE type is described in section 4.1.5 of the 1.1.2 specification and has two important fields.

```
OMX_STRING cMIMEType;
OMX_AUDIO_CODINGTYPE eEncoding;
```

On the RPi, MIMEType is NULL, which it shouldn't really be. I don't think it will get fixed.

The encoding is an enumerated data type. There are a large number of possible values, given in section 4.1.3 of the 1.1.2 specification. The types include PCM (pulse code modulated), AAC, MP3, Vorbis, and WMA. These are also defined in the header file /opt/vc/include/IL/OMX Audio.h.

Here is where it gets a bit more interesting: that header file not only defines the "standard" OMX audio coding types but also defines an extra set: FLAC, DDP, DTS, and so on (none of which I have heard of). They are defined as part of the OMX_AUDIO_CODINGTYPE enumeration, in the section "Reserved region for introducing Vendor Extensions." In other words, it's perfectly legitimate but not standardized.

Using the OMX_PARAM_PORTDEFINITIONTYPE value you get from querying the port for general information, you can query for the audio types supported with the following:

```
void getAudioPortInformation(int nPort, OMX PARAM PORTDEFINITIONTYPE sPortDef) {
    printf("Port %d requires %d buffers\n", nPort, sPortDef.nBufferCountMin);
    printf("Port %d has min buffer size %d bytes\n", nPort, sPortDef.nBufferSize);
    if (sPortDef.eDir == OMX DirInput) {
        printf("Port %d is an input port\n", nPort);
    } else {
        printf("Port %d is an output port\n", nPort);
    switch (sPortDef.eDomain) {
    case OMX PortDomainAudio:
        printf("Port %d is an audio port\n", nPort);
        printf("Port mimetype %s\n",
               sPortDef.format.audio.cMIMEType);
        switch (sPortDef.format.audio.eEncoding) {
        case OMX AUDIO CodingPCM:
            printf("Port encoding is PCM\n");
            break:
        case OMX_AUDIO CodingVORBIS:
            printf("Port encoding is Ogg Vorbis\n");
            break;
        case OMX AUDIO CodingMP3:
            printf("Port encoding is MP3\n");
            break;
        default:
            printf("Port encoding is not PCM or MP3 or Vorbis, is %d\n",
                   sPortDef.format.audio.eEncoding);
        }
        getSupportedAudioFormats(nPort);
        break;
        /* could put other port types here */
    default:
        printf("Port %d is not an audio port\n", nPort);
    }
}
```

But now you can go much deeper. If the port can support MP3 data, what variations on MP3 does it support? For example, MP3 files can have different sampling rates (48 KHz, 44.1 KHz, and so on), number of bits per sample (16, 24, and so on), and number of channels (1, 2, 5, and so on). These can all be queried by—deep breath!—another set of data types.

The first type is OMX_AUDIO_PARAM_PORTFORMATTYPE (see section 4.1.6 of the 1.1.2 specification). It is quite simple.

```
typedef struct OMX_AUDIO_PARAM_PORTFORMATTYPE {
   OMX_U32 nSize;
   OMX_VERSIONTYPE nVersion;
   OMX_U32 nPortIndex;
   OMX_U32 nIndex;
   OMX_AUDIO_CODINGTYPE eEncoding;
} OMX_AUDIO_PARAM_PORTFORMATTYPE;
```

The first two fields are common to all OpenMAX structs: size and version. The third is the port index you are looking at. The fifth is the encoding: PCM, MP3, Vorbis, and so on. The new one is the fourth: the index.

You know from the OMX_PARAM_PORTDEFINITIONTYPE field portdef.format.audio.eEncoding that the port will support a single audio type such as PCM. But it may also support more, such as MP3 or AAC. That's what the index is for, for the different types of audio data. The index starts at zero and keeps increasing until you get an error trying to get parameters with that index value.

So, you start with a struct of type OMX_PARAM_PORTDEFINITIONTYPE and set the index to 0. You then keep asking for parameters with an OMX_IndexParamAudioPortFormat index to OMX_GetParameter. Each time round you increase the index by one until OMX_GetParameter returns an error. On each iteration, you get a new supported audio type.

For example, on the RPi, the audio_render component has one input port that suports PCM and DDT data. You will see the code in just a minute.

Well, if you now know that PCM is supported, you can go further and ask for what parameters it supports. Before doing that, here is the code to list the formats and call for this further level of detail:

```
void getSupportedAudioFormats(int indentLevel, int portNumber) {
    OMX AUDIO PARAM PORTFORMATTYPE sAudioPortFormat;
    setHeader(&sAudioPortFormat, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    sAudioPortFormat.nIndex = 0;
    sAudioPortFormat.nPortIndex = portNumber;
    printf("Supported audio formats are:\n");
    for(;;) {
       err = OMX_GetParameter(handle,
                               OMX IndexParamAudioPortFormat,
                               &sAudioPortFormat);
       if (err == OMX ErrorNoMore) {
            printf("No more formats supported\n");
            return;
        }
       /* This shouldn't occur, but does with Broadcom library */
       if (sAudioPortFormat.eEncoding == OMX AUDIO CodingUnused) {
             printf("No coding format returned\n");
             return;
        }
```

```
switch (sAudioPortFormat.eEncoding) {
        case OMX AUDIO CodingPCM:
            printf("Supported encoding is PCM\n");
            getPCMInformation(portNumber);
        case OMX AUDIO CodingVORBIS:
            printf("Supported encoding is Ogg Vorbis\n");
            break;
        case OMX AUDIO CodingMP3:
            printf("Supported encoding is MP3\n");
            getMP3Information(portNumber);
            break;
#ifdef RASPBERRY PI
        case OMX AUDIO CodingFLAC:
            printf("Supported encoding is FLAC\n");
            break;
        case OMX AUDIO CodingDDP:
            printf("Supported encoding is DDP\n");
        case OMX_AUDIO_CodingDTS:
            printf("Supported encoding is DTS\n");
            break;
        case OMX AUDIO CodingWMAPRO:
            printf("Supported encoding is WMAPRO\n");
            break;
        case OMX AUDIO CodingATRAC3:
            printf("Supported encoding is ATRAC3\n");
            break;
        case OMX AUDIO CodingATRACX:
            printf("Supported encoding is ATRACX\n");
        case OMX_AUDIO_CodingATRACAAL:
            printf("Supported encoding is ATRACAAL\n");
            break;
#endif
        case OMX AUDIO CodingAAC:
            printf("Supported encoding is AAC\n");
            break;
        case OMX AUDIO CodingWMA:
            printf("Supported encoding is WMA\n");
            break;
        case OMX AUDIO CodingRA:
            printf("Supported encoding is RA\n");
            break;
        case OMX AUDIO CodingAMR:
            printf("Supported encoding is AMR\n");
            break;
        case OMX AUDIO CodingEVRC:
            printf("Supported encoding is EVRC\n");
            break;
```

```
case OMX_AUDIO_CodingG726:
            printf("Supported encoding is G726\n");
            break;
        case OMX_AUDIO_CodingMIDI:
            printf("Supported encoding is MIDI\n");
            break;
        default:
            printf("Supported encoding is not PCM or MP3 or Vorbis, is Ox%X\n",
                   sAudioPortFormat.eEncoding);
        sAudioPortFormat.nIndex++;
    }
}
    So, to finally get down to the detail level, you need to look at the functions you define such as
getPCMInformation, getMP3Information, and so on.
    You will just look at PCM. Other types can be looked at in a similar way. Section 4.1.7 of the 1.1.2
specification defines the struct OMX AUDIO PARAM PCMMODETYPE.
typedef struct OMX_AUDIO_PARAM PCMMODETYPE {
    OMX U32 nSize;
    OMX VERSIONTYPE nVersion;
    OMX U32 nPortIndex;
    OMX U32 nChannels;
    OMX NUMERICALDATATYPE eNumData;
    OMX ENDIANTYPE eEndian;
    OMX BOOL bInterleaved;
    OMX U32 nBitPerSample;
    OMX U32 nSamplingRate;
    OMX AUDIO PCMMODETYPE ePCMMode;
    OMX AUDIO CHANNELTYPE eChannelMapping[OMX AUDIO MAXCHANNELS];
} OMX AUDIO PARAM PCMMODETYPE;
    The index to look up this struct is OMX_IndexParamAudioPcm. (The full list of indices and data types for
audio is in Table 4.2, for video is in Table 4-45, and for images is in Table 4-65.)
    The following is the code to get this information:
void getPCMInformation(int portNumber) {
    /* assert: PCM is a supported mode */
    OMX AUDIO PARAM PCMMODETYPE sPCMMode;
    /* set it into PCM format before asking for PCM info */
    if (setEncoding(portNumber, OMX AUDIO CodingPCM) != OMX ErrorNone) {
        fprintf(stderr, "Error in setting coding to PCM\n");
        return;
    }
    setHeader(&sPCMMode, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nPortIndex = portNumber;
```

err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);

```
if(err != OMX_ErrorNone){
        printf("PCM mode unsupported\n");
    } else {
        printf(" PCM default sampling rate %d\n", sPCMMode.nSamplingRate);
        printf(" PCM default bits per sample %d\n", sPCMMode.nBitPerSample);
        printf(" PCM default number of channels %d\n", sPCMMode.nChannels);
}
    A program to dump all of this type of information is info.c.
   Based on code
   Copyright (C) 2007-2009 STMicroelectronics
   Copyright (C) 2007-2009 Nokia Corporation and/or its subsidiary(-ies).
   under the LGPL
#include <stdio.h>
#include <stdlib.h>
#include <fcntl.h>
#include <string.h>
#include <pthread.h>
#include <unistd.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <OMX Types.h>
#include <OMX Audio.h>
#ifdef RASPBERRY PI
#include <bcm host.h>
#endif
OMX ERRORTYPE err;
OMX HANDLETYPE handle;
OMX VERSIONTYPE specVersion, compVersion;
OMX CALLBACKTYPE callbacks;
#define indent {int n = 0; while (n++ < indentLevel*2) putchar(' ');}</pre>
static void setHeader(OMX PTR header, OMX U32 size) {
    /* header->nVersion */
    OMX VERSIONTYPE* ver = (OMX VERSIONTYPE*)(header + sizeof(OMX U32));
    /* header->nSize */
    *((OMX U32*)header) = size;
    /* for 1.2
       ver->s.nVersionMajor = OMX VERSION MAJOR;
       ver->s.nVersionMinor = OMX_VERSION_MINOR;
```

```
ver->s.nRevision = OMX_VERSION_REVISION;
      ver->s.nStep = OMX VERSION STEP;
    */
   ver->s.nVersionMajor = specVersion.s.nVersionMajor;
   ver->s.nVersionMinor = specVersion.s.nVersionMinor;
   ver->s.nRevision = specVersion.s.nRevision;
   ver->s.nStep = specVersion.s.nStep;
}
void printState() {
   OMX STATETYPE state;
    err = OMX GetState(handle, &state);
    if (err != OMX_ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
       exit(1);
    }
    switch (state) {
    case OMX StateLoaded: fprintf(stderr, "StateLoaded\n"); break;
    case OMX StateIdle: fprintf(stderr, "StateIdle\n"); break;
   case OMX StateExecuting: fprintf(stderr, "StateExecuting\n"); break;
    case OMX StatePause: fprintf(stderr, "StatePause\n"); break;
    case OMX_StateWaitForResources: fprintf(stderr, "StateWiat\n"); break;
   default: fprintf(stderr, "State unknown\n"); break;
}
OMX ERRORTYPE setEncoding(int portNumber, OMX AUDIO CODINGTYPE encoding) {
    OMX_PARAM_PORTDEFINITIONTYPE sPortDef;
    setHeader(&sPortDef, sizeof(OMX_PARAM PORTDEFINITIONTYPE));
    sPortDef.nPortIndex = portNumber;
    sPortDef.nPortIndex = portNumber;
    err = OMX GetParameter(handle, OMX IndexParamPortDefinition, &sPortDef);
    if(err != OMX ErrorNone){
       fprintf(stderr, "Error in getting OMX PORT DEFINITION TYPE parameter\n",
0);
       exit(1);
    sPortDef.format.audio.eEncoding = encoding;
    sPortDef.nBufferCountActual = sPortDef.nBufferCountMin;
   err = OMX_SetParameter(handle, OMX_IndexParamPortDefinition, &sPortDef);
   return err;
}
void getPCMInformation(int indentLevel, int portNumber) {
    /* assert: PCM is a supported mode */
   OMX_AUDIO_PARAM_PCMMODETYPE sPCMMode;
```

```
/* set it into PCM format before asking for PCM info */
    if (setEncoding(portNumber, OMX AUDIO CodingPCM) != OMX ErrorNone) {
        fprintf(stderr, "Error in setting coding to PCM\n");
        return;
    }
    setHeader(&sPCMMode, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nPortIndex = portNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        indent printf("PCM mode unsupported\n");
    } else {
        indent printf(" PCM default sampling rate %d\n", sPCMMode.nSamplingRate);
        indent printf(" PCM default bits per sample %d\n", sPCMMode.nBitPerSample);
        indent printf(" PCM default number of channels %d\n", sPCMMode.nChannels);
    }
    /*
    setHeader(&sAudioPortFormat, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    sAudioPortFormat.nIndex = 0;
    sAudioPortFormat.nPortIndex = portNumber;
    */
void getMP3Information(int indentLevel, int portNumber) {
    /* assert: MP3 is a supported mode */
    OMX AUDIO PARAM MP3TYPE sMP3Mode;
    /* set it into MP3 format before asking for MP3 info */
    if (setEncoding(portNumber, OMX AUDIO CodingMP3) != OMX ErrorNone) {
        fprintf(stderr, "Error in setting coding to MP3\n");
        return:
    }
    setHeader(&sMP3Mode, sizeof(OMX AUDIO PARAM MP3TYPE));
    sMP3Mode.nPortIndex = portNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioMp3, &sMP3Mode);
    if(err != OMX ErrorNone){
        indent printf("MP3 mode unsupported\n");
        indent printf(" MP3 default sampling rate %d\n", sMP3Mode.nSampleRate);
        indent printf(" MP3 default bits per sample %d\n", sMP3Mode.nBitRate);
        indent printf(" MP3 default number of channels %d\n", sMP3Mode.nChannels);
    }
}
void getSupportedImageFormats(int indentLevel, int portNumber) {
    OMX IMAGE PARAM PORTFORMATTYPE sImagePortFormat;
    setHeader(&sImagePortFormat, sizeof(OMX IMAGE PARAM PORTFORMATTYPE));
    sImagePortFormat.nIndex = 0;
    sImagePortFormat.nPortIndex = portNumber;
```

```
#ifdef LIM
    printf("LIM doesn't set image formats properly\n");
   return;
#endif
    indent printf("Supported image formats are:\n");
    indentLevel++;
    for(;;) {
       err = OMX GetParameter(handle, OMX IndexParamImagePortFormat, &sImagePortFormat);
       if (err == OMX ErrorNoMore) {
            indent printf("No more formats supported\n");
            return;
        }
        /* This shouldn't occur, but does with Broadcom library */
       if (sImagePortFormat.eColorFormat == OMX IMAGE CodingUnused) {
             indent printf("No coding format returned\n");
             return;
        }
        indent printf("Image format compression format 0x%X\n",
                      sImagePortFormat.eCompressionFormat);
        indent printf("Image format color encoding 0x%X\n",
                      sImagePortFormat.eColorFormat);
        sImagePortFormat.nIndex++;
    }
}
void getSupportedVideoFormats(int indentLevel, int portNumber) {
    OMX VIDEO PARAM PORTFORMATTYPE sVideoPortFormat;
    setHeader(&sVideoPortFormat, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    sVideoPortFormat.nIndex = 0;
    sVideoPortFormat.nPortIndex = portNumber;
#ifdef LIM
   printf("LIM doesn't set video formats properly\n");
   return;
#endif
    indent printf("Supported video formats are:\n");
    for(;;) {
       err = OMX GetParameter(handle, OMX IndexParamVideoPortFormat, &sVideoPortFormat);
       if (err == OMX ErrorNoMore) {
            indent printf("No more formats supported\n");
            return;
        }
       /* This shouldn't occur, but does with Broadcom library */
       if (sVideoPortFormat.eColorFormat == OMX VIDEO CodingUnused) {
             indent printf("No coding format returned\n");
             return;
        }
```

```
indent printf("Video format encoding 0x%X\n",
                      sVideoPortFormat.eColorFormat);
        sVideoPortFormat.nIndex++;
    }
}
void getSupportedAudioFormats(int indentLevel, int portNumber) {
    OMX AUDIO PARAM PORTFORMATTYPE sAudioPortFormat;
    setHeader(&sAudioPortFormat, sizeof(OMX_AUDIO_PARAM_PORTFORMATTYPE));
    sAudioPortFormat.nIndex = 0;
    sAudioPortFormat.nPortIndex = portNumber;
#ifdef LIM
    printf("LIM doesn't set audio formats properly\n");
    return;
#endif
    indent printf("Supported audio formats are:\n");
    for(;;) {
        err = OMX GetParameter(handle, OMX IndexParamAudioPortFormat, &sAudioPortFormat);
        if (err == OMX ErrorNoMore) {
            indent printf("No more formats supported\n");
            return;
        }
        /* This shouldn't occur, but does with Broadcom library */
        if (sAudioPortFormat.eEncoding == OMX AUDIO CodingUnused) {
             indent printf("No coding format returned\n");
             return;
        }
        switch (sAudioPortFormat.eEncoding) {
        case OMX AUDIO CodingPCM:
            indent printf("Supported encoding is PCM\n");
            getPCMInformation(indentLevel+1, portNumber);
            break;
        case OMX AUDIO CodingVORBIS:
            indent printf("Supported encoding is Ogg Vorbis\n");
            break;
        case OMX AUDIO CodingMP3:
            indent printf("Supported encoding is MP3\n");
            getMP3Information(indentLevel+1, portNumber);
            break:
#ifdef RASPBERRY PI
        case OMX AUDIO CodingFLAC:
            indent printf("Supported encoding is FLAC\n");
            break;
        case OMX AUDIO CodingDDP:
            indent printf("Supported encoding is DDP\n");
            break;
```

```
case OMX AUDIO CodingDTS:
            indent printf("Supported encoding is DTS\n");
            break:
        case OMX_AUDIO CodingWMAPRO:
            indent printf("Supported encoding is WMAPRO\n");
            break;
        case OMX AUDIO CodingATRAC3:
            indent printf("Supported encoding is ATRAC3\n");
        case OMX AUDIO CodingATRACX:
            indent printf("Supported encoding is ATRACX\n");
        case OMX_AUDIO_CodingATRACAAL:
            indent printf("Supported encoding is ATRACAAL\n");
            break;
#endif
        case OMX_AUDIO_CodingAAC:
            indent printf("Supported encoding is AAC\n");
        case OMX_AUDIO_CodingWMA:
            indent printf("Supported encoding is WMA\n");
            break;
        case OMX AUDIO CodingRA:
            indent printf("Supported encoding is RA\n");
            break;
        case OMX AUDIO CodingAMR:
            indent printf("Supported encoding is AMR\n");
            break;
        case OMX AUDIO CodingEVRC:
            indent printf("Supported encoding is EVRC\n");
        case OMX_AUDIO_CodingG726:
            indent printf("Supported encoding is G726\n");
            break;
        case OMX AUDIO CodingMIDI:
            indent printf("Supported encoding is MIDI\n");
            break;
        case OMX AUDIO Coding:
            indent printf("Supported encoding is \n");
            break;
            */
        default:
            indent printf("Supported encoding is not PCM or MP3 or Vorbis, is 0x%X\n",
                  sAudioPortFormat.eEncoding);
        sAudioPortFormat.nIndex++;
    }
}
```

```
void getAudioPortInformation(int indentLevel, int nPort, OMX_PARAM_PORTDEFINITIONTYPE
    indent printf("Port %d requires %d buffers\n", nPort, sPortDef.nBufferCountMin);
    indent printf("Port %d has min buffer size %d bytes\n", nPort, sPortDef.nBufferSize);
    if (sPortDef.eDir == OMX DirInput) {
        indent printf("Port %d is an input port\n", nPort);
    } else {
        indent printf("Port %d is an output port\n", nPort);
    switch (sPortDef.eDomain) {
    case OMX PortDomainAudio:
        indent printf("Port %d is an audio port\n", nPort);
        indent printf("Port mimetype %s\n",
               sPortDef.format.audio.cMIMEType);
        switch (sPortDef.format.audio.eEncoding) {
        case OMX AUDIO CodingPCM:
            indent printf("Port encoding is PCM\n");
            break:
        case OMX AUDIO CodingVORBIS:
            indent printf("Port encoding is Ogg Vorbis\n");
            break;
        case OMX AUDIO CodingMP3:
            indent printf("Port encoding is MP3\n");
        default:
            indent printf("Port encoding is not PCM or MP3 or Vorbis, is %d\n",
                   sPortDef.format.audio.eEncoding);
        getSupportedAudioFormats(indentLevel+1, nPort);
        break:
        /* could put other port types here */
        indent printf("Port %d is not an audio port\n", nPort);
    }
}
void getAllAudioPortsInformation(int indentLevel) {
    OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    int startPortNumber;
    int nPorts;
    int n;
    setHeader(&param, sizeof(OMX PORT PARAM TYPE));
```

```
err = OMX_GetParameter(handle, OMX IndexParamAudioInit, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting audio OMX PORT PARAM TYPE parameter\n", 0);
       return;
    indent printf("Audio ports:\n");
    indentLevel++;
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    if (nPorts == 0) {
       indent printf("No ports of this type\n");
       return;
    }
    indent printf("Ports start on %d\n", startPortNumber);
    indent printf("There are %d open ports\n", nPorts);
    for (n = 0; n < nPorts; n++) {
       setHeader(&sPortDef, sizeof(OMX PARAM PORTDEFINITIONTYPE));
        sPortDef.nPortIndex = startPortNumber + n;
       err = OMX_GetParameter(handle, OMX_IndexParamPortDefinition, &sPortDef);
        if(err != OMX ErrorNone){
            fprintf(stderr, "Error in getting OMX PORT DEFINITION TYPE parameter\n", 0);
            exit(1);
        indent printf("Port %d has %d buffers of size %d\n",
                      sPortDef.nPortIndex,
                      sPortDef.nBufferCountActual,
                      sPortDef.nBufferSize);
        indent printf("Direction is %s\n",
                      (sPortDef.eDir == OMX DirInput ? "input" : "output"));
       getAudioPortInformation(indentLevel+1, startPortNumber + n, sPortDef);
   }
}
void getAllVideoPortsInformation(int indentLevel) {
   OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    int startPortNumber;
    int nPorts;
    int n;
    setHeader(&param, sizeof(OMX PORT PARAM TYPE));
    err = OMX_GetParameter(handle, OMX_IndexParamVideoInit, &param);
    if(err != OMX ErrorNone){
       fprintf(stderr, "Error in getting video OMX PORT PARAM TYPE parameter\n", 0);
       return;
    }
```

```
printf("Video ports:\n");
    indentLevel++;
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    if (nPorts == 0) {
        indent printf("No ports of this type\n");
        return:
    }
    indent printf("Ports start on %d\n", startPortNumber);
    indent printf("There are %d open ports\n", nPorts);
    for (n = 0; n < nPorts; n++) {
        setHeader(&sPortDef, sizeof(OMX PARAM PORTDEFINITIONTYPE));
        sPortDef.nPortIndex = startPortNumber + n;
        err = OMX_GetParameter(handle, OMX_IndexParamPortDefinition, &sPortDef);
        if(err != OMX ErrorNone){
            fprintf(stderr, "Error in getting OMX_PORT_DEFINITION_TYPE parameter\n", 0);
            exit(1);
        //getVideoPortInformation(indentLevel+1, startPortNumber + n, sPortDef);
        indent printf("Port %d has %d buffers (minimum %d) of size %d\n",
                      sPortDef.nPortIndex,
                      sPortDef.nBufferCountActual,
                      sPortDef.nBufferCountMin,
                      sPortDef.nBufferSize);
        indent printf("Direction is %s\n",
                      (sPortDef.eDir == OMX DirInput ? "input" : "output"));
        getSupportedVideoFormats(indentLevel+1, startPortNumber + n);
    }
}
void getAllImagePortsInformation(int indentLevel) {
    OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    int startPortNumber;
    int nPorts;
    int n;
    setHeader(&param, sizeof(OMX_PORT_PARAM_TYPE));
    err = OMX GetParameter(handle, OMX IndexParamImageInit, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting image OMX_PORT_PARAM_TYPE parameter\n", 0);
        return;
    printf("Image ports:\n");
    indentLevel++;
```

```
startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    if (nPorts == 0) {
        indent printf("No ports of this type\n");
    }
    indent printf("Ports start on %d\n", startPortNumber);
    indent printf("There are %d open ports\n", nPorts);
    for (n = 0; n < nPorts; n++) {
       setHeader(&sPortDef, sizeof(OMX PARAM PORTDEFINITIONTYPE));
       sPortDef.nPortIndex = startPortNumber + n;
       err = OMX GetParameter(handle, OMX IndexParamPortDefinition, &sPortDef);
        if(err != OMX ErrorNone){
            fprintf(stderr, "Error in getting OMX_PORT_DEFINITION_TYPE parameter\n", 0);
            exit(1);
        }
        indent printf("Port %d has %d buffers (minimum %d) of size %d\n",
                      sPortDef.nPortIndex,
                      sPortDef.nBufferCountActual,
                      sPortDef.nBufferCountMin,
                      sPortDef.nBufferSize);
        indent printf("Direction is %s\n",
                      (sPortDef.eDir == OMX DirInput ? "input" : "output"));
        //getImagePortInformation(indentLevel+1, startPortNumber + n, sPortDef);
       getSupportedImageFormats(indentLevel+1, startPortNumber + n);
   }
}
void getAllOtherPortsInformation(int indentLevel) {
   OMX PORT PARAM TYPE param;
   OMX PARAM PORTDEFINITIONTYPE sPortDef;
    int startPortNumber;
    int nPorts;
    int n;
    setHeader(&param, sizeof(OMX PORT PARAM TYPE));
    err = OMX GetParameter(handle, OMX IndexParamOtherInit, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting other OMX PORT PARAM TYPE parameter\n", 0);
       exit(1);
    printf("Other ports:\n");
    indentLevel++;
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
```

```
if (nPorts == 0) {
        indent printf("No ports of this type\n");
        return;
    }
    indent printf("Ports start on %d\n", startPortNumber);
    indent printf("There are %d open ports\n", nPorts);
    indent printf("Port %d has %d buffers of size %d\n",
                  sPortDef.nPortIndex,
                  sPortDef.nBufferCountActual,
                  sPortDef.nBufferSize);
    indent printf("Direction is %s\n",
                  (sPortDef.eDir == OMX DirInput ? "input" : "output"));
}
void getAllPortsInformation(int indentLevel) {
    OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    int startPortNumber;
    int nPorts;
    int n;
    setHeader(&param, sizeof(OMX PORT PARAM TYPE));
    err = OMX GetParameter(handle, OMX IndexParamVideoInit, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting video OMX_PORT_PARAM_TYPE parameter\n", 0);
        return;
    }
    printf("Video ports:\n");
    indentLevel++;
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    if (nPorts == 0) {
        indent printf("No ports of this type\n");
        return;
    }
    indent printf("Ports start on %d\n", startPortNumber);
    indent printf("There are %d open ports\n", nPorts);
    for (n = 0; n < nPorts; n++) {
        setHeader(&sPortDef, sizeof(OMX_PARAM_PORTDEFINITIONTYPE));
        sPortDef.nPortIndex = startPortNumber + n;
        err = OMX GetParameter(handle, OMX IndexParamPortDefinition, &sPortDef);
        if(err != OMX ErrorNone){
            fprintf(stderr, "Error in getting OMX PORT DEFINITION TYPE parameter\n", 0);
            exit(1);
        }
```

```
indent printf("Port %d has %d buffers of size %d\n",
                      sPortDef.nPortIndex,
                      sPortDef.nBufferCountActual,
                      sPortDef.nBufferSize);
        indent printf("Direction is %s\n",
                      (sPortDef.eDir == OMX DirInput ? "input" : "output"));
        switch (sPortDef.eDomain) {
       case OMX PortDomainVideo:
           indent printf("Domain is video\n");
           getSupportedVideoFormats(indentLevel+1, startPortNumber + n);
           break;
       case OMX PortDomainImage:
           indent printf("Domain is image\n");
           getSupportedImageFormats(indentLevel+1, startPortNumber + n);
           break;
       case OMX PortDomainAudio:
           indent printf("Domain is audio\n");
           getSupportedAudioFormats(indentLevel+1, startPortNumber + n);
       case OMX PortDomainOther:
           indent printf("Domain is other\n");
           // getSupportedOtherFormats(indentLevel+1, startPortNumber + n);
           break:
        }
        //getVideoPortInformation(indentLevel+1, startPortNumber + n, sPortDef);
        if (sPortDef.eDomain == OMX PortDomainVideo)
           getSupportedVideoFormats(indentLevel+1, startPortNumber + n);
       else
           indent printf("Not a video port\n");
    }
}
int main(int argc, char** argv) {
    OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    OMX AUDIO PORTDEFINITIONTYPE sAudioPortDef;
    OMX AUDIO PARAM PORTFORMATTYPE sAudioPortFormat;
   OMX AUDIO PARAM PCMMODETYPE sPCMMode;
#ifdef RASPBERRY PI
    //char *componentName = "OMX.broadcom.audio mixer";
    //char *componentName = "OMX.broadcom.audio mixer";
    char *componentName = "OMX.broadcom.video_render";
#ifdef LIM
    char *componentName = "OMX.limoi.alsa_sink";
```

```
#else
    char *componentName = "OMX.st.volume.component";
#endif
#endif
    unsigned char name[128]; /* spec says 128 is max name length */
    OMX UUIDTYPE uid;
    int startPortNumber;
    int nPorts;
    int n;
    /* ovveride component name by command line argument */
    if (argc == 2) {
        componentName = argv[1];
# ifdef RASPBERRY PI
    bcm_host_init();
# endif
    err = OMX_Init();
    if(err != OMX ErrorNone) {
        fprintf(stderr, "OMX_Init() failed\n", 0);
        exit(1);
    /** Ask the core for a handle to the volume control component
    err = OMX GetHandle(&handle, componentName, NULL /*app private data */, &callbacks);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX GetHandle failed\n", 0);
        exit(1);
    err = OMX GetComponentVersion(handle, name, &compVersion, &specVersion, &uid);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX_GetComponentVersion failed\n", 0);
        exit(1);
    printf("Component name: %s version %d.%d, Spec version %d.%d\n",
           name, compVersion.s.nVersionMajor,
           compVersion.s.nVersionMinor,
           specVersion.s.nVersionMajor,
           specVersion.s.nVersionMinor);
    /** Get ports information */
    //getAllPortsInformation(0);
    getAllAudioPortsInformation(0);
    getAllVideoPortsInformation(0);
    getAllImagePortsInformation(0);
    getAllOtherPortsInformation(0);
    exit(0);
}
```

The output for the video_render component is as follows:

```
Component name: OMX.broadcom.video render: 0 version 0.0, Spec version 1.1
Audio ports:
 No ports of this type
Video ports:
 Ports start on 90
 There are 1 open ports
 Port 90 has 3 buffers (minimum 2) of size 15360
 Direction is input
    Supported video formats are:
   Video format encoding 0x14
   Video format encoding 0x27
   Video format encoding 0x17
   Video format encoding 0x17
   Video format encoding 0x7F000003
   Video format encoding 0x6
   Video format encoding OxC
   Video format encoding OxB
   Video format encoding 0x7F000001
   No more formats supported
Image ports:
 No ports of this type
Other ports:
 No ports of this type
```

Conclusion

In this chapter, you looked at how to get information about OpenMAX components. So far it isn't hard; the information is just extremely voluminous because of the complexities and variations among all the components supported.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAX IL 1.1.2 Specification: https://www.khronos.org/registry/omxil/specs/OpenMAX_IL_1_1_2 Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAXIL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 9



OpenMAX IL uses a state model for each component. Within each state certain operations can be performed, while others must be done before the next state transition can occur.

Building Programs

The programs in this chapter can be built using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2

OMX_LIBS = -lopenmaxil

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS)

EXE = wontwork working event

all: $(EXE)
```

Component States

Every component has a state and can go through a series of state transitions. There are three "desirable" states: Loaded, Idle, and Executing. There are some less desirable states such as Wait for Resources and Invalid, and if a component is in one of those states except transiently, then your program probably won't be working properly.

The state transition diagram is Figure 2-3 of the 1.1.2 specification.

© Jan Newmarch 2017




Figure 9-1. OpenMAX state transitions

Whenever a component changes state, it will invoke the event callback handler established for that component. I ignored this in earlier chapters and will cover it in more detail later. For now, you have to give a non-NULL function to the EventHandler callback struct, which is passed when getting a handle to a component. Minimally, it will look like this:

```
OMX ERRORTYPE cEventHandler(
                            OMX HANDLETYPE hComponent,
                            OMX PTR pAppData,
                            OMX EVENTTYPE eEvent,
                            OMX U32 Data1,
                            OMX U32 Data2,
                            OMX PTR pEventData) {
    // do nothing
    return OMX ErrorNone;
}
OMX CALLBACKTYPE callbacks = { .EventHandler = cEventHandler,
                                 .EmptyBufferDone = NULL,
                                 .FillBufferDone = NULL
};
err = OMX_GetHandle(&handle, componentName,
                    NULL, &callbacks);
```

A created component moves into the Loaded state. Requests to change to another state are done using the following call (section 3.2.2.2 of the 1.1.2 specification):

Loaded to Idle

What you want to do for any component is to move it from Loaded to Idle with the following:

```
OMX_SendCommand(handle,
OMX_CommandStateSet,
OMX_StateIdle,
NULL);
```

A Nonworking Program

This is where you now hit hurdle #1 in OpenMAX programming: a request to change state has an effect only if all the prerequisites are met for the new state. To draw an analogy, if you want your car to change from a stopped state to a moving state, then in preparation for this you have to insert the ignition key, switch on the engine, release the parking brake, engage gears, and so on. If any one of these steps is missing, the state change just won't occur.

The first major change that you want to happen will be from OMX_StateLoaded to OMX_StateIdle. The following program creates a program and requests the state change. If you run it, you will see that it just sits in the Loaded state and never makes the transition. The program is wontwork.c. I've included some convenience functions: err2str and printState.

```
* WARNING: THIS PROGRAM DOESN'T WORK
#include <stdio.h>
#include <stdlib.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
char *err2str(int err) {
    switch (err) {
    case OMX ErrorInsufficientResources: return "OMX ErrorInsufficientResources";
    case OMX ErrorUndefined: return "OMX ErrorUndefined";
    case OMX ErrorInvalidComponentName: return "OMX ErrorInvalidComponentName";
    case OMX ErrorComponentNotFound: return "OMX ErrorComponentNotFound";
    case OMX ErrorInvalidComponent: return "OMX ErrorInvalidComponent";
    case OMX ErrorBadParameter: return "OMX ErrorBadParameter";
    case OMX ErrorNotImplemented: return "OMX ErrorNotImplemented";
    case OMX ErrorUnderflow: return "OMX ErrorUnderflow";
    case OMX_ErrorOverflow: return "OMX_ErrorOverflow";
    case OMX ErrorHardware: return "OMX ErrorHardware"
    case OMX ErrorInvalidState: return "OMX ErrorInvalidState";
    case OMX_ErrorStreamCorrupt: return "OMX_ErrorStreamCorrupt";
    case OMX_ErrorPortsNotCompatible: return "OMX ErrorPortsNotCompatible";
    case OMX ErrorResourcesLost: return "OMX ErrorResourcesLost";
    case OMX ErrorNoMore: return "OMX ErrorNoMore";
```

```
case OMX_ErrorVersionMismatch: return "OMX_ErrorVersionMismatch";
    case OMX ErrorNotReady: return "OMX ErrorNotReady";
    case OMX ErrorTimeout: return "OMX ErrorTimeout";
    case OMX ErrorSameState: return "OMX ErrorSameState";
    case OMX ErrorResourcesPreempted: return "OMX ErrorResourcesPreempted";
    case OMX ErrorPortUnresponsiveDuringAllocation: return "OMX
ErrorPortUnresponsiveDuringAllocation";
    case OMX ErrorPortUnresponsiveDuringDeallocation: return "OMX
ErrorPortUnresponsiveDuringDeallocation";
    case OMX ErrorPortUnresponsiveDuringStop: return "OMX ErrorPortUnresponsiveDuringStop";
    case OMX ErrorIncorrectStateTransition: return "OMX ErrorIncorrectStateTransition";
    case OMX ErrorIncorrectStateOperation: return "OMX ErrorIncorrectStateOperation";
    case OMX_ErrorUnsupportedSetting: return "OMX_ErrorUnsupportedSetting";
    case OMX ErrorUnsupportedIndex: return "OMX ErrorUnsupportedIndex";
    case OMX ErrorBadPortIndex: return "OMX ErrorBadPortIndex";
    case OMX ErrorPortUnpopulated: return "OMX ErrorPortUnpopulated";
    case OMX ErrorComponentSuspended: return "OMX ErrorComponentSuspended";
    case OMX ErrorDynamicResourcesUnavailable: return "OMX
ErrorDynamicResourcesUnavailable";
    case OMX ErrorMbErrorsInFrame: return "OMX ErrorMbErrorsInFrame";
    case OMX ErrorFormatNotDetected: return "OMX ErrorFormatNotDetected";
    case OMX ErrorContentPipeOpenFailed: return "OMX ErrorContentPipeOpenFailed";
    case OMX ErrorContentPipeCreationFailed: return "OMX ErrorContentPipeCreationFailed";
    case OMX ErrorSeperateTablesUsed: return "OMX ErrorSeperateTablesUsed";
    case OMX ErrorTunnelingUnsupported: return "OMX ErrorTunnelingUnsupported";
    default: return "unknown error";
}
void printState(OMX HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    switch (state) {
    case OMX StateLoaded: printf("StateLoaded\n"); break;
    case OMX StateIdle: printf("StateIdle\n"); break;
    case OMX StateExecuting: printf("StateExecuting\n"); break;
    case OMX StatePause: printf("StatePause\n"); break;
    case OMX StateWaitForResources: printf("StateWait\n"); break;
    case OMX StateInvalid: printf("StateInvalid\n"); break;
    default: printf("State unknown\n"); break;
}
OMX ERRORTYPE cEventHandler(
                            OMX HANDLETYPE hComponent,
                            OMX PTR pAppData,
```

```
OMX_EVENTTYPE eEvent,
                            OMX U32 Data1,
                            OMX U32 Data2,
                            OMX PTR pEventData) {
    printf("Hi there, I am in the %s callback\n", func );
    printf("Event is %i\n", (int)eEvent);
    printf("Param1 is %i\n", (int)Data1);
    printf("Param2 is %i\n", (int)Data2);
    return OMX ErrorNone;
}
OMX CALLBACKTYPE callbacks = { .EventHandler = cEventHandler,
                                .EmptyBufferDone = NULL,
                                .FillBufferDone = NULL
};
int main(int argc, char** argv) {
    int i;
    char *componentName;
    OMX ERRORTYPE err;
    OMX HANDLETYPE handle;
    if (argc < 2) {
        fprintf(stderr, "Usage: %s component-name\n", argv[0]);
        exit(1);
    componentName = argv[1];
    bcm host init();
    err = OMX Init();
    if(err != OMX ErrorNone) {
        fprintf(stderr, "OMX Init() failed %s\n", err2str(err));
        exit(1);
    /** Ask the core for a handle to the component
    err = OMX GetHandle(&handle, componentName,
                        // the next two fields are discussed later
                        NULL, &callbacks);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX GetHandle failed %s\n", err2str(err));
        exit(1);
    }
    // check our current state - should be Loaded
    printState(handle);
```

```
// request a move to idle
    OMX SendCommand(handle,
                     OMX CommandStateSet,
                     OMX StateIdle,
                     NULL);
    int n = 0;
    while (n++ < 10) {
        sleep(1);
        // are we there yet?
        printState(handle);
    }
    exit(0);
}
    The output from
../wontwork OMX.broadcom.audio capture
    is similar to the following:
StateLoaded
Hi there, I am in the cEventHandler callback
Event is 1
Param1 is -2147479552
Param2 is 1
StateLoaded
StateLoaded
StateLoaded
. . .
```

What's Wrong with It?

The OpenMAX 1.1.2 specification in section 3.1.1.2.1.1, "OMX_StateLoaded to OMX_StateIdle," says the following:

If the IL client requests a state transition from OMX_StateLoaded to OMX_StateIdle, the component shall acquire all of its static resources, including buffers for all enabled ports, before completing the transition. The component does not acquire buffers for any disabled ports. Furthermore, before the transition can complete, the buffer supplier, which is always the IL client when not tunneling, shall ensure that the non-supplier possesses all of its buffers.

Clear? Well, maybe not. What it is saying is that the component must have everything right, including allocating all of the input and output buffers. Alternatively, you can do the equivalent of leaving the car on a hill and just releasing the parking brake, which is a much simpler way of moving! For a component, this means disabling all of the ports. This can get you into an Idle state, and then you can worry about the next transition.

To disable all of the ports, you have to use the techniques in the previous chapter: find all of the video ports, all of the audio ports, all of the image ports, and all of the other ports. For each one, call the following:

```
OMX SendCommand(handle, OMX CommandPortDisable,
                <port index>, NULL);
    The progam is working.c.
#include <stdio.h>
#include <stdlib.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <bcm host.h>
char *err2str(int err) {
   return "omitted";
void printState(OMX HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX_GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    switch (state) {
    case OMX StateLoaded: printf("StateLoaded\n"); break;
    case OMX StateIdle: printf("StateIdle\n"); break;
    case OMX StateExecuting: printf("StateExecuting\n"); break;
    case OMX StatePause: printf("StatePause\n"); break;
    case OMX StateWaitForResources: printf("StateWait\n"); break;
    case OMX StateInvalid: printf("StateInvalid\n"); break;
    default: printf("State unknown\n"); break;
}
OMX ERRORTYPE cEventHandler(
                            OMX HANDLETYPE hComponent,
                            OMX PTR pAppData,
                            OMX EVENTTYPE eEvent,
                            OMX U32 Data1,
                            OMX U32 Data2,
                            OMX PTR pEventData) {
    printf("Hi there, I am in the %s callback\n", __func__);
    printf("Event is %i\n", (int)eEvent);
    printf("Param1 is %i\n", (int)Data1);
```

```
printf("Param2 is %i\n", (int)Data2);
   return OMX ErrorNone;
}
OMX CALLBACKTYPE callbacks = { .EventHandler = cEventHandler,
                                 .EmptyBufferDone = NULL,
                                 .FillBufferDone = NULL
};
void disableSomePorts(OMX HANDLETYPE handle, OMX INDEXTYPE indexType) {
    OMX PORT PARAM TYPE param;
    int startPortNumber, endPortNumber;
    int nPorts;
    int n;
    OMX_ERRORTYPE err;
    memset(&param, 0, sizeof(OMX PORT PARAM TYPE));
    param.nSize = sizeof(OMX PORT PARAM TYPE);
    param.nVersion.nVersion = OMX VERSION;
    err = OMX_GetParameter(handle, indexType, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting image OMX PORT PARAM TYPE parameter\n"
);
        return;
    }
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    endPortNumber = startPortNumber + nPorts;
    for (n = startPortNumber; n < endPortNumber; n++) {</pre>
        OMX_SendCommand(handle, OMX_CommandPortDisable,
                        n, NULL);
    }
}
void disableAllPorts(OMX HANDLETYPE handle) {
    disableSomePorts(handle, OMX IndexParamVideoInit);
    disableSomePorts(handle, OMX IndexParamImageInit);
    disableSomePorts(handle, OMX IndexParamAudioInit);
    disableSomePorts(handle, OMX_IndexParamOtherInit);
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    OMX ERRORTYPE err;
    OMX HANDLETYPE handle;
```

```
if (argc < 2) {
        fprintf(stderr, "Usage: %s component-name\n", argv[0]);
        exit(1);
    componentName = argv[1];
    bcm_host_init();
   err = OMX Init();
    if(err != OMX_ErrorNone) {
        fprintf(stderr, "OMX_Init() failed %s\n", err2str(err));
    /** Ask the core for a handle to the component
   err = OMX_GetHandle(&handle, componentName,
                        // the next two fields are discussed later
                        NULL, &callbacks);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX GetHandle failed %s\n", err2str(err));
        exit(1);
    }
    sleep(1);
    // check our current state - should be Loaded
   printState(handle);
   disableAllPorts(handle);
    // request a move to idle
   OMX_SendCommand(handle,
                    OMX CommandStateSet,
                    OMX StateIdle,
                    NULL);
    int n = 0;
   while (n++ < 10) {
        sleep(1);
        // are we there yet?
        printState(handle);
    }
   exit(0);
}
   When run with the following:
        ./working OMX.broadcom.video render
```

it successfully makes the transition to Idle state, as shown here:

```
./working OMX.broadcom.video_render
StateLoaded
Hi there, I am in the cEventHandler callback
Event is 0
Param1 is 2
Param2 is 90
Hi there, I am in the cEventHandler callback
Event is 0
Param1 is 0
Param1 is 0
Param2 is 2
StateIdle
StateIdle
StateIdle
```

Idle to Executing

Once a component is in Idle state, a request can be made to move it to Executing. This is actually pretty easy and generally succeeds. Once it is in Executing state, it can start filling and emptying buffers (you haven't looked at buffers yet).

When Do State Changes Occur?

In the "working" program of an earlier section, you did a loop with a sleep to print the current state. If you want to detect when a state change has occurred, you could do a similar sort of "busy wait."

That isn't really satisfactory: OpenMAX should be able to able to tell you when a state change occurs. And it does: when a state change occurs in a component, it generates an event that is given to the event handler callback.

The event handler callback is discussed in section 3.1.2.9.1 of the 1.1.2 specification. It is defined as follows:

```
OMX_ERRORTYPE (*EventHandler)(
    OMX_IN OMX_HANDLETYPE hComponent,
    OMX_IN OMX_PTR pAppData,
    OMX_IN OMX_EVENTTYPE eEvent,
    OMX_IN OMX_U32 nData1,
    OMX_IN OMX_U32 nData2,
    OMX_IN OMX_PTR pEventData);
```

The hComponent is the handle to the component. The eEvent is an enumerated data type giving possible event types. The data values contain values appropriate to the event. These are described in Table 3-7 of the 1.1.2 specification.

Table 9-1. Parameters in events

eEvent	nData1	nData2	pEventData
OMX_EventCmdComplete	OMX_CommandStateSet	State reached	Null
	OMX_CommandFlush	Port index	Null
	OMX_CommandPort Disable	Port index	Null
	OMX_CommandPort Enable	Port index	Null
	OMX_CommandMark Buffer	Port index	Null
OMX_EventError	Error code	0	Null
OMX_EventMark	0	0	Data linked to the mark, if any
OMX_EventPortSettings Changed	port index	0	Null
OMX_EventBufferFlag	port index	nFlags unaltered	Null
OMX_EventResources Acquired	0	0	Null
OMX_EventDynamic ResourcesAvailable	0	0	Null

For now, the important event is OMX_EventCmdComplete with nData1 set to OMX_CommandStateSet. The value in nData2 is then the state reached: OMX StateIdle, and so on.

The program event.c monitors events. When run on the OMX.broadcom.clock component, it reports disabling all five ports, transitioning to Idle, and then transitioning to Executing.

```
#include <stdio.h>
#include <stdlib.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
char *err2str(int err) {
   return "omitted";
void printState(OMX HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    switch (state) {
    case OMX StateLoaded: printf("StateLoaded\n"); break;
    case OMX StateIdle: printf("StateIdle\n"); break;
    case OMX_StateExecuting: printf("StateExecuting\n"); break;
```

```
case OMX StatePause: printf("StatePause\n"); break;
    case OMX StateWaitForResources: printf("StateWait\n"); break;
    case OMX StateInvalid: printf("StateInvalid\n"); break;
    default: printf("State unknown\n"); break;
}
OMX ERRORTYPE cEventHandler(
                            OMX HANDLETYPE hComponent,
                            OMX_PTR pAppData,
                            OMX EVENTTYPE eEvent,
                            OMX U32 Data1,
                            OMX_U32 Data2,
                            OMX PTR pEventData) {
    if(eEvent == OMX_EventCmdComplete) {
        if (Data1 == OMX CommandStateSet) {
            printf("Component State changed to ");
            switch ((int)Data2) {
            case OMX StateInvalid:
                printf("OMX StateInvalid\n");
                break;
            case OMX_StateLoaded:
                printf("OMX StateLoaded\n");
                break;
            case OMX StateIdle:
                printf("OMX_StateIdle\n");
                break;
            case OMX StateExecuting:
                printf("OMX StateExecuting\n");
                break;
            case OMX StatePause:
                printf("OMX StatePause\n");
                break;
            case OMX StateWaitForResources:
                printf("OMX StateWaitForResources\n");
               break;
            }
        } else if (Data1 == OMX CommandPortEnable){
            printf("OMX State Port enabled %d\n", (int) Data2);
        } else if (Data1 == OMX CommandPortDisable){
            printf("OMX State Port disabled %d\n", (int) Data2);
    } else if(eEvent == OMX EventBufferFlag) {
        if((int)Data2 == OMX BUFFERFLAG EOS) {
            printf("Event is buffer end of stream\n");
    } else if(eEvent == OMX EventError) {
      if (Data1 == OMX_ErrorSameState) {
        printf("Already in requested state\n");
```

```
} else {
        printf("Event is Error %X\n", Data1);
    } else if(eEvent == OMX_EventMark) {
        printf("Event is Buffer Mark\n");
    } else if(eEvent == OMX EventPortSettingsChanged) {
        printf("Event is PortSettingsChanged\n");
    return OMX_ErrorNone;
}
OMX_CALLBACKTYPE callbacks = { .EventHandler = cEventHandler,
                                .EmptyBufferDone = NULL,
                                .FillBufferDone = NULL
};
void disableSomePorts(OMX HANDLETYPE handle, OMX INDEXTYPE indexType) {
    OMX PORT PARAM TYPE param;
    int startPortNumber, endPortNumber;
    int nPorts;
    int n;
    OMX ERRORTYPE err;
    //setHeader(&param, sizeof(OMX_PORT_PARAM_TYPE));
    memset(&param, 0, sizeof(OMX PORT PARAM TYPE));
    param.nSize = sizeof(OMX_PORT_PARAM_TYPE);
    param.nVersion.nVersion = OMX VERSION;
    err = OMX_GetParameter(handle, indexType, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting image OMX PORT PARAM TYPE parameter\n"
, 0);
        return;
    }
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    endPortNumber = startPortNumber + nPorts;
    for (n = startPortNumber; n < endPortNumber; n++) {</pre>
        OMX_SendCommand(handle, OMX_CommandPortDisable,
                        n, NULL);
    }
}
```

```
void disableAllPorts(OMX HANDLETYPE handle) {
    disableSomePorts(handle, OMX IndexParamVideoInit);
    disableSomePorts(handle, OMX IndexParamImageInit);
    disableSomePorts(handle, OMX_IndexParamAudioInit);
    disableSomePorts(handle, OMX IndexParamOtherInit);
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    OMX ERRORTYPE err;
    OMX HANDLETYPE handle;
    if (argc < 2) {
        fprintf(stderr, "Usage: %s component-name\n", argv[0]);
        exit(1);
    componentName = argv[1];
    bcm host init();
    err = OMX Init();
    if(err != OMX ErrorNone) {
        fprintf(stderr, "OMX_Init() failed %s\n", err2str(err));
    /** Ask the core for a handle to the component
    */
    err = OMX GetHandle(&handle, componentName,
                        // the next two fields are discussed later
                        NULL, &callbacks);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "OMX_GetHandle failed %s\n", err2str(err));
        exit(1);
    }
    sleep(1);
    // check our current state - should be Loaded
    printState(handle);
    disableAllPorts(handle);
    // request a move to idle
    OMX SendCommand(handle,
                    OMX CommandStateSet,
                    OMX StateIdle,
                    NULL);
    sleep(2);
    printState(handle);
```

```
// and to executing
    OMX SendCommand(handle,
                    OMX CommandStateSet,
                    OMX StateExecuting,
    sleep(2);
    printState(handle);
   exit(0);
}
   Here's the output:
$ ./event OMX.broadcom.clock
StateLoaded
OMX State Port disabled 80
OMX State Port disabled 81
OMX State Port disabled 82
OMX State Port disabled 83
OMX State Port disabled 84
OMX State Port disabled 85
Component State changed to OMX StateIdle
Component State changed to OMX StateExecuting
StateExecuting
```

What to Do When a State Change Occurs?

OpenMAX is inherently an asynchronous system. Each component is a "black box," and the client using it has no idea nor control over how a component does its work. It may be fast, it may be slow, or it may never complete the requested activity (as in the wontwork program).

Events do not occur synchronously in the client's thread. They occur in a separate thread. Calls to the event handler are, however, blocking synchronous calls to the component. That is, the component cannot do any more work until the event is handled by the client's code. OpenMAX puts a time limit on this (section 3.1.2.9.1) of five milliseconds.

That isn't much time. What the client needs to do in this component's thread is to signal a wakeup call in its *own* thread. That is, the client should block in its own thread, waiting on a wakeup event from the component's thread.

The client can do this in a portable way using Posix threads. Posix threads are well documented. You would need code such as the following:

```
pthread_mutex_t mutex;
OMX_STATETYPE currentState = OMX_StateLoaded;
pthread_cond_t stateCond;

void waitFor(OMX_STATETYPE state) {
    printf("Waiting for %p\n", state);
    pthread mutex lock(&mutex);
```

waitFor is called in the client thread, and wakeUp is called in the event handler.

I won't give any examples of using this here, but it is easy to add to the event example. Examples of this are in my Linux sound book. The RPi's GPU has its own VCOS thread system and has built a library, the ilclient library, around these. So, it's off to this topic in the next chapter.

Conclusion

A key issue in OpenMAX programming is handling state changes for each component. This chapter has discussed one of the critical issues using general OpenMAX calls: setting parameters on components in order that they change state in an appropriate manner.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAXIL 1.1.2 Specification: https://www.khronos.org/registry/omxil/ specs/OpenMAX IL 1 1 2 Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAX IL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

¹To be published by Apress

CHAPTER 10



The IL Client library is designed to make it easier to use OpenMAX on the RPi. It is not portable, but if you want to build only RPi applications (or for other Broadcom GPU systems), it can reduce the effort and frustration of using OpenMAX.

Building Programs

The IL Client library is not a standard library on the RPi. It is actually in the hello_pi directory, in /opt/vc/src/hello_pi/libs/ilclient/. You may have to build this yourself using the Makefile in that directory. You can build the program in this chapter using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
OMX_ILCLIENT_INC = -I/opt/vc/src/hello_pi/libs/ilclient
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OMX_LIBS = -lopenmaxil
OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS) $(OMX_ILCLIENT_LIBS)

all: il_working
```

© Jan Newmarch 2017

Public Functions

The Il Client functions are documented in the file /opt/vc/src/hello_pi/libs/ilclient/ilclient.h. The types ILCLIENT_T and COMPONENT_T are also defined in this file, but you don't really need to look at them; just use them as though they were opaque types.

```
ILCLIENT T *ilclient init(void);
int ilclient create component(ILCLIENT T *handle,
                              COMPONENT T **comp,
                              char *name,
                              ILCLIENT CREATE FLAGS T flags)
void ilclient cleanup components(COMPONENT T *list[])
            il working.c
int ilclient change component state(COMPONENT T *comp,
                                    OMX STATETYPE state);
void ilclient disable port(COMPONENT T *comp,
                           int portIndex)
void ilclient_enable_port(COMPONENT_T *comp,
                          int portIndex);
int ilclient enable port buffers(COMPONENT T *comp,
                                 int portIndex,
                                 ILCLIENT MALLOC T ilclient malloc,
                                 ILCLIENT FREE T ilclient free,
                                 void *userdata);
void ilclient disable port buffers(COMPONENT T *comp,
                                   int portIndex,
                                    OMX BUFFERHEADERTYPE *bufferList,
                                    ILCLIENT_FREE_T ilclient_free,
                                    void *userdata);
int ilclient setup tunnel(TUNNEL T *tunnel,
                          unsigned int portStream,
                          int timeout);
void ilclient disable tunnel(TUNNEL T *tunnel);
void ilclient flush tunnels(TUNNEL T *tunnel,
                                              int max);
void ilclient teardown tunnels(TUNNEL T *tunnels)
OMX_BUFFERHEADERTYPE* ilclient_get_output_buffer(COMPONENT_T *comp,
                                                  int portIndex,
                                                  int block);
```

```
OMX BUFFERHEADERTYPE* ilclient get input buffer(COMPONENT T *comp,
                                                 int portIndex,
                                                 int block);
int ilclient remove event(COMPONENT T *comp,
                          OMX EVENTTYPE event,
                          OMX U32 nData1,
                          int ignore1,
                          OMX U32 nData2,
                          int ignore2);
void ilclient return events(COMPONENT T *comp);
 int ilclient wait for event(COMPONENT T *comp,
                             OMX EVENTTYPE event,
                             OMX U32 nData1,
                             int ignore1,
                             OMX U32 nData2,
                             int ignore2,
                             int event flag,
                             int timeout);
int ilclient wait for command complete(COMPONENT T *comp,
                                        OMX COMMANDTYPE command,
                                        OMX U32 nData2);
int ilclient wait for command complete dual(COMPONENT T *comp,
                                             OMX COMMANDTYPE command,
                                             OMX U32 nData2,
                                             COMPONENT T *related);
void ilclient debug output(char *format, ...);
int ilclient_get_port_index(COMPONENT_T *comp,
                            OMX DIRTYPE dir,
                            OMX PORTDOMAINTYPE type,
                            int index);
OMX HANDLETYPE ilclient get handle(COMPONENT T *comp);
 int ilclient suggest bufsize(COMPONENT T *comp,
                              OMX U32 nBufSizeHint);
```

Creating a Client

In the previous chapter, you created a handle to a component using OMX_GetHandle and then promptly disabled all ports. The function ilclient_create_component will do this for you with the following:

```
ILCLIENT T *handle;
```

Please note that the names used for the component are *not* the full names; this library prefixes OMX.broadcom. to the component name, so you just specify the last part of the name: clock, image_decode, and so on.

You don't need this yet, but this is the right point to mention it: components use buffers, and this function can also be used to set which types of buffers are allowed. The default is no buffers. Input and output buffers can be allowed by extending the flags of the last argument.

Changing Component State

The function ilclient_change_component_state should now be used to ask for a change of state rather than OMX_SendCommand. Not only does it call for a state change, but it also blocks, waiting for the change to occur. For example, to change a component to Idle state, you call the following:

In the previous chapter, you monitored state changes by installing an event handler on the component. This library installs its own handlers, so you don't need to do that. (If you do try, you will probably mess up the library.) The IL Client library looks after event handling.

The equivalent of the event.c program to change the state of the previous chapter is much simpler now. It is il working.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <OMX_Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
void printState(OMX_HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    switch (state) {
                                     printf("StateLoaded\n"); break;
    case OMX StateLoaded:
    case OMX StateIdle:
                                     printf("StateIdle\n"); break;
    case OMX_StateIdle: printf("StateIdle\n"); break;
case OMX_StateExecuting: printf("StateExecuting\n"); break;
    case OMX StatePause:
                                   printf("StatePause\n"); break;
    case OMX StateWaitForResources: printf("StateWait\n"); break;
    case OMX_StateInvalid: printf("StateInvalid\n"); break;
    default:
                                     printf("State unknown\n"); break;
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    int err;
    ILCLIENT T *handle;
    COMPONENT_T *component;
    if (argc < 2) {
        fprintf(stderr, "Usage: %s component-name\n", argv[0]);
        exit(1);
    componentName = argv[1];
    bcm host init();
    handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
```

```
if (OMX_Init() != OMX_ErrorNone) {
        ilclient_destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    err = ilclient_create_component(handle,
                                 &component,
                                 componentName,
                                 ILCLIENT_DISABLE_ALL_PORTS
    if (err == -1) {
        fprintf(stderr, "Component create failed\n");
        exit(1);
    printState(ilclient_get_handle(component));
    err = ilclient change component state(component,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(component));
    err = ilclient change component state(component,
                                           OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Executing\n");
        exit(1);
    printState(ilclient get handle(component));
    exit(0);
    This can be run with the following, for example (note the IL Client version of the component name):
./il working video render
    It has the following output:
StateLoaded
StateIdle
StateExecuting
```

}

Waiting for Events

Although the library generally takes care of events, there are times when your application needs to ensure that certain events have occurred. The function to do this is ilclient wait for event.

You will see uses of this later.

Debugging Clients

OpenMAX is not a friendly environment when things go wrong. If you are lucky, OpenMAX will generate an error. More often, expected state changes won't occur, buffers won't be consumed or produced, and so on, and you don't get any indication apart from a hung application. The IL Client library can help isolate where these problems occur.

OpenMAX errors are generally handled silently by the IL Client library. In other words, you aren't told about them. However, you can set an error callback function with ilclient_set_error_callback, and in this you can try to handle the error.

The simplest handler is just to print the error.

Many IL Client functions return zero on success or a negative value on failure. Sometimes this will tell you what the failure is, but anyway it tells you where it occurs. Combined with the error callback, this can help pin down problems. For example, the command ilclient_wait_for_command_complete returns 0 if the command successfully completed (or returns OMX_ErrorSameState, which doesn't really mean an error) or -1 if a different error occurred.

Some functions have a timeout parameter. These functions return 0 on success while the failure value will show that the timeout has occurred. This is a strong indication that, for example, an expected change has not occurred. For example, the command ilclient_setup_tunnel returns -1 on timeout and other negative values for other errors.

Conclusion

I have briefly introduced the IL Client library. You will use it extensively in the following chapters.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAX IL 1.1.2 Specification: https://www.khronos.org/registry/omxil/specs/OpenMAX_IL_1_1_2_Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAX IL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 11



OpenMAX components have input buffers to give data to the component and output buffers to return data either to the application or to the next component in a pipeline. This chapter looks at buffer management both using OpenMAX and using the IL Client library on the Raspberry Pi.

Building Programs

You can build the programs in this chapter using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
OMX_ILCLIENT_INC = -I/opt/vc/src/hello_pi/libs/ilclient
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2

OMX_LIBS = -lopenmaxil
OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS) $(OMX_ILCLIENT_LIBS)

all: il buffer il decode image
```

Buffers

Data is transferred into and out of components using buffers, which are just byte arrays. Each component has ports, and the ports each have a number of buffers. The program portinfo of Chapter 8 can be used to list how many buffers a port has, how many it must minimally have, and what the recommended buffer size is.

© Jan Newmarch 2017

For example, running this on the Broadcom video decode component's input port gives the following:

```
$./portinfo OMX.broadcom.video_decode 130
Component name: OMX.broadcom.video_decode:46 version 0.0, Spec version 1.1
Port 130
    is input port
    Domain is Video
    Buffer count 20
Buffer minimum count 1
Buffer size 81920 bytes
```

When a component is created, it has an array of pointers to buffer headers (a placeholder for buffers and information about them) but doesn't actually have any memory allocated either for the headers or for the buffers. These have to be allocated. In the next section, you'll look at the OpenMAX calls to do this, and then in the following section you'll see how the IL Client library manages this.

OpenMAX Buffer Allocation

There are two OpenMAX calls to get buffers for a port. The first is OMX_AllocateBuffer where the IL client asks the component to do all the work for them (section 3.2.2.15 of the specification). Typical code is as follows:

The component must be in the Loaded state or the port must be disabled. Typically, an application will disable the port and then allocate the buffers.

The other call is OMX_UseBuffer (section 3.2.2.14). This takes a buffer allocated either by the client or by another component and uses that as its own buffer.

The IL Client Library

You don't need to worry about buffer allocation. The library does it for you. The function ilclient_enable_port_buffers does the relevant buffer allocation for that port. The following is a typical call:

(You can give your own malloc function, but it is easier to let the library use its own.) Once buffers have been allocated, the port can be moved to an enabled state as follows:

```
ilclient_enable_port(component, <port_index>)
```

This is a blocking call and will complete when the port has changed state.

You can modify the state change program of the previous chapter to create buffers for its ports. For simplicity, you hard-code a component (in this example, the Broadcom image_encode component), which has one input port 340 and one output port 341. Note that you have to set the component create flags to the following:

```
ILCLIENT DISABLE ALL PORTS
ILCLIENT ENABLE INPUT BUFFERS
ILCLIENT_ENABLE_OUTPUT_BUFFERS
    If you don't, you may get obscure errors such as the following:
assertion failure:ilclient.c:747:ilclient change component state():error == OMX ErrorNone
Program received signal SIGABRT, Aborted.
Oxb6e41bfc in raise () from /lib/arm-linux-gnueabihf/libc.so.6
    If this occurs, it's best to use a debugger such as gdb to step into ilclient_change_component_state to
find out what the actual error is.
    The program is il_buffer.c.
#include <stdio.h>
#include <stdlib.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
void printState(OMX HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX_GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    switch (state) {
    case OMX_StateLoaded:
                                     printf("StateLoaded\n"); break;
    case OMX StateIdle:
                                     printf("StateIdle\n"); break;
                                     printf("StateExecuting\n"); break;
    case OMX StateExecuting:
    case OMX StatePause:
                                     printf("StatePause\n"); break;
    case OMX_StateWaitForResources: printf("StateWait\n"); break;
    case OMX StateInvalid:
                                     printf("StateInvalid\n"); break;
    default:
                                     printf("State unknown\n"); break;
```

}

```
char *err2str(int err) {
    switch (err) {
    case OMX ErrorInsufficientResources: return "OMX ErrorInsufficientResources";
    case OMX_ErrorUndefined: return "OMX_ErrorUndefined";
    case OMX_ErrorInvalidComponentName: return "OMX ErrorInvalidComponentName";
    case OMX ErrorComponentNotFound: return "OMX ErrorComponentNotFound";
    case OMX ErrorInvalidComponent: return "OMX ErrorInvalidComponent";
    case OMX ErrorBadParameter: return "OMX ErrorBadParameter";
    case OMX ErrorNotImplemented: return "OMX ErrorNotImplemented";
    case OMX ErrorUnderflow: return "OMX ErrorUnderflow";
    case OMX ErrorOverflow: return "OMX ErrorOverflow";
    case OMX ErrorHardware: return "OMX ErrorHardware";
    case OMX ErrorInvalidState: return "OMX ErrorInvalidState";
    case OMX ErrorStreamCorrupt: return "OMX ErrorStreamCorrupt";
    case OMX ErrorPortsNotCompatible: return "OMX ErrorPortsNotCompatible";
    case OMX ErrorResourcesLost: return "OMX ErrorResourcesLost";
    case OMX ErrorNoMore: return "OMX ErrorNoMore";
    case OMX ErrorVersionMismatch: return "OMX ErrorVersionMismatch";
    case OMX ErrorNotReady: return "OMX ErrorNotReady";
    case OMX ErrorTimeout: return "OMX ErrorTimeout";
    case OMX ErrorSameState: return "OMX ErrorSameState";
    case OMX ErrorResourcesPreempted: return "OMX ErrorResourcesPreempted";
    case OMX ErrorPortUnresponsiveDuringAllocation: return
"OMX ErrorPortUnresponsiveDuringAllocation";
    case OMX ErrorPortUnresponsiveDuringDeallocation: return
"OMX ErrorPortUnresponsiveDuringDeallocation";
    case OMX ErrorPortUnresponsiveDuringStop: return "OMX ErrorPortUnresponsiveDuringStop";
    case OMX ErrorIncorrectStateTransition: return "OMX ErrorIncorrectStateTransition";
    case OMX ErrorIncorrectStateOperation: return "OMX_ErrorIncorrectStateOperation";
    case OMX ErrorUnsupportedSetting: return "OMX ErrorUnsupportedSetting";
    case OMX_ErrorUnsupportedIndex: return "OMX_ErrorUnsupportedIndex";
    case OMX ErrorBadPortIndex: return "OMX ErrorBadPortIndex";
    case OMX ErrorPortUnpopulated: return "OMX ErrorPortUnpopulated";
    case OMX ErrorComponentSuspended: return "OMX ErrorComponentSuspended";
    case OMX ErrorDynamicResourcesUnavailable: return
"OMX ErrorDynamicResourcesUnavailable";
    case OMX ErrorMbErrorsInFrame: return "OMX ErrorMbErrorsInFrame";
    case OMX ErrorFormatNotDetected: return "OMX ErrorFormatNotDetected";
    case OMX ErrorContentPipeOpenFailed: return "OMX ErrorContentPipeOpenFailed";
    case OMX ErrorContentPipeCreationFailed: return "OMX ErrorContentPipeCreationFailed";
    case OMX ErrorSeperateTablesUsed: return "OMX ErrorSeperateTablesUsed";
    case OMX ErrorTunnelingUnsupported: return "OMX ErrorTunnelingUnsupported";
    default: return "unknown error";
    }
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int main(int argc, char** argv) {
```

```
int i;
 char *componentName;
 int err;
 ILCLIENT_T *handle;
COMPONENT T *component;
 componentName = "image_encode";
bcm host init();
handle = ilclient init();
 if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
 }
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
 }
ilclient set error callback(handle,
                            error callback,
                            NULL);
err = ilclient create component(handle,
                             &component,
                             componentName,
                             ILCLIENT DISABLE ALL PORTS
                                 ILCLIENT ENABLE INPUT BUFFERS
                                 ILCLIENT_ENABLE_OUTPUT_BUFFERS
                             );
 if (err == -1) {
    fprintf(stderr, "Component create failed\n");
    exit(1);
printState(ilclient_get_handle(component));
err = ilclient change component state(component,
                                       OMX StateIdle);
 if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
 printState(ilclient get handle(component));
 // input port
 ilclient enable port buffers(component, 340,
                              NULL, NULL, NULL);
```

```
ilclient_enable port(component, 340);
    // the input port is enabled and has input buffers allocated
    // output port
    ilclient enable port buffers(component, 341,
                                 NULL, NULL, NULL);
    ilclient enable port(component, 341);
    // the output port is enabled and has output buffers allocated
    err = ilclient change component state(component,
                                           OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Executing\n");
        exit(1);
    printState(ilclient get handle(component));
    exit(0);
}
    The output from running ./il buffer video decode is as follows:
StateLoaded
StateIdle
OMX error OMX ErrorSameState
OMX error OMX ErrorSameState
StateExecuting
```

The "errors" called OMX ErrorSameState aren't errors at all and can be ignored.

Writing to and Reading from Buffers

The whole point of using OpenMAX on the RPi is to get data into and out of the Broadcom GPU using the OpenMAX components. You do this by loading up the input buffers of a component with data and asking the component to empty them with a call OMX_EmptyThisBuffer. When the component has processed the data, it signals an OMX_FillBufferDone event for an output buffer, at which point your application will take the processed data and do something with it.

When a component has finished processing its input buffer data, it signals back to the client with an OMX_EmptyBufferDone event. At this point, the client can put more data into the buffer for processing by the component.

Similarly, when a client has finished doing something with the output data, it returns the buffer to the component by calling the function OMX FillThisBuffer.

One input buffer may produce none or more buffers of output data. An output buffer can consume data from one or more input buffers. There is no direct correlation between emptying an input buffer and filling an output buffer. Essentially these processes should be done concurrently by the client.

```
whenever there is an empty input buffer
put data into the input buffer
call EmptyThis Buffer
```

Whenever an output buffer is full process its data call FillThisBuffer

Now of course things are not that simple. Unless you want to get into Video Core or Posix threads, a sequential version of this is easier. It looks like this:

```
while there is more input data
   if there is an empty input buffer
      put data into the input buffer
      call EmptyThis Buffer
   if there is a full output buffer
      process its data
      call FillThisBuffer

// cleanup any remaining output data
while there is another full output buffer
   process its data
   call FillThisBuffer
```

Of course, this begs the question of how you know that there are empty input buffers and full output buffers. There are IL Client calls to do this.

```
ilclient_get_input_buffer
ilclient_get output buffer
```

These look after the background event processing for OMX_EmptyBufferDone and OMX_FillBufferDone. These calls can be blocking or nonblocking. Block if you know that there must be a buffer available before you can continue, but don't block otherwise (busy wait).

Sequence of Actions

call FillThisBuffer

The pseudo-code for a simple application would ideally look like this:

```
create component in loaded state with all ports disabled move the component to idle state enable input ports (creating input port buffers) enable output ports (creating output port buffers) move the component to executing state

while there is more input data if there is an empty input buffer put data into the input buffer call EmptyThis Buffer if there is a full output buffer process its data call FillThisBuffer

while there is another full output buffer process its data
```

The EOS Flag

The client will generally know when there is no more data. It will have finished reading from a file, a socket connection will have closed, and so on. It will need to pass this information into the component so that it in turn can pass it back out to the client to signal that there are no more output buffers.

The client signals this by setting the flag OMX_BUFFERFLAG_EOS in the flags field of the buffer header. Typical code to read data from a file into input buffers, setting EOS on completion, looks like this:

```
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                          COMPONENT T *component,
                                          OMX BUFFERHEADERTYPE *buff header,
                                          int *toread) {
    OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    return r;
}
```

When getting information from the output buffers, the client will be watching for that flag. Minimal code to just print the size of output data and exit on end-of-stream is as follows:

A Hiccup: Port Settings Changed

The little flies in this ointment are these:

- Most components need to know at least something about their input data before
 they can begin to handle it. For example, to handle image data, the image_decode
 component must be told that the data is in JPEG format (for example).
- Even if the component knows the input data format, it won't know up front how much space to allocate for output buffers. It can't know this until it has processed at least some of the input data.

The first point will be examined in detail in later chapters. In the following program, just ignore set_image_decoder_input_format for now.

The second problem is dealt with by OpenMAX generating an OMX_PortSettingsChanged event. When this occurs is problematic: it may occur after (or during) the processing of the first block. This seems to occur with JPEG images, for example. But there may need to be a number of blocks read. This seems to occur with H.264 video files.

The IL Client library has two relevant functions to look for OMX PortSettingsChanged events.

- The call ilclient_wait_for_event is a blocking call with an error timeout. This can be used if you know there is (or should be) an event coming within the timeout period. The return value will tell you whether it succeeded.
- The call ilclient_remove_event checks the previous event list and returns success if it is able to remove an event from this list. This mechanism waits until the event has already occurred and then detects it.

The blocking ilclient_wait_for_event works on a JPEG image. The second method works on an H.264 movie. I haven't found the middle ground yet.

To handle the case of a blocking wait, the following changes need to be made to the pseudo-code:

- Enable the input ports but not the output ones
- Send a single block of data into the component's input port
- Wait for a PortSettingsChanged event on the component's output port
- Enable the output port
- Continue emptying and filling buffers

The pseudo-code now looks like this:

create component in loaded state with all ports disabled move the component to idle state

```
enable input ports (creating input port buffers)
move the component to executing state
put data into an input buffer
call EmptyThis Buffer
wait for port settings changed on the output port
enable output ports (creating output port buffers)
while there is more input data
    if there is an empty input buffer
         put data into the input buffer
         call EmptyThis Buffer
    if there is a full output buffer
         process its data
         call FillThisBuffer
while there is another full output buffer
     process its data
     call FillThisBuffer
```

Example Image Decoding

To make this more concrete, the following program decodes an image using the decode_image component. You aren't (at this point) interested in decoding images, so ignore the function void set_image_decoder_input format, which just lets the decoder know the input format (JPEG data).

The program almost follows the pseudo-code of the previous section. The divergence is caused by what seems to be a bug to me. When the client has finished its data, it adds OMX_BUFFERFLAG_EOS. However, if the total data is less than the size of the image_decode's input buffers, the component doesn't pass this through. The program hangs. The workaround is to reset the data and send it again.

The program is il_decode_image.c.

The output on a typical JPEG file from, for example, ./il_decode_image jan-us-2006.jpg looks like this:

```
StateLoaded
StateIdle
Setting image decoder format
OMX error OMX ErrorSameState
StateExecuting
Read 81920
OMX error OMX ErrorSameState
Read 81920
Got a filled buffer with 0, allocated 10616832
Read 81920
Read 81920
. . .
Read 81920
Read 3901
Setting EOS on input
Getting last output buffers
```

```
Got eos event
Got a filled buffer with 10616832, allocated 10616832
Got EOS on output
    The program is
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
void printState(OMX HANDLETYPE handle) {
    OMX STATETYPE state;
    OMX ERRORTYPE err;
    err = OMX GetState(handle, &state);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error on getting state\n");
        exit(1);
    }
    switch (state) {
    case OMX StateLoaded:
                                     printf("StateLoaded\n"); break;
    case OMX StateIdle:
                                     printf("StateIdle\n"); break;
                               printf("StateExecuting\n"); break;
printf("StatePause\n"): break;
    case OMX_StateExecuting:
    case OMX StatePause:
                                     printf("StatePause\n"); break;
    case OMX StateWaitForResources: printf("StateWait\n"); break;
                                     printf("StateInvalid\n"); break;
    case OMX_StateInvalid:
                                     printf("State unknown\n"); break;
    default:
}
char *err2str(int err) {
    return "error deleted";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
```

```
return -1;
    }
   return(st.st_size);
}
static void set_image_decoder_input_format(COMPONENT T *component) {
   // set input image format
    OMX IMAGE PARAM PORTFORMATTYPE imagePortFormat;
    memset(&imagePortFormat, 0, sizeof(OMX_IMAGE_PARAM_PORTFORMATTYPE));
    imagePortFormat.nSize = sizeof(OMX IMAGE PARAM PORTFORMATTYPE);
    imagePortFormat.nVersion.nVersion = OMX VERSION;
    imagePortFormat.nPortIndex = 320;
    imagePortFormat.eCompressionFormat = OMX IMAGE CodingJPEG;
    OMX_SetParameter(ilclient_get_handle(component),
                     OMX IndexParamImagePortFormat, &imagePortFormat);
}
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff_size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                        buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    }
    return r;
}
OMX ERRORTYPE save info from filled buffer(COMPONENT T *component,
                                           OMX BUFFERHEADERTYPE * buff header) {
    OMX_ERRORTYPE r;
    printf("Got a filled buffer with %d, allocated %d\n",
```

```
buff_header->nFilledLen,
           buff header->nAllocLen);
    if (buff header->nFlags & OMX BUFFERFLAG EOS) {
        printf("Got EOS on output\n");
        exit(0);
    }
    // do something here, like save the data - do nothing this time
    // and then refill it
   r = OMX FillThisBuffer(ilclient get handle(component),
                           buff header);
    if (r != OMX_ErrorNone) {
        fprintf(stderr, "Fill buffer error %s\n",
                err2str(r));
   return r;
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    int err;
    char *img;
    ILCLIENT T *handle;
   COMPONENT T *component;
    FILE *fp;
    int toread;
   OMX BUFFERHEADERTYPE *buff header;
    if (argc < 2) {
        fprintf(stderr, "Usage: %s jpeg-image\n", argv[0]);
        exit(1);
    img = argv[1];
    if ((fp = fopen(img, "r")) == NULL) {
        fprintf(stderr, "Can't open: %s\n", img);
        exit(2);
    if (( toread = get file size(img)) == -1) {
        fprintf(stderr, "Can't stat: %s\n", img);
        exit(2);
    }
    componentName = "image_decode";
    bcm host init();
    handle = ilclient init();
    if (handle == NULL) {
```

```
fprintf(stderr, "IL client init failed\n");
     exit(1);
 }
if (OMX Init() != OMX ErrorNone) {
     ilclient destroy(handle);
     fprintf(stderr, "OMX init failed\n");
     exit(1);
 }
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient_set_eos_callback(handle,
                          eos callback,
                          NULL);
err = ilclient_create_component(handle,
                             &component,
                             componentName,
                             ILCLIENT DISABLE ALL PORTS
                                 ILCLIENT ENABLE INPUT BUFFERS
                                  ILCLIENT_ENABLE_OUTPUT_BUFFERS
                             );
 if (err == -1) {
     fprintf(stderr, "Component create failed\n");
     exit(1);
 printState(ilclient get handle(component));
 err = ilclient change component state(component,
                                        OMX _StateIdle);
 if (err < 0) {
     fprintf(stderr, "Couldn't change state to Idle\n");
     exit(1);
 printState(ilclient get handle(component));
 // must be before we enable buffers
 set image decoder input format(component);
 // input port
 ilclient enable port buffers(component, 320,
                              NULL, NULL, NULL);
 ilclient enable port(component, 320);
 err = ilclient_change_component_state(component,
                                       OMX StateExecuting);
 if (err < 0) {
```

```
fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
}
printState(ilclient_get_handle(component));
// Read the first block so that the component can get
// the dimensions of the image and call port settings
// changed on the output port to configure it
buff header =
    ilclient_get_input_buffer(component,
                              320,
                              1 /* block */);
if (buff_header != NULL) {
    read into buffer and empty(fp,
                               component,
                               buff_header,
                               &toread);
    // If all the file has been read in, then
    // we have to re-read this first block.
    // Broadcom bug?
    if (toread <= 0) {
        printf("Rewinding\n");
        // wind back to start and repeat
        fp = freopen(IMG, "r", fp);
        toread = get file size(IMG);
    }
}
// wait for first input block to set params for output port
ilclient_wait_for_event(component,
                        OMX EventPortSettingsChanged,
                        321, 0, 0, 1,
                        ILCLIENT_EVENT_ERROR | ILCLIENT_PARAMETER_CHANGED,
                        10000);
// now enable output port since port params have been set
ilclient enable port buffers(component, 321,
                             NULL, NULL, NULL);
ilclient_enable_port(component, 321);
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have an input buffer we can fill and empty?
    buff header =
        ilclient get input buffer(component,
                                  1 /* block */);
    if (buff header != NULL) {
```

```
read_into_buffer_and_empty(fp,
                                component,
                                buff header,
                                &toread);
    }
    // do we have an output buffer that has been filled?
    buff header =
        ilclient get output buffer(component,
                                   0 /* no block */);
    if (buff header != NULL) {
        save_info_from_filled_buffer(component,
                                      buff header);
    }
}
while (1) {
    printf("Getting last output buffers\n");
    buff header =
        ilclient get output buffer(component,
                                    321,
                                    1 /* block */);
    if (buff header != NULL) {
        save info from filled buffer(component,
                                      buff header);
    }
}
exit(0);
```

Conclusion

}

Buffers are the means of communicating data to and from components. This chapter has looked at how to manage buffers. You briefly looked at the OpenMAX calls but spent the most time using the Broadcom IL library.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAXIL 1.1.2 Specification: https://www.khronos.org/registry/omxil/specs/OpenMAX IL 1 1 2 Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAXIL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 12

Image Processing on the Raspberry Pi

This chapter looks at handling single images using OpenMAX on the Raspberry Pi. It also introduces a pipeline of components and looks at alternative ways of handling communication between them.

Building Programs

You can build the programs in this chapter using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
OMX_ILCLIENT_INC = -I/opt/vc/src/hello_pi/libs/ilclient
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2

OMX_LIBS = -lopenmaxil
OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS) $(OMX_ILCLIENT_LIBS)

all: il_decode_image_redone il_render_image_notunnel il_render_image
```

Image Components

The Raspberry Pi has a number of OpenMAX components specifically for image processing.

- image_decode
- image encode
- image read

© Jan Newmarch 2017

- image_write
- image fx
- resize (also does format changes)
- source (creates raw bitmap images)
- transition (transitions between two images)
- write still (writes an image from pixel data)
- video render (renders both images and movies)

Image Formats

OpenMAX has a number of data structures used to get and set information about components. You have seen some of these before.

- OMX_PORT_PARAM_TYPE: This is used with the index parameter OMX_ IndexParamImageInit in a call to OMX_GetParameter. This gives the number of image ports and the port number of the first port.
- OMX_PARAM_PORTDEFINITIONTYPE: This is used with the index parameter OMX_PARAM_PORTDEFINITIONTYPE to give, for each port, the number of buffers, the size of each buffer, and the direction (input or output) of the port.
- OMX_IMAGE_PORTDEFINITIONTYPE: This is a field of the OMX_PARAM_ PORTDEFINITIONTYPE for images.
- OMX_IMAGE_PARAM_PORTFORMATTYPE: This is used to get information about the different formats supported by each port.

Some of these were discussed in Chapter 8.

You haven't looked at the field OMX_IMAGE_PORTDEFINITIONTYPE, which is part of the port definition information. It contains the following relevant fields:

```
typedef struct OMX_IMAGE_PORTDEFINITIONTYPE {
    OMX_STRING cMIMEType;
    OMX_U32 nFrameWidth;
    OMX_U32 nFrameHeight;
    OMX_S32 nStride;
    OMX_U32 nSliceHeight;
    OMX_U32 nSliceHeight;
    OMX_IMAGE_CODINGTYPE eCompressionFormat;
    OMX_IMAGE_PORTDEFINITIONTYPE;
```

The last two fields are the current values set for the port. The *possible* values are obtained from the next structure, OMX_IMAGE_PARAM_PORTFORMATTYPE, so I will discuss it in the next paragraph. The major fields you get here, though, are parameters about the image size: nFrameWidth, nFrameHeight, nStride, and nSliceHeight. These are parameters you often need if you are, say, saving a decoded image in a different format such as TGA.

OMX IMAGE PARAM PORTFORMATTYPE is defined (in section 4.4.4 in the 1.1.2 specification) as follows:

The first two fields are common to all OpenMAX structures. The nPortIndex field is the port you are looking at. The nIndex field is to distinguish between all of the different format types supported by this port. The eCompressionFormat and eColorFormat fields give information about the format.

The values for OMX_IMAGE_CODINGTYPE are given in Table 4-66 of the 1.1.2 specification and on the RPi are given in the file /opt/vc/include/IL/OMX Image.h, as follows:

```
typedef enum OMX IMAGE CODINGTYPE {
                                        /** Value when format is N/A */
     OMX IMAGE CodingUnused,
     OMX IMAGE CodingAutoDetect, /** Auto detection of image format */
     OMX IMAGE CodingJPEG,
                                     /** JPEG/JFIF image format */
    OMX_IMAGE_CodingDPEG2K, /** JPEG 2000 image format */
OMX_IMAGE_CodingEXIF, /** EXIF image format */
OMX_IMAGE_CodingTIFF, /** TIFF image format */
OMX_IMAGE_CodingGIF, /** Graphics image format */
     OMX IMAGE CodingPNG,
                                      /** PNG image format */
    OMX_IMAGE_CodingLZW, /** LZW image format */
OMX_IMAGE_CodingBMP, /** Windows Bitmap format */
     OMX IMAGE CodingKhronosExtensions = 0x6F000000, /** Reserved region for introducing
Khronos Standard Extensions */
     OMX IMAGE CodingVendorStartUnused = 0x7F000000, /** Reserved region for introducing
Vendor Extensions */
     OMX IMAGE CodingTGA,
     OMX IMAGE CodingPPM,
     OMX IMAGE CodingMax = 0x7FFFFFFF
} OMX IMAGE CODINGTYPE;
```

Unfortunately, on the RPi, the only value given is OMX_IMAGE_CodingUnused, so this field does not give useful information about queries. However, the values here may need to be set in the OMX_IMAGE_PORTDEFINITIONTYPE field to set the data compression type.

The type $OMX_COLOR_FORMATTYPE$ is more informative. It is defined in the file $/opt/vc/include/IL/OMX_IVCommon.h$ as follows:

```
typedef enum OMX_COLOR_FORMATTYPE {
   OMX_COLOR_FormatUnused,
   OMX_COLOR_FormatMonochrome,
   OMX_COLOR_Format8bitRGB332,
   OMX_COLOR_Format12bitRGB444,
   OMX_COLOR_Format16bitARGB4444,
   OMX_COLOR_Format16bitARGB1555,
   OMX_COLOR_Format16bitRGB565,
   OMX_COLOR_Format16bitBGR565,
   OMX_COLOR_Format18bitRGB6666,
```

```
OMX COLOR Format18bitARGB1665,
   OMX COLOR Format19bitARGB1666,
   OMX COLOR Format24bitRGB888,
   OMX_COLOR_Format24bitBGR888,
   OMX COLOR Format24bitARGB1887,
   OMX COLOR Format25bitARGB1888,
   OMX COLOR Format32bitBGRA8888,
   OMX COLOR Format32bitARGB8888,
   OMX COLOR FormatYUV411Planar,
   OMX COLOR FormatYUV411PackedPlanar,
   OMX COLOR FormatYUV420Planar,
   OMX COLOR FormatYUV420PackedPlanar,
   OMX COLOR FormatYUV420SemiPlanar,
   OMX COLOR FormatYUV422Planar,
   OMX COLOR FormatYUV422PackedPlanar,
   OMX COLOR FormatYUV422SemiPlanar,
   OMX COLOR FormatYCbYCr,
   OMX COLOR FormatYCrYCb,
   OMX COLOR FormatCbYCrY,
   OMX COLOR FormatCrYCbY,
   OMX COLOR FormatYUV444Interleaved,
   OMX COLOR FormatRawBayer8bit,
   OMX COLOR FormatRawBayer10bit,
   OMX COLOR FormatRawBayer8bitcompressed,
   OMX_COLOR_FormatL2,
   OMX COLOR FormatL4,
   OMX COLOR FormatL8,
   OMX_COLOR_FormatL16,
   OMX COLOR FormatL24,
   OMX COLOR FormatL32,
   OMX COLOR FormatYUV420PackedSemiPlanar,
   OMX COLOR FormatYUV422PackedSemiPlanar,
   OMX COLOR Format18BitBGR666,
   OMX COLOR Format24BitARGB6666,
   OMX COLOR Format24BitABGR6666,
   OMX COLOR FormatKhronosExtensions = 0x6F000000, /** Reserved region for introducing
   Khronos Standard Extensions */
   OMX COLOR FormatVendorStartUnused = 0x7F000000, /** Reserved region for introducing
   Vendor Extensions */
   OMX COLOR Format32bitABGR8888,
   OMX COLOR Format8bitPalette,
   OMX COLOR FormatYUVUV128,
   OMX COLOR FormatRawBayer12bit,
   OMX COLOR FormatBRCMEGL,
   OMX COLOR FormatBRCMOpaque,
   OMX COLOR FormatYVU420PackedPlanar,
   OMX COLOR FormatYVU420PackedSemiPlanar,
   OMX COLOR FormatMax = 0x7FFFFFFF
} OMX COLOR FORMATTYPE;
```

That's a rather large number of formats!

Running the program info from Chapter 8 shows the following for the image decode component:

```
Image ports:
 Ports start on 320
 There are 2 open ports
 Port 320 has 3 buffers (minimum 2) of size 81920
 Direction is input
    Supported image formats are:
     No coding format returned
 Port 321 has 1 buffers (minimum 1) of size 541696
 Direction is output
    Supported image formats are:
     Image format compression format 0
     Image format color encoding 0x6
     Image format compression format 0
     Image format color encoding 0x14
     Image format compression format 0
     Image format color encoding 0x17
     Image format compression format 0
     Image format color encoding 0x7F000001
     Image format compression format 0
     Image format color encoding 0x10
     No more formats supported
```

The color codings are as follows:

- 0x6: OMX COLOR Format16bitRGB565
- 0x14: OMX COLOR FormatYUV420PackedPlanar
- 0x17: OMX COLOR FormatYUV422PackedPlanar
- 0x7F000001: OMX COLOR Format32bitABGR8888
- 0x10: OMX COLOR Format32bitARGB8888

This looks good: both YUV and RGB formats are supported. But if you look into the Broadcom specification for the image_decode component, you get this statement for the OMX_IndexParamImagePortFormat:

The input port supports several compressed formats, the output port supports several color formats. However, the component doesn't support color format changing, so the color format will be set to match that emitted by the encountered image format.

In other words, you only get out the format that you put in. If the image input is RGB, then so is the output, while if the image input is YUV, then so is the output. Format changing is supported by the Broadcom component resize and will be shown in a later example.

Decoding a JPEG Image

In Chapter 11, I gave an example that decoded a JPEG image from a file. There the emphasis was on buffer management; now you will redo it with the emphasis on decoding images.

Well, actually you won't do much more. You just get the output image parameters with the following call:

```
void get output port settings(COMPONENT T *component) {
    OMX PARAM PORTDEFINITIONTYPE portdef;
    printf("Port settings changed\n");
    // need to setup the input for the resizer with the output of the
    // decoder
    portdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    portdef.nVersion.nVersion = OMX VERSION;
    portdef.nPortIndex = 321;
    OMX GetParameter(ilclient get handle(component),
                     OMX IndexParamPortDefinition, &portdef);
    unsigned int uWidth =
        (unsigned int) portdef.format.image.nFrameWidth;
    unsigned int uHeight =
        (unsigned int) portdef.format.image.nFrameHeight;
    unsigned int uStride =
        (unsigned int) portdef.format.image.nStride;
    unsigned int uSliceHeight =
        (unsigned int) portdef.format.image.nSliceHeight;
    printf("Frame width %d, frame height %d, stride %d, slice height %d\n",
           uWidth,
           uHeight,
           uStride,
           uSliceHeight);
    printf("Getting format Compression 0x%x Color Format: 0x%x\n",
           (unsigned int) portdef.format.image.eCompressionFormat,
           (unsigned int) portdef.format.image.eColorFormat);
}
    This call should appear immediately after the port setting's event has been received. The code is in
il decode image redone.c (not shown).
    The new output from one JPEG file run by ./il decode image redone cimg0135.jpg is as follows:
Port settings changed
Frame width 3072, frame height 2304, stride 3072, slice height 2304
Getting format Compression 0x0 Color Format: 0x14
```

So, the output color format is OMX COLOR FormatYUV420PackedPlanar.

Tunneling

The previous example used just a single component. This won't be the norm. To display an image, you will need a decode component and a render component, for example. The IL client can look after all of the input and output buffers, copying data or pointers between them. Alternatively, the components may be able to exchange information directly between themselves, a technique called *tunneling*. (There is a third mechanism called *proprietary communication* that I won't spend time on.)

IL Client Multimedia Framework Framework Framework Framework Framework OpenMAX Core Component Component Component Component Tunneled Communication Source Host Sink Accelerator Component Component Component Component Non-Tunneled **IPC IPC** Communication Hardware Accelerated

These communication models are shown in Figure 2-2 of the 1.1.2 specification, reproduced here:

Figure 12-1. Possible communication paths between components

The Broadcom components support tunneling. This can make it much easier to write an application using multiple components (but not that easy, of course!). The basic simplification is as follows: you don't have to set up buffers between tunneled ports, you don't have to negotiate data formats between them, and you don't have to move data between the buffers; the components look after this themselves.

You still have to feed data into the first component's input buffers and take data out of the last component's output buffers. You also have to look after the state management of the components and their ports, even the tunneled ones.

The pseudo-code for a single component was given in the previous chapter as follows:

```
create component in loaded state with all ports disabled move the component to idle state enable input ports (creating input port buffers) enable output ports (creating output port buffers) move the component to executing state

while there is more input data
   if there is an empty input buffer
      put data into the input buffer
      call EmptyThis Buffer
   if there is a full output buffer
      process its data
   call FillThisBuffer
```

```
while there is another full output buffer process its data call FillThisBuffer
```

The modification for two components, A and B, with a tunnel between them is as follows:

```
create component A in loaded state with all ports disabled
move the component to idle state
enable input ports (creating input port buffers)
create component B in loaded state with all ports disabled
move the component to idle state
enable output ports (creating output port buffers)
setup a tunnel between the output ports of A and the
    input ports of B
// note: the components will have created their own buffers
enable output ports of A (NOT creating output port buffers)
enable input ports of B (NOT creating input port buffers)
move component A to executing state
move component B to executing state
while there is more input data
    if there is an empty input buffer on A
         put data into the input buffer
         call EmptyThis Buffer
    if there is a full output buffer on B
         process its data
         call FillThisBuffer
while there is another full output buffer on B
     process its data
     call FillThisBuffer
```

Essentially you just split the input and output sides, with OpenMAX doing the tunnel communication between the components.

The previous pseudo-code is fine if the sizes of buffers are fixed and known from the beginning. This isn't the case with components such as <code>image_decode</code>, where the size of the output buffers isn't known until at least one input buffer has been processed. This complicates the code as the tunnel now cannot be established until a port setting's changed event has been received on the first component's output port. A tunnel can be established only if the components are in the Loaded state or if their relevant ports are disabled.

There is a convenience function called ilclient_setup_tunnel in the IL Client library that can handle the state issues of the components and their ports. It also has a timeout parameter, which if nonzero will manage waiting for a PortSettingsEvent option. You will ignore this option for now, as it hides too much of what is going on.

The IL Client library tunneling calls use a struct.

```
COMPONENT_T *sink; /** The sink component */
   int sink port;
                        /** The input port index on the sink component */
} TUNNEL T;
    The calls also use the convenience macro set tunnel to set parameters, as follows:
    TUNNEL T tunnel;
    set tunnel(&tunnel, decodeComponent, 321, renderComponent, 90);
    The function ilclient_setup_tunnel takes three parameters.
int ilclient setup tunnel(TUNNEL T *tunnel,
                           unsigned int portStream,
                           int timeout);
    You will set the third parameter to 0. The timeout will be 0 if you want to handle PortSettingsChanged
events yourself.
    The revised pseudo-code for this case is as follows:
create component A in loaded state with all ports disabled
move the component to idle state
enable input ports (creating input port buffers)
create component B in loaded state with all ports disabled
move the component to idle state
enable output ports (creating output port buffers)
move component A to executing state
put data into an input buffer of component A
call EmptyThis Buffer
wait for port settings changed on the output port of component A
// ilclient setup tunnel will handle these steps
// move component A back to idle state
// disable output ports of component A
setup the tunnel between the ports of components A and B
// note: the components will have created their own buffers
enable output ports of component A (NOT creating output port buffers)
enable output ports of component B (NOT creating input port buffers)
while there is more input data
    if there is an empty input buffer on A
         put data into the input buffer
         call EmptyThis Buffer
    if there is a full output buffer on B
         process its data
         call FillThisBuffer
```

```
while there is another full output buffer on B
    process its data
    call FillThisBuffer
```

Rendering an Image Using Tunnelling

In the first program in this chapter, you used the image_decode component to decode a JPEG image into YUV format. To render this, you need a render component. The OpenMAX specification surprisingly does not specify any image render components. However, the Broadcom implementation has the component video render, which will render both single images and videos.

The video_render component has one input port, 60, and no output ports (its output goes to the render device). So, you can simplify the pseudo-code because you won't have any data output buffers and can just concentrate on the input side.

The program to decode and render an image is il render image.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <bcm host.h>
#include <ilclient.h>
void printState(OMX HANDLETYPE handle) {
    // code elided
}
char *err2str(int err) {
    return "error elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
            perror("Stat'ing img file");
            return -1;
    return(st.st size);
}
```

```
unsigned int uWidth;
unsigned int uHeight;
OMX_ERRORTYPE read_into_buffer_and_empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
       printf("Setting EOS on input\n");
       buff_header->nFlags |= OMX_BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                        buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   return r;
}
static void set image decoder input format(COMPONENT T *component) {
   // set input image format
   printf("Setting image decoder format\n");
   OMX IMAGE PARAM PORTFORMATTYPE imagePortFormat;
    //setHeader(&imagePortFormat, sizeof(OMX_IMAGE_PARAM_PORTFORMATTYPE));
    memset(&imagePortFormat, 0, sizeof(OMX IMAGE PARAM PORTFORMATTYPE));
    imagePortFormat.nSize = sizeof(OMX IMAGE PARAM PORTFORMATTYPE);
    imagePortFormat.nVersion.nVersion = OMX_VERSION;
    imagePortFormat.nPortIndex = 320;
    imagePortFormat.eCompressionFormat = OMX IMAGE CodingJPEG;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamImagePortFormat, &imagePortFormat);
}
void setup_decodeComponent(ILCLIENT_T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
```

```
err = ilclient create component(handle,
                                decodeComponent,
                                decodeComponentName,
                                ILCLIENT_DISABLE_ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                     /* |
                                     ILCLIENT ENABLE OUTPUT BUFFERS
                                );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set image decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                              char *renderComponentName,
                              COMPONENT_T **renderComponent) {
    int err;
   err = ilclient create component(handle,
                                renderComponent,
                                renderComponentName,
                                ILCLIENT_DISABLE_ALL_PORTS
                                   /* |
                                    ILCLIENT ENABLE INPUT BUFFERS
                                );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
    err = ilclient_change_component_state(*renderComponent,
                                          OMX_StateIdle);
```

```
if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
int main(int argc, char** argv) {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    char *img;
    ILCLIENT T *handle;
    COMPONENT T *decodeComponent;
    COMPONENT T *renderComponent;
    FILE *fp;
    int toread;
    OMX BUFFERHEADERTYPE *buff header;
    if (argc < 2) {
        fprintf(stderr, "Usage: %s jpeg-image\n", argv[0]);
        exit(1);
    img = argv[1];
    if ((fp = fopen(img, "r")) == NULL) {
    fprintf(stderr, "Can't open: %s\n", img);
          exit(2);
    if (( toread = get_file_size(img)) == -1) {
          fprintf(stderr, "Can't stat: %s\n", img);
          exit(2);
    decodeComponentName = "image decode";
    renderComponentName = "video_render";
    bcm host init();
    handle = ilclient_init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
   if (OMX_Init() != OMX_ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
```

```
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient_set_eos_callback(handle,
                          eos callback,
                          NULL);
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
 // input port
 ilclient_enable_port_buffers(decodeComponent, 320,
                              NULL, NULL, NULL);
 ilclient enable port(decodeComponent, 320);
 err = ilclient change component state(decodeComponent,
                                       OMX StateExecuting);
 if (err < 0) {
     fprintf(stderr, "Couldn't change state to Executing\n");
     exit(1);
 printState(ilclient get handle(decodeComponent));
 // Read the first block so that the decodeComponent can get
 // the dimensions of the image and call port settings
 // changed on the output port to configure it
 buff header =
     ilclient get input buffer(decodeComponent,
                               320,
                               1 /* block */);
 if (buff header != NULL) {
     read into buffer and empty(fp,
                                decodeComponent,
                                buff header,
                                &toread);
     // If all the file has been read in, then
     // we have to re-read this first block.
     // Broadcom bug?
     if (toread <= 0) {
         printf("Rewinding\n");
         // wind back to start and repeat
         fp = freopen(img, "r", fp);
         toread = get file size(img);
     }
 }
 // wait for first input block to set params for output port
 ilclient wait for event(decodeComponent,
                         OMX EventPortSettingsChanged,
                         321, 0, 0, 1,
                         ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                         5);
```

```
printf("Port settings changed\n");
 TUNNEL T tunnel;
 set_tunnel(&tunnel, decodeComponent, 321, renderComponent, 90);
 if ((err = ilclient setup tunnel(&tunnel, 0, 0)) < 0) {
     fprintf(stderr, "Error setting up tunnel %X\n", err);
     exit(1);
 } else {
     printf("Tunnel set up ok\n");
 }
// Okay to go back to processing data
// enable the decode output ports
OMX SendCommand(ilclient get handle(decodeComponent),
                OMX CommandPortEnable, 321, NULL);
ilclient enable port(decodeComponent, 321);
// enable the render output ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX CommandPortEnable, 90, NULL);
*/
ilclient enable port(renderComponent, 90);
// set both components to executing state
 err = ilclient_change_component_state(decodeComponent,
                                       OMX StateExecuting);
 if (err < 0) {
     fprintf(stderr, "Couldn't change state to Idle\n");
     exit(1);
 err = ilclient change component state(renderComponent,
                                       OMX StateExecuting);
 if (err < 0) {
     fprintf(stderr, "Couldn't change state to Idle\n");
     exit(1);
 }
 // now work through the file
 while (toread > 0) {
     OMX ERRORTYPE r;
     // do we have a decode input buffer we can fill and empty?
     buff header =
         ilclient get input buffer(decodeComponent,
                                   1 /* block */);
```

Rendering an Image Without Tunneling

If you choose not to use tunneling, then you have to handle all of the intermediate steps in managing the transfer of information from the decoder to the renderer. This adds a measure of complexity but may be needed if, say, you want to overlay text onto a decoded image. The basic mechanism is to create buffers for one component using OMX_AllocateBuffer or ilclient_enable_port_buffers and to share the resultant buffers using OMX_UseBuffer.

In the tunneling case, you had to wait until one input buffer had been processed before you knew enough about the input image and could establish the tunnel. Similarly, you have to wait for the first buffer before you can set up your nontunneled equivalent.

The first major difference lies in structure formats: the decoder uses the image type OMX_IMAGE_PORTDEFINITIONTYPE, while the renderer uses the video type OMX_VIDEO_PORTDEFINITIONTYPE. While these share many common fields, they are not all aligned in the same place in memory. So, some fields have to be copied across from the image format to the video format.

This involves getting the OMX_IMAGE_PORTDEFINITIONTYPE structure for each component, changing some fields in the video component, and setting them back into the video component. The code to do this is as follows:

```
// Get default values of render
    rportdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    rportdef.nVersion.nVersion = OMX VERSION;
    rportdef.nPortIndex = 90;
    rportdef.nBufferSize = portdef.nBufferSize;
    nBufferSize = portdef.nBufferSize;
    err = OMX GetParameter(ilclient get handle(renderComponent),
                           OMX IndexParamPortDefinition, &rportdef);
    if (err != OMX ErrorNone) {
       fprintf(stderr, "Error getting render port params %s\n", err2str(err));
       return err;
    }
    // tell render input what the decoder output will be providing
    rportdef.format.video.nFrameWidth = portdef.format.image.nFrameWidth;
    rportdef.format.video.nFrameHeight = portdef.format.image.nFrameHeight;
    rportdef.format.video.nStride = portdef.format.image.nStride;
    rportdef.format.video.nSliceHeight = portdef.format.image.nSliceHeight;
    err = OMX SetParameter(ilclient get handle(renderComponent),
                           OMX IndexParamPortDefinition, &rportdef);
    if (err != OMX ErrorNone) {
       fprintf(stderr, "Error setting render port params %s\n", err2str(err));
       return err;
    } else {
       printf("Render port params set up ok, buf size %d\n",
               portdef.nBufferSize);
    }
   return OMX ErrorNone;
}
```

Once the first input buffer has been processed, you can call the previous function to synchronize formats and also create output buffers (only one!) for the decoder. You can use the standard IL Client library call to create the buffers <code>ilclient_enable_port_buffers</code> and enable this port with the following:

There is no need at this point to share the buffer. Anyway, you don't yet have access to the decoder's buffers, not until a nonblocking call to ilclient_get_output_buffer has succeeded in returning an output buffer from the decoder. Once that has been done, a buffer header of type OMX_BUFFERHEADERTYPE * is made available to the client. You can then reuse the buffer in this header.

The following function is a bit messy: you have only one output buffer header from the decoder but three input buffer headers for the renderer. You disable two of them by setting their buffers to NULL. For the shared one, you can share only the *buffer*; the buffer *header* must be distinct. The call OMX_UseBuffer creates a distinct header but shares the buffer. Unfortunately, you must also copy across information from one buffer

header to the other. This type of behavior isn't documented, just something you discover painfully after an hour or so with the debugger and guessing a lot. What has to be copied is the length of the filled buffer.

There is one documented behavior in the 1.1.2 specification's section 3.2.2.14.

OMX_UseBuffer macro shall be executed under the following conditions:

- ...
- On a disabled port when the component is in the OMX_StateExecuting, the OMX_ StatePause, or the OMX_StateIdle state

The problem is that this is either wrong or misleading or the Broadcom implementation is broken. Even when the state is Executing, you have to *enable* the port, not *disable* it! Ho-hum, another two days wasted figuring that out.

The relevant code is as follows:

```
OMX BUFFERHEADERTYPE *pOutputBufferHeader = NULL;
OMX BUFFERHEADERTYPE **ppRenderInputBufferHeader;
int use buffer(COMPONENT T *renderComponent,
                OMX BUFFERHEADERTYPE *buff header) {
    int ret;
    OMX PARAM PORTDEFINITIONTYPE portdef;
    ppRenderInputBufferHeader =
        (OMX BUFFERHEADERTYPE **) malloc(sizeof(void) *
    OMX SendCommand(ilclient get handle(renderComponent),
                    OMX CommandPortEnable, 90, NULL);
    ilclient wait for event(renderComponent,
                            OMX EventCmdComplete,
                            OMX CommandPortEnable, 1,
                            90, 1, 0,
                            5000);
    printState(ilclient get handle(renderComponent));
    ret = OMX_UseBuffer(ilclient_get_handle(renderComponent),
                        &ppRenderInputBufferHeader[0],
                        90,
                        NULL,
                        nBufferSize,
                        buff header->pBuffer);
```

```
if (ret != OMX_ErrorNone) {
        fprintf(stderr, "Eror sharing buffer %s\n", err2str(ret));
        return ret;
    } else {
        printf("Sharing buffer ok\n");
    }
    ppRenderInputBufferHeader[0]->nAllocLen =
        buff header->nAllocLen;
    int n;
    for (n = 1; n < 3; n++) {
        printState(ilclient_get_handle(renderComponent));
        ret = OMX UseBuffer(ilclient get handle(renderComponent),
                             &ppRenderInputBufferHeader[n],
                             90,
                             NULL,
                             Ο,
                             NULL);
        if (ret != OMX ErrorNone) {
            fprintf(stderr, "Eror sharing null buffer %s\n", err2str(ret));
            return ret;
        }
    }
    ilclient enable port(renderComponent, 90);
    ret = ilclient_change_component_state(renderComponent,
                                           OMX StateExecuting);
    if (ret < 0) {
        fprintf(stderr, "Couldn't change render state to Executing\n");
        exit(1);
    return 0;
    Those are the major issues. Playing games with component state and port state until it works is
standard. The program is il_render_image_notunnel.c.
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX_Component.h>
#include <bcm host.h>
#include <ilclient.h>
#define IMG "hype.jpg"
char *img_file = IMG;
```

```
void printState(OMX_HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "elided";
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
void error_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st size);
}
unsigned int uWidth;
unsigned int uHeight;
unsigned int nBufferSize;
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                          COMPONENT T *component,
                                          OMX_BUFFERHEADERTYPE *buff_header,
                                          int *toread) {
    OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    printf("Read %d\n", nread);
    buff_header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                            buff header);
```

```
if (r != OMX_ErrorNone) {
       fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   return r;
}
static void set image decoder input format(COMPONENT T *component) {
    printf("Setting image decoder format\n");
    OMX IMAGE PARAM PORTFORMATTYPE imagePortFormat;
    memset(&imagePortFormat, 0, sizeof(OMX_IMAGE_PARAM_PORTFORMATTYPE));
    imagePortFormat.nSize = sizeof(OMX IMAGE PARAM PORTFORMATTYPE);
    imagePortFormat.nVersion.nVersion = OMX VERSION;
    imagePortFormat.nPortIndex = 320;
    imagePortFormat.eCompressionFormat = OMX IMAGE CodingJPEG;
    OMX SetParameter(ilclient get handle(component),
                     OMX_IndexParamImagePortFormat, &imagePortFormat);
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
   err = ilclient create component(handle,
                                    decodeComponent,
                                    decodeComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT ENABLE OUTPUT BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
       exit(1);
    printState(ilclient get handle(*decodeComponent));
   err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
       fprintf(stderr, "Couldn't change state to Idle\n");
       exit(1);
    printState(ilclient get handle(*decodeComponent));
```

```
// must be before we enable buffers
    set image decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient_create_component(handle,
                                    renderComponent,
                                    renderComponentName,
                                    ILCLIENT_DISABLE_ALL_PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
    printState(ilclient get handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
OMX BUFFERHEADERTYPE *pOutputBufferHeader = NULL;
OMX BUFFERHEADERTYPE **ppRenderInputBufferHeader;
int setup shared buffer format(COMPONENT T *decodeComponent,
                               COMPONENT T *renderComponent) {
    OMX_PARAM_PORTDEFINITIONTYPE portdef, rportdef;;
    int ret;
    OMX ERRORTYPE err;
    // need to setup the input for the render with the output of the
    portdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    portdef.nVersion.nVersion = OMX VERSION;
    portdef.nPortIndex = 321;
    OMX_GetParameter(ilclient_get_handle(decodeComponent),
                     OMX IndexParamPortDefinition, &portdef);
    // Get default values of render
    rportdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    rportdef.nVersion.nVersion = OMX VERSION;
    rportdef.nPortIndex = 90;
```

```
rportdef.nBufferSize = portdef.nBufferSize;
    nBufferSize = portdef.nBufferSize;
   err = OMX GetParameter(ilclient get handle(renderComponent),
                           OMX IndexParamPortDefinition, &rportdef);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error getting render port params %s\n", err2str(err));
       return err;
    }
    // tell render input what the decoder output will be providing
    //Copy some
    rportdef.format.video.nFrameWidth = portdef.format.image.nFrameWidth;
    rportdef.format.video.nFrameHeight = portdef.format.image.nFrameHeight;
    rportdef.format.video.nStride = portdef.format.image.nStride;
    rportdef.format.video.nSliceHeight = portdef.format.image.nSliceHeight;
   err = OMX SetParameter(ilclient get handle(renderComponent),
                           OMX IndexParamPortDefinition, &rportdef);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error setting render port params %s\n", err2str(err));
       return err;
    } else {
       printf("Render port params set up ok, buf size %d\n",
               portdef.nBufferSize);
    }
   return OMX_ErrorNone;
}
int use buffer(COMPONENT T *renderComponent,
                OMX BUFFERHEADERTYPE *buff header) {
    int ret:
    OMX PARAM_PORTDEFINITIONTYPE portdef;
    ppRenderInputBufferHeader =
        (OMX BUFFERHEADERTYPE **) malloc(sizeof(void) *
    OMX_SendCommand(ilclient_get_handle(renderComponent),
                    OMX_CommandPortEnable, 90, NULL);
    ilclient_wait_for_event(renderComponent,
                            OMX EventCmdComplete,
                            OMX CommandPortEnable, 1,
                            90, 1, 0,
                            5000);
    printState(ilclient_get_handle(renderComponent));
```

```
ret = OMX_UseBuffer(ilclient_get_handle(renderComponent),
                        &ppRenderInputBufferHeader[0],
                        90,
                        NULL,
                        nBufferSize,
                        buff header->pBuffer);
    if (ret != OMX ErrorNone) {
        fprintf(stderr, "Eror sharing buffer %s\n", err2str(ret));
        return ret;
    } else {
        printf("Sharing buffer ok\n");
    ppRenderInputBufferHeader[0]->nAllocLen =
        buff header->nAllocLen;
    int n;
    for (n = 1; n < 3; n++) {
        printState(ilclient get handle(renderComponent));
        ret = OMX UseBuffer(ilclient get handle(renderComponent),
                            &ppRenderInputBufferHeader[n],
                            90,
                            NULL,
                            0,
                            NULL);
        if (ret != OMX ErrorNone) {
            fprintf(stderr, "Eror sharing null buffer %s\n", err2str(ret));
            return ret;
        }
    }
    ilclient enable port(renderComponent, 90);
    ret = ilclient_change_component_state(renderComponent,
                                           OMX StateExecuting);
    if (ret < 0) {
        fprintf(stderr, "Couldn't change render state to Executing\n");
        exit(1);
   return 0;
int main(int argc, char** argv) {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    FILE *fp;
    int toread;
    ILCLIENT T *handle;
```

}

```
COMPONENT_T *decodeComponent;
COMPONENT T *renderComponent;
if (argc == 2) {
    img file = argv[1];
if ((fp = fopen(img_file, "r")) == NULL) {
    fprintf(stderr, "Can't open: %s\n", img file);
    exit(2);
if ((toread = get file size(img file) == -1) {
    fprintf(stderr, "Can't stat: %s\n", img file);
    exit(2);
}
OMX BUFFERHEADERTYPE *buff_header;
decodeComponentName = "image decode";
renderComponentName = "video render";
bcm host init();
handle = ilclient init();
if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
}
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
}
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient set eos callback(handle,
                          eos callback,
                          NULL);
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
ilclient enable port buffers(decodeComponent, 320,
                             NULL, NULL, NULL);
ilclient_enable_port(decodeComponent, 320);
```

```
err = ilclient_change_component_state(decodeComponent,
                                       OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change decode state to Executing\n");
printState(ilclient_get_handle(decodeComponent));
// Read the first block so that the decodeComponent can get
// the dimensions of the image and call port settings
// changed on the output port to configure it
buff header =
    ilclient_get_input_buffer(decodeComponent,
                               1 /* block */);
if (buff header != NULL) {
    read into buffer and empty(fp,
                                decodeComponent,
                                buff header,
                                &toread);
    // If all the file has been read in, then
    // we have to re-read this first block.
    // Broadcom bug?
    if (toread <= 0) {
        printf("Rewinding\n");
        // wind back to start and repeat
        fp = freopen(img_file, "r", fp);
        toread = get file size(img file);
}
// wait for first input block to set params for output port
ilclient_wait_for_event(decodeComponent,
                         OMX EventPortSettingsChanged,
                         321, 0, 0, 1,
                         ILCLIENT_EVENT_ERROR | ILCLIENT_PARAMETER_CHANGED,
                         10000);
printf("Port settings changed\n");
setup shared buffer format(decodeComponent, renderComponent);
ilclient_enable_port_buffers(decodeComponent, 321,
                              NULL, NULL, NULL);
ilclient enable port(decodeComponent, 321);
// set decoder only to executing state
err = ilclient change component state(decodeComponent,
                                       OMX_StateExecuting);
```

```
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
}
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have a decode input buffer we can fill and empty?
    buff header =
        ilclient get input buffer(decodeComponent,
                                  320,
                                  1 /* block */);
    if (buff header != NULL) {
        read_into_buffer_and_empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
    }
    // do we have an output buffer that has been filled?
    buff header =
        ilclient get output buffer(decodeComponent,
                                  321,
                                  0 /* no block */);
    if (buff header != NULL) {
        printf("Got an output buffer length %d\n",
               buff header->nFilledLen);
        if (buff header->nFlags & OMX BUFFERFLAG EOS) {
            printf("Got EOS\n");
        if (pOutputBufferHeader == NULL) {
            use_buffer(renderComponent, buff_header);
            pOutputBufferHeader = buff header;
        }
        if (buff header->nFilledLen > 0) {
            OMX EmptyThisBuffer(ilclient get handle(renderComponent),
                                buff_header);
        }
        OMX_FillThisBuffer(ilclient_get_handle(decodeComponent),
                           buff header);
    }
}
int done = 0;
while (!done) {
    printf("Getting last output buffers\n");
    buff header =
```

```
ilclient get output buffer(decodeComponent,
                                        321,
                                        1 /* block */);
        printf("Got a final output buffer length %d\n",
               buff header->nFilledLen);
        if (buff_header->nFlags & OMX_BUFFERFLAG EOS) {
            printf("Got EOS\n");
            done = 1;
        }
        if (pOutputBufferHeader == NULL) {
            use buffer(renderComponent, buff header);
            pOutputBufferHeader = buff header;
        }
        ppRenderInputBufferHeader[0]->nFilledLen = buff header->nFilledLen;
        OMX EmptyThisBuffer(ilclient get handle(renderComponent),
                            ppRenderInputBufferHeader[0]);
  }
    sleep(100);
   exit(0);
}
```

Conclusion

This chapter has shown basic image handling using multiple components. There are more complex things that can be done, which will be addressed in later editions of this book.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAX IL 1.1.2 Specification: https://www.khronos.org/registry/omxil/ specs/OpenMAX_IL_1_1_2_Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAX IL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 13



This chapter looks at video processing using the Broadcom GPU on the Raspberry Pi.

Building Programs

You can build the programs in this chapter using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OMX_INC = -I /opt/vc/include/IL
OMX_ILCLIENT_INC = -I/opt/vc/src/hello_pi/libs/ilclient
INCLUDES = $(DMX_INC) $(EGL_INC) $(OMX_INC) $(OMX_ILCLIENT_INC)

CFLAGS=-g -DRASPBERRY_PI -DOMX_SKIP64BIT $(INCLUDES)

CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OMX_LIBS = -lopenmaxil
OMX_ILCLIENT_LIBS = -L/opt/vc/src/hello_pi/libs/ilclient -lilclient

LDLIBS = $(DMX_LIBS) $(EGL_LIBS) $(OMX_LIBS) $(OMX_ILCLIENT_LIBS)

all: il decode video il render video
```

Video Components

The Raspberry Pi has a number of OpenMAX components specifically for video processing, as shown here:

- camera
- egl render
- video decode

© Jan Newmarch 2017

- video_encode
- video render
- video scheduler
- video splitter

Video Formats

OpenMAX has a number of data structures used to get and set information about components. You have seen some of these before.

- OMX_PORT_PARAM_TYPE: This is used with the index parameter OMX_IndexParamVideoInit in a call to OMX_GetParameter. This gives the number of video ports and the port number of the first port.
- OMX_PARAM_PORTDEFINITIONTYPE: This is used with the index parameter OMX_PARAM_PORTDEFINITIONTYPE to give, for each port, the number of buffers, the size of each buffer, and the direction (input or output) of the port.
- OMX_VIDEO_PORTDEFINITIONTYPE: This is a field of the OMX_PARAM_PORTDEFINITIONTYPE for videos.
- OMX_VIDEO_PARAM_PORTFORMATTYPE: This is used to get information about the different formats supported by each port.

Some of these were discussed in Chapter 8.

You haven't looked at the field OMX_VIDEO_PORTDEFINITIONTYPE, which is part of the port definition information. It contains the following relevant fields:

```
typedef struct OMX_VIDEO_PORTDEFINITIONTYPE {
    OMX_STRING cMIMEType;
    OMX_NATIVE_DEVICETYPE pNativeRender;
    OMX_U32 nFrameWidth;
    OMX_U32 nFrameHeight;
    OMX_U32 nStride;
    OMX_U32 nSliceHeight;
    OMX_U32 nBitrate;
    OMX_U32 xFramerate;
    OMX_BOOL bFlagErrorConcealment;
    OMX_VIDEO_CODINGTYPE eCompressionFormat;
    OMX_COLOR_FORMATTYPE eColorFormat;
    OMX_NATIVE_WINDOWTYPE pNativeWindow;
} OMX_VIDEO_PORTDEFINITIONTYPE;
```

The last two but one fields are the current values set for the port. The *possible* values are obtained from the next structure OMX_VIDEO_PARAM_PORTFORMATTYPE, so I will discuss it in the next paragraph. The major fields you get here, though, are parameters about the video size: nFrameWidth, nFrameHeight, nStride, and nSliceHeight. These are parameters you often need if you are, say, saving a decoded video in a different format such as MPEG4.

The OMX_VIDEO_PARAM_PORTFORMATTYPE is defined (in section 4.3.5 in the 1.1.2 specification) as follows:

The first two fields are common to all OpenMAX structures. The nPortIndex field is the port you are looking at. The nIndex field is to distinguish between all the different format types supported by this port. The eCompressionFormat and eColorFormat fields give information about the format, while the last field gives the frame rate of the video in frames per second.

The values for OMX_VIDEO_CODINGTYPE are given in Table 4-66 of the 1.1.2 specification and on the RPi are given in the file /opt/vc/include/IL/OMX_Video.h, as shown here:

```
typedef enum OMX VIDEO CODINGTYPE {
     OMX VIDEO CodingUnused, /** Value when coding is N/A */
     OMX_VIDEO_CodingAutoDetect, /** Autodetection of coding type */
     OMX_VIDEO_CodingMPEG2, /** AKA: H.262 */
    OMX_VIDEO_CodingH263, /** H.263 */
OMX_VIDEO_CodingMPEG4, /** MPEG-4 */
OMX_VIDEO_CodingWV, /** all versions of Windows Media Video */
OMX_VIDEO_CodingRV, /** all versions of Real Video */
OMX_VIDEO_CodingAVC, /** H.264/AVC */
OMX_VIDEO_CodingMIDEC /** MALE OF THE OWN VIDEO CodingMIDEC /** MALE OF THE OWN VIDEO CODING MIDEC /**
     OMX VIDEO CodingMJPEG,
                                         /** Motion JPEG */
     OMX VIDEO CodingKhronosExtensions = 0x6F000000, /** Reserved region for introducing
Khronos Standard Extensions */
     OMX VIDEO CodingVendorStartUnused = 0x7F000000, /** Reserved region for introducing
Vendor Extensions */
     OMX_VIDEO_CodingVP6, /** On2 VP6 */
     OMX VIDEO CodingVP7,
                                        /** On2 VP7 */
     OMX VIDEO CodingVP8,
                                        /** On2 VP8 */
                                        /* raw YUV video */
     OMX VIDEO CodingYUV,
     OMX VIDEO CodingSorenson, /** Sorenson */
     OMX VIDEO CodingTheora, /** Theora */
     OMX VIDEO CodingMVC,
                                         /** H.264/MVC */
     OMX VIDEO CodingMax = 0x7FFFFFFF
} OMX VIDEO CODINGTYPE;
     The type OMX COLOR FORMATTYPE is more informative. It is defined in the file /opt/vc/include/IL/
OMX IVCommon.h, as follows:
typedef enum OMX_COLOR_FORMATTYPE {
     OMX COLOR FormatUnused,
     OMX COLOR FormatMonochrome,
     OMX COLOR Format8bitRGB332,
     OMX COLOR Format12bitRGB444,
     OMX COLOR Format16bitARGB4444,
     OMX COLOR Format16bitARGB1555,
```

```
OMX COLOR Format16bitRGB565,
    OMX COLOR Format16bitBGR565,
    OMX COLOR Format18bitRGB666,
    OMX_COLOR_Format18bitARGB1665,
    OMX COLOR Format19bitARGB1666,
    OMX COLOR Format24bitRGB888,
    OMX COLOR Format24bitBGR888,
    OMX COLOR Format24bitARGB1887,
    OMX COLOR Format25bitARGB1888,
    OMX COLOR Format32bitBGRA8888,
    OMX COLOR Format32bitARGB8888,
    OMX COLOR FormatYUV411Planar,
    OMX COLOR FormatYUV411PackedPlanar,
    OMX COLOR FormatYUV420Planar,
    OMX COLOR FormatYUV420PackedPlanar,
    OMX COLOR FormatYUV420SemiPlanar,
    OMX COLOR FormatYUV422Planar,
    OMX COLOR FormatYUV422PackedPlanar,
    OMX COLOR FormatYUV422SemiPlanar,
    OMX COLOR FormatYCbYCr,
    OMX COLOR FormatYCrYCb,
    OMX COLOR FormatCbYCrY,
    OMX COLOR FormatCrYCbY,
    OMX COLOR FormatYUV444Interleaved,
    OMX COLOR FormatRawBayer8bit,
    OMX COLOR FormatRawBayer10bit,
    OMX COLOR FormatRawBayer8bitcompressed,
    OMX_COLOR_FormatL2,
    OMX COLOR FormatL4,
    OMX COLOR FormatL8,
    OMX COLOR FormatL16,
    OMX COLOR FormatL24,
    OMX COLOR FormatL32,
    OMX COLOR FormatYUV420PackedSemiPlanar,
    OMX COLOR FormatYUV422PackedSemiPlanar,
    OMX COLOR Format18BitBGR666,
    OMX COLOR Format24BitARGB6666,
    OMX COLOR Format24BitABGR6666,
    OMX COLOR FormatKhronosExtensions = 0x6F000000, /** Reserved region for introducing
Khronos Standard Extensions */
    OMX COLOR FormatVendorStartUnused = 0x7F000000, /** Reserved region for introducing
Vendor Extensions */
    OMX COLOR Format32bitABGR8888,
    OMX COLOR Format8bitPalette,
    OMX COLOR FormatYUVUV128,
    OMX COLOR FormatRawBayer12bit,
    OMX COLOR FormatBRCMEGL,
    OMX COLOR FormatBRCMOpaque,
    OMX COLOR FormatYVU420PackedPlanar,
    OMX COLOR FormatYVU420PackedSemiPlanar,
    OMX COLOR FormatMax = 0x7FFFFFFF
} OMX COLOR FORMATTYPE;
```

That's a rather large number of formats!

Running the program info from Chapter 8 shows the following for the video decode component:

```
Video ports:
```

Ports start on 130

There are 2 open ports

Port 130 has 20 buffers (minimum 1) of size 81920

Direction is input

Supported video formats are:

Video format encoding 0x14

Video compression format 0x4

Video format encoding 0x14

Video compression format 0x7

Video format encoding 0x14

Video compression format 0x7F000007

Video format encoding 0x14

Video compression format 0x8

Video format encoding 0x14

Video compression format 0x5

Video format encoding 0x14

Video compression format 0x3

Video format encoding 0x14

Video compression format 0x2

Video format encoding 0x14

Video compression format 0x7F000001

Video format encoding 0x14

Video compression format 0x7F000002

Video format encoding 0x14

Video compression format 0x7F000003

Video format encoding 0x14

Video compression format 0x6

Video format encoding 0x14

Video compression format 0x7F000004

Video format encoding 0x14

Video compression format 0x7F000005

Video format encoding 0x14

Video compression format 0x7F000006

Video format encoding 0x14

Video compression format 0x0

No more formats supported

Port 131 has 1 buffers (minimum 1) of size 115200

Direction is output

Supported video formats are:

Video format encoding 0x14

Video compression format 0x0

No more formats supported

The compression formats are as follows:

- 0x2: OMX VIDEO CodingMPEG2
- 0x3: OMX VIDEO CodingH263

- 0x4: OMX VIDEO CodingMPEG4
- 0x5: OMX VIDEO CodingWMV
- 0x6: OMX VIDEO CodingRV
- 0x7: OMX VIDEO CodingAVC
- 0x8: OMX VIDEO CodingMJPEG
- 0x7F000001: OMX VIDEO CodingVP6
- 0x7F000002: OMX VIDEO CodingVP7
- 0x7F000003: OMX VIDEO CodingVP8
- 0x7F000004: OMX VIDEO CodingYUV
- 0x7F000005: OMX_VIDEO_CodingSorenson
- 0x7F000006: OMX VIDEO CodingTheora

Currently I have not confirmed any of these except for H.264 (CodingAVC).

Decoding an H.264 File

The program to decode a video into an uncompressed format is essentially the same as the one for decoding an image. There is an essential difference: reading one block is not enough for the component to get information about the video file format, and multiple block reads generally have to occur.

In this example, you just slap a loop around reading the initial blocks until a PortSettingsChanged event occurs. The call to ilclient_wait_for_event will time out for the first set of calls, so you drop the timeout period from 10 seconds down to 2 seconds. This isn't any good for interactive viewing, of course, but here you are just decoding.

The significant change from the image-decoding program is this initial loop:

```
int port settings changed = 0;
while (!port settings changed) {
   buff header =
        ilclient get input buffer(component,
                                  130,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   component,
                                   buff header,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            fp = freopen(VIDEO, "r", fp);
            toread = get file size(VIDEO);
```

```
}
        }
        // try if this block sets params for output port
        err = ilclient wait for event(component,
                                      OMX EventPortSettingsChanged,
                                       131, 0, 0, 1,
                                       ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                       2000);
        if (err < 0) {
            printf("Wait for port settings changed timed out\n");
            port_settings_changed = 1;
        }
    }
    The full program is il decode video.c.
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
#define video "/opt/vc/src/hello pi/hello video/test.h264"
void printState(OMX HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
   return "elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
            perror("Stat'ing video file");
            return -1;
```

```
return(st.st_size);
}
static void set video decoder input format(COMPONENT T *component) {
   // set input video format
    printf("Setting video decoder format\n");
    OMX VIDEO PARAM PORTFORMATTYPE videoPortFormat;
    //setHeader(&videoPortFormat, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    memset(&videoPortFormat, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    videoPortFormat.nSize = sizeof(OMX VIDEO PARAM PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
    videoPortFormat.nPortIndex = 130;
    videoPortFormat.eCompressionFormat = OMX VIDEO CodingAVC;
    OMX_SetParameter(ilclient_get_handle(component),
                     OMX IndexParamVideoPortFormat, &videoPortFormat);
}
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
    printf("Read %d, %d still left\n", nread, *toread);
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                        buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    }
    return r;
}
OMX ERRORTYPE save info from filled buffer(COMPONENT T *component,
                                           OMX BUFFERHEADERTYPE * buff header) {
    OMX_ERRORTYPE r;
    printf("Got a filled buffer with %d, allocated %d\n",
           buff header->nFilledLen,
```

```
buff header->nAllocLen);
    if (buff header->nFlags & OMX BUFFERFLAG EOS) {
        printf("Got EOS on output\n");
        exit(0);
    }
    // and then refill it
    r = OMX FillThisBuffer(ilclient get handle(component),
                           buff header);
    if (r != OMX_ErrorNone) {
        fprintf(stderr, "Fill buffer error %s\n",
                err2str(r));
   return r;
}
void get output port settings(COMPONENT T *component) {
   OMX PARAM PORTDEFINITIONTYPE portdef;
    printf("Port settings changed\n");
    // need to setup the input for the resizer with the output of the
    // decoder
    portdef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
    portdef.nVersion.nVersion = OMX VERSION;
    portdef.nPortIndex = 131;
    OMX GetParameter(ilclient get handle(component),
                     OMX IndexParamPortDefinition, &portdef);
    unsigned int uWidth =
        (unsigned int) portdef.format.video.nFrameWidth;
    unsigned int uHeight =
        (unsigned int) portdef.format.video.nFrameHeight;
    unsigned int uStride =
        (unsigned int) portdef.format.video.nStride;
    unsigned int uSliceHeight =
        (unsigned int) portdef.format.video.nSliceHeight;
    printf("Frame width %d, frame height %d, stride %d, slice height %d\n",
           uWidth,
           uHeight,
           uStride,
           uSliceHeight);
    printf("Getting format Compression 0x%x Color Format: 0x%x\n",
           (unsigned int) portdef.format.video.eCompressionFormat,
           (unsigned int) portdef.format.video.eColorFormat);
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    int err;
    ILCLIENT_T *handle;
```

```
COMPONENT_T *component;
 FILE *fp = fopen(video, "r");
 int toread = get_file_size(video);
 OMX_BUFFERHEADERTYPE *buff_header;
 componentName = "video decode";
 bcm host init();
 handle = ilclient_init();
 if (handle == NULL) {
     fprintf(stderr, "IL client init failed\n");
     exit(1);
 }
if (OMX Init() != OMX ErrorNone) {
     ilclient destroy(handle);
     fprintf(stderr, "OMX init failed\n");
     exit(1);
 }
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient_set_eos_callback(handle,
                          eos callback,
                          NULL);
 err = ilclient create component(handle,
                             &component,
                             componentName,
                             ILCLIENT DISABLE ALL PORTS
                                  ILCLIENT ENABLE INPUT BUFFERS
                                  ILCLIENT ENABLE OUTPUT BUFFERS
                             );
 if (err == -1) {
     fprintf(stderr, "Component create failed\n");
     exit(1);
 printState(ilclient get handle(component));
 err = ilclient_change_component_state(component,
                                       OMX StateIdle);
 if (err < 0) {
     fprintf(stderr, "Couldn't change state to Idle\n");
     exit(1);
 printState(ilclient get handle(component));
 // must be before we enable buffers
 set video decoder input format(component);
```

```
// input port
ilclient_enable_port_buffers(component, 130,
                             NULL, NULL, NULL);
ilclient_enable_port(component, 130);
err = ilclient change component state(component,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(component));
// Read the first block so that the component can get
// the dimensions of the video and call port settings
// changed on the output port to configure it
int port settings changed = 0;
while (!port settings changed) {
buff header =
    ilclient get input buffer(component,
                              1 /* block */);
if (buff header != NULL) {
    read into buffer and empty(fp,
                               component,
                               buff header,
                               &toread);
    // If all the file has been read in, then
    // we have to re-read this first block.
    // Broadcom bug?
    if (toread <= 0) {
        printf("Rewinding\n");
        // wind back to start and repeat
        fp = freopen(video, "r", fp);
        toread = get file size(video);
    }
}
// wait for first input block to set params for output port
err = ilclient wait for event(component,
                              OMX EventPortSettingsChanged,
                              131, 0, 0, 1,
                              ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
if (err < 0) {
    printf("Wait for port settings changed timed out\n");
} else {
    port_settings_changed = 1;
err = ilclient_remove_event(component,
```

```
OMX_EventPortSettingsChanged,
                              131, 0, 0, 1);
if (err < 0) {
    printf("Wait for remove port settings changed timed out\n");
    port settings changed = 1;
}
get_output_port_settings(component);
// now enable output port since port params have been set
ilclient_enable_port_buffers(component, 131,
                             NULL, NULL, NULL);
ilclient enable port(component, 131);
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have an input buffer we can fill and empty?
    buff header =
        ilclient get input buffer(component,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                               component,
                               buff header,
                               &toread);
    }
    // do we have an output buffer that has been filled?
    buff header =
        ilclient get output buffer(component,
                                  0 /* no block */);
    if (buff header != NULL) {
        save info from filled buffer(component,
                                     buff header);
    } else {
        printf("No filled buffer\n");
}
while (1) {
    printf("Getting last output buffers\n");
    buff header =
        ilclient_get_output_buffer(component,
                                    1 /* block */);
```

The program runs with no command-line parameters. The Videocore library comes with a standard H.264 example clip, /opt/vc/src/hello_pi/hello_video/test.h264, from Big Buck Bunny. It reads multiple frames before a PortSettngsChanged event occurs at which time the video format can be determined.

```
Read 81920, 30353369 still left
Empty buffer done
Wait for port settings changed timed out
Wait for remove port settings changed timed out
Read 81920, 30271449 still left
Empty buffer done
Wait for remove port settings changed timed out
Port settings changed
Frame width 1920, frame height 1080, stride 1920, slice height 1088
Getting format Compression 0x0 Color Format: 0x14
```

Rendering an H.264 Video

In a similar manner to decoding an image, rendering a video closely follows the code for rendering an image. However, there is now a major difference in how you wait for the initial PortSettingsChanged event. You have seen these two possibilities so far:

- Read the first part of the data and then block, waiting for the PortSettingsChanged event that you know will come.
- Keep reading data, each time block waiting for the PortSettingsChanged event and timing out if it doesn't arrive.

Neither of these two is acceptable for the immediate rendering of videos. It may take more than one read, and waiting on timeouts is too slow. Instead, you need to adopt an alternative approach based on the ilclient_remove_event function, which returns true if it can remove an event from the list of those events already seen.

The revised wait for the PortSettingsChanged event is as follows:

```
while there is more data
read a new buffer
empty the buffer

if a PortSettingsChanged event has occurred
break

if there is no more data
```

```
block waiting for a PortSettingsChanged event
if failed on timeout
    error
else
    break
```

(This algorithm should be generally applicable. But it breaks on the tunneled image rendering for unknown reasons.)

The video-rendering program using this is il render video.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <bcm host.h>
#include <ilclient.h>
#define VIDEO "/opt/vc/src/hello pi/hello video/test.h264"
char *video_file = VIDEO;
void printState(OMX HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing video file");
        return -1;
    return(st.st size);
}
unsigned int uWidth;
unsigned int uHeight;
```

```
OMX_ERRORTYPE read_into_buffer_and_empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
   OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff_size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
    printf("Read %d, %d still left\n", nread, *toread);
    if (*toread <= 0) {
       printf("Setting EOS on input\n");
       buff_header->nFlags |= OMX_BUFFERFLAG_EOS;
   r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    if (r != OMX_ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   return r;
}
static void set video decoder input format(COMPONENT T *component) {
    int err;
    // set input video format
    printf("Setting video decoder format\n");
    OMX VIDEO PARAM PORTFORMATTYPE videoPortFormat;
    //setHeader(&videoPortFormat, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    memset(&videoPortFormat, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
   videoPortFormat.nSize = sizeof(OMX_VIDEO_PARAM_PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
   videoPortFormat.nPortIndex = 130;
   videoPortFormat.eCompressionFormat = OMX_VIDEO_CodingAVC;
   err = OMX SetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
       fprintf(stderr, "Error setting video decoder format %s\n", err2str(err));
       exit(1);
    } else {
       printf("Video decoder format set up ok\n");
    }
}
```

```
void setup_decodeComponent(ILCLIENT_T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
    err = ilclient create component(handle,
                                     decodeComponent,
                                     decodeComponentName,
                                     ILCLIENT DISABLE ALL PORTS
                                     ILCLIENT ENABLE INPUT BUFFERS
                                     ILCLIENT ENABLE OUTPUT BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set video decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient create component(handle,
                                     renderComponent,
                                     renderComponentName,
                                     ILCLIENT DISABLE ALL PORTS
                                     ILCLIENT ENABLE INPUT BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                          OMX_StateIdle);
```

```
if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
   printState(ilclient get handle(*renderComponent));
}
int main(int argc, char** argv) {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    ILCLIENT T *handle;
   COMPONENT T *decodeComponent;
   COMPONENT_T *renderComponent;
   FILE *fp;
    int toread;
   OMX_BUFFERHEADERTYPE *buff_header;
    if (argc == 2) {
        video file = argv[1];
    if ((fp = fopen(video file, "r")) == NULL) {
        fprintf(stderr, "Can't open: %s\n", video file);
        exit(2);
    if ((toread = get_file_size(video_file)) == -1) {
        fprintf(stderr, "Can't stat: %s\n", video file);
        exit(2);
    }
    decodeComponentName = "video decode";
    renderComponentName = "video_render";
    bcm host init();
   handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient set error callback(handle,
                                error callback,
                                NULL);
```

```
ilclient_set_eos_callback(handle,
                          eos callback,
                          NULL);
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
ilclient_enable_port_buffers(decodeComponent, 130,
                             NULL, NULL, NULL);
ilclient enable port(decodeComponent, 130);
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(decodeComponent));
// Read blocks and break out when we see a
// PortSettingsChanged
while (toread > 0) {
    buff header =
        ilclient get input buffer(decodeComponent,
                                  130,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            fp = freopen(video file, "r", fp);
            toread = get file_size(video_file);
        }
    }
    if (toread > 0 && ilclient_remove_event(decodeComponent,
                                            OMX EventPortSettingsChanged,
                                             131, 0, 0, 1) == 0) {
        printf("Removed port settings event\n");
        break;
    } else {
```

```
printf("No portr settting seen yet\n");
    }
    // wait for first input block to set params for output port
    if (toread == 0) {
        // wait for first input block to set params for output port
        err = ilclient wait for event(decodeComponent,
                                     OMX EventPortSettingsChanged,
                                     131, 0, 0, 1,
                                     ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                     2000);
        if (err < 0) {
            fprintf(stderr, "No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            break;
        }
    }
}
// set the decode component to idle and disable its ports
err = ilclient_change_component_state(decodeComponent,
                                      OMX StateIdle);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
ilclient_disable_port(decodeComponent, 131);
ilclient disable port buffers(decodeComponent, 131,
                              NULL, NULL, NULL);
// set up the tunnel between decode and render ports
err = OMX SetupTunnel(ilclient get handle(decodeComponent),
                      ilclient get handle(renderComponent),
                      90);
if (err != OMX_ErrorNone) {
    fprintf(stderr, "Error setting up tunnel %X\n", err);
    exit(1);
} else {
    printf("Tunnel set up ok\n");
// Okay to go back to processing data
// enable the decode output ports
OMX SendCommand(ilclient get handle(decodeComponent),
                OMX CommandPortEnable, 131, NULL);
ilclient enable port(decodeComponent, 131);
```

```
// enable the render output ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX CommandPortEnable, 90, NULL);
ilclient enable port(renderComponent, 90);
// set both components to executing state
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
err = ilclient change component state(renderComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
}
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have a decode input buffer we can fill and empty?
    buff header =
        ilclient get_input_buffer(decodeComponent,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                    decodeComponent,
                                    buff header,
                                   &toread);
    }
ilclient wait for event(renderComponent,
                        OMX EventBufferFlag,
                        90, 0, OMX BUFFERFLAG EOS, 0,
                        ILCLIENT BUFFER FLAG EOS, 10000);
printf("EOS on render\n");
sleep(10);
exit(0);
```

The program takes the default H.264 but can be overridden by a command-line option. It plays the short segment and then terminates.

}

Going Full-Screen

The Broadcom version of OpenMAX has a nonstandard configuration mechanism that can be applied to video-rendering components. This can be done as follows:

Conclusion

This chapter has looked at decoding and rendering H.264 video streams. Playing MP4 files is covered in Chapter 16.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAXIL 1.1.2 Specification: https://www.khronos.org/registry/omxil/specs/OpenMAX IL 1 1 2 Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAX IL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 14



This chapter looks at audio processing on the Raspberry Pi. The support from OpenMAX is weaker: there is no satisfactory decode component. You have to resort to FFmpeg to decode and render audio.

Building Programs

Some programs in this chapter use libraries from the LibAV project, so development files from LibAV need to be installed.

```
sudo apt-get install libavcodec-dev
sudo apt-get install libavformat-dev
```

You can then build the programs in this chapter using the Makefile, which adds in the LibAV libraries.

```
DMX INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs host/linux
EGL INC =
OMX INC =
          -I /opt/vc/include/IL
OMX ILCLIENT INC = -I/opt/vc/src/hello pi/libs/ilclient
INCLUDES = $(DMX INC) $(EGL INC) $(OMX INC) $(OMX ILCLIENT INC)
CFLAGS=-g -DRASPBERRY PI -DOMX SKIP64BIT $(INCLUDES)
CPPFLAGS =
DMX LIBS = -L/opt/vc/lib/ -lbcm host -lvcos -lvchiq arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OMX LIBS = -lopenmaxil
OMX ILCLIENT LIBS = -L/opt/vc/src/hello pi/libs/ilclient -lilclient
AV_LIBS = $(shell pkg-config --libs libavcodec libavformat libavutil)
LDLIBS = $(DMX LIBS) $(EGL LIBS) $(OMX LIBS) $(OMX ILCLIENT LIBS) $(AV LIBS)
all: api-example il render audio \
     il ffmpeg render audio il test audio encodings \
     il_ffmpeg_render_resample_audio
```

© Jan Newmarch 2017 203

Audio Components

The Raspberry Pi has a number of OpenMAX components specifically for audio processing.

- audio capture
- audio decode
- audio encode
- audio lowpower
- audio mixer
- audio processor
- audio render
- audio splitter

Audio Formats

OpenMAX has a number of data structures used to get and set information about components. You have seen some of these before.

- OMX_PORT_PARAM_TYPE: This is used with the index parameter
 OMX_IndexParamImageInit in a call to OMX_GetParameter. This gives the number of image ports and the port number of the first port.
- OMX_PARAM_PORTDEFINITIONTYPE: This is used with the index parameter OMX_PARAM_PORTDEFINITIONTYPE to give, for each port, the number of buffers, the size of each buffer, and the direction (input or output) of the port.
- OMX_AUDIO_PORTDEFINITIONTYPE: This is a field of the OMX_PARAM_PORTDEFINITIONTYPE for images.
- OMX_AUDIO_PARAM_PORTFORMATTYPE: This is used to get information about the different formats supported by each port.

Some of these were discussed in Chapter X.

You haven't looked at the field OMX_AUDIO_PORTDEFINITIONTYPE, which is part of the port definition information. It contains the following relevant fields:

```
typedef struct OMX_AUDIO_PORTDEFINITIONTYPE {
   OMX_STRING cMIMEType;
   OMX_NATIVE_DEVICETYPE pNativeRender;
   OMX_BOOL bFlagErrorConcealment;
   OMX_AUDIO_CODINGTYPE eEncoding;
} OMX_AUDIO_PORTDEFINITIONTYPE;
```

The last two fields are the current values set for the port. The *possible* values are obtained from the next structure, OMX_AUDIO_PARAM_PORTFORMATTYPE, so I will discuss it in the next paragraph. The major field you get here is the audio encoding.

OMX AUDIO PARAM PORTFORMATTYPE is defined (in section 4.1.16 in the 1.1.2 specification) as follows:

```
typedef struct OMX_AUDIO_PARAM_PORTFORMATTYPE {
   OMX_U32 nSize;
   OMX_VERSIONTYPE nVersion;
   OMX_U32 nPortIndex;
   OMX_U32 nIndex;
   OMX_AUDIO_CODINGTYPE eEncoding;
} OMX_AUDIO PARAM PORTFORMATTYPE;
```

The first two fields are common to all OpenMAX structures. The nPortIndex field is the port you are looking at. The nIndex field is to distinguish between all the different format types supported by this port. The eEncoding field gives information about the format.

The values for OMX_AUDIO_CODINGTYPE are given in Table 4-66 of the 1.1.2 specification and on the RPi are given in the file /opt/vc/include/IL/OMX_Audio.h, as follows:

```
typedef enum OMX AUDIO CODINGTYPE {
    OMX AUDIO CodingUnused = 0, /** Placeholder value when coding is N/A */
    OMX AUDIO CodingAutoDetect, /** auto detection of audio format */
    OMX AUDIO CodingPCM,
                                 /** Any variant of PCM coding */
                                 /** Any variant of ADPCM encoded data */
    OMX AUDIO CodingADPCM,
    OMX AUDIO CodingAMR,
                                 /** Any variant of AMR encoded data */
    OMX AUDIO CodingGSMFR,
                                 /** Any variant of GSM fullrate (i.e. GSM610) */
                                 /** Any variant of GSM Enhanced Fullrate encoded data*/
    OMX AUDIO CodingGSMEFR,
    OMX AUDIO CodingGSMHR,
                                 /** Any variant of GSM Halfrate encoded data */
    OMX AUDIO CodingPDCFR,
                                 /** Any variant of PDC Fullrate encoded data */
                                 /** Any variant of PDC Enhanced Fullrate encoded data */
    OMX AUDIO CodingPDCEFR,
    OMX AUDIO CodingPDCHR,
                                 /** Any variant of PDC Halfrate encoded data */
                                 /** Any variant of TDMA Fullrate encoded data (TIA/EIA-136-420) */
    OMX AUDIO CodingTDMAFR,
                                 /** Any variant of TDMA Enhanced Fullrate encoded data
    OMX AUDIO CodingTDMAEFR,
(TIA/EIA-136-410) */
    OMX AUDIO CodingQCELP8,
                                 /** Any variant of QCELP 8kbps encoded data */
    OMX AUDIO CodingQCELP13,
                                 /** Any variant of QCELP 13kbps encoded data */
                                 /** Any variant of EVRC encoded data */
    OMX AUDIO CodingEVRC,
                                 /** Any variant of SMV encoded data */
    OMX AUDIO CodingSMV,
                                 /** Any variant of G.711 encoded data */
    OMX AUDIO CodingG711,
    OMX AUDIO CodingG723,
                                 /** Any variant of G.723 dot 1 encoded data */
                                 /** Any variant of G.726 encoded data */
    OMX AUDIO CodingG726,
    OMX AUDIO_CodingG729,
                                 /** Any variant of G.729 encoded data */
                                 /** Any variant of AAC encoded data */
    OMX AUDIO CodingAAC,
                                 /** Any variant of MP3 encoded data */
    OMX AUDIO CodingMP3,
                                 /** Any variant of SBC encoded data */
    OMX AUDIO CodingSBC,
                                 /** Any variant of VORBIS encoded data */
    OMX AUDIO CodingVORBIS,
    OMX AUDIO CodingWMA,
                                 /** Any variant of WMA encoded data */
    OMX AUDIO CodingRA,
                                 /** Any variant of RA encoded data */
                                 /** Any variant of MIDI encoded data */
    OMX AUDIO CodingMIDI,
    OMX_AUDIO_CodingKhronosExtensions = 0x6F000000, /** Reserved region for introducing
Khronos Standard Extensions */
    OMX AUDIO CodingVendorStartUnused = 0x7F000000, /** Reserved region for introducing
Vendor Extensions */
    OMX AUDIO CodingFLAC,
                                /** Any variant of FLAC */
                               /** Any variant of Dolby Digital Plus */
    OMX AUDIO CodingDDP,
    OMX AUDIO CodingDTS,
                               /** Any variant of DTS */
```

```
/** Any variant of WMA Professional */
    OMX AUDIO CodingWMAPRO,
    OMX AUDIO CodingATRAC3,
                               /** Sony ATRAC-3 variants */
                              /** Sony ATRAC-X variants */
    OMX AUDIO CodingATRACX,
    OMX AUDIO CodingATRACAAL,
                                /** Sony ATRAC advanced-lossless variants */
    OMX AUDIO CodingMax = 0x7FFFFFF
} OMX AUDIO CODINGTYPE;
    Running the program info from Chapter X shows the following for the audio decode component:
Audio ports:
  Ports start on 120
  There are 2 open ports
  Port 120 has 128 buffers of size 16384
  Direction is input
    Port 120 requires 4 buffers
    Port 120 has min buffer size 16384 bytes
    Port 120 is an input port
    Port 120 is an audio port
    Port mimetype (null)
    Port encoding is MP3
      Supported audio formats are:
      Supported encoding is MP3
          MP3 default sampling rate 0
          MP3 default bits per sample 0
          MP3 default number of channels 0
      Supported encoding is PCM
          PCM default sampling rate 0
          PCM default bits per sample 0
          PCM default number of channels 0
      Supported encoding is AAC
      Supported encoding is WMA
      Supported encoding is Ogg Vorbis
      Supported encoding is RA
      Supported encoding is AMR
      Supported encoding is EVRC
      Supported encoding is G726
      Supported encoding is FLAC
      Supported encoding is DDP
      Supported encoding is DTS
      Supported encoding is WMAPRO
      Supported encoding is ATRAC3
      Supported encoding is ATRACX
      Supported encoding is ATRACAAL
      Supported encoding is MIDI
      No more formats supported
  Port 121 has 1 buffers of size 32768
  Direction is output
    Port 121 requires 1 buffers
    Port 121 has min buffer size 32768 bytes
```

Port 121 is an output port Port 121 is an audio port

```
Port mimetype (null)
Port encoding is PCM
Supported audio formats are:
Supported encoding is PCM
PCM default sampling rate 44100
PCM default bits per sample 16
PCM default number of channels 2
Supported encoding is DDP
Supported encoding is DTS
No more formats supported
```

This looks really impressive, but regrettably, none of this is actually supported except for PCM. The following is according to jamesh in "OMX_AllocateBuffer fails for audio decoder component":

The way it works is that the component passes back success for all the codecs it can potentially support (i.e., all the codecs we've ever had going). That is then constrained by what codecs are actually installed. It would be better to run time detect which codecs are present, but that code has never been written since it's never been required. It's also unlikely ever to be done as Broadcom no longer supports audio codecs in this way—they have moved off the Videocore to the host CPU since they are now powerful enough to handle any audio decoding task.

That's kind of sad, really.

So, how do you find out which encodings are really supported? You can get a partial answer by trying to allocate buffers for a particular encoding. So, for each port, you loop through the possible encodings, setting the encoding and trying to allocate the buffers. You can use il_enable_port_buffers for this as it will return -1 if the allocation fails.

The program to do this is il_test_audio_encodings.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <oMX_Core.h>
#include <OMX_Component.h>

#include <bcm_host.h>
#include <ilclient.h>

FILE *outfp;

void printState(OMX_HANDLETYPE handle) {
    // elided
}

char *err2str(int err) {
    return "elided";
}

void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
```

```
fprintf(stderr, "Got eos event\n");
}
void error_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    //fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st size);
}
static void set_audio_decoder_input_format(COMPONENT_T *component,
                                           int port, int format) {
    // set input audio format
    //printf("Setting audio decoder format\n");
    OMX AUDIO PARAM PORTFORMATTYPE audioPortFormat;
    //setHeader(&audioPortFormat, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    memset(&audioPortFormat, 0, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    audioPortFormat.nSize = sizeof(OMX AUDIO PARAM PORTFORMATTYPE);
    audioPortFormat.nVersion.nVersion = OMX VERSION;
    audioPortFormat.nPortIndex = port;
    //audioPortFormat.eEncoding = OMX AUDIO CodingPCM;
    audioPortFormat.eEncoding = format;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    //printf("Format set ok to %d\n", format);
}
char *format2str(OMX AUDIO CODINGTYPE format) {
    switch(format) {
    case OMX AUDIO CodingUnused: return "OMX AUDIO CodingUnused";
    case OMX AUDIO CodingAutoDetect: return "OMX AUDIO CodingAutoDetect";
    case OMX AUDIO CodingPCM: return "OMX AUDIO CodingPCM";
    case OMX AUDIO CodingADPCM: return "OMX AUDIO CodingADPCM";
    case OMX AUDIO CodingAMR: return "OMX AUDIO CodingAMR";
    case OMX AUDIO CodingGSMFR: return "OMX AUDIO CodingGSMFR";
    case OMX AUDIO CodingGSMEFR: return "OMX AUDIO CodingGSMEFR" ;
    case OMX_AUDIO_CodingGSMHR: return "OMX AUDIO CodingGSMHR";
    case OMX_AUDIO_CodingPDCFR: return "OMX_AUDIO_CodingPDCFR";
    case OMX AUDIO CodingPDCEFR: return "OMX AUDIO CodingPDCEFR";
    case OMX AUDIO CodingPDCHR: return "OMX AUDIO CodingPDCHR";
    case OMX_AUDIO_CodingTDMAFR: return "OMX_AUDIO_CodingTDMAFR";
    case OMX AUDIO CodingTDMAEFR: return "OMX AUDIO CodingTDMAEFR";
    case OMX AUDIO CodingQCELP8: return "OMX AUDIO CodingQCELP8";
    case OMX_AUDIO_CodingQCELP13: return "OMX_AUDIO_CodingQCELP13";
```

```
case OMX_AUDIO_CodingEVRC: return "OMX_AUDIO_CodingEVRC";
    case OMX AUDIO CodingSMV: return "OMX AUDIO CodingSMV";
    case OMX AUDIO CodingG711: return "OMX AUDIO CodingG711";
    case OMX AUDIO CodingG723: return "OMX AUDIO CodingG723";
    case OMX AUDIO CodingG726: return "OMX AUDIO CodingG726";
    case OMX_AUDIO_CodingG729: return "OMX AUDIO CodingG729";
    case OMX AUDIO CodingAAC: return "OMX AUDIO CodingAAC";
    case OMX AUDIO CodingMP3: return "OMX AUDIO CodingMP3";
    case OMX AUDIO CodingSBC: return "OMX AUDIO CodingSBC";
    case OMX AUDIO CodingVORBIS: return "OMX AUDIO CodingVORBIS";
   case OMX AUDIO CodingWMA: return "OMX AUDIO CodingWMA";
    case OMX AUDIO CodingRA: return "OMX AUDIO CodingRA";
    case OMX_AUDIO_CodingMIDI: return "OMX_AUDIO_CodingMIDI";
    case OMX AUDIO CodingFLAC: return "OMX AUDIO CodingFLAC";
    case OMX AUDIO CodingDDP: return "OMX AUDIO CodingDDP";
    case OMX AUDIO CodingDTS: return "OMX AUDIO CodingDTS";
    case OMX AUDIO CodingWMAPRO: return "OMX AUDIO CodingWMAPRO";
   case OMX AUDIO CodingATRAC3: return "OMX AUDIO CodingATRAC3";
    case OMX AUDIO CodingATRACX: return "OMX AUDIO CodingATRACX";
    case OMX_AUDIO_CodingATRACAAL: return "OMX AUDIO CodingATRACAAL" ;
    default: return "Unknown format";
    }
}
void test_audio_port_formats(COMPONENT_T *component, int port) {
    int n = 2;
   while (n <= OMX AUDIO CodingMIDI) {
        set_audio_decoder_input_format(component, port, n);
       // input port
       if (ilclient enable port buffers(component, port,
                                         NULL, NULL, NULL) < 0) {
                       Unsupported encoding is %s\n",
                   format2str(n));
        } else {
            printf("
                        Supported encoding is %s\n",
                  format2str(n));
            ilclient disable port buffers(component, port,
                                          NULL, NULL, NULL);
        }
       n++;
    n = OMX AUDIO CodingFLAC;
   while (n <= OMX AUDIO CodingATRACAAL) {
        set audio decoder input format(component, port, n);
       // input port
       if (ilclient enable port buffers(component, port,
                                         NULL, NULL, NULL) < 0) {
            printf("
                        Unsupported encoding is %s\n",
                   format2str(n));
        } else {
```

```
printf("
                        Supported encoding is %s\n",
                   format2str(n));
            ilclient disable port buffers(component, port,
                                          NULL, NULL, NULL);
        }
        n++;
    }
}
void test all audio ports(COMPONENT T *component) {
    OMX PORT PARAM TYPE param;
    OMX PARAM PORTDEFINITIONTYPE sPortDef;
    OMX ERRORTYPE err;
    OMX HANDLETYPE handle = ilclient get handle(component);
    int startPortNumber;
    int nPorts;
    int n;
    //setHeader(&param, sizeof(OMX_PORT_PARAM_TYPE));
    memset(&param, 0, sizeof(OMX PORT PARAM TYPE));
    param.nSize = sizeof(OMX PORT PARAM TYPE);
    param.nVersion.nVersion = OMX VERSION;
    err = OMX_GetParameter(handle, OMX_IndexParamAudioInit, &param);
    if(err != OMX ErrorNone){
        fprintf(stderr, "Error in getting audio OMX PORT PARAM TYPE parameter\n");
        return;
    printf("Audio ports:\n");
    startPortNumber = param.nStartPortNumber;
    nPorts = param.nPorts;
    if (nPorts == 0) {
        printf("No ports of this type\n");
        return;
    }
    printf("Ports start on %d\n", startPortNumber);
    printf("There are %d open ports\n", nPorts);
    for (n = 0; n < nPorts; n++) {
        memset(&sPortDef, 0, sizeof(OMX PARAM PORTDEFINITIONTYPE)) ;
        sPortDef.nSize = sizeof(OMX PARAM PORTDEFINITIONTYPE);
        sPortDef.nVersion.nVersion = OMX VERSION;
        sPortDef.nPortIndex = startPortNumber + n;
        err = OMX GetParameter(handle, OMX IndexParamPortDefinition, &sPortDef);
        if(err != OMX ErrorNone){
            fprintf(stderr, "Error in getting OMX PORT DEFINITION TYPE parameter\n");
            exit(1);
        }
```

```
printf("Port %d has %d buffers of size %d\n",
               sPortDef.nPortIndex,
               sPortDef.nBufferCountActual,
               sPortDef.nBufferSize);
        printf("Direction is %s\n",
               (sPortDef.eDir == OMX DirInput ? "input" : "output"));
        test_audio_port_formats(component, sPortDef.nPortIndex);
    }
}
int main(int argc, char** argv) {
   char *componentName;
    int err;
    ILCLIENT T *handle;
   COMPONENT T *component;
    componentName = "audio decode";
    if (argc == 2) {
        componentName = argv[1];
    }
    bcm_host_init();
   handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
    if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient set error callback(handle,
                                error_callback,
                                NULL);
    ilclient_set_eos_callback(handle,
                              eos_callback,
                              NULL);
   err = ilclient_create_component(handle,
                                    &component,
                                    componentName,
                                    ILCLIENT_DISABLE_ALL_PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT ENABLE OUTPUT BUFFERS
                                    );
```

The program appears to be only partially successful. For the audio_decode component, it shows that only two possible formats can be decoded, PCM and ADPCM, but shows that they can be decoded to MP3, Vorbis, and so on, which seems most unlikely.

```
Audio ports:
Ports start on 120
There are 2 open ports
Port 120 has 128 buffers of size 16384
Direction is input
    Supported encoding is OMX AUDIO CodingPCM
    Supported encoding is OMX AUDIO CodingADPCM
    Unsupported encoding is OMX AUDIO CodingAMR
    Unsupported encoding is OMX AUDIO CodingGSMFR
    Unsupported encoding is OMX AUDIO CodingGSMEFR
    Unsupported encoding is OMX AUDIO CodingGSMHR
    Unsupported encoding is OMX AUDIO CodingPDCFR
    Unsupported encoding is OMX AUDIO CodingPDCEFR
    Unsupported encoding is OMX AUDIO CodingPDCHR
    Unsupported encoding is OMX AUDIO CodingTDMAFR
    Unsupported encoding is OMX AUDIO CodingTDMAEFR
    Unsupported encoding is OMX AUDIO CodingQCELP8
    Unsupported encoding is OMX AUDIO CodingQCELP13
Port 121 has 1 buffers of size 32768
Direction is output
    Supported encoding is OMX AUDIO CodingPCM
    Supported encoding is OMX AUDIO CodingADPCM
    Supported encoding is OMX AUDIO CodingAMR
    Supported encoding is OMX AUDIO CodingGSMFR
    Supported encoding is OMX_AUDIO_CodingGSMEFR
    Supported encoding is OMX AUDIO CodingGSMHR
    Supported encoding is OMX AUDIO CodingPDCFR
    Supported encoding is OMX AUDIO CodingPDCEFR
```

```
Supported encoding is OMX_AUDIO_CodingPDCHR
Supported encoding is OMX_AUDIO_CodingTDMAFR
Supported encoding is OMX_AUDIO_CodingTDMAEFR
Supported encoding is OMX_AUDIO_CodingQCELP8
Supported encoding is OMX_AUDIO_CodingQCELP13
Supported encoding is OMX_AUDIO_CodingEVRC
Supported encoding is OMX_AUDIO_CodingSMV
Supported encoding is OMX_AUDIO_CodingG711
Supported encoding is OMX_AUDIO_CodingG723
Supported encoding is OMX_AUDIO_CodingG726
Supported encoding is OMX_AUDIO_CodingG729
```

Decoding an Audio File Using audio_decode

The Broadcom audio_decode component will decode only Pulse Code Modulated (PCM) format data. It decodes it to...PCM format data. PCM is the binary format commonly used to represent unencoded audio data. In other words, unless Broadcom includes support for some of the audio codecs, then this component is pretty useless.

Rendering PCM Data

Now you'll learn how to render PCM data.

PCM Data

The following is according to Wikipedia:

[PCM] is a method used to digitally represent sampled analog signals. It is the standard form for digital audio in computers and various Blu-ray, DVD, and Compact Disc formats, as well as other uses such as digital telephone systems. A PCM stream is a digital representation of an analog signal, in which the magnitude of the analog signal is sampled regularly at uniform intervals, with each sample being quantized to the nearest value within a range of digital steps.

PCM streams have two basic properties that determine their fidelity to the original analog signal: the sampling rate, which is the number of times per second that samples are taken; and the bit depth, which determines the number of possible digital values that each sample can take.

PCM data can be stored in files as "raw" data. In this case, there is no header information to say what the sampling rate and bit depth are. Many tools such as sox use the file extension to determine these properties. The following is from man soxformat:

f32 and f64 indicate files encoded as 32- and 64-bit (IEEE single and double precision) floating-point PCM, respectively; s8, s16, s24, and s32 indicate 8-, 16-, 24-, and 32-bit signed integer PCM, respectively; u8, u16, u24, and u32 indicate 8-, 16-, 24-, and 32-bit unsigned integer PCM, respectively.

But it should be noted that the file extension is only an aid to understanding some of the PCM codec parameters and how they are stored in the file.

Files can be converted into PCM by tools such as avconv. For example, to convert a WAV file to PCM, you use this:

```
avconv -i enigma.wav -f s16le enigma.s16
```

The output will give information not saved in the file, which you will need to give to a processing program later.

From this you can see that the format is two channels, 44,100 Hz, and 16-bit little-endian. (The file I used was from a group called Enigma, who released an album as open content.)

To check that the encoding worked, you can use aplay as follows:

```
aplay -r 44100 -c 2 -f S16 LE enigma.s16
```

Choosing an Output Device

OpenMAX has a standard audio render component. But what device does it render to? The built-in sound card? A USB sound card? That is not part of OpenMAX IL—there isn't even a way to list the audio devices, only the audio components.

OpenMAX has an extension mechanism that can be used by an OpenMAX implementor to answer questions like this. The Broadcom core implementation has extension types OMX_CONFIG_BRCMAUDIODESTINATIONTYPE and OMX_CONFIG_BRCMAUDIOSOURCETYPE, which can be used to set the audio destination (source) device. Use the following code to do this:

```
void setOutputDevice(const char *name) {
   int32_t success = -1;
   OMX_CONFIG_BRCMAUDIODESTINATIONTYPE arDest;

if (name && strlen(name) < sizeof(arDest.sName)) {
    setHeader(&arDest, sizeof(OMX_CONFIG_BRCMAUDIODESTINATIONTYPE));
    strcpy((char *)arDest.sName, name);

   err = OMX_SetParameter(handle, OMX_IndexConfigBrcmAudioDestination, &arDest);
   if (err != OMX_ErrorNone) {
        fprintf(stderr, "Error on setting audio destination\n");
        exit(1);
    }
}</pre>
```

Here is where Broadcom becomes a bit obscure again. The header file IL/OMX_Broadcom.h states that the default value of sName is local but doesn't give any other values. The Raspberry Pi forums say that this refers to the 3.5 mm analog audio out and that HDMI is chosen by using the value hdmi. No other values are documented, and it seems that the Broadcom OpenMAX IL does not support any other audio devices. In particular, USB audio devices are not supported by the current Broadcom OpenMAX IL components for either input or output. So, you can't use OpenMAX IL for, say, audio capture on the Raspberry Pi since it has no Broadcom-supported audio input.

Setting PCM Format

You can use two functions to set the PCM format. The first contains nothing unusual.

The second gets the current PCM parameters and then sets the required PCM parameters (which you know independently).

```
sPCMMode.nSamplingRate = 44100;
    sPCMMode.nChannels = 2;
    err = OMX_SetParameter(handle, OMX_IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        fprintf(stderr, "PCM mode unsupported\n");
        return;
    } else {
        fprintf(stderr, "PCM mode supported\n");
        fprintf(stderr, "PCM sampling rate %d\n", sPCMMode.nSamplingRate);
fprintf(stderr, "PCM nChannels %d\n", sPCMMode.nChannels);
    }
}
    The program is il render audio.c.
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <bcm host.h>
#include <ilclient.h>
#define AUDIO "enigma.s16"
/* For the RPi name can be "hdmi" or "local" */
void setOutputDevice(OMX HANDLETYPE handle, const char *name) {
    OMX ERRORTYPE err;
    OMX CONFIG BRCMAUDIODESTINATIONTYPE arDest;
    if (name && strlen(name) < sizeof(arDest.sName)) {</pre>
        memset(&arDest, 0, sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE));
        arDest.nSize = sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE);
        arDest.nVersion.nVersion = OMX_VERSION;
        strcpy((char *)arDest.sName, name);
        err = OMX SetParameter(handle, OMX IndexConfigBrcmAudioDestination, &arDest);
        if (err != OMX ErrorNone) {
             fprintf(stderr, "Error on setting audio destination\n");
            exit(1);
        }
    }
}
void setPCMMode(OMX_HANDLETYPE handle, int startPortNumber) {
    OMX AUDIO PARAM PCMMODETYPE sPCMMode;
    OMX ERRORTYPE err;
```

```
memset(&sPCMMode, 0, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nSize = sizeof(OMX AUDIO PARAM PCMMODETYPE);
    sPCMMode.nVersion.nVersion = OMX VERSION;
    sPCMMode.nPortIndex = startPortNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    printf("Sampling rate %d, channels %d\n",
           sPCMMode.nSamplingRate,
           sPCMMode.nChannels);
    sPCMMode.nSamplingRate = 44100;
    sPCMMode.nChannels = 2;
    err = OMX SetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        fprintf(stderr, "PCM mode unsupported\n");
        return;
    } else {
        fprintf(stderr, "PCM mode supported\n");
        fprintf(stderr, "PCM sampling rate %d\n", sPCMMode.nSamplingRate);
        fprintf(stderr, "PCM nChannels %d\n", sPCMMode.nChannels);
    }
}
void printState(OMX HANDLETYPE handle) {
    //elided
char *err2str(int err) {
    return "elided";
}
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
```

```
static void set_audio_render_input_format(COMPONENT_T *component) {
    // set input audio format
    printf("Setting audio render format\n");
    OMX AUDIO PARAM PORTFORMATTYPE audioPortFormat;
    //setHeader(&audioPortFormat, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    memset(&audioPortFormat, 0, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    audioPortFormat.nSize = sizeof(OMX_AUDIO_PARAM_PORTFORMATTYPE);
    audioPortFormat.nVersion.nVersion = OMX VERSION;
    audioPortFormat.nPortIndex = 100;
    OMX GetParameter(ilclient get handle(component),
                     OMX_IndexParamAudioPortFormat, &audioPortFormat);
    audioPortFormat.eEncoding = OMX AUDIO CodingPCM;
    //audioPortFormat.eEncoding = OMX AUDIO CodingMP3;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    setPCMMode(ilclient get handle(component), 100);
}
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                         COMPONENT_T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    return r;
}
int main(int argc, char** argv) {
```

```
int i;
char *componentName;
int err;
ILCLIENT_T *handle;
COMPONENT T *component;
char *audio_file = AUDIO;
if (argc == 2) {
    audio file = argv[1];
}
FILE *fp = fopen(audio file, "r");
int toread = get_file_size(audio_file);
OMX BUFFERHEADERTYPE *buff header;
componentName = "audio render";
bcm_host_init();
handle = ilclient init();
if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
}
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
}
ilclient set error callback(handle,
                            error_callback,
                            NULL);
ilclient_set_eos_callback(handle,
                          eos_callback,
                          NULL);
err = ilclient_create_component(handle,
                                &component,
                                componentName,
                                 ILCLIENT_DISABLE_ALL_PORTS
                                ILCLIENT ENABLE INPUT BUFFERS
                                );
if (err == -1) {
    fprintf(stderr, "Component create failed\n");
    exit(1);
printState(ilclient get handle(component));
```

```
err = ilclient_change_component_state(component,
                                      OMX StateIdle);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
printState(ilclient_get_handle(component));
// must be before we enable buffers
set_audio_render_input_format(component);
setOutputDevice(ilclient get handle(component), "local");
// input port
ilclient enable port buffers(component, 100,
                             NULL, NULL, NULL);
ilclient enable_port(component, 100);
err = ilclient_change_component_state(component,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient_get_handle(component));
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have an input buffer we can fill and empty?
    buff header =
        ilclient get input buffer(component,
                                  100,
                                  1 /* block */);
    if (buff header != NULL) {
        read_into_buffer_and_empty(fp,
                                    component,
                                    buff header,
                                    &toread);
    }
exit(0);
```

The program can be run with the command line of any file with two-channel 16-bit PCM with a sampling rate of 44,100 Hz. This is hard-coded into the program. It would be easy to add command-line parsing along the same lines as aplay.

}

Decoding an MP3 File Using FFmpeg or Avconv

If you want to play a compressed file such as MP3 or Ogg, it has to be decoded, and as noted earlier, the audio_decode component doesn't do this. So, you have to turn to another system. The prominent audio-decoding systems are FFmpeg (forked to LibAV) and GStreamer. I will use LibAV as that is the default install on the RPi.

FFmpeg was started in 2000. LibAV forked from it in 2011. Over time, both of the libraries and the file formats have evolved. Consequently, there are code examples on the Web that are no longer appropriate. Generally, FFmpeg and LibAV follow the same API and are generally interchangeable at the API code level—but not always.

The current FFmpeg source distro includes a program called doc/examples/decoding_encoding_c, while the LibAV distro has a similar example, called avcodec.c, which can decode MP3 files to PCM format. These *almost* work on the MP3 files I tried because the output format from the decoder has changed from *interleaved* to *planar*, and the examples have not been updated to reflect this.

The difference is easily illustrated with stereo: interleaved means LRLRLR. With planar, a set of consecutive Rs are given after a set of consecutive Ls, as in LLLLLL...RRRRR. Interleaved is a degenerate case of planar with a run length of 1.

A frame of video/audio that is decoded by FFmpeg/LibAV is built in a struct AVFrame. This includes the following fields:

```
typedef struct AVFrame {
    uint8_t *data[AV_NUM_DATA_POINTERS];
    int linesize[AV_NUM_DATA_POINTERS];
    int nb_samples;
}
```

In the interleaved case, all the samples are in data[0]. In the planar case, they are in data[0], data[1], There does not seem to be an explicit indicator of how many planar streams there are, but if a data element is non-null, it seems to contain a stream. So, by walking the data array until you find NULL, you can find the number of streams.

Many tools such as aplay will accept only interleaved samples. So, given multiple planar streams, you have to interleave them yourself. This isn't hard once you know the sample size in bytes, the length of each stream, and the number of streams (a more robust way is given in a later section).

The revised program, which reads from an MP3 file and writes decoded data to /tmp/test.sw, is api-example.c.

```
* copyright (c) 2001 Fabrice Bellard
 * This file is part of Libav.
 * Libav is free software; you can redistribute it and/or
 * modify it under the terms of the GNU Lesser General Public
 * License as published by the Free Software Foundation; either
 * version 2.1 of the License, or (at your option) any later version.
 * Libav is distributed in the hope that it will be useful,
 * but WITHOUT ANY WARRANTY; without even the implied warranty of
 * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU
 * Lesser General Public License for more details.
 * You should have received a copy of the GNU Lesser General Public
 * License along with Libav; if not, write to the Free Software
 * Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
 */
// From http://code.haskell.org/~thielema/audiovideo-example/cbits/
/**
 * @file
 * libavcodec API use example.
 * @example libavcodec/api-example.c
 * Note that this library only handles codecs (mpeg, mpeg4, etc...),
 * not file formats (avi, vob, etc...). See library 'libavformat' for the
 * format handling
#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#ifdef HAVE AV CONFIG H
#undef HAVE_AV_CONFIG_H
#endif
```

```
#include "libavcodec/avcodec.h"
#include <libavformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#define INBUF SIZE 4096
#define AUDIO INBUF SIZE 20480
#define AUDIO REFILL THRESH 4096
/*
* Audio decoding.
static void audio_decode_example(const char *outfilename, const char *filename)
   AVCodec *codec;
   AVCodecContext *c = NULL;
    int len;
    FILE *f, *outfile;
   uint8_t inbuf[AUDIO_INBUF_SIZE + FF_INPUT_BUFFER_PADDING_SIZE];
   AVPacket avpkt;
   AVFrame *decoded frame = NULL;
    int num streams = 0;
    int sample size = 0;
   av_init_packet(&avpkt);
   printf("Audio decoding\n");
    /* find the mpeg audio decoder */
   codec = avcodec find decoder(AV CODEC ID MP3);
    if (!codec) {
        fprintf(stderr, "codec not found\n");
        exit(1);/home/httpd/html/RPi-hidden/OpenMAX/Audio/BST.mp3
    }
   c = avcodec alloc context3(codec);;
    /* open it */
    if (avcodec open2(c, codec, NULL) < 0) {</pre>
        fprintf(stderr, "could not open codec\n");
        exit(1);
    }
   f = fopen(filename, "rb");
    if (!f) {
        fprintf(stderr, "could not open %s\n", filename);
        exit(1);
   outfile = fopen(outfilename, "wb");
    if (!outfile) {
        av free(c);
```

```
exit(1);
}
/* decode until eof */
avpkt.data = inbuf;
avpkt.size = fread(inbuf, 1, AUDIO INBUF SIZE, f);
while (avpkt.size > 0) {
    int got frame = 0;
    if (!decoded frame) {
        if (!(decoded frame = avcodec alloc frame())) {
            fprintf(stderr, "out of memory\n");
            exit(1);
        }
    } else
        avcodec get frame defaults(decoded frame);
    len = avcodec_decode_audio4(c, decoded_frame, &got_frame, &avpkt);
    if (len < 0) {
        fprintf(stderr, "Error while decoding\n");
        exit(1);
    if (got frame) {
        printf("Decoded frame nb_samples %d, format %d\n",
               decoded frame->nb samples,
               decoded frame->format);
        if (decoded_frame->data[1] != NULL)
            printf("Data[1] not null\n");
        elseAV LIBS = $(shell pkg-config --libs libavcodec libavformat libavutil)
            printf("Data[1] is null\n");
        /* if a frame has been decoded, output it */
        int data size = av samples get buffer size(NULL, c->channels,
                                                   decoded_frame->nb_samples,
                                                    c->sample fmt, 1);
        // first time: count the number of planar streams
        if (num streams == 0) {
            while (num streams < AV NUM DATA POINTERS &&
                   decoded frame->data[num streams] != NULL)
                num_streams++;
        }
        // first time: set sample_size from 0 to e.g 2 for 16-bit data
        if (sample size == 0) {
            sample size =
                data_size / (num_streams * decoded_frame->nb_samples);
        }
        int m, n;
        for (n = 0; n < decoded frame->nb samples; n++) {
            // interleave the samples from the planar streams
```

```
for (m = 0; m < num_streams; m++) {</pre>
                    fwrite(&decoded frame->data[m][n*sample size],
                           1, sample size, outfile);
                }
            }
        }
        avpkt.size -= len;
        avpkt.data += len;
        if (avpkt.size < AUDIO REFILL THRESH) {</pre>
            /* Refill the input buffer, to avoid trying to decode
             * incomplete frames. Instead of this, one could also use
             * a parser, or use a proper container format through
             * libavformat. */
            memmove(inbuf, avpkt.data, avpkt.size);
            avpkt.data = inbuf;
            len = fread(avpkt.data + avpkt.size, 1,
                        AUDIO INBUF SIZE - avpkt.size, f);
            if (len > 0)
                avpkt.size += len;
        }
    }
    fclose(outfile);
    fclose(f);
    avcodec close(c);
   av free(c);
   av_free(decoded_frame);
}
int main(int argc, char **argv)
   const char *filename = "BST.mp3";
   AVFormatContext *pFormatCtx = NULL;
    if (argc == 2) {
        filename = argv[1];
    // Register all formats and codecs
    av register all();
    if(avformat open input(&pFormatCtx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
        return -1; // Couldn't open file
    // Retrieve stream information
    if(avformat find stream info(pFormatCtx, NULL)<0)</pre>
        return -1; // Couldn't find stream information
    av_dump_format(pFormatCtx, 0, filename, 0);
    printf("Num streams %d\n", pFormatCtx->nb streams);
   printf("Bit rate %d\n", pFormatCtx->bit rate);
    audio decode example("/tmp/test.sw", filename);
```

```
return 0;
}
```

You can build the program using make. As it does not depend on OpenMAX, it can also be built independently using the compile command.

```
cc -c -g api-example.c
cc api-example.o -lavutil -lavcodec -lavformat -o api-example -lm
```

It can be run with an MP3 file being the command-line parameter. You can test the result as follows (you may need to change parameters):

```
aplay -r 44100 -c 2 -f S16 LE /tmp/test.sw
```

Rendering MP3 Using FFmpeg or LibAV and OpenMAX

Since the Broadcom audio_decode component is apparently of little use, if you actually want to play MP3, Ogg, or other encoded formats, you have to use FFmpeg/LibAV (or GStreamer) to decode the audio to PCM and then pass it to the Broadcom audio_render component.

Essentially this means taking the last two programs and mashing them together. It isn't hard, just a bit messy. The only tricky point is that the buffers returned from FFmpeg/LibAV and the buffers used by audio_render are different sizes, and you don't really know which will be bigger. If the audio_render input buffers are bigger, then you just copy (and interleave) the FFmpeg data across; if smaller, then you have to keep fetching new buffers as each one is filled.

The resultant program is il ffmpeg render audio.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
#include "libavcodec/avcodec.h"
#include <libayformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#define INBUF SIZE 4096
#define AUDIO INBUF SIZE 20480
#define AUDIO REFILL THRESH 4096
#define AUDIO "BST.mp3"
/* For the RPi name can be "hdmi" or "local" */
void setOutputDevice(OMX HANDLETYPE handle, const char *name) {
    OMX ERRORTYPE err;
    OMX CONFIG BRCMAUDIODESTINATIONTYPE arDest;
```

```
if (name && strlen(name) < sizeof(arDest.sName)) {</pre>
        memset(&arDest, 0, sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE));
        arDest.nSize = sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE);
        arDest.nVersion.nVersion = OMX VERSION;
        strcpy((char *)arDest.sName, name);
        err = OMX SetParameter(handle, OMX IndexConfigBrcmAudioDestination, &arDest);
        if (err != OMX ErrorNone) {
            fprintf(stderr, "Error on setting audio destination\n");
            exit(1);
        }
   }
}
void setPCMMode(OMX HANDLETYPE handle, int startPortNumber) {
   OMX AUDIO PARAM_PCMMODETYPE sPCMMode;
   OMX ERRORTYPE err;
    memset(&sPCMMode, 0, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nSize = sizeof(OMX AUDIO PARAM PCMMODETYPE);
    sPCMMode.nVersion.nVersion = OMX VERSION;
    sPCMMode.nPortIndex = startPortNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    printf("Sampling rate %d, channels %d\n",
           sPCMMode.nSamplingRate,
           sPCMMode.nChannels);
    sPCMMode.nSamplingRate = 44100;
    sPCMMode.nChannels = 2; // assumed for now - should be checked
    err = OMX SetParameter(handle, OMX_IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        fprintf(stderr, "PCM mode unsupported\n");
        return;
    } else {
        fprintf(stderr, "PCM mode supported\n");
        fprintf(stderr, "PCM sampling rate %d\n", sPCMMode.nSamplingRate);
        fprintf(stderr, "PCM nChannels %d\n", sPCMMode.nChannels);
    }
}
void printState(OMX HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
   return "error elided";
}
```

```
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
AVPacket avpkt;
AVCodecContext *c = NULL;
/*
 * Audio decoding.
static void audio_decode_example(const char *filename)
    AVCodec *codec;
    av init packet(&avpkt);
    printf("Audio decoding\n");
    /* find the mpeg audio decoder */
    codec = avcodec_find_decoder(AV_CODEC_ID_MP3);
    if (!codec) {
        fprintf(stderr, "codec not found\n");
        exit(1);
    }
    c = avcodec_alloc_context3(codec);;
    /* open it */
    if (avcodec_open2(c, codec, NULL) < 0) {</pre>
        fprintf(stderr, "could not open codec\n");
        exit(1);
    }
}
static void set_audio_render_input_format(COMPONENT_T *component) {
    // set input audio format
    printf("Setting audio render format\n");
    OMX_AUDIO_PARAM_PORTFORMATTYPE audioPortFormat;
```

```
//setHeader(&audioPortFormat, sizeof(OMX_AUDIO_PARAM_PORTFORMATTYPE));
    memset(&audioPortFormat, 0, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    audioPortFormat.nSize = sizeof(OMX AUDIO PARAM PORTFORMATTYPE);
    audioPortFormat.nVersion.nVersion = OMX VERSION;
    audioPortFormat.nPortIndex = 100;
    OMX GetParameter(ilclient get handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    audioPortFormat.eEncoding = OMX AUDIO CodingPCM;
    //audioPortFormat.eEncoding = OMX AUDIO CodingMP3;
    OMX_SetParameter(ilclient_get_handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    setPCMMode(ilclient_get_handle(component), 100);
}
int num streams = 0;
int sample size = 0;
OMX ERRORTYPE read into buffer and empty(AVFrame *decoded frame,
                                         COMPONENT T *component,
                                         // OMX BUFFERHEADERTYPE *buff header,
                                         int total len) {
    OMX ERRORTYPE r;
   OMX BUFFERHEADERTYPE *buff_header = NULL;
    int k, m, n;
    if (total_len <= 4096) { //buff_header->nAllocLen) {
        // all decoded frame fits into one OpenMAX buffer
       buff header =
            ilclient get_input_buffer(component,
                                      1 /* block */);
       for (k = 0, n = 0; n < decoded_frame->nb_samples; n++) {
            for (m = 0; m < num streams; m++) {
               memcpy(&buff header->pBuffer[k],
                       &decoded_frame->data[m][n*sample_size],
                       sample size);
                k += sample size;
            }
        }
       buff header->nFilledLen = k;
       r = OMX EmptyThisBuffer(ilclient get handle(component),
                                buff header);
       if (r != OMX_ErrorNone) {
            fprintf(stderr, "Empty buffer error %s\n",
                    err2str(r));
        }
```

```
return r;
    }
    // more than one OpenMAX buffer required
    for (k = 0, n = 0; n < decoded frame->nb samples; n++) {
        if (k == 0) {
             buff header =
                ilclient get input buffer(component,
                                           1 /* block */);
        }
        // interleave the samples from the planar streams
        for (m = 0; m < num streams; m++) {</pre>
            memcpy(&buff_header->pBuffer[k],
                   &decoded frame->data[m][n*sample size],
                   sample size);
            k += sample_size;
        }
        if (k >= buff_header->nAllocLen) {
            // this buffer is full
            buff header->nFilledLen = k;
            r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                     buff header);
            if (r != OMX ErrorNone) {
                fprintf(stderr, "Empty buffer error %s\n",
                        err2str(r));
            }
            k = 0;
            buff header = NULL;
        }
    if (buff header != NULL) {
            buff header->nFilledLen = k;
            r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                     buff header);
            if (r != OMX ErrorNone) {
                fprintf(stderr, "Empty buffer error %s\n",
                        err2str(r));
            }
    }
    return r;
}
int main(int argc, char** argv) {
    int i;
    char *componentName;
    int err;
```

```
ILCLIENT_T *handle;
COMPONENT T *component;
AVFormatContext *pFormatCtx = NULL;
char *audio file = AUDIO;
if (argc == 2) {
    audio file = argv[1];
FILE *fp = fopen(audio file, "r");
int toread = get file size(audio file);
OMX BUFFERHEADERTYPE *buff header;
componentName = "audio_render";
bcm host init();
handle = ilclient init();
if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
}
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
}
ilclient set error callback(handle,
                            error callback.
                            NULL);
ilclient set eos callback(handle,
                          eos callback,
                          NULL);
err = ilclient create component(handle,
                                &component,
                                componentName,
                                ILCLIENT DISABLE ALL PORTS
                                ILCLIENT ENABLE INPUT BUFFERS
if (err == -1) {
    fprintf(stderr, "Component create failed\n");
    exit(1);
printState(ilclient get handle(component));
```

```
err = ilclient_change_component_state(component,
                                       OMX StateIdle);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
printState(ilclient_get_handle(component));
// FFmpeg init
av register all();
if(avformat open input(&pFormatCtx, audio file, NULL, NULL)!=0) {
    fprintf(stderr, "Can't get format\n");
    return -1; // Couldn't open file
// Retrieve stream information
if(avformat_find_stream_info(pFormatCtx, NULL)<0)</pre>
    return -1; // Couldn't find stream information
av dump format(pFormatCtx, 0, audio file, 0);
audio decode example(audio file);
// must be before we enable buffers
set audio render input format(component);
setOutputDevice(ilclient_get_handle(component), "local");
// input port
ilclient_enable_port_buffers(component, 100,
                             NULL, NULL, NULL);
ilclient enable port(component, 100);
err = ilclient change component state(component,
                                       OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(component));
// now work through the file
int len;
FILE *f;
uint8 t inbuf[AUDIO INBUF SIZE + FF INPUT BUFFER PADDING SIZE];
AVFrame *decoded_frame = NULL;
f = fopen(audio file, "rb");
if (!f) {
    fprintf(stderr, "could not open %s\n", audio file);
    exit(1);
}
```

```
/* decode until eof */
avpkt.data = inbuf;
avpkt.size = fread(inbuf, 1, AUDIO INBUF SIZE, f);
while (avpkt.size > 0) {
    int got frame = 0;
    if (!decoded frame) {
        if (!(decoded frame = avcodec alloc frame())) {
            fprintf(stderr, "out of memory\n");
            exit(1);
        }
    } else
        avcodec get frame defaults(decoded frame);
    len = avcodec_decode_audio4(c, decoded_frame, &got_frame, &avpkt);
    if (len < 0) {
        fprintf(stderr, "Error while decoding\n");
        exit(1);
    if (got frame) {
        /* if a frame has been decoded, we want to send it to OpenMAX */
        int data size = av samples get buffer size(NULL, c->channels,
                                                    decoded frame->nb samples,
                                                    c->sample_fmt, 1);
        // first time: count the number of planar streams
        if (num streams == 0) {
            while (num_streams < AV NUM DATA POINTERS &&
                   decoded frame->data[num streams] != NULL)
                num streams++;
        }
        // first time: set sample size from 0 to e.g 2 for 16-bit data
        if (sample_size == 0) {
            sample size =
                data_size / (num_streams * decoded frame->nb samples);
        }
        // Empty into render audio input buffers
        read_into_buffer_and_empty(decoded_frame,
                                   component,
                                   data size
                                   );
    }
    avpkt.size -= len;
    avpkt.data += len;
    if (avpkt.size < AUDIO REFILL THRESH) {</pre>
        /* Refill the input buffer, to avoid trying to decode
         * incomplete frames. Instead of this, one could also use
         * a parser, or use a proper container format through
         * libavformat. */
```

```
memmove(inbuf, avpkt.data, avpkt.size);
        avpkt.data = inbuf;
        len = fread(avpkt.data + avpkt.size, 1,
                    AUDIO_INBUF_SIZE - avpkt.size, f);
        if (len > 0)
            avpkt.size += len;
    }
}
printf("Finished decoding MP3\n");
// clean up last empty buffer with EOS
buff header =
    ilclient get input buffer(component,
                               1 /* block */);
buff header->nFilledLen = 0;
int r;
buff header->nFlags |= OMX BUFFERFLAG EOS;
r = OMX EmptyThisBuffer(ilclient get handle(component),
                        buff header);
if (r != OMX ErrorNone) {
    fprintf(stderr, "Empty buffer error %s\n",
            err2str(r));
} else {
    printf("EOS sent\n");
fclose(f);
avcodec close(c);
av free(c);
av free(decoded frame);
sleep(10);
exit(0);
```

The compiled program will take a command-line argument that is the name of an MP3 file and play it to the analog audio port.

Rendering MP3 with ID3 Extensions Using FFmpeg or LibAV and OpenMAX

MP3 was originally designed as a stereo format without metadata information (artist, date of recording, and so on). Now you have 5.1 and 6.1 formats with probably more coming. The MP3 Surround extension looks after this. Metadata is typically added as an ID3 extension. (I discovered this only after the previous program broke badly on some newer MP3 files I have: no MP3 header.)

The command file will identify such files with the following:

```
$ file Beethoven.mp3
Beethoven.mp3: Audio file with ID3 version 2.3.0
```

}

An MP3 file will usually have two *channels* for stereo. An MP3+ID3 file containing, say, an image file, will have two *streams*, one for the audio and one for the image. The av_dump_format will show all the IDE metadata, plus the image stream.

```
Input #0, mp3, from 'Beethoven.mp3':
 Metadata:
                   : 2013 Naxos Digital Services Ltd.
    copyright
                   : String Quartets - BEETHOVEN L van HAYDN FJ MOZART WA SCHUBERT F
    album
JANACEK L (Petersen Quar~1
                   : US2TL0937001
   TSRC
   title
                   : String Ouartet No 6 in B-Flat Major Op 18 No 6 I Allegro con brio
                   : String Quartets - BEETHOVEN L van HAYDN FJ MOZART WA SCHUBERT F
   TIT1
JANACEK L (Petersen Quar~1
    disc
                   : 1
   TLEN
                   : 522200
   track
                   : 1
   publisher
                   : Capriccio-(C51147)
   encoder
                   : LAME 32bits version 3.98.2 (http://www.mp3dev.org/)
   album artist : Petersen Quartet
   artist
                   : Petersen Quartet
                   : Beethoven, Ludwig van
   TEXT
   TOFN
                   : 729325.mp3
   genre
                   : Classical Music
                   : Beethoven, Ludwig van
   composer
                   : 2009
    date
 Duration: 00:08:42.24, start: 0.000000, bitrate: 323 kb/s
    Stream #0.0: Audio: mp3, 44100 Hz, 2 channels, s16p, 320 kb/s
    Stream #0.1: Video: mjpeg, yuvj444p, 500x509 [PAR 300:300 DAR 500:509], 90k tbn
   Metadata:
     title
     comment
                      : Cover (front)
```

Stream 0 is the audio stream, while an image is in stream 1.

You want to pass the MP3 stream to the FFmpeg/LibAV audio decoder but *not* the image stream. An AV frame contains the field stream_index that can be used to distinguish between them. If it is the audio stream, pass it to the OMX audio renderer; otherwise, skip it. You will see similar behavior when you look at rendering audio and video MPEG files. You find the audio stream index by asking av_find_best_stream for the AVMEDIA TYPE AUDIO stream.

In the previous sections, you read chunks in from the audio file and then relied on the decoder to break that into frames. That is now apparently on the way out. Instead, you should use the function av_read_frame, which reads only one frame at a time.

Unfortunately, on the RPi distro I was using, libavcodec-extra was at package 52, and that has a broken implementation of av_read_frame. You will need to do a package upgrade of LibAV to version 53 or later in order for the following code to work (the original version got the stream index wrong).

So, by this stage, you read frames using av_read_frame, find the audio stream index of the frame, and use this to distinguish between audio and other. You still get frames with the audio samples in the wrong format such as AV_SAMPLE_FMT_S16P instead of AV_SAMPLE_FMT_S16. In the previous sections, you reformatted the stream by hand. But of course, the formats might change again, so your code would break.

The Audio Resample package gives a general-purpose way of managing this. It requires more setup, but once done will be more stable...

...except for a little glitch: this is one of the few areas in which FFmpeg and LibAV have different APIs. How to do it with FFmpeg is shown in "How to convert sample rate from AV_SAMPLE_FMT_FLTP to AV_SAMPLE_FMT_S16?" (http://stackoverflow.com/questions/14989397/how-to-convert-sample-rate-from-av-sample-fmt-fltp-to-av-sample-fmt-s16). You are using LibAV, which is basically the same but with differently named types. The following sets up the conversion parameters:

AVAudioResampleContext *swr = avresample alloc context();

```
av_opt_set_int(swr, "in_channel_layout", audio_dec_ctx->channel_layout, 0);
    av_opt_set_int(swr, "out_channel_layout", audio dec ctx->channel layout, 0);
    av_opt_set_int(swr, "in_sample_rate", audio_dec_ctx->sample_rate
av_opt_set_int(swr, "out_sample_rate", audio_dec_ctx->sample_rate
av_opt_set_int(swr, "in_sample_fmt", audio_dec_ctx->sample_fmt, 0);
av_opt_set_int(swr, "out_sample_fmt", AV_SAMPLE_FMT_S16, 0);
                                                      audio dec ctx->sample rate, 0);
                                                      audio dec ctx->sample rate, 0);
    avresample open(swr);
    The following performs the conversion:
    uint8 t *buffer;
    av samples alloc(&buffer, &out linesize, 2, decoded frame->nb samples,
                         AV SAMPLE FMT S16, 0);
    avresample convert(swr, &buffer,
                           decoded frame->linesize[0],
                           decoded frame->nb samples,
                           decoded frame->data,
                           decoded frame->linesize[0],
                           decoded frame->nb samples);
    The revised program is il ffmpeg render resample audio.c.
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
#include "libavcodec/avcodec.h"
#include <libayformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#include "libavutil/opt.h"
#include "libavresample/avresample.h"
#define INBUF SIZE 4096
#define AUDIO INBUF SIZE 20480
#define AUDIO REFILL THRESH 4096
#define AUDIO "Bethoven.mp3"
```

```
AVCodecContext *audio_dec_ctx;
int audio stream idx;
/* For the RPi name can be "hdmi" or "local" */
void setOutputDevice(OMX HANDLETYPE handle, const char *name) {
   OMX ERRORTYPE err;
   OMX CONFIG BRCMAUDIODESTINATIONTYPE arDest;
    if (name && strlen(name) < sizeof(arDest.sName)) {</pre>
       memset(&arDest, 0, sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE));
       arDest.nSize = sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE);
       arDest.nVersion.nVersion = OMX VERSION;
       strcpy((char *)arDest.sName, name);
       err = OMX SetParameter(handle, OMX IndexConfigBrcmAudioDestination, &arDest);
       if (err != OMX ErrorNone) {
            fprintf(stderr, "Error on setting audio destination\n");
            exit(1);
       }
   }
}
void setPCMMode(OMX HANDLETYPE handle, int startPortNumber) {
   OMX AUDIO PARAM PCMMODETYPE sPCMMode;
   OMX ERRORTYPE err;
    memset(&sPCMMode, 0, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nSize = sizeof(OMX AUDIO PARAM PCMMODETYPE);
    sPCMMode.nVersion.nVersion = OMX VERSION;
    sPCMMode.nPortIndex = startPortNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    printf("Sampling rate %d, channels %d\n",
           sPCMMode.nSamplingRate,
           sPCMMode.nChannels);
    sPCMMode.nSamplingRate = 44100;
    sPCMMode.nChannels = 2; // assumed for now - should be checked
    err = OMX SetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        fprintf(stderr, "PCM mode unsupported\n");
       return;
    } else {
        fprintf(stderr, "PCM mode supported\n");
       fprintf(stderr, "PCM sampling rate %d\n", sPCMMode.nSamplingRate);
       fprintf(stderr, "PCM nChannels %d\n", sPCMMode.nChannels);
    }
}
```

```
void printState(OMX_HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "error elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
AVPacket avpkt;
static void set audio render input format(COMPONENT T *component) {
    // set input audio format
    printf("Setting audio render format\n");
    OMX AUDIO PARAM PORTFORMATTYPE audioPortFormat;
    //setHeader(&audioPortFormat, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    memset(&audioPortFormat, 0, sizeof(OMX_AUDIO_PARAM_PORTFORMATTYPE));
    audioPortFormat.nSize = sizeof(OMX AUDIO PARAM PORTFORMATTYPE);
    audioPortFormat.nVersion.nVersion = OMX VERSION;
    audioPortFormat.nPortIndex = 100;
    OMX_GetParameter(ilclient_get_handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    audioPortFormat.eEncoding = OMX AUDIO CodingPCM;
    //audioPortFormat.eEncoding = OMX AUDIO CodingMP3;
    OMX SetParameter(ilclient get handle(component),
                     OMX_IndexParamAudioPortFormat, &audioPortFormat);
    setPCMMode(ilclient get handle(component), 100);
}
```

```
int num streams = 0;
int sample size = 0;
OMX ERRORTYPE read into buffer and empty(AVFrame *decoded frame,
                                               COMPONENT T *component,
                                               // OMX BUFFERHEADERTYPE *buff header,
                                               int total len) {
    OMX ERRORTYPE r;
    OMX BUFFERHEADERTYPE *buff header = NULL;
    // do this once only
    AVAudioResampleContext *swr = avresample alloc context();
    av_opt_set_int(swr, "in_channel_layout", audio_dec_ctx->channel_layout, 0);
av_opt_set_int(swr, "out_channel_layout", audio_dec_ctx->channel_layout, 0);
    av_opt_set_int(swr, "in_sample_rate", audio_dec_ctx->sample_rate, 0);
    av_opt_set_int(swr, "out_sample_rate", audio_dec_ctx->sample_rate
av_opt_set_int(swr, "in_sample_fmt", audio_dec_ctx->sample_fmt, 0);
av_opt_set_int(swr, "out_sample_fmt", AV_SAMPLE_FMT_S16, 0);
                                                  audio dec ctx->sample rate, 0);
    avresample open(swr);
    int required decoded size = 0;
    int out linesize;
    required decoded size =
         av_samples_get_buffer_size(&out_linesize, 2,
                                        decoded frame->nb samples,
                                        AV SAMPLE FMT S16, 0);
    uint8 t *buffer;
    av samples alloc(&buffer, &out linesize, 2, decoded frame->nb samples,
                       AV SAMPLE FMT S16, 0);
    avresample convert(swr, &buffer,
                          decoded frame->linesize[0],
                          decoded frame->nb samples,
                          // decoded frame->extended data,
                          decoded frame->data,
                          decoded frame->linesize[0],
                          decoded_frame->nb_samples);
    while (required decoded size >= 0) {
         buff header =
             ilclient get input buffer(component,
                                           100,
                                            1 /* block */);
         if (required decoded size > 4096) {
             memcpy(buff header->pBuffer,
                     buffer, 4096);
             buff header->nFilledLen = 4096;
             buffer += 4096;
         } else {
              memcpy(buff header->pBuffer,
                     buffer, required decoded size);
             buff header->nFilledLen = required decoded size;
```

```
required_decoded_size -= 4096;
        r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                buff header);
        if (r != OMX ErrorNone) {
            fprintf(stderr, "Empty buffer error %s\n",
                    err2str(r));
            return r;
        }
    }
    return r;
}
FILE *favpkt = NULL;
int main(int argc, char** argv) {
    int i;
    char *componentName;
    int err;
    ILCLIENT_T *handle;
    COMPONENT T *component;
    AVFormatContext *pFormatCtx = NULL;
    char *audio file = AUDIO;
    if (argc == 2) {
        audio file = argv[1];
    }
    OMX BUFFERHEADERTYPE *buff header;
    componentName = "audio_render";
    bcm host init();
    handle = ilclient_init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
    if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient set error callback(handle,
                                error callback,
                                NULL);
```

```
ilclient_set_eos_callback(handle,
                          eos callback,
                          NULL);
err = ilclient create component(handle,
                                &component,
                                componentName,
                                ILCLIENT DISABLE ALL PORTS
                                ILCLIENT ENABLE INPUT BUFFERS
                                );
if (err == -1) {
    fprintf(stderr, "Component create failed\n");
    exit(1);
printState(ilclient get handle(component));
err = ilclient change component state(component,
                                      OMX StateIdle);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
printState(ilclient get handle(component));
// FFmpeg init
av register all();
if(avformat_open_input(&pFormatCtx, audio_file, NULL, NULL)!=0) {
    fprintf(stderr, "Can't get format\n");
    return -1; // Couldn't open file
// Retrieve stream information
if(avformat find stream info(pFormatCtx, NULL)<0)</pre>
    return -1; // Couldn't find stream information
av dump format(pFormatCtx, 0, audio file, 0);
int ret;
if ((ret = av find best stream(pFormatCtx, AVMEDIA TYPE AUDIO, -1, -1, NULL, 0)) >= 0) {
    //AVCodecContext* codec context;
    AVStream *audio stream;
    int sample rate;
    audio stream idx = ret;
    fprintf(stderr, "Audio stream index is %d\n", ret);
    audio_stream = pFormatCtx->streams[audio_stream_idx];
    audio dec ctx = audio stream->codec;
    sample_rate = audio_dec_ctx->sample_rate;
    printf("Sample rate is %d\n", sample rate);
    printf("Sample format is %d\n", audio dec ctx->sample fmt);
    printf("Num channels %d\n", audio_dec_ctx->channels);
```

```
if (audio_dec_ctx->channel_layout == 0) {
        audio dec ctx->channel layout =
            av get default channel layout(audio dec ctx->channels);
    }
    AVCodec *codec = avcodec find decoder(audio stream->codec->codec id);
    if (avcodec open2(audio dec ctx, codec, NULL) < 0) {
        fprintf(stderr, "could not open codec\n");
        exit(1);
    }
    if (codec) {
        printf("Codec name %s\n", codec->name);
}
av init packet(&avpkt);
// must be before we enable buffers
set audio render input format(component);
setOutputDevice(ilclient_get_handle(component), "local");
// input port
ilclient enable port buffers(component, 100,
                             NULL, NULL, NULL);
ilclient enable port(component, 100);
err = ilclient change component state(component,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(component));
// now work through the file
int len;
uint8_t inbuf[AUDIO_INBUF_SIZE + FF_INPUT_BUFFER PADDING SIZE];
AVFrame *decoded frame = NULL;
/* decode until eof */
avpkt.data = inbuf;
av_read_frame(pFormatCtx, &avpkt);
while (avpkt.size > 0) {
    printf("Packet size %d\n", avpkt.size);
    printf("Stream idx is %d\n", avpkt.stream index);
    printf("Codec type %d\n", pFormatCtx->streams[1]->codec->codec type);
```

```
if (avpkt.stream index != audio stream idx) {
        // it's an image, subtitle, etc
        av read frame(pFormatCtx, &avpkt);
        continue;
    }
    int got_frame = 0;
    if (favpkt == NULL) {
        favpkt = fopen("tmp.mp3", "wb");
    fwrite(avpkt.data, 1, avpkt.size, favpkt);
    if (!decoded frame) {
        if (!(decoded frame = avcodec alloc frame())) {
            fprintf(stderr, "out of memory\n");
            exit(1);
        }
    }
    len = avcodec decode audio4(audio dec ctx,
                                 decoded_frame, &got_frame, &avpkt);
    if (len < 0) {
        fprintf(stderr, "Error while decoding\n");
        exit(1);
    if (got frame) {
        /* if a frame has been decoded, we want to send it to OpenMAX */
        int data size =
            av samples get buffer size(NULL, audio dec ctx->channels,
                                       decoded frame->nb samples,
                                       audio dec ctx->sample fmt, 1);
        // Empty into render audio input buffers
        read into buffer and empty(decoded frame,
                                   component,
                                   data_size
                                   );
    av_read_frame(pFormatCtx, &avpkt);
    continue;
printf("Finished decoding MP3\n");
// clean up last empty buffer with EOS
buff header =
    ilclient get input buffer(component,
                              100,
                              1 /* block */);
buff header->nFilledLen = 0;
int r;
```

}

The program takes an MP3 file as a command-line argument, defaulting to a file called Beethoven.mp3.

Conclusion

Audio support is not so good with the RPi. You have to use tools such as FFmpeg/LibAV or Gstreamer.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAXIL 1.1.2 Specification: https://www.khronos.org/registry/omxil/ specs/OpenMAX_IL_1_1_2_Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAXIL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- Source code for ARM side libraries for interfacing to Raspberry Pi GPU: https://github.com/raspberrypi/userland

CHAPTER 15



OpenMAX generally forms a self-contained system that can display videos using the GPU. OpenGL ES is a distinct system that can use the GPU to draw graphics. There is a hook to allow OpenMAX videos to be displayed on OpenGL ES surfaces on the Raspberry Pi, which is discussed in this chapter.

EGLImage

EGL is the platform-independant way of drawing windows for OpenVG and OpenGL ES. OpenMAX has a buffer type corresponding to an EGL window, and this allows OpenMAX to render into windows also used by OpenGL ES.

OpenMAX

OpenMAX uses buffers to pass information into and out of components. Some components such as video_render communicate directly with the hardware to render their output buffers. Also, OpenMAX has an additional type of EGLImage that can be used as a buffer by some components. Images written to an EGLImage can then be rendered by OpenGL or OpenVG.

The OpenMAX specification says exactly *nothing* about how to create an EGLImage; this data type is not part of OpenMAX. All it talks about is how a component can be given an EGLImage to use for a buffer, and that is by using the call UseEGLImageBuffer.

```
OMX_UseEGLImage(hComponent,

ppBufferHdr,

nPortIndex,

pAppPrivate,

eglImage);
```

Even if you have an EGLImage, there is no guarantee that a component will be able to use it. It may not be set up to use this type of buffer, and if it can't, then the call to OMX_UseEGLImageBuffer will return OMX_ErrorNotImplemented.

OpenMAX is silent about which components will be able to handle this buffer type. It is not part of the OpenMAX specification.

© Jan Newmarch 2017 245

OpenGL

The type EGLImage is not part of the OpenGL ES specification either; it doesn't talk about how to display images from other sources.

eglCreateImageKHR

The function eglCreateImageKHR provides the missing link. The KHR_image_base specification defines a Khronos standard extension to OpenGL ES.

This extension defines a new EGL resource type that is suitable for sharing 2D arrays of image data between client APIs and the EGLImage. Although the intended purpose is sharing 2D image data, the underlying interface makes no assumptions about the format or purpose of the resource being shared, leaving those decisions to the application and associated client APIs.

The specification defines these functions:

The display and context are standard OpenGL ES. The target is not tightly specified:

<target> specifies the type of resource being used as the EGLImage source (examples include two-dimensional textures in OpenGL ES contexts and VGImage objects in OpenVG contexts).

The buffer is the resource used, cast to type EGLClientBuffer.

For OpenGL ES, a value of EGL_GL_TEXTURE_2D_KHR is given in eglext.h and can be used to specify that the resource is an OpenGL ES texture. The buffer itself is an OpenGL ES texture ID.

Broadcom GPU

There are two marvelous examples in the hello_pi source tree: hello_videocube and hello_teapot. The examples given later are based on these. However, they use OpenGL ES version 1, whereas new applications should use OpenGL ES version 2. An examination of these examples also reveals a number of issues.

Components

The Broadcom video_render component does not support EGLImage. Instead, there is a new component called egl render. This takes video or image inputs but also has an output buffer, which must be set to the EGLImage.

Threads

OpenGL ES has a processing loop, which typically draws frames as quickly as possible. OpenMAX also has a processing loop as it feeds data through a component pipeline. One of these can be run in the main thread, but the other requires its own thread, easily given by pthreads.

The OpenMAX thread will be filling the EGLImage buffer; the OpenGL ES thread will be using this to draw a texture. Should there be synchronization? The RPi examples have none, and it doesn't seem to be a problem.

Rendering a Video into an OpenGL ES Texture

Rendering using an EGLImage falls naturally into two sections: setting up the OpenGL ES environment and setting up the OpenMAX environment. These two are essentially disjoint, with the connection point being the creation of the EGLImage in the OpenGL ES part and setting that as a buffer in the OpenMAX part. The two parts then each run in their own thread.

The OpenGL ES you use is borrowed from the image-drawing program of Chapter 12. The only substantive change is to the function CreateSimpleTexture2D where you create an EGLImage and hand that to a new POSIX thread that runs the OpenMAX code.

```
GLuint CreateSimpleTexture2D(ESContext *esContext)
   // Texture object handle
   GLuint textureId;
   UserData *userData = esContext->userData;
   //userData->width = esContext->width;
   //userData->height = esContext->height;
   // Generate a texture object
   glGenTextures ( 1, &textureId );
   // Bind the texture object
   glBindTexture ( GL_TEXTURE_2D, textureId );
   // Load the texture
   glTexImage2D ( GL TEXTURE 2D, 0, GL RGBA,
                  IMAGE SIZE WIDTH, IMAGE SIZE HEIGHT,
                  o, GL RGBA, GL UNSIGNED BYTE, NULL );
   // Set the filtering mode
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MIN FILTER, GL NEAREST );
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MAG FILTER, GL NEAREST );
   //glTexParameteri(GL TEXTURE 2D, GL TEXTURE WRAP S, GL CLAMP TO EDGE);
   //glTexParameteri(GL TEXTURE 2D, GL TEXTURE WRAP T, GL CLAMP TO EDGE);
```

```
/* Create EGL Image */
   eglImage = eglCreateImageKHR(
                esContext->eglDisplay,
                esContext->eglContext,
                EGL GL TEXTURE 2D KHR,
                textureId, // (EGLClientBuffer)esContext->texture, 0);
   if (eglImage == EGL NO IMAGE KHR)
      printf("eglCreateImageKHR failed.\n");
      exit(1);
   }
   // Start rendering
   pthread create(&thread1, NULL, video decode test, eglImage);
   return textureId;
}
    The full file for the OpenGL ES code is square.c.
//
// Book:
             OpenGL(R) ES 2.0 Programming Guide
// Authors: Aaftab Munshi, Dan Ginsburg, Dave Shreiner
// ISBN-10: 0321502795
// ISBN-13: 9780321502797
// Publisher: Addison-Wesley Professional
// URLs: http://safari.informit.com/9780321563835
              http://www.opengles-book.com
//
//
// Simple Texture2D.c
//
//
      This is a simple example that draws a quad with a 2D
//
      texture image. The purpose of this example is to demonstrate
      the basics of 2D texturing
//
#include <stdlib.h>
#include <stdio.h>
#include "esUtil.h"
#include "EGL/eglext.h"
#include "triangle.h"
typedef struct
   // Handle to a program object
   GLuint programObject;
```

```
// Attribute locations
  GLint positionLoc;
  GLint texCoordLoc;
   // Sampler location
  GLint samplerLoc;
   // Texture handle
  GLuint textureId;
  GLubyte *image;
    int width, height;
} UserData;
static void* eglImage = 0;
static pthread_t thread1;
#define IMAGE SIZE WIDTH 1920
#define IMAGE SIZE HEIGHT 1080
GLuint CreateSimpleTexture2D(ESContext *esContext)
  // Texture object handle
  GLuint textureId;
  UserData *userData = esContext->userData;
   //userData->width = esContext->width;
   //userData->height = esContext->height;
   // Generate a texture object
   glGenTextures ( 1, &textureId );
   // Bind the texture object
  glBindTexture ( GL_TEXTURE_2D, textureId );
   // Load the texture
   glTexImage2D ( GL_TEXTURE_2D, 0, GL_RGBA,
                  IMAGE SIZE WIDTH, IMAGE SIZE HEIGHT,
                  o, GL RGBA, GL UNSIGNED BYTE, NULL );
   // Set the filtering mode
   glTexParameteri ( GL TEXTURE 2D, GL TEXTURE MIN FILTER, GL NEAREST );
   glTexParameteri ( GL_TEXTURE_2D, GL_TEXTURE_MAG_FILTER, GL NEAREST );
   //glTexParameteri(GL TEXTURE 2D, GL TEXTURE WRAP S, GL CLAMP TO EDGE);
   //glTexParameteri(GL TEXTURE 2D, GL TEXTURE WRAP T, GL CLAMP TO EDGE);
   /* Create EGL Image */
   eglImage = eglCreateImageKHR(
                esContext->eglDisplay,
                esContext->eglContext,
```

```
EGL_GL_TEXTURE_2D_KHR,
                textureId, // (EGLClientBuffer)esContext->texture, 0);
  if (eglImage == EGL_NO_IMAGE_KHR)
     printf("eglCreateImageKHR failed.\n");
     exit(1);
   }
  // Start rendering
  pthread create(&thread1, NULL, video decode test, eglImage);
  return textureId;
}
// Initialize the shader and program object
int Init ( ESContext *esContext )
    UserData *userData = esContext->userData;
   GLbyte vShaderStr[] =
     "attribute vec4 a position;
      "attribute vec2 a texCoord;
                                    \n"
      "varying vec2 v texCoord;
                                    \n"
      "void main()
                                    \n"
     "{
"
                                    \n"
         gl_Position = a_position; \n"
          v texCoord = a texCoord; \n"
                                    \n";
   GLbyte fShaderStr[] =
      "precision mediump float;
                                                            \n"
      "varying vec2 v_texCoord;
                                                            \n"
      "uniform sampler2D s texture;
                                                            \n"
      "void main()
                                                            \n"
      "{
"
        gl_FragColor = texture2D( s_texture, v_texCoord );\n"
                                                            \n";
  // Load the shaders and get a linked program object
  userData->programObject = esLoadProgram ( vShaderStr, fShaderStr );
  // Get the attribute locations
  userData->positionLoc = glGetAttribLocation ( userData->programObject, "a position" );
  userData->texCoordLoc = glGetAttribLocation ( userData->programObject, "a_texCoord" );
  // Get the sampler location
  userData->samplerLoc = glGetUniformLocation ( userData->programObject, "s_texture" );
```

```
// Load the texture
   userData->textureId = CreateSimpleTexture2D (esContext);
  glClearColor (0.5f, 0.5f, 0.5f, 1.0f);
  return GL_TRUE;
///
// Draw a triangle using the shader pair created in Init()
void Draw ( ESContext *esContext )
  UserData *userData = esContext->userData;
  GLfloat vVertices[] = { -1.0f, 1.0f, 0.0f, // Position 0
                           0.0f, 0.0f, // TexCoord 0
                          -1.0f, -1.0f, 0.0f, // Position 1
                                             // TexCoord 1
                           0.0f, 1.0f,
                           1.0f, -1.0f, 0.0f, // Position 2
                           1.0f, 1.0f, // TexCoord 2
                           1.0f, 1.0f, 0.0f, // Position 3
                           1.0f, 0.0f // TexCoord 3
                        }:
  GLushort indices[] = { 0, 1, 2, 0, 2, 3 };
   // Set the viewport
  glViewport ( 0, 0, 1920, 1080); //esContext->width, esContext->height );
   // Clear the color buffer
  glClear ( GL COLOR BUFFER BIT );
   // Use the program object
  glUseProgram ( userData->programObject );
   // Load the vertex position
  glVertexAttribPointer ( userData->positionLoc, 3, GL FLOAT,
                          GL_FALSE, 5 * sizeof(GLfloat), vVertices );
   // Load the texture coordinate
   glVertexAttribPointer ( userData->texCoordLoc, 2, GL FLOAT,
                          GL_FALSE, 5 * sizeof(GLfloat), &vVertices[3] );
   glEnableVertexAttribArray ( userData->positionLoc );
  glEnableVertexAttribArray ( userData->texCoordLoc );
   // Bind the texture
   glActiveTexture ( GL_TEXTURE0 );
  glBindTexture ( GL TEXTURE 2D, userData->textureId );
   // Set the sampler texture unit to 0
   glUniform1i ( userData->samplerLoc, 0 );
```

```
glDrawElements ( GL_TRIANGLES, 6, GL_UNSIGNED_SHORT, indices );
}
///
// Cleanup
void ShutDown ( ESContext *esContext )
{
   UserData *userData = esContext->userData;
   // Delete texture object
   glDeleteTextures ( 1, &userData->textureId );
   // Delete program object
   glDeleteProgram ( userData->programObject );
   free(esContext->userData);
}
int main ( int argc, char *argv[] )
{
   ESContext esContext;
   UserData userData;
   int width = 1920, height = 1080;
   GLubyte *image;
   esInitContext ( &esContext );
   esContext.userData = &userData;
   esCreateWindow ( &esContext, "Simple Texture 2D", width, height, ES WINDOW RGB );
   if (!Init ( &esContext ) )
      return 0;
   esRegisterDrawFunc ( &esContext, Draw );
   esMainLoop ( &esContext );
   ShutDown ( &esContext );
}
```

The code on the OpenMAX side is a bit more complicated. The rendering component changes from video_render to egl_render, and this component has an output port, 221. This needs the EGLImage attached with the following:

```
OMX_UseEGLImage(ILC_GET_HANDLE(egl_render), &eglBuffer, 221, NULL, eglImage)
```

This should be attached after the PortSettingsChanged event has been received by the video_decode component and the tunnel has been set up between the two components.

You need to fill the EGL Image buffer. This is done by the usual OMX_FillThisBuffer call. But what happens when it is full? There is no specification for this. What the Broadcom component appears to do is to render its contents onto the EGL surface. The examples do not show any synchronization technique, so does it just happen?

After it has been filled (and rendered?), the buffer should be filled again. When a buffer is filled, it generates a FilledBuffer event that is caught by the IL Client library. The library includes a hook called ilclient_set_fill buffer done callback whereby you can add a callback function that just refills the buffer.

```
void my fill buffer done(void* data, COMPONENT T* comp)
    if (OMX FillThisBuffer(ilclient get handle(egl render), eglBuffer) != OMX ErrorNone)
            printf("OMX FillThisBuffer failed in callback\n");
            exit(1);
        }
}
   With these additions, the code to render the video to the EGLImage is in the file video.c.
/*
 Copyright (c) 2012, Broadcom Europe Ltd
 Copyright (c) 2012, OtherCrashOverride
 All rights reserved.
 Redistribution and use in source and binary forms, with or without
 modification, are permitted provided that the following conditions are met:
 * Redistributions of source code must retain the above copyright
 notice, this list of conditions and the following disclaimer.
 * Redistributions in binary form must reproduce the above copyright
 notice, this list of conditions and the following disclaimer in the
 documentation and/or other materials provided with the distribution.
 * Neither the name of the copyright holder nor the
 names of its contributors may be used to endorse or promote products
 derived from this software without specific prior written permission.
 THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND
 ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
 WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE
 DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY
```

ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

```
// Video decode demo using OpenMAX IL though the ilcient helper library
#include <stdio.h>
#include <stdlib.h>
```

```
#include <string.h>
#include <sys/stat.h>
#include "bcm_host.h"
#include "ilclient.h"
static OMX BUFFERHEADERTYPE* eglBuffer = NULL;
static COMPONENT T* egl render = NULL;
static void* eglImage = 0;
void my fill buffer done(void* data, COMPONENT T* comp)
{
    if (OMX FillThisBuffer(ilclient get handle(egl render), eglBuffer) != OMX ErrorNone)
            printf("OMX_FillThisBuffer failed in callback\n");
            exit(1);
        }
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
#define err2str(x) ""
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                          COMPONENT T *component,
                                          OMX BUFFERHEADERTYPE *buff header,
                                          int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff_size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                            buff header);
    if (r != OMX ErrorNone) {
```

```
fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   }
   return r;
}
// Modified function prototype to work with pthreads
void *video decode test(void* arg)
{
    const char* filename = "/opt/vc/src/hello pi/hello video/test.h264";
   eglImage = arg;
    if (eglImage == 0)
            printf("eglImage is null.\n");
           exit(1);
        }
   OMX VIDEO PARAM PORTFORMATTYPE format;
   OMX TIME CONFIG CLOCKSTATETYPE cstate;
   COMPONENT T *video decode = NULL;
    COMPONENT_T *list[3]; // last entry should be null
   TUNNEL T tunnel[2]; // last entry should be null
    ILCLIENT T *client;
    FILE *in;
    int status = 0;
    unsigned int data len = 0;
    memset(list, 0, sizeof(list));
   memset(tunnel, 0, sizeof(tunnel));
    if((in = fopen(filename, "rb")) == NULL)
        return (void *)-2;
    if((client = ilclient_init()) == NULL)
            fclose(in);
            return (void *)-3;
        }
    if(OMX_Init() != OMX_ErrorNone)
            ilclient destroy(client);
            fclose(in);
            return (void *)-4;
        }
    // callback
    ilclient set fill buffer done callback(client, my fill buffer done, 0);
```

```
// create video_decode
    if(ilclient create component(client, &video decode, "video decode", ILCLIENT DISABLE
ALL PORTS | ILCLIENT ENABLE INPUT BUFFERS) != 0)
        status = -14;
    list[0] = video decode;
    // create egl render
    if(status == 0 && ilclient create component(client, &egl render, "egl render", ILCLIENT
DISABLE ALL PORTS | ILCLIENT ENABLE OUTPUT BUFFERS) != 0)
        status = -14;
    list[1] = egl render;
    set_tunnel(tunnel, video_decode, 131, egl_render, 220);
    ilclient change component state(video decode, OMX StateIdle);
    memset(&format, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    format.nSize = sizeof(OMX VIDEO PARAM PORTFORMATTYPE);
    format.nVersion.nVersion = OMX VERSION;
    format.nPortIndex = 130;
    format.eCompressionFormat = OMX VIDEO CodingAVC;
    if (status != 0) {
        fprintf(stderr, "Error has occurred %d\n", status);
        exit(1);
    }
    if(OMX SetParameter(ILC GET HANDLE(video decode),
                        OMX IndexParamVideoPortFormat, &format) != OMX ErrorNone) {
        fprintf(stderr, "Error setting port format\n");
        exit(1);
    }
    if(ilclient enable port buffers(video decode, 130, NULL, NULL, NULL) != 0) {
        fprintf(stderr, "Error enablng port buffers\n");
        exit(1);
    }
    OMX BUFFERHEADERTYPE *buf;
    int port settings changed = 0;
    int first_packet = 1;
    ilclient change component state(video decode, OMX StateExecuting);
    int toread = get file size(filename);
    // Read the first block so that the video decode can get
    // the dimensions of the video and call port settings
    // changed on the output port to configure it
    while (toread > 0) {
        buf =
            ilclient get input buffer(video decode,
                                      130,
                                      1 /* block */);
```

```
if (buf != NULL) {
        read_into_buffer_and_empty(in,
                                   video decode,
                                   buf,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            //fp = freopen(IMG, "r", fp);
            rewind(in);
            toread = get file size(filename);
        }
   }
   if (toread > 0 && ilclient_remove_event(video_decode,
                                            OMX EventPortSettingsChanged,
                                             131, 0, 0, 1) == 0) {
        printf("Removed port settings event\n");
        break;
    } else {
        // printf("No portr settting seen yet\n");
   // wait for first input block to set params for output port
   if (toread == 0) {
        int err;
        // wait for first input block to set params for output port
        err = ilclient_wait_for_event(video_decode,
                                      OMX EventPortSettingsChanged,
                                      131, 0, 0, 1,
                                      ILCLIENT_EVENT_ERROR | ILCLIENT_PARAMETER_CHANGED,
                                      2000);
        if (err < 0) {
            fprintf(stderr, "No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            break;
   }
}
if(ilclient_setup_tunnel(tunnel, 0, 0) != 0)
        status = -7;
        exit(1);
    }
```

```
// Set egl_render to idle
    ilclient change component state(egl render, OMX StateIdle);
    // Enable the output port and tell egl_render to use the texture as a buffer
    //ilclient enable port(egl render, 221); THIS BLOCKS SO CANT BE USED
    if (OMX SendCommand(ILC GET HANDLE(egl render), OMX CommandPortEnable, 221, NULL) !=
OMX ErrorNone)
        {
            printf("OMX CommandPortEnable failed.\n");
            exit(1);
        }
    if (OMX UseEGLImage(ILC GET HANDLE(egl render), &eglBuffer, 221, NULL, eglImage) !=
OMX ErrorNone)
        {
            printf("OMX UseEGLImage failed.\n");
            exit(1);
        }
    // Set egl_render to executing
    ilclient change component state(egl render, OMX StateExecuting);
    // Request egl render to write data to the texture buffer
    if(OMX FillThisBuffer(ILC GET HANDLE(egl render), eglBuffer) != OMX ErrorNone)
        {
            printf("OMX FillThisBuffer failed.\n");
            exit(1);
        }
   // now work through the file
    while (toread > 0) {
        OMX ERRORTYPE r;
        // do we have a decode input buffer we can fill and empty?
        buf =
            ilclient get input buffer(video decode,
                                      1 /* block */);
        if (buf != NULL) {
            read_into_buffer_and_empty(in,
                                       video decode,
                                       buf,
                                       &toread);
    sleep(2);
    // need to flush the renderer to allow video_decode to disable its input port
    ilclient flush tunnels(tunnel, 1);
    ilclient_disable_port_buffers(video_decode, 130, NULL, NULL);
```

```
fclose(in);
ilclient_disable_tunnel(tunnel);
ilclient_teardown_tunnels(tunnel);

ilclient_state_transition(list, OMX_StateIdle);
ilclient_state_transition(list, OMX_StateLoaded);

ilclient_cleanup_components(list);

OMX_Deinit();

ilclient_destroy(client);
return (void *)status;
}
```

Conclusion

This chapter showed you how to render a video from OpenMAX onto an EGL surface using OpenGL ES. By changing the OpenGL ES program, complex effects such as spinning the image or rendering to a "teapot" texture can be achieved.

Resources

- OpenMAXIL: The Standard for Media Library Portability: https://www.khronos. org/openmax/il/
- OpenMAXIL 1.1.2 Specification: https://www.khronos.org/registry/omxil/specs/OpenMAX_IL_1_1_2 Specification.pdf
- Raspberry Pi OpenMAX forum: www.raspberrypi.org/forums/viewforum.php?f=70
- VMCS-X OpenMAXIL Components: www.jvcref.com/files/PI/documentation/ ilcomponents/
- OpenGL ES Shading Language: https://www.khronos.org/files/opengles_shading language.pdf
- OpenGL ES Specification: https://www.khronos.org/registry/gles/specs/2.0/es full spec 2.0.25.pdf
- KHR_image_base defines KHR extensions for OpenGL ES: https://www.khronos.org/registry/egl/extensions/KHR/EGL_KHR_image_base.txt
- Changing the eglImage used by egl_render: www.raspberrypi.org/forums/ viewtopic.php?t=41958&p=414954
- Demo H264 video clips: www.h264info.com/clips.html

CHAPTER 16



This chapter covers how to play multiplexed files on the Raspberry Pi such as MP4 files, which consist of both audio and video streams. OpenMAX does not support demultiplexing such files, so you must use a software demuxer such as FFmpeg or LibAV. The libraries available on the RPi do not support the decoding of encoded audio streams, so you need to use a software decoder. Finally, you need to manage the synchronization of video and audio streams.

This chapter would not have been possible without seeing what was done in omxplayer. Many thanks to its authors!

Desperate Debugging

Sometimes nothing works. Debugging using gdb or similar gets you nowhere. Broadcom has a command called vcdbg that can report on what the GPU is doing. It is run with the following:

```
vcgencmd cache_flush
vcgencmd set_logging level=0x40
sudo vcdbg log msg
```

In code, you can call the following:

```
vcos log set level(VCOS LOG CATEGORY, VCOS LOG TRACE);
```

You can find more information at http://elinux.org/RPI_vcgencmd_usage and https://github.com/nezticle/RaspberryPi-BuildRoot/wiki/VideoCore-Tools.

Multimedia Files

Multimedia files containing both audio and video are *container* files. Typically they will have header information and then streams of audio and video data, usually interleaved in some way, where each stream has its own appropriate format.

There are many such formats (see, for example, Wikipedia's "Digital container format" article, at http://en.wikipedia.org/wiki/Digital_container_format#Multimedia_container_formats). You will just look at the MP4 format here. An MP4 file will typically contain both audio and video streams but may also contain subtitles and still images.

© Jan Newmarch 2017 261

Although an MP4 file can contain audio and video streams of many different formats, the most common are Advanced Audio Coding (AAC) for audio and H.264 for video.

The program mediainfo can show a huge amount of information about a file. For example, for the sample file Big Buck Bunny, it shows the following:

General

Complete name : big_buck_bunny.mp4

Format : MPEG-4

Format profile : Base Media / Version 2

Codec ID : mp42
File size : 5.26 MiB
Duration : 1mn Os
Overall bit rate : 734 Kbps

Encoded date : UTC 2010-02-09 01:55:39
Tagged date : UTC 2010-02-09 01:55:40

Video

ID : 2 Format : AVC

Format/Info : Advanced Video Codec

Format profile : Baseline@L3.0

Format settings, CABAC : No
Format settings, ReFrames : 2 frames
Format settings, GOP : M=1, N=64
Codec ID : avc1

Codec ID/Info : Advanced Video Coding

Duration: 1mn OsDuration_LastFrame: 95msBit rate: 613 KbpsWidth: 640 pixelsHeight: 360 pixelsDisplay aspect ratio: 16:9

Frame rate mode : Constant
Frame rate : 24.000 fps
Color space : YUV
Chroma subsampling : 4:2:0
Bit depth : 8 bits
Scan type : Progressive
Bits/(Pixel*Frame) : 0.111

Stream size : 4.39 MiB (83%) Language : English

Encoded date : UTC 2010-02-09 01:55:39
Tagged date : UTC 2010-02-09 01:55:40

Color primaries : BT.601 NTSC
Transfer characteristics : BT.709
Matrix coefficients : BT.601

Audio

ID : 1
Format : AAC

Format/Info : Advanced Audio Codec

Format profile : LC Codec ID : 40 Duration : 1mn Os Source duration : 1mn Os Bit rate mode : Constant Bit rate : 64.0 Kbps Channel(s) : 2 channels Channel positions : Front: L R Sampling rate : 22.05 KHz Compression mode : Lossy Stream size : 478 KiB (9%) Source stream size : 478 KiB (9%) Language : English

Encoded date : UTC 2010-02-09 01:55:39
Tagged date : UTC 2010-02-09 01:55:40

The main points for now are the video format Advanced Video Codec (H.264) and the audio format AAC.

Demuxing Multimedia Files

To play a multimedia file, the file must be split into two streams, or *demultiplexed*. Typically the streams will be interleaved as a sequence of packets of each type. Because of the large variety of possible multimedia file formats, *none* of them are supported by the Broadcom GPU, although there have been repeated requests for at least some to be supported (for example, see www.raspberrypi.org/forums/viewtopic.php?t=32601&p=280735).

To demux a file, a software package such as FFmpeg or LibAV must be used. FFmpeg and LibAV forked some years ago, through a vitriolic and ongoing brawl. The Debian package for the RPi uses LibAV, while the superb multimedia omxplayer uses FFmpeg. In addition, there is a continual evolution of code, formats, codecs, and so on, so it can be traumatic figuring out what code to build. Added to the difficulties of OpenMAX itself, this is not an easy area to navigate.

Decoding the Audio Stream Using LibAV

In this section, you'll just look at managing an audio stream using LibAV/FFmpeg. This is a continually changing area, and the working version as of March 2015 uses LibAV codec version 54.35. Adding in OpenMAX will be done in the following section.

LibAV forked from FFmpeg acrimoniously (use Google to dig up the details). Debian and most Debian-derived systems use LibAV. omxplayer doesn't: it uses FFmpeg. The two forks align much of the time but not always. The headers are different, sometimes the APIs differ, and of course there may be semantic differences. I'm going to use LibAV since that is what is installed in the Raspbian package. I take no sides, other than to comment that I know the packages must keep evolving with developments in AV codecs, containers, and so on, but to add the complexity of two parallel packages is an added burden on the developer.

Whatever you do, using either package involves setting up a *format context*. This is initialized with a call to avformat_open, which takes a file name as a parameter. A (container) file will contain one or more streams, and you can find information about all of this with avformat_find_stream_info. This can be printed out with av dump format.

You can find the audio stream through the call av_find_best_stream, which returns an index into the array of streams maintained by the context.

If you want to demultiplex only the streams, this is sufficient for setup. This is the case for the video AVC streams as the Broadcom GPU can decode and render them. For audio, the situation is not so good: the Broadcom GPU will handle only WAV or raw PCM data. So, you have to decode the AAC stream in software.

You can find the decoder and its context from additional calls to avcodec_find_decoder and avcodec_ alloc context3.

Some codecs pull out extra information from the audio stream that the codec context didn't see. However, it turns out that the context may need those extra pieces of information. This is a bit yucky: the extra data has to be installed from the codec into its context (shouldn't this be done with avcodec_alloc_context?). After this has been done, the codec can be opened by avcodec_open2.

This initialization code is as follows:

```
int setup demuxer(const char *filename) {
    // Register all formats and codecs
    av register all();
    if(avformat open input(&pFormatCtx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
        return -1; // Couldn't open file
    }
    // Retrieve stream information
    if (avformat find stream info(pFormatCtx, NULL) < 0) {</pre>
        return -1; // Couldn't find stream information
    }
    printf("Format:\n");
    av dump format(pFormatCtx, 0, filename, 0);
    int ret:
    ret = av find best stream(pFormatCtx, AVMEDIA TYPE AUDIO, -1, -1, NULL, 0);
    if (ret >= 0) {
        audio stream idx = ret;
        audio stream = pFormatCtx->streams[audio stream idx];
        audio dec ctx = audio stream->codec;
        AVCodec *codec = avcodec find decoder(audio stream->codec->codec id);
        codec context = avcodec alloc context3(codec);
        // copy across info from codec about extradata
        codec context->extradata = audio stream->codec->extradata;
        codec context->extradata size = audio stream->codec->extradata size;
        if (codec) {
            printf("Codec name %s\n", codec->name);
        }
        if (!avcodec open2(codec context, codec, NULL) < 0) {
            fprintf(stderr, "Could not find open the needed codec");
            exit(1);
        }
    }
   return 0;
}
```

The main AV processing loop reads packets using av_read_frame. If they are audio packets, then they need to be decoded into frames in a slightly convoluted way by using avcodec_decode_audio4. The returned value is *not* the size of the decoded frame but is the size of the packet *consumed* by the decoding. Strictly, you should loop until the amount consumed equals the size of the read packet, but you can ignore that here, assuming that the total packet is consumed.

At one time it appeared that LibAV/FFmpeg decoded AAC frames into raw PCM data, with each channel interleaved by each sample, AV_SAMPLE_FMT_S16. Now they decode into a format called AV_SAMPLE_FMT_FLTP, which is a fixed-point planar format (multiple samples in each channel are together). These need to be converted, using the package AVResample, which uses a different API in LibAV and FFmpeg. Using LibAV, you create a buffer for a stereo big enough to hold enough 16-bit samples with av_samples_alloc and then convert the samples with avresample_convert.

For this exercise, you then save the 16-bit stereo samples to a file. The code is as follows:

```
FILE *out = fopen("tmp.s16", "w");
// for converting from AV SAMPLE FMT FLTP to AV SAMPLE FMT S16
// Set up SWR context once you've got codec information
AVAudioResampleContext *swr = avresample alloc context();
av_opt_set_int(swr, "in_channel_layout", audio_dec_ctx->channel_layout, 0);
av_opt_set_int(swr, "out_channel_layout", audio_dec ctx->channel layout, 0);
av_opt_set_int(swr, "in_sample_rate",
                                         audio dec ctx->sample rate, 0);
av_opt_set_int(swr, "out_sample_rate",
                                       audio dec ctx->sample rate, 0);
av_opt_set_int(swr, "in_sample_fmt", AV_SAMPLE_FMT_FLTP, 0);
av opt set int(swr, "out sample fmt", AV SAMPLE FMT S16, 0);
avresample_open(swr);
int buffer size;
int num_ret;
/* read frames from the file */
AVFrame *frame = avcodec alloc frame(); // av frame alloc
while (av read frame(pFormatCtx, &pkt) >= 0) {
    // printf("Read pkt %d\n", pkt.size);
    AVPacket orig pkt = pkt;
    if (pkt.stream index == audio stream idx) {
        // printf(" read audio pkt %d\n", pkt.size);
        // fwrite(pkt.data, 1, pkt.size, out);
        AVPacket avpkt;
        int got frame;
        av init packet(&avpkt);
        avpkt.data = pkt.data;
        avpkt.size = pkt.size;
        uint8 t *buffer;
        if (((err = avcodec decode audio4(codec context,
                                          frame,
                                          &got_frame,
                                          &avpkt)) < 0) || !got frame) {
            fprintf(stderr, "Error decoding %d\n", err);
```

```
continue;
        }
        int out linesize;
        av samples get buffer size(&out linesize, 2, frame->nb samples,
                                        AV SAMPLE FMT S16, 0);
        av samples alloc(&buffer, &out linesize, 2, frame->nb samples,
                         AV SAMPLE FMT S16, 0);
        avresample convert(swr, &buffer, frame->linesize[0],
                           frame->nb samples, frame->extended data,
                           frame->linesize[0], frame->nb samples);
        printf("Pkt size %d, decoded to %d line size %d\n",
               pkt.size, err, out linesize);
        printf("Samples: pkt size %d nb samples %d\n",
              pkt.size, frame->nb samples);
        printf("Buffer is (decoded size %d) %d %d %d %d %d \n",
               required decoded size,
               buffer[0], buffer[1], buffer[2], buffer[3], err);
        fwrite(buffer, 1, frame->nb samples*4, out);
   av free packet(Vig pkt);
}
The complete program is ffmpeg demux decode audio.c.
The resultant raw PCM file can be played with the following:
```

aplay -c 2 -r 22050 -f S16_LE tmp.s16

Or it can be converted to WAV format, for example, and then played with any player such as mplayer.

```
sox -c 2 -r 22050 tmp.s16 tmp.wav
```

Note that the audio file contains raw PCM data only, and this does not contain any information such as the sampling rate of 22050 Hz. You have to supply this yourself, using information from av_dump_format or mediainfo. Playing using aplay requires this explicitly, while conversion to WAV format by sox adds in WAV header information to the PCM data.

Rendering an Audio Stream

Now that you have successfully demuxed and decoded the audio stream into a stream of PCM data, sending it to the Broadcom audio render device is straightforward using the techniques covered in Chapter 14.

Essentially, you set up the OMX audio renderer using information from the LibAV decoder and then feed the decoded packets into the audio renderer. It's just a loong program by this stage!

The full program is il ffmpeg demux render audio.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <vcos logging.h>
#define VCOS LOG CATEGORY (&il ffmpeg log category)
static VCOS LOG CAT T il ffmpeg log category;
#include <ilclient.h>
#include "libavcodec/avcodec.h"
#include <libavformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#include "libavresample/avresample.h"
#define INBUF SIZE 4096
#define AUDIO INBUF SIZE 20480
#define AUDIO_REFILL THRESH 4096
char *IMG = "taichi.mp4";
static AVCodecContext *audio dec ctx = NULL;
static AVStream *audio stream = NULL;
static AVPacket pkt;
AVFormatContext *pFormatCtx = NULL;
AVAudioResampleContext *swr;
int sample_rate;
int channels;
static int audio_stream_idx = -1;
AVCodec *codec;
void setPCMMode(OMX HANDLETYPE handle, int startPortNumber) {
    OMX AUDIO PARAM PCMMODETYPE sPCMMode;
    OMX ERRORTYPE err;
    memset(&sPCMMode, 0, sizeof(OMX AUDIO PARAM PCMMODETYPE));
    sPCMMode.nSize = sizeof(OMX_AUDIO_PARAM_PCMMODETYPE);
    sPCMMode.nVersion.nVersion = OMX VERSION;
    sPCMMode.nPortIndex = startPortNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &sPCMMode);
```

```
printf("Sampling rate %d, channels %d\n",
           sPCMMode.nSamplingRate,
           sPCMMode.nChannels);
    //sPCMMode.nSamplingRate = 44100; // for taichi
    //sPCMMode.nSamplingRate = 22050; // for big buck bunny
    sPCMMode.nSamplingRate = sample rate; // for anything
    sPCMMode.nChannels = channels;
    err = OMX_SetParameter(handle, OMX_IndexParamAudioPcm, &sPCMMode);
    if(err != OMX ErrorNone){
        fprintf(stderr, "PCM mode unsupported\n");
        return;
    } else {
        fprintf(stderr, "PCM mode supported\n");
        fprintf(stderr, "PCM sampling rate %d\n", sPCMMode.nSamplingRate);
        fprintf(stderr, "PCM nChannels %d\n", sPCMMode.nChannels);
    }
}
static void set audio render input format(COMPONENT T *component) {
    // set input audio format
    printf("Setting audio render format\n");
    OMX AUDIO PARAM PORTFORMATTYPE audioPortFormat;
    //setHeader(&audioPortFormat, sizeof(OMX_AUDIO_PARAM_PORTFORMATTYPE));
    memset(&audioPortFormat, 0, sizeof(OMX AUDIO PARAM PORTFORMATTYPE));
    audioPortFormat.nSize = sizeof(OMX AUDIO PARAM PORTFORMATTYPE);
    audioPortFormat.nVersion.nVersion = OMX VERSION;
    audioPortFormat.nPortIndex = 100;
    OMX GetParameter(ilclient get handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    audioPortFormat.eEncoding = OMX AUDIO CodingPCM;
    //audioPortFormat.eEncoding = OMX AUDIO CodingMP3;
    OMX_SetParameter(ilclient_get_handle(component),
                     OMX IndexParamAudioPortFormat, &audioPortFormat);
    setPCMMode(ilclient_get_handle(component), 100);
}
void printState(OMX HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "error elided";
}
```

```
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    printf("Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    printf("OMX error %s\n", err2str(data));
void port settings callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    printf("Got port Settings event\n");
    // exit(0);
}
void empty_buffer_done_callback(void *userdata, COMPONENT T *comp) {
    // printf("Got empty buffer done\n");
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st size);
}
OMX_ERRORTYPE read_audio_into_buffer_and_empty(AVFrame *decoded_frame,
                                                COMPONENT T *component,
                                                // OMX BUFFERHEADERTYPE *buff header,
                                                int total len) {
    OMX ERRORTYPE r;
    OMX BUFFERHEADERTYPE *buff header = NULL;
#if AUDIO DECODE
    int port index = 120;
#else
    int port index = 100;
#endif
    int required decoded size = 0;
    int out linesize;
    required decoded size =
        av samples get buffer size(&out linesize, 2,
                                    decoded_frame->nb_samples,
                                   AV SAMPLE FMT S16, 0);
    uint8 t *buffer, *start buffer;
    av_samples_alloc(&buffer, &out_linesize, 2, decoded_frame->nb_samples,
                     AV SAMPLE FMT S16, 0);
    start buffer = buffer;
```

```
avresample_convert(swr, &buffer,
                   decoded frame->linesize[0],
                   decoded frame->nb samples,
                   // decoded_frame->extended_data,
                   decoded frame->data,
                   decoded frame->linesize[0],
                   decoded frame->nb samples);
// printf("Decoded audio size %d\n", required decoded size);
/* printf("Audio timestamp %11d\n", (decoded_frame->pkt_pts * USECS_IN_SEC *
   atime base num /
   atime base den));
//print clock time("OMX Audio empty timestamp");
while (required decoded size > 0) {
    buff header =
        ilclient get input buffer(component,
                                  port index,
                                  1 /* block */);
    buff header->nTimeStamp = ToOMXTime((uint64 t)
                                        (decoded frame->pkt pts * USECS IN SEC *
                                         atime base num /
                                         atime base den));
    */
    int len = buff_header->nAllocLen;
    if (required decoded size > len) {
        // fprintf(stderr, "Buffer not big enough %d, looping\n", len);
        memcpy(buff header->pBuffer,
               buffer, len);
        buff header->nFilledLen = len;
        buffer += len;
    } else {
        memcpy(buff_header->pBuffer,
               buffer, required decoded size);
        buff header->nFilledLen = required decoded size;
    // gettimeofday(&tv, NULL);
    // printf("Time audio empty start %ld\n",
    // tv.tv sec * USECS IN SEC + tv.tv usec - starttime);
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    // gettimeofday(&tv, NULL);
    // printf("Time audio empty stop %ld\n",
    // tv.tv_sec * USECS_IN_SEC + tv.tv_usec - starttime);
    //exit on omx error(r, "Empty buffer error %s\n");
```

```
required_decoded_size -= len;
    //av freep(&start buffer[0]);
    av_free(&start_buffer[0]);
    return r;
}
AVCodecContext* codec context;
int setup demuxer(const char *filename) {
    // Register all formats and codecs
    av register all();
    if(avformat_open_input(&pFormatCtx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
        return -1; // Couldn't open file
    }
    // Retrieve stream information
    if (avformat find stream info(pFormatCtx, NULL) < 0) {</pre>
        return -1; // Couldn't find stream information
    printf("Format:\n");
    av_dump_format(pFormatCtx, 0, filename, 0);
    int ret;
    ret = av_find_best_stream(pFormatCtx, AVMEDIA_TYPE_AUDIO, -1, -1, NULL, 0);
    if (ret >= 0) {
        audio stream idx = ret;
        // audio_stream_idx = 2; // JN
        audio stream = pFormatCtx->streams[audio stream idx];
        audio dec_ctx = audio_stream->codec;
        sample rate = audio dec ctx->sample rate;
        channels = audio_dec_ctx->channels;
        printf("Sample rate is %d channels %d\n", sample rate, channels);
        AVCodec *codec = avcodec_find_decoder(audio_stream->codec->codec_id);
        codec context = avcodec alloc context3(codec);
        // copy across info from codec about extradata
        codec context->extradata = audio stream->codec->extradata;
        codec context->extradata size = audio stream->codec->extradata size;
        if (codec) {
            printf("Codec name %s\n", codec->name);
        }
        if (!avcodec open2(codec context, codec, NULL) < 0) {
            fprintf(stderr, "Could not find open the needed codec");
            exit(1);
        }
```

```
}
    return 0;
}
/* For the RPi name can be "hdmi" or "local" */
void setOutputDevice(OMX HANDLETYPE handle, const char *name) {
    OMX ERRORTYPE err;
    OMX CONFIG BRCMAUDIODESTINATIONTYPE arDest;
    if (name && strlen(name) < sizeof(arDest.sName)) {</pre>
        memset(&arDest, 0, sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE));
        arDest.nSize = sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE);
        arDest.nVersion.nVersion = OMX_VERSION;
        strcpy((char *)arDest.sName, name);
        err = OMX SetParameter(handle, OMX IndexConfigBrcmAudioDestination, &arDest);
        if (err != OMX ErrorNone) {
            fprintf(stderr, "Error on setting audio destination\n");
            exit(1);
        }
    }
}
void setup_audio_renderComponent(ILCLIENT_T *handle,
                                 char *componentName,
                                 COMPONENT T **component) {
    int err;
    err = ilclient create component(handle,
                                     component,
                                     componentName,
                                     ILCLIENT DISABLE ALL PORTS
                                     ILCLIENT_ENABLE_INPUT_BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "Component create failed\n");
        exit(1);
    printState(ilclient_get_handle(*component));
    err = ilclient change component state(*component,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*component));
    // must be before we enable buffers
    set audio render input format(*component);
```

```
setOutputDevice(ilclient_get_handle(*component), "local");
    //setOutputDevice(ilclient get handle(*component), "hdmi");
    // input port
    ilclient enable_port_buffers(*component, 100,
                                 NULL, NULL, NULL);
    ilclient_enable_port(*component, 100);
   err = ilclient change component state(*component,
                                          OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Executing\n");
        exit(1);
   printState(ilclient get handle(*component));
}
int main(int argc, char** argv) {
   char *renderComponentName;
    int err;
    ILCLIENT T *handle;
   COMPONENT T *renderComponent;
    if (argc > 1) {
        IMG = argv[1];
   OMX BUFFERHEADERTYPE *buff header;
    setup demuxer(IMG);
    renderComponentName = "audio_render";
    bcm host init();
    handle = ilclient init();
    // vcos log set level(VCOS LOG CATEGORY, VCOS LOG TRACE);
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
    if (OMX Init() != OMX ErrorNone) {
        ilclient_destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient set error callback(handle,
```

```
error callback,
                              NULL);
ilclient set eos callback(handle,
                            eos callback,
                            NULL);
ilclient set port settings callback(handle,
                                       port settings callback,
                                       NULL);
ilclient set empty buffer done callback(handle,
                                            empty buffer done callback,
                                            NULL):
setup audio renderComponent(handle, renderComponentName, &renderComponent);
FILE *out = fopen("tmp.se16", "wb");
// for converting from AV_SAMPLE_FMT_FLTP to AV_SAMPLE_FMT_S16
// Set up SWR context once you've got codec information
//AVAudioResampleContext *swr = avresample alloc context();
swr = avresample alloc context();
av_opt_set_int(swr, "in_channel_layout",
                av get default channel layout(audio dec ctx->channels) , 0);
av_opt_set_int(swr, "out_channel_layout", AV_CH_LAYOUT_STEREO, 0);
av_opt_set_int(swr, "in_sample_rate", audio_dec_ctx->sample_rate
                                              audio dec ctx->sample rate, 0);
av_opt_set_int(swr, "out_sample_rate",
                                              audio dec ctx->sample rate, 0);
av_opt_set_int(swr, "in_sample_fmt", audio_dec_ctx->sample_fmt, 0);
av_opt_set_int(swr, "out_sample_fmt", AV_SAMPLE_FMT_S16, 0);
avresample open(swr);
fprintf(stderr, "Num channels for resmapling %d\n",
       av get channel layout nb channels(AV CH LAYOUT STEREO));
int buffer size;
int num ret;
/* read frames from the file */
AVFrame *frame = avcodec alloc frame(); // av frame alloc
while (av read frame(pFormatCtx, &pkt) >= 0) {
    // printf("Read pkt %d\n", pkt.size);
    AVPacket orig pkt = pkt;
    if (pkt.stream index == audio stream idx) {
         // printf(" read audio pkt %d\n", pkt.size);
        //fwrite(pkt.data, 1, pkt.size, out);
        AVPacket avpkt;
        int got frame;
        av_init_packet(&avpkt);
        avpkt.data = pkt.data;
        avpkt.size = pkt.size;
```

```
uint8 t *buffer;
            if (((err = avcodec decode audio4(codec context,
                                                frame.
                                               &got_frame,
                                               &avpkt)) < 0) || !got_frame) {</pre>
                fprintf(stderr, "Error decoding %d\n", err);
                continue;
            int required decoded size = 0;
            if (audio dec ctx->sample fmt == AV SAMPLE FMT S16) {
                buffer = frame->data;
            } else {
                read audio into buffer and empty(frame,
                                          renderComponent,
                                          required decoded size
            fwrite(buffer, 1, frame->nb_samples*4, out);
        }
        av_free_packet(&orig_pkt);
    }
    exit(0);
}
```

Rendering the Video Stream (at Full Speed)

An MP4 file will usually contain an H.264 video stream, so I will restrict discussion to that type. This can be decoded by the GPU using the Broadcom component OMX.broadcom.video_decode. There is no need to decode this in software. So, a first cut at rendering the video stream is to first demux it using FFmpeg/LibAV, pass it into the Broadcom video decoder, and then pass it into the Broadcom video renderer, OMX.broadcom.video render.

It works, but with no controls, it will play the video as fast as it can render it, just as though it was playing every frame on fast-forward. Nevertheless, it is worth looking at as there are some wrinkles arising from the decoding to be addressed.

Demuxing an MP4 file takes place, as described earlier. Instead of selecting on audio frames, you now select on video frames. But on feeding it to an OMX component, you are now back in the situation of needing to wait for a PortSettingsChanged event to occur before setting up the tunnel between the decode and render components. The code follows the structure of earlier examples, looping through the file until you get the event, setting up the tunnel, and then looping through the rest of the file. It's nothing new.

Setting up the demuxer, however, requires code specific to video rather than audio. Once you have found the "best video stream," you can extract video data from it such as image width and height. But also, you may get *extradata*, which is more information about the video stream. (This may include things such as Huffman tables, but you don't need to look into the details, fortunately.)

This is similar to passing extra data from the audio codec to the audio context, but it isn't so simple. First you have to capture it and then send it into the video decoder through an OMX input buffer.

The code to set up the demuxer is as follows:

```
int setup demuxer(const char *filename) {
    // Register all formats and codecs
    av register all();
    if(avformat_open_input(&pFormatCtx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
       return -1; // Couldn't open file
    // Retrieve stream information
    if (avformat find stream info(pFormatCtx, NULL) < 0) {
        return -1; // Couldn't find stream information
    printf("Format:\n");
    av_dump_format(pFormatCtx, 0, filename, 0);
    int ret;
    ret = av_find_best_stream(pFormatCtx, AVMEDIA_TYPE_VIDEO, -1, -1, NULL, 0);
    if (ret >= 0) {
       video stream idx = ret;
       video stream = pFormatCtx->streams[video stream idx];
       video dec ctx = video stream->codec;
        img width
                         = video stream->codec->width;
                         = video stream->codec->height;
        img height
        extradata
                          = video stream->codec->extradata;
        extradatasize
                          = video stream->codec->extradata size;
       AVCodec *codec = avcodec_find_decoder(video_stream->codec->codec_id);
        if (codec) {
            printf("Codec name %s\n", codec->name);
    }
   return 0;
}
```


The extra data needs to be fed into the video decoder, just like the extra data for audio needed to be fed into the audio decoder. This time, the video decoder is the OpenMAX component, and sending the data to it means getting a buffer, copying the data into it, and emptying the buffer, before sending any data frames.

```
if(omx buffer == NULL)
      fprintf(stderr, "%s - buffer error 0x%08x", func , omx err);
    return 0;
  omx buffer->nOffset = 0;
  omx buffer->nFilledLen = extradatasize;
  if(omx buffer->nFilledLen > omx buffer->nAllocLen)
      fprintf(stderr, "%s - omx_buffer->nFilledLen > omx_buffer-nAllocLen", __func__);
    return 0;
  }
  memset((unsigned char *)omx buffer->pBuffer, 0x0, omx buffer->nAllocLen);
  memcpy((unsigned char *)omx buffer->pBuffer, extradata, omx buffer->nFilledLen);
  omx buffer->nFlags = OMX BUFFERFLAG CODECCONFIG | OMX BUFFERFLAG ENDOFFRAME;
  omx err = OMX EmptyThisBuffer(ilclient get handle(component),
                                 omx buffer);
  if (omx err != OMX ErrorNone)
      fprintf(stderr, "%s - OMX EmptyThisBuffer() failed with result(0x%x)\n", __func__,
      omx err);
    return 0;
  } else {
      printf("Config sent, emptying buffer %d\n", extradatasize);
}
return 1;
```

That is the essential extra point in decoding the video and sending it to the renderer. The code is at il ffmpeg demux render video full speed.c and, as mentioned before, plays the video as fast as it can.

Rendering the Video Stream (with Scheduling)

Playing the video stream at a reasonable speed adds substantial layers of complexity. You need to add a clock and a scheduler to begin with. The scheduler is interposed between the decoder and the renderer, and the scheduler takes times from the clock.



There are now four OpenMAX components to set up.

- video decode
- video render
- video_scheduler
- clock

The code for the first three is straightforward.

```
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
    err = ilclient_create_component(handle,
                                     decodeComponent,
                                     decodeComponentName,
                                     ILCLIENT_DISABLE_ALL_PORTS
                                     ILCLIENT ENABLE INPUT BUFFERS
                                     ILCLIENT ENABLE OUTPUT BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    err = ilclient_change_component_state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient_get_handle(*decodeComponent));
    // must be before we enable buffers
    set_video_decoder_input_format(*decodeComponent);
}
void setup_renderComponent(ILCLIENT_T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient create component(handle,
                                     renderComponent,
                                     renderComponentName,
                                     ILCLIENT DISABLE ALL PORTS
```

```
ILCLIENT ENABLE INPUT BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
    printState(ilclient_get_handle(*renderComponent));
   err = ilclient change component state(*renderComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
   printState(ilclient get handle(*renderComponent));
}
void setup schedulerComponent(ILCLIENT T *handle,
                           char *schedulerComponentName,
                           COMPONENT T **schedulerComponent) {
    int err;
   err = ilclient create component(handle,
                                    schedulerComponent,
                                    schedulerComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
    if (err == -1) {
        fprintf(stderr, "SchedulerComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*schedulerComponent));
   err = ilclient change component state(*schedulerComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*schedulerComponent));
}
```

The clock component is new. The clock can use a variety of sources for its timing information. For this case, you are dealing with video (and later audio). The clock can use a video clock or an audio clock as its time reference source. Here you want to deal only with video, so you use a video clock.

```
OMX_TIME_CONFIG_ACTIVEREFCLOCKTYPE refClock;
refClock.nSize = sizeof(OMX_TIME_CONFIG_ACTIVEREFCLOCKTYPE);
refClock.nVersion.nVersion = OMX_VERSION;
refClock.eClock = OMX_TIME_RefClockVideo;
```

How the clock locates its reference clock doesn't seem to be specified anywhere. It seems to be a bit of "behind-the-scenes" magic done implicitly by OMX implementors. There are hints in the 1.1.2 specification in section 6.2.6, "Audio-Video File Playback Example Use Case," which shows that it is probably the scheduler that plays this role.

The clock needs to have a rate set. This is set in the field xScale of an OMX_TIME_CONFIG_SCALETYPE struct. The values do not seem to be clearly specified by OpenMAX. The wonderful omxplayer seems to have tried various values for this in different versions. The only clue is that section 3.2.2.11.2, "Sample Code Showing Calling Sequence," of the 1.1.2 specification shows the following:

```
oScale.xScale = 0x00020000; /*2x*/
```

From this you can guess that the value of normal speed could be 0x00010000, but by juggling other parameters, this need not be the case (which is what omxplayer currently does). Assuming this value, the code is as follows:

```
OMX TIME CONFIG SCALETYPE scaleType;
scaleType.nSize = sizeof(OMX TIME CONFIG SCALETYPE);
scaleType.nVersion.nVersion = OMX VERSION;
scaleType.xScale = 0x00010000;
OMX SetConfig(ilclient get handle(*clockComponent),
                        OMX IndexConfigTimeScale, &scaleType);
    The complete clock setup is as follows:
void setup clockComponent(ILCLIENT T *handle,
                           char *clockComponentName,
                           COMPONENT T **clockComponent) {
    int err;
    err = ilclient_create_component(handle,
                                     clockComponent,
                                     clockComponentName,
                                     ILCLIENT_DISABLE ALL PORTS
    if (err == -1) {
        fprintf(stderr, "ClockComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*clockComponent));
    err = ilclient change component state(*clockComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*clockComponent));
    printClockState(*clockComponent);
```

```
OMX TIME CONFIG ACTIVEREFCLOCKTYPE refClock;
    refClock.nSize = sizeof(OMX TIME CONFIG ACTIVEREFCLOCKTYPE);
    refClock.nVersion.nVersion = OMX VERSION;
    refClock.eClock = OMX_TIME_RefClockVideo;
    err = OMX SetConfig(ilclient get handle(*clockComponent),
                        OMX IndexConfigTimeActiveRefClock, &refClock);
    if(err != OMX ErrorNone) {
        fprintf(stderr, "COMXCoreComponent::SetConfig - %s failed with omx err(0x%x)\n",
              "clock", err);
    }
    OMX TIME CONFIG SCALETYPE scaleType;
    scaleType.nSize = sizeof(OMX TIME CONFIG SCALETYPE);
    scaleType.nVersion.nVersion = OMX VERSION;
    scaleType.xScale = (1 << 16);</pre>
   err = OMX SetConfig(ilclient get handle(*clockComponent),
                        OMX IndexConfigTimeScale, &scaleType);
    if(err != OMX ErrorNone) {
        fprintf(stderr, "COMXCoreComponent::SetConfig - %s failed with omx err(0x%x)\n",
              "clock", err);
    }
}
```

Execution reads from the file, demuxing frames using FFmpeg/LibAV and sending frames to the decoder until a PortSettingsChanged event occurs. Then it sets up tunnels. There are three of these:

- From the decoder to the scheduler
- From the clock to the scheduler
- From the scheduler to the renderer

Here's an example:

```
TUNNEL_T decodeTunnel;
set_tunnel(&decodeTunnel, decodeComponent, 131, schedulerComponent, 10);
if ((err = ilclient_setup_tunnel(&decodeTunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up decode tunnel %X\n", err);
    exit(1);
} else {
    printf("Decode tunnel set up ok\n");
}

TUNNEL_T schedulerTunnel;
set_tunnel(&schedulerTunnel, schedulerComponent, 11, renderComponent, 90);
if ((err = ilclient_setup_tunnel(&schedulerTunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up scheduler tunnel %X\n", err);
    exit(1);
} else {
    printf("Scheduler tunnel set up ok\n");
}</pre>
```

```
TUNNEL_T clockTunnel;
    set tunnel(&clockTunnel, clockComponent, 80, schedulerComponent, 12);
    if ((err = ilclient setup tunnel(&clockTunnel, 0, 0)) < 0) {
        fprintf(stderr, "Error setting up clock tunnel %X\n", err);
        exit(1);
    } else {
        printf("Clock tunnel set up ok\n");
    startClock(clockComponent);
    The clock is started with the following:
void startClock(COMPONENT_T *clockComponent) {
    OMX ERRORTYPE err = OMX ErrorNone;
    OMX TIME CONFIG CLOCKSTATETYPE clockState;
    memset(&clockState, 0, sizeof( OMX TIME CONFIG CLOCKSTATETYPE));
    clockState.nSize = sizeof( OMX TIME CONFIG CLOCKSTATETYPE);
    clockState.nVersion.nVersion = OMX VERSION;
    err = OMX GetConfig(ilclient get handle(clockComponent),
                         OMX IndexConfigTimeClockState, &clockState);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error getting clock state %s\n", err2str(err));
        return;
    clockState.eState = OMX TIME ClockStateRunning;
    err = OMX SetConfig(ilclient get handle(clockComponent),
                        OMX IndexConfigTimeClockState, &clockState);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error starting clock %s\n", err2str(err));
        return;
    }
}
    Now you turn to the tricky part of the program: matching the timing of the LibAV/FFmpeg packets to
the OMX decoder. The relevant information from LibAV/FFmpeg is contained in the following structures:
typedef struct AVPacket {
    int64 t pts;
    int64 t dts;
} AVPacket;
typedef struct AVStream {
    AVRational r frame rate;
    AVRational time base;
} AVStream;
```

The field you have to match it to is as follows:

```
typedef struct OMX_BUFFERHEADERTYPE
{
    OMX_TICKS nTimeStamp;
    ...
} OMX_BUFFERHEADERTYPE;
```

The fields dts and pts refer to "decode timestamp" and "presentation timestamp," respectively. A good explanation is given by the tutorial at http://dranger.com/ffmpeg/tutorial05.html by dranger. The conclusion is that you aren't actually interested in the decode time, only the presentation time, pts.

The values of these from some typical files are useful in explaining these fields. Note that the type AVRational represents a number with numerator (num) and denominator (den).

File	time_base		r_frame_rate			
	num	den	num (fps rate)	den (fps scale)	pts Increment	Frame Rate
Big Buck Bunny	1	600	24	1	25	23.96
Tai Chi	1	29969	29969	1000	1000	29.97
ClipCanvas	1	600	25	1	24	25
small	1	90000	30	1	3000	30
Wildlife	1	2997	2997	100	100	29.97
Sintel	1	24	24	1	1	24

The times for LibAV/FFmpeg are in seconds. So, for Big Buck Bunny, the timebase is 1/600 second, the frame rate is 24 frames per second, and the pts increment is 25 timebase units. The timebase and the frame rate are given from the demuxer.

The pts values are given in the decoded packets. They may not be in order, so you may have to look at several values to obtain the highest common factor.

The relation between these fields is as follows:

```
pts increment × timebase = 1 / frame rate
```

so that the following values are true:

- For Big Buck Bunny, $25 \times 1 / 600 = 1 / 24$.
- For Tai Chi, 1000 × 1 / 299969 = 1000 / 2997 = 1 / 29.969.
- For ClipCanvas, $24 \times 1 / 600 = 1 / 25$.

- For small, $3000 \times 1 / 90000 = 1 / 30$.
- For Wildlife, $100 \times 1 / 2997 = 100 / 2997 = 1 / 29.97$.

Each frame occurs at the time pts * timebase seconds.

Let's turn to OMX. Section 6.2.1, "Timestamps," of the 1.1.2 specification states that the timestamp structure will be "interpreted as a signed 64-bit value representing microseconds." This means any seconds value from LibAV/FFmpeg needs to be multiplied by 1,000,000 to convert it to OMX timestamp microseconds. This relates LibAV/FFmpeg to OMX timestamps with the following:

```
buff header->nTimeStamp = pts * 1000000 * time base num / time base den;
```

On 32-bit CPUs like the RPi, the 64-bit timestamp needs to be unpacked into a struct with two 32-bit fields. This is done with the following:

```
OMX_TICKS ToOMXTime(int64_t pts)
{
    OMX_TICKS ticks;
    ticks.nLowPart = pts;
    ticks.nHighPart = pts >> 32;
    return ticks;
}
```

Once the tunnels are set up and the clock is running, the program reads and demuxes frames and then sends them to the decoder. The complete program is il ffmpeg demux render video.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <vcos logging.h>
#define VCOS LOG CATEGORY (&il ffmpeg log category)
static VCOS LOG CAT T il ffmpeg log category;
#include <ilclient.h>
#include "libavcodec/avcodec.h"
#include <libavformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#define INBUF SIZE 4096
#define AUDIO INBUF SIZE 20480
#define AUDIO REFILL THRESH 4096
char *IMG = "taichi.mp4";
```

```
static AVCodecContext *video_dec_ctx = NULL;
static AVStream *video stream = NULL;
static AVPacket pkt;
AVFormatContext *pFormatCtx = NULL;
static int video stream idx = -1;
uint8 t extradatasize;
void *extradata;
AVCodec *codec;
void printState(OMX_HANDLETYPE handle) {
    // elided
char *err2str(int err) {
   return "error elided";
void printClockState(COMPONENT T *clockComponent) {
    OMX ERRORTYPE err = OMX ErrorNone;
    OMX TIME CONFIG CLOCKSTATETYPE clockState;
    memset(&clockState, 0, sizeof( OMX_TIME_CONFIG_CLOCKSTATETYPE));
    clockState.nSize = sizeof( OMX TIME CONFIG CLOCKSTATETYPE);
    clockState.nVersion.nVersion = OMX VERSION;
    err = OMX_GetConfig(ilclient_get_handle(clockComponent),
                        OMX IndexConfigTimeClockState, &clockState);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error getting clock state %s\n", err2str(err));
        return;
    switch (clockState.eState) {
    case OMX TIME ClockStateRunning:
        printf("Clock running\n");
        break;
    case OMX TIME ClockStateWaitingForStartTime:
        printf("Clock waiting for start time\n");
        break;
    case OMX TIME ClockStateStopped:
        printf("Clock stopped\n");
        break:
    default:
        printf("Clock in other state\n");
    }
}
```

```
void startClock(COMPONENT T *clockComponent) {
    OMX ERRORTYPE err = OMX ErrorNone;
    OMX TIME CONFIG CLOCKSTATETYPE clockState;
    memset(&clockState, 0, sizeof( OMX TIME CONFIG CLOCKSTATETYPE));
    clockState.nSize = sizeof( OMX TIME CONFIG CLOCKSTATETYPE);
    clockState.nVersion.nVersion = OMX_VERSION;
    err = OMX GetConfig(ilclient get handle(clockComponent),
                        OMX IndexConfigTimeClockState, &clockState);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error getting clock state %s\n", err2str(err));
        return;
    clockState.eState = OMX TIME ClockStateRunning;
    err = OMX_SetConfig(ilclient_get_handle(clockComponent),
                        OMX IndexConfigTimeClockState, &clockState);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error starting clock %s\n", err2str(err));
        return;
    }
}
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    printf("Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    printf("OMX error %s\n", err2str(data));
}
void port settings callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    printf("Got port Settings event\n");
    // exit(0);
}
void empty buffer done callback(void *userdata, COMPONENT T *comp) {
    printf("Got empty buffer done\n");
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
```

```
unsigned int uWidth;
unsigned int uHeight;
unsigned int fpsscale;
unsigned int fpsrate;
unsigned int time base num;
unsigned int time_base_den;
#ifdef OMX SKIP64BIT
OMX_TICKS ToOMXTime(int64_t pts)
    OMX TICKS ticks;
    ticks.nLowPart = pts;
   ticks.nHighPart = pts >> 32;
    return ticks;
}
#else
#define FromOMXTime(x) (x)
#endif
OMX ERRORTYPE copy into buffer and empty(AVPacket *pkt,
                                          COMPONENT T *component,
                                          OMX BUFFERHEADERTYPE *buff header) {
    OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int size = pkt->size;
    uint8 t *content = pkt->data;
    while (size > 0) {
        buff header->nFilledLen = (size > buff_header->nAllocLen-1) ?
            buff header->nAllocLen-1 : size;
        memset(buff header->pBuffer, 0x0, buff header->nAllocLen);
        memcpy(buff_header->pBuffer, content, buff_header->nFilledLen);
        size -= buff header->nFilledLen;
        content += buff header->nFilledLen;
        if (size < buff size) {</pre>
            memcpy((unsigned char *)buff_header->pBuffer,
                   pkt->data, size);
            printf("Buffer not big enough %d %d\n", buff_size, size);
            return -1;
        buff header->nFilledLen = size;
        */
        buff header->nFlags = 0;
        if (size \langle = 0 \rangle
            buff header->nFlags |= OMX BUFFERFLAG ENDOFFRAME;
```

```
printf(" DTS is %s %ld\n", "str", pkt->dts);
        printf(" PTS is %s %ld\n", "str", pkt->pts);
        if (pkt->dts == 0) {
            buff header->nFlags |= OMX BUFFERFLAG STARTTIME;
        } else {
            buff header->nTimeStamp = ToOMXTime((uint64 t)
                                                 (pkt->pts * 1000000/
                                                 time base den));
            printf("Time stamp %d\n",
                                        buff header->nTimeStamp);
        }
        r = OMX EmptyThisBuffer(ilclient get handle(component),
                                buff header);
        if (r != OMX ErrorNone) {
            fprintf(stderr, "Empty buffer error %s\n",
                    err2str(r));
        } else {
            printf("Emptying buffer %p\n", buff header);
        if (size > 0) {
             buff header =
                ilclient get input buffer(component,
                                          130,
                                           1 /* block */);
        }
    return r;
}
int img width, img height;
int SendDecoderConfig(COMPONENT T *component, FILE *out)
{
    OMX ERRORTYPE omx err = OMX ErrorNone;
    /* send decoder config */
    if(extradatasize > 0 && extradata != NULL)
            fwrite(extradata, 1, extradatasize, out);
            OMX BUFFERHEADERTYPE *omx buffer = ilclient get input buffer(component,
                                                                          130,
                                                                          1 /* block */);
            if(omx buffer == NULL)
                    fprintf(stderr, "%s - buffer error 0x%08x", __func__, omx_err);
                    return 0;
                }
```

```
omx buffer->nOffset = 0;
            omx buffer->nFilledLen = extradatasize;
            if(omx buffer->nFilledLen > omx buffer->nAllocLen)
                {
                    fprintf(stderr, "%s - omx buffer->nFilledLen > omx buffer->nAllocLen",
                    func );
                    return 0;
                }
            memset((unsigned char *)omx buffer->pBuffer, 0x0, omx buffer->nAllocLen);
            memcpy((unsigned char *)omx buffer->pBuffer, extradata, omx buffer->nFilledLen);
            omx buffer->nFlags = OMX BUFFERFLAG CODECCONFIG | OMX BUFFERFLAG ENDOFFRAME;
            omx err = OMX EmptyThisBuffer(ilclient get handle(component),
                                           omx buffer);
            if (omx_err != OMX_ErrorNone)
                {
                    fprintf(stderr, "%s - OMX EmptyThisBuffer() failed with result(0x%x)\n",
                    __func__, omx_err);
                   return 0;
                } else {
                printf("Config sent, emptying buffer %d\n", extradatasize);
            }
        }
   return 1;
}
OMX_ERRORTYPE set_video_decoder_input_format(COMPONENT_T *component) {
    int err;
    // set input video format
    printf("Setting video decoder format\n");
    OMX VIDEO PARAM PORTFORMATTYPE videoPortFormat;
    memset(&videoPortFormat, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
   videoPortFormat.nSize = sizeof(OMX VIDEO PARAM PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
   videoPortFormat.nPortIndex = 130;
   err = OMX GetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error getting video decoder format %s\n", err2str(err));
       return err;
   videoPortFormat.nPortIndex = 130;
    videoPortFormat.nIndex = 0;
    videoPortFormat.eCompressionFormat = OMX VIDEO CodingAVC;
    videoPortFormat.eColorFormat = OMX COLOR FormatUnused;
   videoPortFormat.xFramerate = 0;
```

```
#if 1 // doesn't seem to make any difference!!!
    if (fpsscale > 0 && fpsrate > 0) {
        videoPortFormat.xFramerate =
            (long long)(1<<16)*fpsrate / fpsscale;</pre>
    } else {
        videoPortFormat.xFramerate = 25 * (1<<16);</pre>
    printf("FPS num %d den %d\n", fpsrate, fpsscale);
    printf("Set frame rate to %d\n", videoPortFormat.xFramerate);
#endif
    err = OMX SetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error setting video decoder format %s\n", err2str(err));
        return err;
    } else {
        printf("Video decoder format set up ok\n");
    }
    OMX PARAM PORTDEFINITIONTYPE portParam;
    memset(&portParam, 0, sizeof( OMX PARAM PORTDEFINITIONTYPE));
    portParam.nSize = sizeof( OMX PARAM PORTDEFINITIONTYPE);
    portParam.nVersion.nVersion = OMX_VERSION;
    portParam.nPortIndex = 130;
    err = OMX GetParameter(ilclient get handle(component),
                            OMX IndexParamPortDefinition, &portParam);
    if(err != OMX ErrorNone)
            fprintf(stderr, "COMXVideo::Open error OMX_IndexParamPortDefinition omx_
            err(0x%08x)\n", err);
            return err;
        }
    printf("Default framerate %d\n", portParam.format.video.xFramerate);
    portParam.nPortIndex = 130;
    portParam.format.video.nFrameWidth = img width;
    portParam.format.video.nFrameHeight = img_height;
    err = OMX SetParameter(ilclient get handle(component),
                            OMX IndexParamPortDefinition, &portParam);
    if(err != OMX ErrorNone)
        {
            fprintf(stderr, "COMXVideo::Open error OMX_IndexParamPortDefinition omx_
            err(0x%08x)\n", err);
            return err;
    return OMX ErrorNone;
}
```

```
int setup_demuxer(const char *filename) {
    // Register all formats and codecs
   av register all();
    if(avformat_open_input(&pFormatCtx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
       return -1; // Couldn't open file
    // Retrieve stream information
    if (avformat find stream info(pFormatCtx, NULL) < 0) {</pre>
       return -1; // Couldn't find stream information
    printf("Format:\n");
    av_dump_format(pFormatCtx, 0, filename, 0);
    int ret;
    ret = av_find_best_stream(pFormatCtx, AVMEDIA_TYPE_VIDEO, -1, -1, NULL, 0);
    if (ret >= 0) {
       video stream idx = ret;
       video stream = pFormatCtx->streams[video stream idx];
       video dec ctx = video stream->codec;
       img width
                         = video stream->codec->width;
                         = video stream->codec->height;
       img height
       extradata = video_stream->codec->extradata;
extradatasize = video_stream->codec->extradata_size;
fnsscale
       = video stream->time base.num;
       time base den
                              = video stream->time base.den;
       printf("Rate %d scale %d time base %d %d\n",
               video stream->r frame rate.num,
               video_stream->r_frame_rate.den,
               video stream->time base.num,
               video stream->time base.den);
       AVCodec *codec = avcodec find decoder(video stream->codec->codec id);
        if (codec) {
            printf("Codec name %s\n", codec->name);
    }
   return 0;
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT_T **decodeComponent) {
    int err;
```

```
err = ilclient_create_component(handle,
                                     decodeComponent,
                                     decodeComponentName,
                                     ILCLIENT_DISABLE_ALL_PORTS
                                     ILCLIENT ENABLE INPUT BUFFERS
                                     ILCLIENT ENABLE OUTPUT BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
    printState(ilclient get handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set video decoder input format(*decodeComponent);
}
void setup_renderComponent(ILCLIENT_T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient create component(handle,
                                     renderComponent,
                                     renderComponentName,
                                     ILCLIENT DISABLE ALL PORTS
                                     ILCLIENT_ENABLE_INPUT_BUFFERS
                                     );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
```

```
void setup_schedulerComponent(ILCLIENT_T *handle,
                              char *schedulerComponentName,
                              COMPONENT T **schedulerComponent) {
    int err;
    err = ilclient create component(handle,
                                    schedulerComponent,
                                    schedulerComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
    if (err == -1) {
        fprintf(stderr, "SchedulerComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*schedulerComponent));
    err = ilclient_change_component_state(*schedulerComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient_get_handle(*schedulerComponent));
}
void setup_clockComponent(ILCLIENT_T *handle,
                          char *clockComponentName,
                          COMPONENT T **clockComponent) {
    int err;
    err = ilclient create component(handle,
                                    clockComponent,
                                    clockComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    );
    if (err == -1) {
        fprintf(stderr, "ClockComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*clockComponent));
    err = ilclient change component state(*clockComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    }
```

```
printState(ilclient_get_handle(*clockComponent));
    printClockState(*clockComponent);
    OMX_COMPONENTTYPE*clock = ilclient_get_handle(*clockComponent);
    OMX TIME CONFIG ACTIVEREFCLOCKTYPE refClock;
    refClock.nSize = sizeof(OMX_TIME_CONFIG_ACTIVEREFCLOCKTYPE);
    refClock.nVersion.nVersion = OMX VERSION;
    refClock.eClock = OMX_TIME_RefClockVideo; // OMX CLOCKPORTO;
   err = OMX SetConfig(ilclient get handle(*clockComponent),
                        OMX IndexConfigTimeActiveRefClock, &refClock);
    if(err != OMX_ErrorNone) {
        fprintf(stderr, "COMXCoreComponent::SetConfig - %s failed with omx_err(0x%x)\n",
                "clock", err);
    }
    OMX TIME CONFIG SCALETYPE scaleType;
    scaleType.nSize = sizeof(OMX TIME CONFIG SCALETYPE);
    scaleType.nVersion.nVersion = OMX VERSION;
    scaleType.xScale = 0x00010000;
   err = OMX SetConfig(ilclient get handle(*clockComponent),
                        OMX IndexConfigTimeScale, &scaleType);
    if(err != OMX_ErrorNone) {
        fprintf(stderr, "COMXCoreComponent::SetConfig - %s failed with omx err(0x%x)\n",
                "clock", err);
    }
}
int main(int argc, char** argv) {
    char *decodeComponentName;
    char *renderComponentName;
    char *schedulerComponentName;
    char *clockComponentName;
    int err;
    ILCLIENT T *handle;
   COMPONENT T *decodeComponent;
    COMPONENT T *renderComponent;
    COMPONENT T *schedulerComponent;
   COMPONENT T *clockComponent;
    if (argc > 1) {
        IMG = argv[1];
    }
    OMX BUFFERHEADERTYPE *buff header;
    setup demuxer(IMG);
```

```
decodeComponentName = "video_decode";
renderComponentName = "video render";
schedulerComponentName = "video scheduler";
clockComponentName = "clock";
bcm host init();
handle = ilclient init();
vcos log set level(VCOS LOG CATEGORY, VCOS LOG TRACE);
if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
}
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
}
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient set eos callback(handle,
                          eos callback,
                          NULL);
ilclient set port settings callback(handle,
                                    port settings callback,
                                    NULL);
ilclient set empty_buffer_done_callback(handle,
                                        empty buffer done callback,
                                        NULL);
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
setup schedulerComponent(handle, schedulerComponentName, &schedulerComponent);
setup clockComponent(handle, clockComponentName, &clockComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
err = ilclient enable_port_buffers(decodeComponent, 130,
                                   NULL, NULL, NULL);
if (err < 0) {
    fprintf(stderr, "Couldn't enable buffers\n");
    exit(1);
ilclient enable port(decodeComponent, 130);
err = ilclient_change_component_state(decodeComponent,
                                      OMX StateExecuting);
```

```
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
   exit(1);
printState(ilclient get handle(decodeComponent));
FILE *out = fopen("tmp.h264", "wb");
SendDecoderConfig(decodeComponent, out);
/* read frames from the file */
while (av read frame(pFormatCtx, &pkt) >= 0) {
   printf("Read pkt %d\n", pkt.size);
   AVPacket orig pkt = pkt;
    if (pkt.stream index == video stream idx) {
        printf(" read video pkt %d\n", pkt.size);
        fwrite(pkt.data, 1, pkt.size, out);
        buff header =
            ilclient get input buffer(decodeComponent,
                                      130,
                                      1 /* block */);
        if (buff header != NULL) {
            copy into buffer and empty(&pkt,
                                       decodeComponent,
                                       buff_header);
        } else {
            fprintf(stderr, "Couldn't get a buffer\n");
        err = ilclient wait for event(decodeComponent,
                                      OMX EventPortSettingsChanged,
                                      131, 0, 0, 1,
                                      ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                      0);
        if (err < 0) {
            printf("No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            // exit(0);
            break;
        }
        if (ilclient remove event(decodeComponent,
                                  OMX EventPortSettingsChanged,
                                  131, 0, 0, 1) == 0) {
            printf("Removed port settings event\n");
            //exit(0);
            break;
        } else {
```

```
printf("No portr settting seen yet\n");
        }
    }
    av_free_packet(&orig_pkt);
}
TUNNEL T decodeTunnel;
set tunnel(&decodeTunnel, decodeComponent, 131, schedulerComponent, 10);
if ((err = ilclient setup tunnel(&decodeTunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up decode tunnel %X\n", err);
    exit(1);
} else {
    printf("Decode tunnel set up ok\n");
TUNNEL T schedulerTunnel;
set tunnel(&schedulerTunnel, schedulerComponent, 11, renderComponent, 90);
if ((err = ilclient setup tunnel(&schedulerTunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up scheduler tunnel %X\n", err);
    exit(1);
} else {
    printf("Scheduler tunnel set up ok\n");
TUNNEL T clockTunnel;
set tunnel(&clockTunnel, clockComponent, 80, schedulerComponent, 12);
if ((err = ilclient setup tunnel(&clockTunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up clock tunnel %X\n", err);
    exit(1);
} else {
    printf("Clock tunnel set up ok\n");
startClock(clockComponent);
printClockState(clockComponent);
// Okay to go back to processing data
// enable the decode output ports
OMX_SendCommand(ilclient_get_handle(decodeComponent),
                OMX CommandPortEnable, 131, NULL);
ilclient enable port(decodeComponent, 131);
// enable the clock output ports
OMX SendCommand(ilclient get handle(clockComponent),
                OMX CommandPortEnable, 80, NULL);
ilclient enable port(clockComponent, 80);
// enable the scheduler ports
OMX SendCommand(ilclient get handle(schedulerComponent),
                OMX CommandPortEnable, 10, NULL);
```


```
ilclient_enable_port(schedulerComponent, 10);
OMX SendCommand(ilclient get handle(schedulerComponent),
                OMX_CommandPortEnable, 11, NULL);
ilclient enable port(schedulerComponent, 11);
OMX SendCommand(ilclient get handle(schedulerComponent),
                OMX CommandPortEnable, 12, NULL);
ilclient enable port(schedulerComponent, 12);
// enable the render input ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX_CommandPortEnable, 90, NULL);
ilclient enable port(renderComponent, 90);
// set both components to executing state
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
err = ilclient change component state(renderComponent,
                                      OMX_StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
}
err = ilclient_change_component_state(schedulerComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
}
err = ilclient change component state(clockComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
}
// now work through the file
while (av_read_frame(pFormatCtx, &pkt) >= 0) {
    printf("Read pkt after port settings %d\n", pkt.size);
    fwrite(pkt.data, 1, pkt.size, out);
```

```
if (pkt.stream_index != video_stream_idx) {
            continue;
        }
        printf(" is video pkt\n");
        //printf(" Best timestamp is %d\n", );
        // do we have a decode input buffer we can fill and empty?
        buff header =
            ilclient get input buffer(decodeComponent,
                                       1 /* block */):
        if (buff header != NULL) {
            copy_into_buffer_and_empty(&pkt,
                                       decodeComponent,
                                       buff header);
        }
        err = ilclient wait for event(decodeComponent,
                                       OMX EventPortSettingsChanged,
                                       131, 0, 0, 1,
                                       ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
        if (err >= 0) {
            printf("Another port settings change\n");
        }
    }
    ilclient wait for event(renderComponent,
                            OMX EventBufferFlag,
                            90, 0, OMX BUFFERFLAG EOS, 0,
                            ILCLIENT BUFFER FLAG EOS, 10000);
   printf("EOS on render\n");
   exit(0);
}
```

Rendering Both Audio and Video

The code is getting long and messy. I've done some cleanup to bring in some macros and other functions to simplify creating and manipulating OMX components. I've also collapsed the two while loops into one, checking—usually redundantly—the port setting's changed event. This simplifies the code and doesn't cost much.

You now have both the audio and video decode/render streams. You can picture this as follows:



The audio stream does the following:

- Decodes in software using avcodec_decode_audio4
- Resamples this to get it into the right format with avresample convert
- Sends it to the OMX audio render component

The video stream does the following:

- Decodes packets using the OMX video decoder component
- Schedules them using the OMX scheduler
- Passes packets to the OMX renderer

You also have an OMX clock. People are apparently much more sensitive to aberrations in audio than in video, so all recommendations are to set the clock to the audio stream rather than to the video stream.

- You should set the clock to the audio clock (probably the audio renderer).
- You should set the scheduler to the clock.

Use the Audio Decoder?

The RPi can apparently decode some audio formats, such as AC3 and DTS. It doesn't need to use software decoding for these. So, it can use the OMX audio decoder for some formats. The omxplayer includes the audio decoder in the audio pipeline, even for PCM data.

The audio decoder can't actually deal with PCM data, which is what will come out of the LibAV decoder. It can manage WAV data, which has the additional header information of sample size, and so on. So, if the OMX audio decoder is inserted into the pipeline, additional code must first send the appropriate WAV header information to the OMX decoder before sending the PCM data.

```
// from omxplayer linux/PlatformDefs.h
// header for PCM audio data
typedef unsigned short WORD;
typedef unsigned int DWORD;
typedef struct tWAVEFORMATEX {
    WORD format_tag;
    WORD channels;
    DWORD samples_per_sec;
    DWORD avg_bytes_per_sec;
    WORD block_align;
```

```
WORD
           bits_per_sample;
           cb size;
   WORD
} attribute (( packed )) WAVEFORMATEX, *PWAVEFORMATEX;
int send audio decoder config(COMPONENT T *component, FILE *out)
   WAVEFORMATEX wave header =
       {.format tag = 0x0001, //WAVE FORMAT PCM
         .channels = channels,
        .samples_per_sec = sample rate,
         .avg bytes per sec = 0,
         .block align = block align,
         .bits_per_sample = bits_per_sample,
         .cb size = 0};
   OMX ERRORTYPE omx err = OMX ErrorNone;
   OMX BUFFERHEADERTYPE *omx buffer = ilclient get input buffer(component,
                                                                1 /* block */):
   if(omx buffer == NULL) {
           fprintf(stderr, "%s - buffer error 0x%08x", func , omx err);
           return 0;
   }
   omx buffer->nOffset = 0;
   omx buffer->nFilledLen = sizeof(wave header);
   if(omx buffer->nFilledLen > omx buffer->nAllocLen) {
           fprintf(stderr, "%s - omx buffer->nFilledLen > omx buffer->nAllocLen",
            __func__);
           return 0;
   }
   memset((unsigned char *)omx buffer->pBuffer, 0x0,
          omx buffer->nAllocLen);
   memcpy((unsigned char *)omx_buffer->pBuffer, &wave_header,
          sizeof(wave header));
   omx buffer->nFlags = OMX BUFFERFLAG CODECCONFIG | OMX BUFFERFLAG ENDOFFRAME;
   omx err = OMX EmptyThisBuffer(ilclient get handle(component),
                                  omx buffer);
   exit_on_omx_error(omx_err, "Error setting up audio config %s\n");
   return 1;
}
```

In the program that follows, a switch called AUDIO_DECODE is used to toggle whether the audio decode component is inserted into the audio pipeline. I've done that in case you want to use the code specifically in one or the other modes. The program is il ffmpeg demux render audio video.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <vcos logging.h>
//#define VCOS LOG CATEGORY (&il ffmpeg log category)
// VCOS LOG CAT_T il_ffmpeg_log_category;
#include <ilclient.h>
// #include <sys/time.h>
#include "libavcodec/avcodec.h"
#include <libavformat/avformat.h>
#include "libavutil/mathematics.h"
#include "libavutil/samplefmt.h"
#include "libavutil/opt.h"
#include "libavresample/avresample.h"
#define USECS IN SEC 1000000
// from omxplayer OMXCore.h
// initialise any OMX struct
#define OMX INIT STRUCTURE(a) \
 memset(&(a), 0, sizeof(a)); \
  (a).nSize = sizeof(a); \
  (a).nVersion.s.nVersionMajor = OMX VERSION MAJOR; \
  (a).nVersion.s.nVersionMinor = OMX VERSION MINOR; \
  (a).nVersion.s.nRevision = OMX VERSION REVISION; \
  (a).nVersion.s.nStep = OMX VERSION STEP
// from omxplayer linux/PlatformDefs.h
// header for PCM audio data
typedef unsigned short WORD;
typedef unsigned int DWORD;
typedef struct tWAVEFORMATEX {
           format_tag;
   WORD
           channels;
   WORD
   DWORD samples_per_sec;
   DWORD
           avg bytes per sec;
   WORD
           block_align;
   WORD
           bits per sample;
   WORD
           cb size;
} __attribute__((__packed__)) WAVEFORMATEX, *PWAVEFORMATEX;
```

```
//#define VCOS LOG CATEGORY (&il ffmpeg log category)
// VCOS LOG CAT T il ffmpeg log category;
// struct timeval tv;
// time t starttime = 0;
// default file to play
char *fname = "taichi.mp4";
// libav/ffmpeg vbls
AVCodecContext *video_dec_ctx = NULL;
AVStream *video stream = NULL;
AVPacket pkt;
AVFormatContext *format ctx = NULL;
AVCodecContext *audio dec ctx;
AVAudioResampleContext *swr;
AVCodec *codec;
 int video stream idx = -1;
int audio stream idx;
// data passed from video demux to video decoder
uint8 t extradatasize;
void *extradata;
// use the OMX audio decoder?
#define AUDIO DECODE 1
// OMX/IL vbls
ILCLIENT T *handle;
COMPONENT T *video decode component;
COMPONENT T *video render component;
COMPONENT T *audio render component;
COMPONENT T *scheduler_component;
COMPONENT_T *clock_component;
#if AUDIO DECODE
COMPONENT_T *audio_decode_component;
#endif
char *video decode component name = "video decode";
char *video_render_component_name = "video render";
char *audio render component name = "audio render";
char *scheduler component name = "video scheduler";
char *clock component name = "clock";
#if AUDIO DECODE
// OMX/IL vbls
ILCLIENT T *handle;
COMPONENT_T *video decode component;
COMPONENT T *video render component;
COMPONENT T *audio render component;
```

```
COMPONENT_T *scheduler_component;
COMPONENT T *clock component;
#if AUDIO DECODE
COMPONENT_T *audio_decode_component;
#endif
char *video_decode_component_name = "video_decode";
char *video render component name = "video render";
char *audio render component name = "audio render";
char *scheduler_component_name = "video_scheduler";
char *clock component name = "clock";
#if AUDIO DECODE
char *audio decode component name = "audio decode";
#endif
// audio parameters
int sample rate;
int channels;
int block align;
int bits per sample;
// video parameters
int img width, img height;
unsigned int fpsscale;
unsigned int fpsrate;
unsigned int vtime base num;
unsigned int vtime base den;
unsigned int atime base num;
unsigned int atime base den;
#ifdef OMX SKIP64BIT
OMX TICKS ToOMXTime(int64 t pts)
{
    OMX_TICKS ticks;
    ticks.nLowPart = pts;
    ticks.nHighPart = pts >> 32;
    return ticks;
}
#else
#define FromOMXTime(x) (x)
#endif
int64_t convert_timestamp(int64_t pts, int den, int num) {
    return pts;
}
void exit on il error(int err, char *err str) {
    if (err < 0) {
        fprintf(stderr, err_str);
        exit(1);
    }
}
```

```
void print_state(OMX_HANDLETYPE handle) {
    // elided
char *err2str(int err) {
   return "error elided";
void exit on omx error(int err, char *err str) {
    if (err != OMX_ErrorNone) {
       fprintf(stderr, err_str, err2str(err));
       exit(1);
    }
}
void print_clock_state(COMPONENT_T *clock_component) {
   OMX ERRORTYPE err = OMX ErrorNone;
   OMX_TIME_CONFIG_CLOCKSTATETYPE clock_state;
   OMX INIT STRUCTURE(clock state);
    err = OMX GetConfig(ilclient get handle(clock component),
                        OMX IndexConfigTimeClockState, &clock state);
    exit on omx error(err, "Error getting clock state %s\n");
    switch (clock state.eState) {
   case OMX TIME ClockStateRunning:
       printf("Clock running\n");
       break;
   case OMX TIME ClockStateWaitingForStartTime:
        printf("Clock waiting for start time\n");
       break;
    case OMX TIME ClockStateStopped:
        printf("Clock stopped\n");
       break:
    default:
       printf("Clock in other state\n");
}
void start_clock(COMPONENT_T *clock component) {
    OMX ERRORTYPE err = OMX ErrorNone;
   OMX_TIME_CONFIG_CLOCKSTATETYPE clock_state;
   OMX INIT STRUCTURE(clock state);
    err = OMX GetConfig(ilclient get handle(clock component),
                        OMX IndexConfigTimeClockState, &clock state);
    exit_on_omx_error(err, "Error getting clock state %s\n");
```

```
clock_state.eState = OMX_TIME_ClockStateRunning;
    err = OMX SetConfig(ilclient get handle(clock component),
                        OMX IndexConfigTimeClockState, &clock state);
    exit_on_omx_error(err, "Error starting clock %s\n");
}
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    printf("Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    printf("OMX error %s\n", err2str(data));
}
void port settings callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got port settings event\n");
}
void empty_buffer_done_callback(void *userdata, COMPONENT_T *comp) {
    // printf("Got empty buffer done\n");
void setup callbacks() {
    ilclient set error callback(handle,
                                error_callback,
                                NULL);
    ilclient set eos callback(handle,
                              eos callback,
                              NULL);
    ilclient set port settings callback(handle,
                                         port settings callback,
                                        NULL);
    ilclient set empty buffer done callback(handle,
                                            empty_buffer_done_callback,
                                            NULL);
}
void print clock time(char *s) {
    OMX TIME CONFIG TIMESTAMPTYPE stamp;
    OMX INIT STRUCTURE(stamp);
    stamp.nPortIndex = 81;
    OMX GetParameter(ilclient get handle(clock component),
                     OMX IndexConfigTimeCurrentMediaTime,
                     //OMX IndexConfigTimeCurrentAudioReference,
                     &stamp);
    //printf("%s %u%u\n", s, stamp.nTimestamp.nHighPart,
           stamp.nTimestamp.nLowPart);
}
```

```
OMX ERRORTYPE copy video into buffer and empty(AVPacket *pkt,
                                                COMPONENT T *component) {
    OMX ERRORTYPE r;
    OMX_BUFFERHEADERTYPE *buff_header = NULL;
    //int buff size = buff_header->nAllocLen;
    int size = pkt->size;
    uint8 t *content = pkt->data;
    while (size > 0) {
        buff header =
            ilclient get input buffer(component,
                                       130,
                                       1 /* block */);
        buff header->nFilledLen = (size > buff header->nAllocLen-1) ?
            buff header->nAllocLen-1 : size;
        memset(buff header->pBuffer, 0x0, buff header->nAllocLen);
        memcpy(buff header->pBuffer, content, buff header->nFilledLen);
        size -= buff header->nFilledLen;
        content += buff header->nFilledLen;
        buff header->nFlags = 0;
        if (size \langle = 0 \rangle
            buff header->nFlags |= OMX BUFFERFLAG ENDOFFRAME;
        if (pkt->dts == 0) {
            buff header->nFlags |= OMX_BUFFERFLAG_STARTTIME;
            buff header->nTimeStamp = ToOMXTime((uint64 t)
                                                 (pkt->pts * USECS IN SEC *
                                                  vtime base num /
                                                  vtime base den));
            // printf("Video timestamp %u\n", buff_header->nTimeStamp.nLowPart);
        }
        r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                buff header);
        exit_on_omx_error(r, "Empty buffer error %s\n");
    }
    return r;
}
OMX ERRORTYPE read audio into buffer and empty(AVFrame *decoded frame,
                                                COMPONENT T *component,
                                                // OMX BUFFERHEADERTYPE *buff header,
                                                int total len) {
    OMX ERRORTYPE r;
    OMX_BUFFERHEADERTYPE *buff_header = NULL;
```

```
#if AUDIO_DECODE
    int port index = 120;
#else
    int port_index = 100;
#endif
    int required_decoded_size = 0;
    int out linesize;
    required_decoded_size =
        av samples get buffer size(&out linesize, 2,
                                    decoded frame->nb samples,
                                   AV SAMPLE FMT S16, 0);
    uint8 t *buffer, *start buffer;
    av samples alloc(&buffer, &out linesize, 2, decoded frame->nb samples,
                     AV_SAMPLE_FMT_S16, 0);
    start buffer = buffer;
    avresample_convert(swr, &buffer,
                       decoded frame->linesize[0],
                       decoded frame->nb samples,
                       decoded frame->data,
                       decoded frame->linesize[0],
                       decoded frame->nb samples);
    while (required_decoded_size > 0) {
        buff header =
            ilclient get input buffer(component,
                                       port_index,
                                       1 /* block */);
        buff header->nTimeStamp = ToOMXTime((uint64 t)
                                             (decoded frame->pkt pts * USECS IN SEC *
                                              atime base num /
                                              atime_base_den));
        int len = buff header->nAllocLen;
        if (required decoded size > len) {
            memcpy(buff header->pBuffer,
                   buffer, len);
            buff_header->nFilledLen = len;
            buffer += len;
        } else {
            memcpy(buff header->pBuffer,
                   buffer, required decoded size);
            buff_header->nFilledLen = required_decoded_size;
        r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                buff header);
        exit on omx error(r, "Empty buffer error %s\n");
```

```
required decoded size -= len;
    }
   av free(&start_buffer[0]);
   return r;
}
int send_video_decoder_config(COMPONENT_T *component)
{
   OMX ERRORTYPE omx err = OMX ErrorNone;
    /* send decoder config */
    if(extradatasize > 0 && extradata != NULL) {
       OMX BUFFERHEADERTYPE *omx buffer =
            ilclient_get_input_buffer(component,
                                      130,
                                      1 /* block */);
        if(omx buffer == NULL) {
            fprintf(stderr, "%s - buffer error 0x%08x", __func__, omx_err);
            return 0;
        }
       omx buffer->nOffset = 0;
       omx buffer->nFilledLen = extradatasize;
        if(omx_buffer->nFilledLen > omx_buffer->nAllocLen) {
            fprintf(stderr, "%s - omx buffer->nFilledLen > omx buffer->nAllocLen",
            func );
            return 0;
        }
       memset((unsigned char *)omx_buffer->pBuffer, 0x0,
               omx buffer->nAllocLen);
       memcpy((unsigned char *)omx buffer->pBuffer, extradata,
               omx buffer->nFilledLen);
       omx_buffer->nFlags = OMX_BUFFERFLAG_CODECCONFIG | OMX BUFFERFLAG ENDOFFRAME;
       omx_err = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                                       omx buffer);
       exit on omx error(omx err, "Setting up video config failed %s\n");
   return 1;
}
int send audio decoder config(COMPONENT T *component, FILE *out)
   WAVEFORMATEX wave header =
        {.format tag = 0x0001, //WAVE FORMAT PCM, // 32768,
         .channels = channels, .samples_per_sec = sample_rate,
         .avg bytes per sec = 0, .block align = block align,
         .bits per sample = bits per sample,
         .cb_size = 0};
```

```
OMX ERRORTYPE omx err = OMX ErrorNone;
    OMX BUFFERHEADERTYPE *omx buffer = ilclient get input buffer(component,
                                                                 1 /* block */);
    if(omx_buffer == NULL) {
            fprintf(stderr, "%s - buffer error 0x%08x", func , omx err);
            return 0;
    }
    omx buffer->nOffset = 0;
    omx_buffer->nFilledLen = sizeof(wave_header);
    if(omx buffer->nFilledLen > omx buffer->nAllocLen) {
            fprintf(stderr, "%s - omx buffer->nFilledLen > omx buffer->nAllocLen",
            func );
            return 0;
    }
    memset((unsigned char *)omx buffer->pBuffer, 0x0,
           omx buffer->nAllocLen);
    memcpy((unsigned char *)omx buffer->pBuffer, &wave header,
           sizeof(wave header));
    omx buffer->nFlags = OMX BUFFERFLAG CODECCONFIG | OMX BUFFERFLAG ENDOFFRAME;
    omx err = OMX EmptyThisBuffer(ilclient get handle(component),
                                   omx buffer);
    exit_on_omx_error(omx_err, "Error setting up audio config %s\n");
    return 1;
}
OMX ERRORTYPE set video decoder input format(COMPONENT T *component) {
    int err;
    // printf("Setting video decoder format\n");
    OMX_VIDEO_PARAM_PORTFORMATTYPE video_port_format;
    OMX INIT STRUCTURE(video port format);
    video_port_format.nPortIndex = 130;
    err = OMX GetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &video port format);
    exit on omx error(err, "Error getting video decoder format %s\n");
    video_port_format.nPortIndex = 130;
    video port format.nIndex = 0;
    video port format.eCompressionFormat = OMX VIDEO CodingAVC;
    video_port_format.eColorFormat = OMX_COLOR_FormatUnused;
    video port format.xFramerate = 0;
```

```
#if 1 // doesn't seem to make any difference!!!
    if (fpsscale > 0 && fpsrate > 0) {
        video port format.xFramerate =
            (long long)(1<<16)*fpsrate / fpsscale;</pre>
    } else {
        video port format.xFramerate = 25 * (1<<16);</pre>
#endif
   err = OMX SetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &video port format);
   exit on omx error(err, "Error setting video decoder format %s\n");
    OMX_PARAM_PORTDEFINITIONTYPE port param;
    OMX INIT STRUCTURE(port param);
    port param.nPortIndex = 130;
   err = OMX GetParameter(ilclient get handle(component),
                            OMX IndexParamPortDefinition, &port param);
    exit_on_omx_error(err, "Error getting video parameters %s\n");
    port param.nPortIndex = 130;
    port param.format.video.nFrameWidth = img width;
   port param.format.video.nFrameHeight = img height;
   err = OMX_SetParameter(ilclient_get_handle(component),
                            OMX IndexParamPortDefinition, &port param);
    exit on omx error(err, "Error setting video params %s\n");
   return OMX ErrorNone;
}
int setup demuxer(const char *filename) {
    // Register all formats and codecs
    av_register_all();
    if(avformat open input(&format ctx, filename, NULL, NULL)!=0) {
        fprintf(stderr, "Can't get format\n");
        return -1; // Couldn't open file
    // Retrieve stream information
    if (avformat_find_stream_info(format_ctx, NULL) < 0) {</pre>
        return -1; // Couldn't find stream information
    av_dump_format(format_ctx, 0, filename, 0);
    int ret;
    ret = av_find_best_stream(format_ctx, AVMEDIA_TYPE_VIDEO, -1, -1, NULL, 0);
    if (ret >= 0) {
        video stream idx = ret;
        video stream = format ctx->streams[video stream idx];
        video dec ctx = video stream->codec;
```

```
img_width = video_stream->codec->width;
                    = video stream->codec->height;
    img height
    extradata = video_stream->codec->extradata;
extradatasize = video_stream->codec->extradata_size;
                    = video stream->r frame rate.den;
    fpsscale
                 = video stream->r frame rate.num;
    fpsrate
    vtime base num
                           = video stream->time base.num;
                           = video stream->time base.den;
    vtime base den
    AVCodec *codec = avcodec_find_decoder(video_stream->codec->codec_id);
    if (codec) {
        // printf("Codec name %s\n", codec->name);
}
if ((ret = av find best stream(format ctx, AVMEDIA TYPE AUDIO, -1, -1, NULL, 0)) >= 0) {
    //AVCodecContext* codec context;
    AVStream *audio_stream;
    audio stream idx = ret;
    fprintf(stderr, "Audio stream index is %d\n", ret);
    audio stream = format ctx->streams[audio stream idx];
    atime base num
                           = audio stream->time base.num;
    atime base den
                           = audio stream->time base.den;
    audio dec ctx = audio stream->codec;
    sample rate = audio dec ctx->sample rate;
    channels = audio dec ctx->channels;
    block align = audio dec ctx->block align;
    bits_per_sample = audio_dec_ctx->bits_per_coded_sample;
    if (audio dec ctx->channel layout == 0) {
        audio_dec_ctx->channel_layout =
            av_get_default_channel_layout(audio dec ctx->channels);
    }
    AVCodec *codec = avcodec find decoder(audio stream->codec->codec id);
    if (avcodec open2(audio dec ctx, codec, NULL) < 0) {
        fprintf(stderr, "could not open codec\n");
        exit(1);
    if (codec) {
        // printf("Codec name %s\n", codec->name);
    }
}
return 0;
```

```
void setup_video_decode_component(ILCLIENT_T *handle,
                                  char *decode component name,
                                  COMPONENT T **decode component) {
    int err;
    err = ilclient_create_component(handle,
                                    decode component,
                                    decode component name,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT_ENABLE_OUTPUT_BUFFERS
                                    );
    exit on il error(err, "DecodeComponent create failed\n");
    err = ilclient change component state(*decode component,
                                          OMX StateIdle);
    exit on il error(err, "Couldn't change state to Idle\n");
    // must be done before we enable buffers
    set_video_decoder_input_format(*decode_component);
}
void setup_video_render_component(ILCLIENT_T *handle,
                                  char *render component name,
                                  COMPONENT T **render component) {
    int err;
    err = ilclient create component(handle,
                                    render component,
                                    render component name,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    );
    exit_on_il_error(err, "RenderComponent create failed\n");
    err = ilclient_change_component_state(*render_component,
                                          OMX StateIdle);
    exit on il error(err, "Couldn't change state to Idle\n");
}
/* For the RPi name can be "hdmi" or "local" */
void set_output_device(OMX_HANDLETYPE handle, const char *name) {
    OMX ERRORTYPE err;
    OMX CONFIG BRCMAUDIODESTINATIONTYPE arDest;
```

```
if (name && strlen(name) < sizeof(arDest.sName)) {</pre>
        memset(&arDest, 0, sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE));
        arDest.nSize = sizeof(OMX CONFIG BRCMAUDIODESTINATIONTYPE);
        arDest.nVersion.nVersion = OMX VERSION;
        strcpy((char *)arDest.sName, name);
        err = OMX SetParameter(handle, OMX IndexConfigBrcmAudioDestination,
                               &arDest);
        exit_on_omx_error(err, "Error on setting audio destination %s\n");
    }
}
void set pcm mode(OMX HANDLETYPE handle, int startPortNumber) {
    OMX AUDIO PARAM PCMMODETYPE pcm mode;
    OMX_ERRORTYPE err;
    OMX INIT STRUCTURE(pcm mode);
    pcm mode.nPortIndex = startPortNumber;
    err = OMX GetParameter(handle, OMX IndexParamAudioPcm, &pcm mode);
    exit on omx error(err, "Error getting audio params %s\n");
    pcm mode.nSamplingRate = sample rate;
    pcm mode.nChannels = channels;
    pcm mode.nBitPerSample = bits per sample;
    err = OMX_SetParameter(handle, OMX_IndexParamAudioPcm, &pcm_mode);
    exit on omx error(err, "PCM mode unsupported %s\n");
}
 void set audio render input format(COMPONENT T *component) {
    OMX AUDIO PARAM PORTFORMATTYPE audio port format;
    OMX INIT STRUCTURE(audio port format);
#if AUDIO DECODE
    int port index = 120;
#else
    int port_index = 100;
#endif
    audio_port_format.nPortIndex = port_index;
    OMX GetParameter(ilclient get handle(component),
                     OMX_IndexParamAudioPortFormat, &audio_port_format);
    audio_port_format.eEncoding = OMX_AUDIO_CodingPCM;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamAudioPortFormat, &audio port format);
```

```
#if AUDIO_DECODE
#else
    set_pcm_mode(ilclient_get_handle(component), 100);
#endif
}
void setup resample context() {
    swr = avresample alloc context();
    av opt set int(swr, "in channel layout",
                     av_get_default_channel_layout(audio_dec_ctx->channels) , 0);
    av_opt_set_int(swr, "out_channel_layout", AV_CH_LAYOUT_STEREO, 0);
    av_opt_set_int(swr, "in_sample_rate", audio_dec_ctx->sample_rate, 0);
    av_opt_set_int(swr, "out_sample_rate", audio_dec_ctx->sample_rate
av_opt_set_int(swr, "in_sample_fmt", audio_dec_ctx->sample_fmt, 0);
av_opt_set_int(swr, "out_sample_fmt", AV_SAMPLE_FMT_S16, 0);
                                                audio dec ctx->sample rate, 0);
    avresample open(swr);
}
#if AUDIO DECODE
void setup audio components(ILCLIENT T *handle,
                               char *decode component name,
                               COMPONENT_T **decode_component,
                               char *render component name,
                               COMPONENT T **render component) {
    int err;
    err = ilclient create component(handle,
                                        decode component,
                                        decode component name,
                                        ILCLIENT DISABLE ALL PORTS
                                        ILCLIENT ENABLE INPUT BUFFERS
                                        );
    exit_on_il_error(err, "DecodeComponent create failed\n");
    err = ilclient change component state(*decode component,
                                              OMX StateIdle);
    exit on il error(err, "Couldn't change state to Idle\n");
    set_audio_render_input_format(*decode_component);
    err = ilclient create component(handle,
                                        render component,
                                        render component name,
                                        ILCLIENT DISABLE ALL PORTS
                                        ILCLIENT ENABLE INPUT BUFFERS
                                        );
```

```
exit_on_il_error(err, "RenderComponent create failed\n");
    err = ilclient_change_component_state(*render component,
                                          OMX_StateIdle);
    exit on il error(err,
                           "Couldn't change state to Idle\n");
    // "local" or "hdmi"
    set_output_device(ilclient_get_handle(*render component), "local");
#if 0 // omxplayer uses this sometimes
    OMX CONFIG BOOLEANTYPE bool type;
    OMX_INIT_STRUCTURE(bool_type);
    bool type.bEnabled = OMX TRUE;
    OMX_SetParameter(ilclient_get_handle(*decode_component),
                     OMX IndexParamBrcmDecoderPassThrough, &bool type);
#endif
}
#else
void setup audio render component(ILCLIENT T *handle,
                                  char *render component name,
                                  COMPONENT T **render component) {
    int err;
    err = ilclient create component(handle,
                                    render component,
                                    render component_name,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    );
    exit on il error(err, "RenderComponent create failed\n");
    err = ilclient change component state(*render component,
                                          OMX StateIdle);
    exit_on_il_error(err, "Couldn't change state to Idle\n");
    set audio render input format(*render component);
    // "local" is 3.5 mm audio, "hdmi" is ... hdmi
    set_output_device(ilclient_get_handle(*render_component), "local");
}
#endif
void setup scheduler component(ILCLIENT T *handle,
                               char *scheduler component name,
                               COMPONENT_T **scheduler_component) {
    int err;
```

```
err = ilclient create component(handle,
                                    scheduler component,
                                    scheduler component name,
                                    ILCLIENT_DISABLE_ALL_PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
   exit on il error(err, "SchedulerComponent create failed\n");
   err = ilclient change component state(*scheduler component,
                                          OMX StateIdle);
   exit_on_il_error(err, "Couldn't change state to Idle\n");
void setup_clock_component(ILCLIENT_T *handle,
                           char *clock component name,
                           COMPONENT T **clock component) {
    int err;
   err = ilclient_create_component(handle,
                                    clock component,
                                    clock component name,
                                    ILCLIENT DISABLE ALL PORTS
                                    );
   exit on il error(err, "ClockComponent create failed\n");
   err = ilclient change component state(*clock component,
                                          OMX StateIdle);
    exit on il error(err, "Couldn't change state to Idle\n");
   OMX TIME CONFIG ACTIVEREFCLOCKTYPE reference clock;
   OMX INIT STRUCTURE(reference_clock);
   reference clock.eClock = OMX TIME RefClockAudio;
   err = OMX_SetConfig(ilclient_get_handle(*clock_component),
                        OMX IndexConfigTimeActiveRefClock, &reference clock);
   exit on omx error(err, "Set config on clock failed %s\n");
   OMX TIME CONFIG SCALETYPE scale type;
   OMX INIT STRUCTURE(scale type);
    scale type.xScale = 0x00010000;s
   err = OMX SetConfig(ilclient get handle(*clock component),
                        OMX_IndexConfigTimeScale, &scale_type);
   exit_on_omx_error(err, "Set config failed on clock %s\n");
}
```

```
void setup_components() {
    setup_video_decode_component(handle, video decode component name,
                                 &video decode component);
    setup video render component(handle, video render component name,
                                 &video render component);
#if AUDIO DECODE
    setup audio components(handle,
                           audio decode component name,
                           &audio decode component,
                           audio render component name,
                           &audio render component);
#else
    setup_audio_render_component(handle, audio_render_component_name,
                                 &audio render component);
#endif
    setup scheduler component(handle, scheduler component name,
                              &scheduler component);
    setup clock component(handle, clock component name,
                          &clock component);
}
void setup_video_tunnel(COMPONENT_T *decode component,
                        COMPONENT T *render component,
                        COMPONENT T *scheduler component,
                        COMPONENT_T *clock component) {
    int err;
    TUNNEL T decode tunnel;
    set tunnel(&decode tunnel, decode component, 131, scheduler component, 10);
    err = ilclient setup tunnel(&decode tunnel, 0, 0);
    exit_on_il_error(err, "Error setting up decode tunnel\n");
    TUNNEL T scheduler tunnel;
    set tunnel(&scheduler tunnel, scheduler component, 11, render component, 90);
    err = ilclient_setup_tunnel(&scheduler_tunnel, 0, 0);
    exit on il error(err, "Error setting up scheduler tunnel\n");
    TUNNEL T clock tunnel;
    set tunnel(&clock tunnel, clock component, 80, scheduler component, 12);
    err = ilclient setup tunnel(&clock tunnel, 0, 0);
    exit on il error(err, "Error setting up clock tunnel\n");
    start clock(clock component);
    print clock state(clock component);
    // Okay to go back to processing data
    // enable the decode output ports
    OMX SendCommand(ilclient get handle(decode component),
                    OMX_CommandPortEnable, 131, NULL);
    ilclient enable port(decode component, 131);
```

```
// enable the clock output ports
    OMX SendCommand(ilclient get handle(clock component),
                    OMX CommandPortEnable, 80, NULL);
    ilclient_enable_port(clock_component, 80);
    // enable the scheduler ports
    OMX_SendCommand(ilclient_get_handle(scheduler_component),
                    OMX CommandPortEnable, 10, NULL);
    ilclient enable port(scheduler component, 10);
    OMX SendCommand(ilclient get handle(scheduler component),
                    OMX CommandPortEnable, 11, NULL);
    ilclient enable port(scheduler component, 11);
    OMX SendCommand(ilclient get handle(scheduler component),
                    OMX CommandPortEnable, 12, NULL);
    ilclient enable port(scheduler component, 12);
    // enable the render input ports
    OMX SendCommand(ilclient get handle(render component),
                    OMX CommandPortEnable, 90, NULL);
    ilclient enable port(render component, 90);
    // set both components to executing state
    err = ilclient change component state(decode component,
                                          OMX StateExecuting);
    exit on il error(err, "Couldn't change state to Executing\n");
    err = ilclient change component state(render component,
                                          OMX StateExecuting);
    exit on il error(err, "Couldn't change state to Executing\n");
    err = ilclient change component state(scheduler component,
                                          OMX StateExecuting);
    exit_on_il_error(err, "Couldn't change state to Executing\n");
    err = ilclient change component state(clock component,
                                          OMX StateExecuting);
    exit on il error(err, "Couldn't change state to Executing\n");
}
void setup audio tunnel(COMPONENT T *audio decode component,
                        COMPONENT_T *audio render component.
                        COMPONENT T *scheduler component,
                        COMPONENT T *clock component) {
    int err;
```

```
// for debugging
    OMX AUDIO PARAM PORTFORMATTYPE audio port format;
    OMX INIT STRUCTURE(audio_port_format);
#if AUDIO DECODE
    int port index = 121;
#else
    int port index = 100;
#endif
    audio port format.nPortIndex = port index;
    OMX GetParameter(ilclient get handle(audio decode component),
                     OMX IndexParamAudioPortFormat, &audio port format);
    OMX AUDIO PARAM PCMMODETYPE pcm mode;
    OMX INIT STRUCTURE(pcm mode);
    pcm mode.nPortIndex = port index;
    OMX GetParameter(ilclient get handle(audio decode component),
                     OMX IndexParamAudioPcm, &pcm mode);
    printf("Sampling rate %d, channels %d\n",
           pcm mode.nSamplingRate,
           pcm mode.nChannels);
    // end debugging
    TUNNEL T audio decode tunnel;
    set tunnel(&audio decode tunnel, audio decode component, 121,
               audio render component, 100);
    err = ilclient setup tunnel(&audio decode tunnel, 0, 0);
    exit_on_il_error(err, "Error setting up decode tunnel\n");
    TUNNEL T clock tunnel;
    set tunnel(&clock tunnel, clock component, 81, audio render component, 101);
    err = ilclient_setup_tunnel(&clock_tunnel, 0, 0);
    exit on il error(err, "Error setting up clock tunnel\n");
    OMX_SendCommand(ilclient_get_handle(audio_decode_component),
                    OMX CommandPortEnable, 121, NULL);
    ilclient enable port(audio decode component, 121);
    err = ilclient change component state(audio render component,
                                          OMX StateExecuting);
    exit on il error(err, "Couldn't change state to Executing\n");
}
void handle_video_packet(AVPacket *pkt) {
    int err;
    pkt->dts = convert_timestamp(pkt->dts, vtime_base_num, vtime_base_den);
    pkt->pts = convert timestamp(pkt->pts, vtime base num, vtime base den);
```

```
copy video into buffer and empty(pkt,
                                     video decode component //,
                                     //buff header
                                     );
   err = ilclient_wait_for_event(video_decode_component,
                                  OMX EventPortSettingsChanged,
                                  131, 0, 0, 1,
                                  ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                  0 /* no block */);
    if (err < 0) {
        //printf("No port settings change\n");
        printf("Video port settings changed\n");
        setup_video_tunnel(video_decode component,
                           video render component,
                           scheduler component,
                           clock component);
   }
}
void handle audio packet(AVPacket *pkt) {
    int err;
    int got frame = 0;
    int len;
   AVFrame *decoded_frame = NULL;
    if (!decoded frame) {
        if (!(decoded_frame = avcodec_alloc_frame())) {
            fprintf(stderr, "out of memory\n");
            exit(1);
        }
    }
    pkt->dts = convert_timestamp(pkt->dts, atime_base_num, atime_base_den);
   pkt->pts = convert timestamp(pkt->pts, atime base num, atime base den);
    len = avcodec_decode_audio4(audio_dec_ctx,
                                decoded frame, &got frame, pkt);
    if (len < 0) {
        fprintf(stderr, "Error while decoding\n");
        exit(1);
    if (got_frame) {
        /* if a frame has been decoded, we want to send it to OpenMAX */
        int data size =
            av_samples_get_buffer_size(NULL, audio_dec_ctx->channels,
                                       decoded frame->nb samples,
                                       audio dec ctx->sample fmt, 1);
        // Empty into decode/render audio input buffers
```

```
#if AUDIO DECODE
        read_audio_into_buffer_and_empty(decoded_frame,
                                          audio decode component,
                                          data_size
#else
        read_audio_into_buffer_and_empty(decoded_frame,
                                          audio render component,
                                          data size
                                          );
#endif
#if AUDIO_DECODE
    err = ilclient wait for event(audio decode component,
                                  OMX EventPortSettingsChanged,
                                  121, 0, 0, 1,
                                  ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                  0 /* no block */);
    if (err < 0) {
        //printf("No port settings change\n");
    } else {
        printf("Audio port settings changed\n");
        setup audio tunnel(audio decode component,
                           audio render component,
                           scheduler_component,
                           clock component);
#endif
}
int main(int argc, char** argv) {
    int err;
    // override default file
    if (argc > 1) {
        fname = argv[1];
    }
    setup demuxer(fname);
    bcm host init();
    // vcos log set level(VCOS LOG CATEGORY, VCOS LOG TRACE);
    handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
```

```
if (OMX_Init() != OMX_ErrorNone) {
        ilclient destroy(handle);
       fprintf(stderr, "OMX init failed\n");
       exit(1);
    }
    setup callbacks();
    setup components();
    setup resample context();
    start clock(clock component);
    print clock state(clock component);
    // both components now in Idle state, no buffers, ports disabled
    // video input port
    err = ilclient enable port buffers(video decode component, 130,
                                       NULL, NULL, NULL);
    exit on il error(err, "Couldn't enable buffers\n");
    ilclient enable port(video decode component, 130);
    err = ilclient change component state(video decode component,
                                          OMX StateExecuting);
    exit_on_il_error(err, "Couldn't change state to Executing\n");
    // audio render
#if AUDIO DECODE
    ilclient enable port buffers(audio decode component, 120,
                                 NULL, NULL, NULL);
    ilclient enable port(audio decode component, 120);
    err = ilclient change component state(audio decode component,
                                          OMX StateExecuting);
    send audio decoder config(audio decode component, NULL);
#else
    ilclient_enable_port_buffers(audio_render_component, 100,
                                 NULL, NULL, NULL);
    ilclient enable port(audio render component, 100);
   err = ilclient change component_state(audio_render_component,
                                          OMX StateExecuting);
#endif
   exit on il error(err, "Couldn't change state to Executing\n");
    send_video_decoder_config(video_decode_component);
    /* read frames from the file */
   while (av read_frame(format_ctx, &pkt) >= 0) {
       AVPacket orig pkt = pkt;
```

Conclusion

This chapter looked at playing files containing both audio and video streams. You have considered only a limited number of formats: MP4 files containing H.264 video and AAC audio. The player omxplayer deals with far more cases and hence has increased complexity. Nevertheless, the concepts discussed and demonstrated here are applicable in those cases too.

Resources

- Proposal for OMX.broadcom.read_media: www.raspberrypi.org/forums/ viewtopic.php?t=32601&p=280735
- H.264 extradata (partially) explained for dummies by Aviad Rozenhek: http://aviadr1.blogspot.com/2010/05/h264-extradata-partially-explained-for.html
- Possible Locations for Sequence/Picture Parameter Set(s) for H.264 Stream byszatmary: http://stackoverflow.com/questions/24884827/possiblelocations-for-sequence-picture-parameter-sets-for-h-264-stream
- Tomaka's blog: libavcodec/libavformat tutorial: http://blog.tomaka17.com/2012/03/libavcodeclibavformat-tutorial/
- An ffmpeg and SDL Tutorial: Tutorial 05: Synching Video by dranger: http://dranger.com/ffmpeg/tutorial05.html

CHAPTER 17



OpenVG is an application programming interface (API) for hardware-accelerated two-dimensional vector and raster graphics. It has not apparently proven immensely popular, but I will need it for drawing text overlays on video images in a later chapter. This is a minimal chapter on OpenVG.

Building Programs

You can build the programs in this chapter using the following Makefile:

```
DMX_INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs_host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs_host/linux
EGL_INC =
OPENVG_INC =
INCLUDES = $(DMX_INC) $(EGL_INC) $(OPENVG_INC)

CFLAGS= $(INCLUDES)
CPPFLAGS =

DMX_LIBS = -L/opt/vc/lib/ -lbcm_host -lvcos -lvchiq_arm -lpthread
EGL_LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OPENVG_LIBS = -lOpenVG

LDFLAGS = $(DMX_LIBS) $(EGL_LIBS) $(OPENVG_LIBS)

SRC = ellipse.c simple_shape.c window.c image.c

all: ellipse simple shape window image
```

Introduction

The OpenVG API is for hardware-accelerated two-dimensional vector and raster graphics. According to the OpenVG specification, it is intended to provide the following:

SVG and Adobe Flash viewers: OpenVG can provide the drawing functionality required for high-performance SVG document viewers that are conformant with version 1.2 of the SVG Tiny profile.

© Jan Newmarch 2017 325

Portable mapping applications: OpenVG can provide dynamic features for map display that would be difficult or impossible to do with an SVG or Flash viewer alone, such as dynamic placement and sizing of street names and markers and efficient viewport culling.

E-book readers: The OpenVG API can provide fast rendering of readable text in Western, Asian, and other scripts.

Games: The OpenVG API is useful for defining sprites, backgrounds, and textures for use in both 2D and 3D games. It can provide two-dimensional overlays (for example, for maps or scores) on top of 3D content.

Scalable user interfaces: OpenVG can be used to render scalable user interfaces, particularly for applications that want to present users with a unique look and feel that is consistent across different screen resolutions.

Low-level graphics device interface: OpenVG can be used as a low-level graphics device interface. Other graphical toolkits, such as windowing systems, may be implemented above OpenVG.

OpenVG hasn't taken off in general. Mesa is the main open source supplier for many graphical toolkits such as OpenGL. While it previously supported OpenVG, this has recently been removed, according to http://cgit.freedesktop.org/mesa/mesa/commit/?id=3acd7a34ab05b87521b74f626ec637e7fdcc6595.

OpenVG API seems to have dwindled away. The code would still be interesting if we wanted to implement NV_path_rendering, but given the trend of the next-gen graphics APIs, it seems unlikely that this becomes ARB or core.

The "next-gen" graphics API this is referring to is probably Vulkan. On the other hand, there are now more than 10 million RPi computers out there capable of running OpenVG. Will that make a difference?

Dispmanx and EGL

Just like OpenGL, OpenVG depends on an EGL surface, which on the RPi is created using Dispmanx. The bare-minimum program is just like window.c from Chapter 5 with these two changes:

• The API is bound to OpenVG rather than OpenGL ES with the following:

```
eglBindAPI(EGL OPENVG API);
```

 Drawing is done using OpenVG calls, where the minimum to clear and draw against a white background is as follows:

```
float c = 1.0;
float clearColor[4] = {c, c, c, 0.5}; // white, semi transparent
vgSetfv(VG_CLEAR_COLOR, 4, clearColor);
vgClear(0, 0, 1920, 1080); // window_width(), window_height());
// do lots of drawing in here
vgFlush();
```

The program is window.c.

```
/*
 * code adapted from openGL-RPi-tutorial-master/encode OGL/
#include <stdio.h>
#include <assert.h>
#include <math.h>
#include <stdlib.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL_STATE_T;
struct egl manager {
    EGLNativeDisplayType xdpy;
    EGLNativeWindowType xwin;
    EGLNativePixmapType xpix;
    EGLDisplay dpy;
    EGLConfig conf;
    EGLContext ctx;
    EGLSurface win;
    EGLSurface pix;
    EGLSurface pbuf;
    EGLImageKHR image;
    EGLBoolean verbose;
    EGLint major, minor;
};
EGL_STATE_T state, *p_state = &state;
void init_egl(EGL_STATE_T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm_host_init();
```

```
static const EGLint attribute list[] =
            EGL RED SIZE, 8,
            EGL_GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL_ALPHA_SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL RENDERABLE TYPE, EGL OPENVG BIT,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL_DEFAULT_DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute_list, &state->config, 1,
             &num configs);
    assert(EGL FALSE != result);
    //result = eglBindAPI(EGL OPENGL ES API);
    result = eglBindAPI(EGL OPENVG API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                      state->config, EGL NO CONTEXT,
                                      NULL);
                                      // breaks if we use this: context_attributes);
    assert(state->context!=EGL NO CONTEXT);
}
void init dispmanx(EGL DISPMANX WINDOW T *nativewindow) {
    int32 t success = 0;
    uint32 t screen width;
    uint32 t screen height;
    DISPMANX ELEMENT HANDLE T dispman element;
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX UPDATE HANDLE T dispman update;
    VC_RECT_T dst_rect;
    VC RECT T src rect;
    bcm_host_init();
```

```
success = graphics_get_display_size(0 /* LCD */,
                                         &screen width,
                                         &screen_height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst_rect.height = screen_height;
    src rect.x = 0;
    src rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman_update = vc_dispmanx_update start( 0 );
    dispman element =
        vc dispmanx element add(dispman update, dispman display,
                                0/*layer*/, &dst_rect, 0/*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen_width;
    nativewindow->height = screen height;
   vc dispmanx update submit sync(dispman update);
   printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                             state->config,
                                             nativewindow, NULL );
    assert(state->surface != EGL NO SURFACE);
    // connect the context to the surface
   result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
   assert(EGL_FALSE != result);
}
void draw(){
   float c = 1.0;
    float clearColor[4] = {c, c, c, 0.5}; // white, no transparency
    vgSetfv(VG_CLEAR_COLOR, 4, clearColor);
```


// create an EGL window surface

```
vgClear(0, 0, 1920, 1080); // window_width(), window_height());
    // do lots of drawing in here
   vgFlush();
}
int
main(int argc, char *argv[])
    EGL DISPMANX WINDOW T nativewindow;
    init_egl(p_state);
    init dispmanx(&nativewindow);
    egl from dispmanx(p state, &nativewindow);
    draw();
    eglSwapBuffers(p state->display, p state->surface);
    sleep(10);
    eglTerminate(p state->display);
    exit(0);
}
```

This is run by window and just clears the screen and shows a white background.

OpenVG Pipeline

OpenVG, like any graphics system, has a multistage pipeline to process drawing. The OpenVG specification shows these for drawing a colored dashed line on a scene of images and various shapes.



To actually draw anything means specifying what might happen at each of these stages.

Drawing a Pink Triangle

In OpenVG you draw and fill *paths*. In the simplest cases, the paths are made up of lines. These can be solid or made up of various dots and dashes. They can be straight or curved in various ways. Where lines join, there are several ways the joins can be managed. The path can be filled with a color, and the lines themselves can be colored. These can all be set by calls to vgSetxxx, where xxx is used to tell the data type being set. For example, vgSetfv means the parameter is a vector of four float values. At the conclusion of setting a path, the path is drawn by vgDrawPath.

A pink dashed triangle is drawn with the following:

```
VGint cap_style = VG_CAP_BUTT;
VGint join_style = VG_JOIN_MITER;
VGfloat color[4] = {1.0, 0.1, 1.0, 0.2}; // pink
VGPaint fill;
```

```
static const VGubyte cmds[] = {VG_MOVE_TO_ABS,
                                   VG LINE TO ABS,
                                   VG LINE TO ABS,
                                   VG CLOSE PATH
    };
    static const VGfloat coords[]
                                    = {630, 630,
                                       902, 630,
                                       750, 924,
                                        630, 630
    };
    VGfloat dash pattern[2] = { 20.f, 20.f };
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD,
                               VG PATH DATATYPE F, 1, 0, 0, 0,
                               VG_PATH_CAPABILITY_APPEND_TO);
    vgAppendPathData(path, 4, cmds, coords);
    fill = vgCreatePaint();
    vgSetParameterfv(fill, VG PAINT COLOR, 4, color);
    vgSetPaint(fill, VG_FILL_PATH);
    vgSetPaint(fill, VG_STROKE_PATH);
    vgSetfv(VG CLEAR COLOR, 4, white color);
    vgSetf(VG_STROKE_LINE_WIDTH, 20);
    vgSeti(VG STROKE CAP STYLE, cap style);
    vgSeti(VG STROKE JOIN STYLE, join style);
    vgSetfv(VG_STROKE_DASH_PATTERN, 2, dash_pattern);
    vgSetf(VG STROKE DASH PHASE, 0.0f);
    vgDrawPath(path, VG_STROKE_PATH|VG_FILL_PATH);
    The program is simple shape.c.
 * code adapted from openGL-RPi-tutorial-master/encode OGL/
#include <stdio.h>
#include <assert.h>
#include <math.h>
#include <stdlib.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
```

```
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL_STATE_T;
struct egl manager {
    EGLNativeDisplayType xdpy;
    EGLNativeWindowType xwin;
    EGLNativePixmapType xpix;
    EGLDisplay dpy;
    EGLConfig conf;
    EGLContext ctx;
    EGLSurface win;
    EGLSurface pix;
    EGLSurface pbuf;
    EGLImageKHR image;
    EGLBoolean verbose;
    EGLint major, minor;
};
EGL STATE T state, *p state = &state;
void init egl(EGL STATE T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm_host_init();
    static const EGLint attribute list[] =
        {
            EGL RED SIZE, 8,
            EGL GREEN SIZE, 8,
            EGL_BLUE_SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL_RENDERABLE_TYPE, EGL_OPENVG_BIT,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL_CONTEXT_CLIENT_VERSION, 2,
            EGL NONE
        };
```

```
// get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute list, &state->config, 1,
             &num configs);
    assert(EGL_FALSE != result);
    //result = eglBindAPI(EGL OPENGL ES API);
    result = eglBindAPI(EGL_OPENVG API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config, EGL NO CONTEXT,
                                       // breaks if we use this: context attributes);
    assert(state->context!=EGL NO CONTEXT);
}
void init dispmanx(EGL DISPMANX WINDOW T *nativewindow) {
    int32_t success = 0;
    uint32 t screen width;
    uint32 t screen height;
    DISPMANX ELEMENT HANDLE T dispman element;
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX_UPDATE_HANDLE_T dispman_update;
    VC RECT T dst rect;
    VC RECT T src rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen_height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst_rect.height = screen_height;
    src rect.x = 0;
    src_rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
```

```
dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
       vc dispmanx element add(dispman update, dispman display,
                                0/*layer*/, &dst rect, 0/*src*/,
                                &src_rect, DISPMANX_PROTECTION NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen_height;
   vc dispmanx update submit sync(dispman update);
   printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow, NULL );
    assert(state->surface != EGL_NO_SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
   assert(EGL FALSE != result);
}
void simple shape() {
   VGint cap_style = VG_CAP_BUTT;
   VGint join style = VG JOIN MITER;
   VGfloat\ color[4] = \{1.0, 0.1, 1.0, 0.2\};
   VGfloat white_color[4] = {1.0, 1.0, 1.0, 0.0}; //1.0};
   VGPaint fill;
    static const VGubyte cmds[] = {VG_MOVE_TO_ABS,
                                   VG LINE TO ABS,
                                   VG LINE TO ABS,
                                   VG CLOSE PATH
    };
    static const VGfloat coords[] = {630, 630,
                                       902, 630,
                                       750, 924
    };
```

```
VGfloat dash_pattern[2] = { 20.f, 20.f };
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD,
                               VG PATH DATATYPE_F, 1, 0, 0, 0,
                               VG_PATH_CAPABILITY_APPEND_TO);
    vgAppendPathData(path, 4, cmds, coords);
    fill = vgCreatePaint();
    vgSetParameterfv(fill, VG PAINT COLOR, 4, color);
    vgSetPaint(fill, VG FILL PATH);
    vgSetPaint(fill, VG STROKE PATH);
    vgSetfv(VG CLEAR COLOR, 4, white color);
    vgSetf(VG_STROKE_LINE_WIDTH, 20);
    vgSeti(VG STROKE CAP STYLE, cap style);
    vgSeti(VG STROKE JOIN STYLE, join style);
    vgSetfv(VG_STROKE_DASH_PATTERN, 2, dash_pattern);
    vgSetf(VG STROKE DASH PHASE, 0.0f);
    vgDrawPath(path, VG_STROKE_PATH|VG_FILL_PATH);
}
void draw(){
    float c = 1.0;
    float clearColor[4] = {c, c, c, c}; // white, no transparency
    vgSetfv(VG CLEAR COLOR, 4, clearColor);
    vgClear(0, 0, 1920, 1080);
    simple shape();
    vgFlush();
}
int
main(int argc, char *argv[])
    EGL_DISPMANX_WINDOW_T nativewindow;
    init egl(p state);
    init dispmanx(&nativewindow);
    egl_from_dispmanx(p_state, &nativewindow);
    draw();
    eglSwapBuffers(p state->display, p state->surface);
    sleep(100);
    eglTerminate(p state->display);
    exit(0);
}
```

This is run with simple_shape.
The figure drawn is as follows (image captured by raspi2png):



Drawing Standard Shapes

The VGU utility library is an optional library that provides a set of common shapes such as polygons, rectangles, and ellipses. The shapes still need to have the stroke and fill parameters set, and so on. The program ellipse.c draws a purple rectangle that decreases in height on each display.

```
#include <stdio.h>
#include <stdlib.h>
//#include <sys/stat.h>
#include <signal.h>
#include <assert.h>
#include <vc dispmanx.h>
#include <bcm host.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
EGL STATE T state, *p state = &state;
void init_egl(EGL_STATE_T *state)
    EGLint num configs;
    EGLBoolean result;
```

```
//bcm_host_init();
    static const EGLint attribute list[] =
            EGL RED_SIZE, 8,
            EGL GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL_ALPHA_SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL SAMPLES, 1,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute_list, &state->config, 1,
             &num configs);
    assert(EGL FALSE != result);
    // Choose the OpenVG API
    result = eglBindAPI(EGL OPENVG API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                      state->config,
                                      NULL, // EGL_NO_CONTEXT,
                                      NULL);
                                      // breaks if we use this: context attributes);
    assert(state->context!=EGL_NO_CONTEXT);
}
void init_dispmanx(EGL_DISPMANX_WINDOW_T *nativewindow) {
    int32 t success = 0;
    uint32 t screen width;
    uint32_t screen_height;
    DISPMANX ELEMENT HANDLE T dispman element;
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX UPDATE HANDLE T dispman update;
    VC RECT T dst rect;
    VC_RECT_T src_rect;
```

```
bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst rect.height = screen height;
    src rect.x = 0;
    src rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
        vc dispmanx element add(dispman update, dispman display,
                                 0 /*layer*/, &dst rect, 0 /*src*/,
                                 &src_rect, DISPMANX_PROTECTION_NONE,
                                 0 /*alpha*/, 0 /*clamp*/, 0 /*transform*/);
    // Build an EGL_DISPMANX_WINDOW_T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen height;
    vc dispmanx update submit sync(dispman update);
    printf("Got a Dispmanx window\n");
}
void egl_from_dispmanx(EGL_STATE_T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    static const EGLint attribute_list[] =
            EGL RENDER BUFFER, EGL SINGLE BUFFER,
            EGL NONE
        };
    state->surface = eglCreateWindowSurface(state->display,
                                             state->config,
                                             nativewindow,
                                             NULL );
                                             //attribute list);
    assert(state->surface != EGL NO SURFACE);
```

```
// connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL FALSE != result);
}
// setfill sets the fill color
void setfill(float color[4]) {
    VGPaint fillPaint = vgCreatePaint();
    vgSetParameteri(fillPaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(fillPaint, VG_PAINT_COLOR, 4, color);
    vgSetPaint(fillPaint, VG FILL PATH);
    vgDestroyPaint(fillPaint);
}
// setstroke sets the stroke color and width
void setstroke(float color[4], float width) {
    VGPaint strokePaint = vgCreatePaint();
    vgSetParameteri(strokePaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(strokePaint, VG PAINT COLOR, 4, color);
    vgSetPaint(strokePaint, VG STROKE PATH);
    vgSetf(VG STROKE LINE WIDTH, width);
    vgSeti(VG STROKE CAP STYLE, VG CAP BUTT);
    vgSeti(VG STROKE JOIN STYLE, VG JOIN MITER);
    vgDestroyPaint(strokePaint);
}
// Ellipse makes an ellipse at the specified location and dimensions, applying style
void Ellipse(float x, float y, float w, float h, float sw, float fill[4], float stroke[4]) {
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD, VG PATH DATATYPE F, 1.0f, 0.0f, 0,
                  O, VG PATH CAPABILITY ALL);
    vguEllipse(path, x, y, w, h);
    setfill(fill);
    setstroke(stroke, sw);
    vgDrawPath(path, VG FILL PATH | VG STROKE PATH);
    vgDestroyPath(path);
}
void draw() {
    EGL DISPMANX WINDOW_T nativewindow;
    init egl(p state);
    init dispmanx(&nativewindow);
    egl from dispmanx(p state, &nativewindow);
    vgClear(0, 0, 1920, 1080);
    VGfloat color[4] = \{0.4, 0.1, 1.0, 1.0\}; // purple
    float c = 1.0;
    float clearColor[4] = {c, c, c, c}; // white non-transparent
    vgSetfv(VG CLEAR COLOR, 4, clearColor);
    vgClear(0, 0, 1920, 1080);
```

```
vgSeti(VG BLEND MODE, VG BLEND SRC OVER);
    static float ht = 200;
    while (1) {
        vgClear(0, 0, 1920, 1080);
        Ellipse(1920/2, 1080/2, 400, ht--, 0, color, color);
        if (ht <= 0) {
            ht = 200;
        eglSwapBuffers(p state->display, p state->surface);
    }
    assert(vgGetError() == VG NO ERROR);
    vgFlush();
    eglSwapBuffers(p state->display, p state->surface);
}
void sig handler(int sig) {
    eglTerminate(p_state->display);
    exit(1);
}
int main(int argc, char** argv) {
    signal(SIGINT, sig handler);
    draw();
    exit(0);
}
    This is run by ellipse.
    It looks like this:
```



Images

OpenVG has the type VGImage to represent images. An image has a format such as RGB, and each pixel takes a number of bytes. For example, the format VG_sXRGB_8888 takes up 4 bytes. Each image consists of rows of pixels, and some images round up the number of bytes per row to, for example, a multiple of 32 bytes. This rounded-up number is called the *stride*. For example, 100 pixels in VG_sXRGB_8888 format would take up 400 bytes, but this might be rounded up to a stride of 416 bytes.

Images can come from a number of sources.

- An external file may hold an image in, for example, PNG format. This will have to be loaded into memory and decoded into the correct format for a VGImage.
- A program may generate an image in memory in the format required for a VGImage.
- An image may be created as an off-screen buffer, and VG drawing calls can be made into it.

The resulting image can be drawn to the current OpenVG surface, either in total or in part.

Creating a VGImage from Memory Data

You can create a grayscale image where each pixel takes 1 byte by creating an image of type VG_sL_8 . You can choose the size as 256×256 . The data for this will then be stored in a 256×256 unsigned char array. For simplicity, you just fill it with increasing values (overflowing when necessary).

To load an array into an image, you use the function vgImageSubData. This takes the image, the data array, the image format, the stride, and the image coordinates.

```
vgImageSubData(img, data,
256, VG_sL_8,
0, 0, 256, 256);
```

Drawing an Image

To draw the image, you must set up an "image-user-to-surface" transformation. This requires setting up a matrix to transform the image to user coordinates, such as a projective transformation. You just use an identity matrix. The resulting image may be subjected to operations such as translation to a different origin. The image can then be drawn as follows:

```
vgSeti(VG_MATRIX_MODE, VG_MATRIX_IMAGE_USER_TO_SURFACE);
vgLoadIdentity();
vgTranslate(200, 30);
vgDrawImage(img);
```

A function to create and draw an image is then as follows:

```
void simple_image() {
    VGImage img;
    img = vgCreateImage(VG sL 8,
                          256, 256,
                          VG_IMAGE_QUALITY_NONANTIALIASED);
    if (img == VG_INVALID_HANDLE) {
        fprintf(stderr, "Can't create simple image\n");
fprintf(stderr, "Error code %x\n", vgGetError());
        exit(2);
    }
    unsigned char val;
    unsigned char data[256*256];
    int n;
    for (n = 0; n < 256*256; n++) {
        val = (unsigned char) n;
        data[n] = val;
    vgImageSubData(img, data,
                     256, VG_sL_8,
                     0, 0, 256, 256);
    vgSeti(VG MATRIX MODE, VG MATRIX IMAGE USER TO SURFACE);
    vgLoadIdentity();
    vgTranslate(200, 30);
    vgDrawImage(img);
    vgDestroyImage(img);
}
```

The image looks like this:

Drawing an Image Using OpenVG Calls

OpenVG can also be used to draw into an off-screen buffer image. This is much more complicated because an image has to be created that is compatible with the display, and then an off-screen surface using a buffer has to be created from this image. The surface must then be made the current drawing surface, and then OpenVG calls can be made to it. The original drawing surface must be restored, and then the image can be drawn to it, as shown earlier.

In setting up the EGL surfaces, you had to create an EGL context. This used the EGLDisplay and also an EGLConfig. The configuration used a list of attributes that typically specify the RGBA characteristics required. This is done by passing to eglChooseConfig an attribute list such as the following:

By experimenting I have found that for the RPi, both RGBA_8888 and RGB_565 but not much else seems to work for a window configuration. I couldn't get a Luminance setting (grayscale) to work.

An off-screen image seems to be even fussier, and I have only been able to get a setting of RGBA_8888 to work. You choose a configuration and build context for the off-screen image using a *pbuffer*, as follows:

```
EGLContext context;
static const EGLint attribute list[] =
        EGL RED SIZE, 8,
        EGL GREEN SIZE, 8,
        EGL BLUE SIZE, 8,
        EGL ALPHA SIZE, 8,
        EGL SURFACE TYPE, EGL PBUFFER BIT,
        EGL RENDERABLE TYPE, EGL OPENVG BIT,
        EGL NONE
    };
EGLConfig config;
drawn image = vgCreateImage(VG sRGBA 8888,
                             256, 256,
                             VG IMAGE QUALITY NONANTIALIASED);
if (drawn image == VG INVALID HANDLE) {
    fprintf(stderr, "Can't create drawn image\n");
   fprintf(stderr, "Error code %x\n", vgGetError());
   exit(2);
vgClearImage(drawn image, 0, 0, 256, 256);
```

The next step is to create an off-screen surface using the call eglCreatePbufferFromClientBuffer. This takes the image coerced to type EGLClientBuffer.

This needs to be made into the current surface with the following:

OpenVG calls can then be made: create a path, set objects into the path, set fill parameters, and so on, and then finally draw the path.

```
VGPath path = vgCreatePath(VG PATH FORMAT STANDARD,
                            VG PATH DATATYPE F, 1.0f,
                            o.of, o, o, VG PATH CAPABILITY ALL);
float height = 40.0;
float arcW = 15.0;
float arcH = 15.0;
vguRoundRect(path, 28, 10,
             200, 60, arcW, arcH);
vguEllipse(path, 128, 200, 60, 40);
setfill(drawn color);
vgDrawPath(path, VG FILL PATH);
The final steps are to reset the drawing surface and then draw the image onto the surface.
eglMakeCurrent(p_state->display, p_state->surface,
               p state->surface,
               p state->context);
vgSeti(VG MATRIX MODE, VG MATRIX IMAGE USER TO SURFACE);
vgLoadIdentity();
vgTranslate(800, 300);
```

```
vgDrawImage(drawn image);
    vgDestroyImage(drawn image);
    The final function to do all this is as follows:
void drawn image() {
    EGLSurface img surface;
    VGImage drawn image;
    EGLContext context;
    static const EGLint attribute list[] =
            //EGL COLOR BUFFER TYPE, EGL LUMINANCE BUFFER,
            // EGL LUMINANCE SIZE, 8,
            EGL RED SIZE, 8,
            EGL GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL SURFACE TYPE, EGL PBUFFER BIT,
            EGL RENDERABLE TYPE, EGL OPENVG BIT,
            EGL_NONE
        };
    EGLConfig config;
    drawn image = vgCreateImage(VG sRGBA 8888,
                                  256, 256,
                                  VG_IMAGE_QUALITY_NONANTIALIASED);
    if (drawn image == VG_INVALID_HANDLE) {
        fprintf(stderr, "Can't create drawn image\n");
        fprintf(stderr, "Error code %x\n", vgGetError());
        exit(2);
    vgClearImage(drawn_image, 0, 0, 256, 256);
    int result, num configs;
    result = eglChooseConfig(p_state->display,
                              attribute list,
                              &config,
                              1,
                              &num configs);
    assert(EGL FALSE != result);gt;display,
    context = eglCreateContext(p_state->display,
                                config, EGL NO CONTEXT,
                                NULL);
    img surface = eglCreatePbufferFromClientBuffer(p state->display,
                                                    EGL OPENVG IMAGE,
                                                     (EGLClientBuffer) drawn_image,
                                                    config,
                                                    NULL);
```

```
if (img_surface == EGL_NO_SURFACE) {
        fprintf(stderr, "Couldn't create pbuffer\n");
        fprintf(stderr, "Error code %x\n", eglGetError());
        exit(1);
    eglMakeCurrent(p state->display, img surface, img surface,
                   context); //p_state->context);
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD,
                               VG_PATH_DATATYPE_F, 1.0f,
                               o.of, o, o, VG PATH CAPABILITY ALL);
    float height = 40.0;
    float arcW = 15.0;
    float arcH = 15.0;
    vguRoundRect(path, 28, 10,
                 200, 60, arcW, arcH);
    vguEllipse(path, 128, 200, 60, 40);
    setfill(drawn color);
    vgDrawPath(path, VG_FILL_PATH);
    eglMakeCurrent(p state->display, p state->surface,
                   p state->surface,
                   p state->context);
    vgSeti(VG_MATRIX_MODE, VG_MATRIX_IMAGE_USER_TO_SURFACE);
    vgLoadIdentity();
    vgTranslate(800, 300);
    vgDrawImage(drawn image);
    vgDestroyImage(drawn image);
}
    The image looks like this:
```

The complete program to draw the simple images is image.c.

Conclusion

This chapter showed you how to draw OpenVG surfaces on a Dispmanx window and introduced you to the OpenVG API.

Resources

- Khronos Group: OpenVG The Standard for Vector Graphics Acceleration: https://www.khronos.org/openvg/
- OpenVG Specification: https://www.khronos.org/registry/vg/specs/openvg-1.1.pdf
- Huang Loren OpenVG Graphics Solutions Tutorial A very good overview of OpenVG capabilities: https://www.yumpu.com/en/document/view/4775633/openvg-graphics-solutions-tutorial
- Mindchunk: OpenVG on the Raspberry Pi describes a simple library to program
 OpenVG on the RPi: https://github.com/ajstarks/openvg
- Why have hardware-accelerated vector graphics not taken off: http://programmers.stackexchange.com/questions/191472/why-have-hardware-accelerated-vector-graphics-not-taken-off

CHAPTER 18

Text Processing in OpenVG on the Raspberry Pi

Displaying text is an important function of any application. *Drawing* the text should be a low-level operation that the application should not be concerned with. It has to be done explicitly in OpenVG, and this chapter discusses various techniques of doing that.

Building Programs

The programs in this chapter require extra libraries in addition to the OpenVG libraries. These need to be installed with the following:

```
sudo apt-get install libcairo2-dev libpango1.0-dev
```

The FreeType 2 packages should already be installed, but if they are not, you will need to get the package freetype2.

You can then build the programs in this chapter using the following Makefile:

```
DMX INC = -I/opt/vc/include/ -I /opt/vc/include/interface/vmcs host/ -I/opt/vc/include/
interface/vcos/pthreads -I/opt/vc/include/interface/vmcs host/linux
EGL_INC =
OPENVG INC =
PANGO CAIRO INC = $(shell pkg-config --cflags pangocairo)
FREETYPE INC = $(shell pkg-config --cflags freetype2)
INCLUDES = $(DMX_INC) $(EGL_INC) $(OPENVG_INC) $(PANGO_CAIRO_INC) $(FREETYPE_INC)
CFLAGS= $(INCLUDES)
CPPFLAGS =
DMX LIBS = -L/opt/vc/lib/ -lbcm host -lvcos -lvchiq arm -lpthread
EGL LIBS = -L/opt/vc/lib/ -lEGL -lGLESv2
OPENVG\ LIBS = -10penVG
PANGO CAIRO LIBS = $(shell pkg-config --libs pangocairo)
FREETYPE LIBS = $(shell pkg-config --libs freetype2)
LDFLAGS = $(DMX LIBS) $(EGL LIBS) $(OPENVG LIBS) $(PANGO CAIRO LIBS) \
   $(FREETYPE LIBS)
all: cairo pango text-bitmap text-font text-outline
```

© Jan Newmarch 2017 349

Drawing Text

Drawing text is an immensely difficult area. Even in English there are the following issues:

- Letters such as g reach below the baseline and need to have space allocated for this.
- Letter combinations such as *ff* are often rendered with a different (ligature) format such as *ff*.
- Letter pairs such as AW are often rendered with less space between the characters to avoid an ugly space between the letters.
- In cursive writing, the shapes of the letters may change to join up with the following or preceding letters.

Once you switch to other languages, the complexities multiply.

- Some languages have right-to-left writing such as Arabic or (often) top to bottom in Chinese.
- Languages such as Chinese have hieroglyphs typically taking twice the width of Latin languages.
- Joining letters in Arabic is an extremely complex issue.

Displaying text involves a number of issues.

- For each character, a *glyph* has to be chosen. A glyph is the visual representation of a character and can vary. In English, varieties can include bold, italic, cursive, and so on, and are often associated with fonts.
- Glyphs have to be laid out on the screen using complex rules for spacing, direction, and so on.

OpenVG has the capability of finding fonts and laying them out at locations on the rendering surface. The *rules* for layout are not part of OpenVG. The simplest rule is just to lay them out one after another, but this will often get them wrong or not visually satisfying.

In this chapter, I will look at a variety of ways of drawing text using OpenVG, trading off ease of use versus complexity of programming and CPU usage on the RPi. Of necessity, this will involve using other libraries such as Cairo, Pango, and the freetype libraries.

Drawing Text Using Cairo

Cairo is a popular 2D graphics library that includes support for "toy" text and complex text processing. The toy library is suitable for simple text layout rules, particularly for Latin languages.

Cairo draws 2D shapes onto surfaces of various kinds. A good tutorial is at http://zetcode.com/gfx/cairo/. Drawing involves creating a surface, drawing into it, and then getting the data out of the surface to display it or otherwise process it. The link with OpenVG from Cairo is provided by a Cairo function and an OpenVG function.

The text parameters are from Cairo.

```
int tex_w = cairo_image_surface_get_width(surface);
    int tex h = cairo image surface get height(surface);
    int tex s = cairo image surface get stride(surface);
    int left = 1920/2 - extents.width/2;
    A program to display a set of lines progressively using the Cairo "toy" text interface is cairo.c.
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <assert.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
#include <bcm host.h>
#include <cairo/cairo.h>
char *lines[] = {"hello", "world", "AWAKE"};
int num lines = 3;
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
EGL STATE T state, *p state = &state;
void init_egl(EGL_STATE_T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm host init();
    static const EGLint attribute list[] =
            EGL_RED_SIZE, 8,
            EGL GREEN SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL_ALPHA_SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL NONE
```

};

```
// get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute list, &state->config, 1,
    &num configs);
    assert(EGL_FALSE != result);
    // Choose the OpenVG API
    result = eglBindAPI(EGL_OPENVG_API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config, EGL NO CONTEXT,
    assert(state->context!=EGL NO CONTEXT);
}
void init dispmanx(EGL DISPMANX WINDOW T *nativewindow) {
    int32_t success = 0;
    uint32 t screen width;
    uint32 t screen height;
    DISPMANX ELEMENT HANDLE T dispman element; // | FT LOAD NO SCALE);
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX_UPDATE_HANDLE_T dispman_update;
    VC RECT T dst rect;
    VC RECT T src rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen_height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst_rect.height = screen_height;
    src rect.x = 0;
    src_rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
```

```
dispman display = vc_dispmanx_display_open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
       vc dispmanx element add(dispman update, dispman display,
                                0 /*layer*/, &dst rect, 0 /*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0 /*clamp*/, 0 /*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen_height;
   vc dispmanx update submit sync(dispman update);
   printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow, NULL );
    assert(state->surface != EGL NO SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
   assert(EGL FALSE != result);
}
void cairo(char *text) {
    int width = 500;
    int height = 200;
   cairo_surface_t *surface = cairo_image_surface_create (CAIRO_FORMAT_ARGB32,
                                                           width, height);
   cairo t *cr = cairo_create(surface);
    cairo rectangle(cr, 0, 0, width, height);
    cairo set source rgb(cr, 0.0, 0.0, 0.5);
    cairo_fill(cr);
    // draw some white text on top
    cairo_set_source_rgb(cr, 1.0, 1.0, 1.0);
    // this is a standard font for Cairo
    cairo select font face (cr, "cairo:serif",
                            CAIRO_FONT_SLANT_NORMAL,
                            CAIRO FONT WEIGHT BOLD);
    cairo set font size (cr, 36);
    cairo_move_to(cr, 10.0, 50.0);
```

```
cairo scale(cr, 1.0f, -1.0f);
    cairo_translate(cr, 0.0f, -50);
    cairo_text_extents_t extents;
    cairo_text_extents(cr, text, &extents);
    cairo_show_text (cr, text);
    int tex_w = cairo_image_surface_get width(surface);
    int tex h = cairo image surface get height(surface);
    int tex_s = cairo_image_surface_get_stride(surface);
    unsigned char* data = cairo image surface get data(surface);
    int left = 1920/2 - extents.width/2;
    vgWritePixels(data, tex s,
                  VG lBGRA_8888, left, 300, tex_w, tex_h );
}
void draw() {
    EGL DISPMANX WINDOW T nativewindow;
    init_egl(p_state);
    init dispmanx(&nativewindow);
    egl from dispmanx(p state, &nativewindow);
    int n = 0;
    while (1) {
        cairo(lines[n++]);
        n %= num lines;
        eglSwapBuffers(p state->display, p state->surface);
        sleep(3);
}
int main(int argc, char** argv) {
    draw();
    exit(0);
}
    Run the program with cairo.
```

This draws each line of text in white on a blue background, as shown here:



Drawing Text Using Pango

While Cairo can draw any form of text, the functions such as cairo_show_text do not have much flexibility. Drawing in, say, multiple colors will involve a lot of work. Pango is a library for handling all aspects of text. There is a Pango Reference Manual (https://developer.gnome.org/pango/stable/), and you can find a good tutorial at www.ibm.com/developerworks/library/l-u-pango2/.

The simplest way of coloring text (and some other effects) is to create the text marked up with HTML, as follows:

```
gchar *markup_text = "<span foreground=\"red\">hello </span><span
foreground=\"black\">world</span>";
```

This has *hello* in red and *world* in black. This is then parsed into the text itself, *red black*, and a set of attribute markups.

```
gchar *markup_text = "<span foreground=\"red\">hello </span><span
foreground=\"black\">world</span>";
PangoAttrList *attrs;
gchar *text;
pango_parse_markup (markup_text, -1,0, &attrs, &text, NULL, NULL);
```

This can be rendered into a Cairo context by creating a PangoLayout from the Cairo context, laying out the text with its attributes in the Pango layout, and then showing this layout in the Cairo context.

```
PangoLayout *layout;
PangoFontDescription *desc;
cairo_move_to(cr, 300.0, 50.0);
layout = pango_cairo_create_layout (cr);
pango_layout_set_text (layout, text, -1);
pango_layout_set_attributes(layout, attrs);
pango_cairo_update_layout (cr, layout);
pango_cairo_show_layout (cr, layout);
```

(Yes, there is a lot of jumping around between libraries in all of this!)

Once the Cairo surface has been drawn, the data can be extracted as in the Cairo example and written into the OpenVG surface. The program is pango.c and is as follows:

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <assert.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
#include <bcm_host.h>
#include <pango/pangocairo.h>
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
EGL_STATE_T state, *p_state = &state;
void init egl(EGL STATE T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm host init();
    static const EGLint attribute_list[] =
            EGL RED SIZE, 8,
            EGL_GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL_ALPHA_SIZE, 8,
            EGL_SURFACE_TYPE, EGL_WINDOW_BIT,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
```

```
// get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute_list, &state->config, 1,
             &num configs);
    assert(EGL_FALSE != result);
    // Choose the OpenVG API
    result = eglBindAPI(EGL OPENVG API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config, EGL NO CONTEXT,
                                      NULL);
   assert(state->context!=EGL NO CONTEXT);
}
void init dispmanx(EGL_DISPMANX_WINDOW_T *nativewindow) {
    int32 t success = 0;
    uint32 t screen width;
   uint32 t screen height;
   DISPMANX ELEMENT HANDLE T dispman element;
   DISPMANX DISPLAY HANDLE T dispman display;
   DISPMANX UPDATE HANDLE T dispman update;
   VC RECT T dst rect;
   VC RECT T src rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen_height);
    assert( success >= 0 );
   dst_rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
   dst_rect.height = screen_height;
    src rect.x = 0;
    src_rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
```

```
vc dispmanx element add(dispman update, dispman display,
                                0/*layer*/, &dst rect, 0/*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen height:
    vc dispmanx update submit sync(dispman update);
    printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL_DISPMANX_WINDOW_T *nativewindow) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow, NULL );
    assert(state->surface != EGL_NO_SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL FALSE != result);
}
// setfill sets the fill color
void setfill(float color[4]) {
    VGPaint fillPaint = vgCreatePaint();
    vgSetParameteri(fillPaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(fillPaint, VG PAINT COLOR, 4, color);
    vgSetPaint(fillPaint, VG FILL PATH);
    vgDestroyPaint(fillPaint);
}
// setstroke sets the stroke color and width
void setstroke(float color[4], float width) {
    VGPaint strokePaint = vgCreatePaint();
    vgSetParameteri(strokePaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(strokePaint, VG PAINT COLOR, 4, color);
    vgSetPaint(strokePaint, VG STROKE PATH);
    vgSetf(VG STROKE LINE WIDTH, width);
    vgSeti(VG STROKE CAP STYLE, VG CAP BUTT);
    vgSeti(VG_STROKE_JOIN_STYLE, VG_JOIN_MITER);
    vgDestroyPaint(strokePaint);
}
// Ellipse makes an ellipse at the specified location and dimensions, applying style
void Ellipse(float x, float y, float w, float h, float sw, float fill[4], float stroke[4]) {
```

```
VGPath path = vgCreatePath(VG_PATH_FORMAT_STANDARD, VG_PATH_DATATYPE_F, 1.0f, 0.0f, 0,
    o, VG PATH CAPABILITY ALL);
    vguEllipse(path, x, y, w, h);
    setfill(fill);
    setstroke(stroke, sw);
    vgDrawPath(path, VG FILL PATH | VG STROKE PATH);
    vgDestroyPath(path);
}
void pango() {
    int width = 500;
    int height = 200;
    cairo surface t *surface = cairo image surface create (CAIRO FORMAT ARGB32,
                                                           width, height);
    cairo_t *cr = cairo_create(surface);
    cairo rectangle(cr, 0, 0, width, height);
    cairo_set_source_rgb(cr, 0.5, 0.5, 0.5);
    cairo fill(cr);
    // Pango marked up text, half red, half black
    gchar *markup text = "<span foreground=\"red\" font='48'>hello</span>\
<span foreground=\"black\" font='48'>AWA㹴犬</span>";
    PangoAttrList *attrs;
    gchar *text;
    pango_parse_markup (markup_text, -1, 0, &attrs, &text, NULL, NULL);
    // draw Pango text
    PangoLayout *layout;
    PangoFontDescription *desc;
    cairo move to(cr, 30.0, 150.0);
    cairo_scale(cr, 1.0f, -1.0f);
    layout = pango cairo create layout (cr);
    pango_layout_set_text (layout, text, -1);
    pango layout set attributes(layout, attrs);
    pango cairo update layout (cr, layout);
    pango_cairo_show_layout (cr, layout);
    int tex w = cairo image surface get width(surface);
    int tex h = cairo image surface get height(surface);
    int tex s = cairo image surface get stride(surface);
    cairo surface flush(surface);
    cairo_format_t type =
        cairo image surface get format (surface);
    printf("Format is (0 is ARGB32) %d\n", type);
    unsigned char* data = cairo_image_surface_get data(surface);
    PangoLayoutLine *layout line =
        pango layout get line(layout, 0);
```

```
PangoRectangle ink rect;
    PangoRectangle logical rect;
    pango layout line get pixel extents (layout line,
                                          &ink rect,
                                          &logical rect);
    printf("Layout line rectangle is %d, %d, %d, %d\n",
           ink_rect.x, ink_rect.y, ink_rect.width, ink_rect.height);
    int left = 1920/2 - ink rect.width/2;
    vgWritePixels(data, tex_s,
                  //VG 1BGRA 8888,
                  VG sARGB 8888 ,
                  left, 300, tex_w, tex_h );
}
void draw()
    EGL DISPMANX WINDOW T nativewindow;
    init_egl(p_state);
    init dispmanx(&nativewindow);
    egl from dispmanx(p state, &nativewindow);
    //draw();
    pango();
    eglSwapBuffers(p state->display, p state->surface);
    sleep(30);
    eglTerminate(p state->display);
    exit(0);
}
int main(int argc, char** argv) {
    draw();
    exit(0);
}
```

The program is run with pango.

This draws some text in red and black onto a gray rectangle against a white backdrop, as shown here:



FreeType

The previous programs basically did all the rendering calculations using the RPi's CPU and used the GPU only to render the resultant images. This is not using the GPU as you want: to manage as much as possible of the rendering calculations.

It is not possible to do everything on the GPU. It doesn't know about Linux file systems, for example. But more important, it doesn't know how or where information about text fonts and glyphs is stored. This information has to be built from an external library and massaged into a form suitable for the RPi's GPU.

The most common library in use on Linux systems now seems to be the FreeType library (www.freetype.org/). Here is the API reference: www.freetype.org/freetype2/docs/reference/ft2-basic_types.html#FT_Glyph_Format. There is also a tutorial at www.freetype.org/freetype2/docs/tutorial/index.html.

Font Faces

The highest-level object in FreeType is an FT_Library. There may be more than one of these, say, one for each thread in a multithreaded application. You will use only one. An FT_Face represents a single typeface in a particular style, such as Palatino Regular or Palatino Italic. An FT_Face is extracted from a font file that may contain many faces. Typically, face 0 is chosen. Once selected, a face may have characteristics such as the pixel size set.

The typical code to set up a face with a particular size is as follows:

Where do you get the font files from? The file type required is usually TrueType with the extension .ttf, and many of these are found in the directory /usr/share/fonts/truetype/. These all contain the ASCII character set, and their appearance can be seen using gnome-font-viewer. For example, the font /usr/share/fonts/truetype/freefont/FreeMonoBold.ttf looks like this:



I want to be able to see Chinese characters as well as ASCII, and I know that with all the packages I have installed, Pango is able to find a font file containing them. Repolho shows at https://repolinux.wordpress.com/2013/03/10/find-out-fallback-font-used-by-fontconfig-for-a-certain-character/how to find a font file for any particular character. For example, for the Chinese character 好 (meaning "good"), the command is as follows:

```
FC_DEBUG=4 pango-view -t '好' 2>&1 |
grep -o 'family: "[^"]\+' |
cut -c 10- | tail -n 1
```

This will display the character in a small box, and when you quit (q) the box, it will print the name of a font file. On my system, it printed Droid Sans Japanese. This is the name of the font but not of the file. By using the following, the file /usr/share/fonts/truetype/droid/DroidSansJapanese.ttf was identified:

locate DroidSansJapanese

(I had installed the package locate and ran updatedb to build the database for the locate command.)

This need not be the only containing this character but is the one used by Pango. (That directory also contains DroidSansFallbackFull.ttf, which would probably be better if I wanted to draw more characters.) It may be that there is no such font file on your system. In that case, download the files zysong.ttf or Cyberbit.ttf.

Paths and Glyphs

Once a face has been set up, you can hand characters to it and get an index for each character in the face using FT_Get_Char_Index(FT_Face face, FT_ULong charcode). Although the function name says Char, with Unicode characters these won't be 8-bit C chars except for the ASCII subset. You will need the full 16- or 32-bit Unicode character, which is an FT_ULong to the FreeType system. So, for example, the Chinese character \$\frac{1}{27}\$ needs to be represented by its Unicode value of 0x597d. Unicode values can be found in many places, such as scarfboy.com.

Once an index is found, the character can be loaded into the face by FT_Load_Glyph. There are two things you can do with a loaded glyph: get it back as an *outline* or convert it to a *bitmap*. In each case there are different things that can done with OpenVG, which are discussed in the following sections.

Extracting the outline of a glyph from a face is easy, as shown here:

```
FT Outline *outline = &ft face->glyph->outline;
```

Getting a bitmap involves more steps: first you get the glyph as an FT_Glyph with FT_Get_Glyph. This is then converted to a bitmap with FT_Glyph_To_Bitmap. But a glyph has no field of a bitmap: it needs to be coerced into type FT_BitmapGlyph, and then the bitmap can be found.

```
FT_Glyph glyph;
FT_Get_Glyph(ft_face->glyph, &glyph);
FT_Glyph_To_Bitmap(&glyph, FT_RENDER_MODE_NORMAL, NULL, 1);
FT_BitmapGlyph bit_glyph = (FT_BitmapGlyph) glyph;
FT_Bitmap bitmap = bit_glyph->bitmap;
```

There are operations that can be performed on a glyph before extracting the bitmap. For example, using an FT Stroker, the corners can be smoothed out. The code to do that is as follows:

Drawing a FreeType Outline

The FT_Outline type from FreeType contains information about the outline of a glyph, but this is not the same form as used in an OpenVG path. It has to be converted from FreeType to OpenVG.

Functions to do this are in /opt/vc/src/hello pi/libs/vgfont/vgft.c.

```
#define SEGMENTS_COUNT_MAX 256
#define COORDS_COUNT_MAX 1024

static VGuint segments_count;
static VGubyte segments[SEGMENTS_COUNT_MAX];
static VGuint coords_count;
static VGfloat coords[COORDS_COUNT_MAX];
```

```
static VGfloat float_from_26_6(FT_Pos x)
{
   return (VGfloat)x / 64.0f;
}
static void convert contour(const FT Vector *points,
                            const char *tags, short points count)
{
   int first coords = coords count;
   int first = 1;
   char last tag = 0;
   int c = 0;
   for (; points count != 0; ++points, ++tags, --points count) {
      ++c;
      char tag = *tags;
      if (first) {
         assert(tag & 0x1);
         assert(c==1); c=0;
         segments[segments_count++] = VG_MOVE_TO;
         first = 0;
      } else if (tag & 0x1) {
         /* on curve */
         if (last tag & 0x1) {
            /* last point was also on -- line */
            assert(c==1); c=0;
            segments[segments count++] = VG LINE TO;
         } else {
            /* last point was off -- quad or cubic */
            if (last tag & 0x2) {
               /* cubic */
               assert(c==3); c=0;
               segments[segments count++] = VG CUBIC TO;
            } else {
               /* quad */
               assert(c==2); c=0;
               segments[segments_count++] = VG_QUAD_TO;
            }
      } else {
         /* off curve */
         if (tag & 0x2) {
            /* cubic */
            assert((last_tag & 0x1) || (last_tag & 0x2)); /* last either on or off and cubic */
         } else {
            /* quad */
```

```
if (!(last tag & 0x1)) {
               /* last was also off curve */
               assert(!(last tag & 0x2)); /* must be quad */
               /* add on point half-way between */
               assert(c==2); c=1;
               segments[segments count++] = VG QUAD TO;
               VGfloat x = (coords[coords count - 2] + float from 26 6(points->x)) * 0.5f;
               VGfloat y = (coords[coords_count - 1] + float_from_26_6(points->y)) * 0.5f;
               coords[coords count++] = x;
               coords[coords count++] = y;
         }
     last_tag = tag;
     coords[coords count++] = float from 26 6(points->x);
     coords[coords_count++] = float_from_26_6(points->y);
   }
   if (last_tag & 0x1) {
     /* last point was also on -- line (implicit with close path) */
     assert(c==0);
   } else {
     ++c;
     /* last point was off -- quad or cubic */
     if (last tag & 0x2) {
         /* cubic */
         assert(c==3); c=0;
         segments[segments count++] = VG CUBIC TO;
     } else {
         /* quad */
         assert(c==2); c=0;
         segments[segments count++] = VG QUAD TO;
     coords[coords count++] = coords[first coords + 0];
     coords[coords count++] = coords[first coords + 1];
   segments[segments count++] = VG CLOSE PATH;
}
static void convert outline(const FT Vector *points,
                            const char *tags, const short *contours,
                            short contours count, short points count)
{
   segments_count = 0;
   coords count = 0;
```

```
short last_contour = 0;
for (; contours_count != 0; ++contours, --contours_count) {
    short contour = *contours + 1;
    convert_contour(points + last_contour, tags + last_contour, contour - last_contour);
    last_contour = contour;
}
assert(last_contour == points_count);
assert(segments_count <= SEGMENTS_COUNT_MAX); /* oops... we overwrote some me
mory */
    assert(coords_count <= COORDS_COUNT_MAX);
}</pre>
```

These functions are used to set segments and coordinates suitable for adding to an OpenVG path created using vgCreatePath with vgAppendPath. The resultant path can then be drawn with vgDrawpath.

```
FT Outline *outline = &ft face->glyph->outline;
if (outline->n contours != 0) {
   vg_path = vgCreatePath(VG_PATH_FORMAT_STANDARD,
                          VG PATH DATATYPE F, 1.0f,
                          o.of, o, o, VG PATH CAPABILITY ALL);
   assert(vg_path != VG_INVALID_HANDLE);
   convert outline(outline->points, outline->tags,
                   outline->contours, outline->n contours,
                   outline->n points);
   vgAppendPathData(vg path, segments count, segments, coords);
} else {
   vg path = VG INVALID HANDLE;
VGfloat strokeColor[4] = {0.4, 0.1, 1.0, 1.0}; // purple
VGfloat fillColor[4] = {1.0, 1.0, 0.0, 1.0}; // yellow
setfill(fillColor);
setstroke(strokeColor, 5);
vgDrawPath(vg path, VG FILL PATH | VG STROKE PATH);
```

It looks like this:



The complete program is text-outline.c.

Drawing a FreeType Bitmap

In an earlier section, you derived an FT_Bitmap for a glyph. The bitmap contains fields for the stride (which it calls *pitch*), width, and height, plus a buffer of data. The format is grayscale with 256 levels. What this becomes in OpenVG I'm not sure. VG sL 8 seems to work OK for me, while omxplayer uses VG A 8.

The only real wrinkle is that the bitmap image is upside down in OpenVG coordinates. So, you can't just use vgCreateImage because that draws the bitmap upside down. Instead, you have to add the data to a VGImage using vgImageSubData. The program omxplayer uses a neat trick to insert the data upside down. While vgImageSubData expects to load data from bottom to top, increasing the stride by one each time, you hand the data in from the top, decreasing the stride each time.

The image is drawn using vgSetPixels to set the location on the screen. The relevant code is as follows:

```
FT Glyph glyph;
FT Get Glyph(ft face->glyph, &glyph);
FT Stroker ft stroker;
FT Stroker New(ft library, &ft stroker);
FT Stroker_Set(ft_stroker,
               200, // line height *border thickness*64.0f,
               FT STROKER LINECAP ROUND,
               FT STROKER LINEJOIN ROUND,
               0);
FT Glyph StrokeBorder(&glyph, ft stroker, 0, 1);
FT Glyph To Bitmap(&glyph, FT RENDER MODE NORMAL, NULL, 1);
FT BitmapGlyph bit glyph = (FT BitmapGlyph) glyph;
FT Bitmap bitmap = bit glyph->bitmap;
printf("Bitmap mode is %d (2 is gray) with %d levels\n",
       bitmap.pixel mode, bitmap.num grays);
int tex s = bitmap.pitch;
int tex w = bitmap.width;
int tex h = bitmap.rows;
VGImage image = vgCreateImage(VG sL 8, tex w, tex h,
                              VG IMAGE QUALITY NONANTIALIASED);
// invert bitmap image
vgImageSubData(image,
               bitmap.buffer + tex_s*(tex_h-1),
               VG sL 8, //VG A 8, VG sL 8 seem to be okay too
               0, 0, tex w, tex h);
vgSetPixels(600, 600, image, 0, 0, tex w, tex h);
```

The complete program is text-bitmap.c, and it looks like this:



There is no border or color control.

VGFonts and Multiple Characters

If you want to draw multiple characters, you need to get multiple outline paths or bitmaps from FreeType and convert them. If characters are repeated or drawn multiple times, then this can lead to redundant processing. OpenVG has a type called VGFont, which can essentially act as a cache for the paths and bitmaps, so that you load each one into the font and then can draw them multiple times without having to repeat the loading process.

A font is created using vgCreateFont, which takes a parameter for the expected size or 0. Paths are added to a font with vgSetGlyphToPath, while bitmaps are added using vgSetGlyphToImage. These take as parameters the font, the index used for the glyph, the path or image, and two other parameters describing the geometry of the path/image. These are discussed next.

VGDrawGlyph

There is then a bonus function: instead of extracting the path or image from the font and then drawing it, the function vgDrawGlyph will perform the drawing for you, stroking or filling the path as required, as follows:

Where it draws the path/image depends on the value of the parameter VG_GLYPH_ORIGIN . This is initially set to an (x, y) location, as follows:

```
VGfloat origin[2] = {300.0f, 300.0f};
vgSetfv(VG_GLYPH_ORIGIN, 2, origin);
```

Each time a glyph is drawn, this location is updated by the width and height of the glyph so that successive glyphs are drawn next to each other.

A pseudo-code algorithm for drawing a string is as follows:

```
for each ch in the string
  if ch is not in the font
  then
    add the glyph to the font, using ch as index
  draw the glyph using ch as index
```

There is only one glitch in this: there is no way of telling whether a glyph is in the font! If you are just adding a small set of glyphs such as the ASCII characters, this is not a problem: just loop through them all adding each one. But if it is a large set, such as the 120,000+ Unicode characters, then you won't want to do that. Instead, you would like to add them on an as-needed basis, say, as you loop through a piece of text.

To avoid repeated additions of a character, you need to keep a list *outside* of OpenVG. I used the hash table from GLib: add it to the hash table when first seen and add it the font, but do not add it if it's already there. The code to add an outline glyph is as follows:

```
void add glyph(int *ch) {
    if (g hash_table_lookup(glyphs_seen, GINT_TO_POINTER(ch)) != NULL) {
        printf("Glyph %d already seen\n", *ch);
        return;
   g_hash_table_insert(glyphs_seen,
                        GINT TO POINTER(ch),
                        GINT TO_POINTER(ch));
    printf("Inserting %d\n", *ch);
    int glyph index = FT Get Char Index(ft face, *ch);
    if (glyph index == 0) printf("No glyph found\n");
    FT Load Glyph(ft face, glyph index,
                  FT LOAD NO HINTING | FT LOAD LINEAR DESIGN);
   VGPath vg path;
   FT Outline *outline = &ft face->glyph->outline;
    if (outline->n contours != 0) {
        vg_path = vgCreatePath(VG PATH FORMAT STANDARD,
                               VG PATH DATATYPE F, 1.0f,
                               o.of, o, o, VG PATH CAPABILITY ALL);
        assert(vg path != VG INVALID HANDLE);
        convert outline(outline->points, outline->tags,
                        outline->contours, outline->n contours,
                        outline->n points);
        vgAppendPathData(vg path, segments count, segments, coords);
    } else {
        vg_path = VG_INVALID_HANDLE;
```

```
VGfloat glyphOrigin[2] = {0.0f, 0.0f};
    printf("Width %d, height %d advance %d\n",
           ft face->glyph->metrics.width,
           ft_face->glyph->metrics.height,
           ft face->glyph->linearHoriAdvance);
    VGfloat escapement[2] = {ft face->glyph->linearHoriAdvance,
                             0.0f};
    vgSetGlyphToPath(font, *ch,
                     vg path, 0,
                     glyphOrigin,
                     escapement);
}
    You can then draw a set of glyphs as follows:
void draw() {
    EGL DISPMANX WINDOW T nativewindow;
    glyphs_seen = g_hash_table_new(g_int_hash, g_int_equal);
    init egl(p state);
    init dispmanx(&nativewindow);
 "/usr/share/fonts/truetype/droid/DroidSansFallbackFull.ttf",
    egl from dispmanx(p state, &nativewindow);
    vgClear(0, 0, 1920, 1080);
    ft init();
    font = vgCreateFont(0);
    //font_border = vgCreateFont(0);
    VGfloat strokeColor[4] = {0.4, 0.1, 1.0, 1.0}; // purple
    VGfloat fillColor[4] = {1.0, 1.0, 0.0, 1.0}; // yellowish
    setfill(fillColor);
    setstroke(strokeColor, 5);
    VGfloat origin[2] = {300.0f, 300.0f};
    vgSetfv(VG_GLYPH_ORIGIN, 2, origin);
    int ch;
    ch = 0x597d;
    add glyph(&ch);
    vgDrawGlyph(font, ch,
                VG_STROKE PATH,
                VG FALSE);
    ch = 'A';
    add glyph(&ch);
```

```
vgDrawGlyph(font, ch,
                VG STROKE PATH,
                VG FALSE);
    ch = 'b';
   add glyph(&ch);
    vgDrawGlyph(font, ch,
                VG STROKE PATH | VG FILL PATH,
                VG FALSE);
    ch = 'g';
    add_glyph(&ch);
    vgDrawGlyph(font, ch,
                VG_STROKE_PATH | VG_FILL_PATH,
                VG FALSE);
    ch = 'b';
    add_glyph(&ch);
   vgDrawGlyph(font, ch,
                VG STROKE PATH,
                VG FALSE);
   vgFlush();
   eglSwapBuffers(p state->display, p_state->surface);
}
```

with appearance



The complete program is text-font.c.

vgDrawGlyphs

In the previous example, you drew some glyphs filled and some in outline only. You could have made other changes too, such as different color fills. However, if *all* the characters are to be drawn using the same parameters, then the convenience function vgDrawGlyphs can be used.

Glyph Metrics

The geometry of a glyph is complex, and I have ignored it so far. For FreeType, the geometry is discussed in the tutorial "Managing Glyphs" at www.freetype.org/freetype2/docs/tutorial/step2.html. The metrics are accessible from the structure face->glyph->metrics and are as follows:

width: This is the width of the glyph image's bounding box. It is independent of the layout direction.

height: This is the height of the glyph image's bounding box. It is independent of the layout direction. Be careful not to confuse it with the height field in the FT Size Metrics structure.

horiBearingX: For horizontal text layouts, this is the horizontal distance from the current cursor position to the leftmost border of the glyph image's bounding box.

horiBearingY: For horizontal text layouts, this is the vertical distance from the current cursor position (on the baseline) to the topmost border of the glyph image's bounding box.


horiAdvance: For horizontal text layouts, this is the horizontal distance to increment the pen position when the glyph is drawn as part of a string of text.

vertBearingX: For vertical text layouts, this is the horizontal distance from the current cursor position to the leftmost border of the glyph image's bounding box.


vertBearingY: For vertical text layouts, this is the vertical distance from the current cursor position (on the baseline) to the topmost border of the glyph image's bounding box.

vertAdvance: For vertical text layouts, this is the vertical distance used to increment the pen position when the glyph is drawn as part of a string of text.

For horizontal layout,



OpenVG does not seem to go into so much detail. The only diagram that is shown is as follows:



When adding a glyph to a font, only the glyph origin and the escapement are set, each as an (x, y) vector. The best values seem to be as follows:

Conclusion

This chapter has looked at a number of different ways of drawing text using OpenVG. There are trade-offs between ease of use and utilizing the GPU.

Resources

- Text in Cairo: http://zetcode.com/gfx/cairo/cairotext/
- Pango Text Attribute Markup Language: https://developer.gnome.org/pango/ stable/PangoMarkupFormat.html

CHAPTER 19



OpenMAX is concerned with displaying images and videos. Both OpenGL ES and OpenVG are concerned with drawing shapes in various ways. Subtitles are systems where dynamic text is drawn on top of images, static or dynamic. This chapter investigates issues in displaying overlays from one system on top of another on the Raspberry Pi.

Introduction

In Chapter 15, you considered drawing OpenMAX images/videos on top of an OpenGL ES surface. In this chapter, you'll consider the converse problem of using an OpenMAX surface and drawing on top of *that* surface.

Drawing OpenMAX onto an OpenGL ES surface required the use of a special function eglCreateImageKHR to link a Dispmanx OpenGL ES surface to an EGLImage that OpenMAX draws into. The converse is simpler.

- 1. Create and render OpenMAX images/videos.
- 2. Create and draw into OpenGL ES/OpenVG surfaces.

For this to work, the GPU must place the OpenMAX surface under the OpenGL ES/OpenVG surface so that drawing into OpenGL ES/OpenVG is drawing into an overlay.

While this allows basic overlays, drawing text adds a substantial layer of complexity. Text is *extremely* complex, even in English, and adding additional languages with their own wrinkles (such as Chinese hieroglyphics or Arabic right-to-left writing) makes this an area where you do *not* want to roll your own solutions. The principal library to manage this currently seems to be Pango built on top of Cairo, so this is investigated in this chapter.

Dispmanx Layers

To ensure that the OpenGL ES/OpenVG surface is drawn on top of the OpenMAX surface, they must be placed in different *layers*. The layer is controlled at the Dispmanx level in the function described in /opt/vc/include/interface/vmcs host/vc dispmanx.h.

© Jan Newmarch 2017 375

```
VC_DISPMANX_ALPHA_T *alpha,
DISPMANX_CLAMP_T *clamp,
DISPMANX_TRANSFORM_T transform );
```

The default for OpenMAX appears to be layer 0. For the overlays in this chapter, you will choose layer 1. In OpenGL ES, you used the utilities from the *OpenGL ES 2.0 Programming Guide* by Aaftab Munshi, Dan Ginsburg, and Dave Shreiner. This creates the Dispmanx window at layer 0 in esUtils.h. This needs to be modified for the OpenGL ES examples discussed here, to set the Dispmanx window at layer 1.

Drawing OpenGL ESon Top of an OpenMAX Image

In Chapter 6, I discussed the program Hello Triangle.c, which draws a triangle into an OpenGL ES surface. In Chapter 12, I showed a program in the section "Rendering an Image Using Tunneling" to render an image using OpenMAX.

Drawing a triangle on top of the image is surprisingly easy: just combine the two sets of code, using the change to the layer of the OpenGL ES Dispmanx window above. With minor adjustments to the two sets of code, the program is il render image gles overlay.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <assert.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <bcm host.h>
#include <ilclient.h>
#include "esUtil.h"
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
```

```
EGL_STATE_T state, *p_state = &state;
typedef struct
   // Handle to a program object
  GLuint programObject;
} UserData;
111
// Create a shader object, load the shader source, and
// compile the shader.
//
GLuint LoadShader ( GLenum type, const char *shaderSrc )
  GLuint shader;
  GLint compiled;
   // Create the shader object
   shader = glCreateShader ( type );
   if ( shader == 0 )
       return 0;
   // Load the shader source
   glShaderSource ( shader, 1, &shaderSrc, NULL );
   // Compile the shader
   glCompileShader ( shader );
   // Check the compile status
   glGetShaderiv ( shader, GL COMPILE STATUS, &compiled );
   if (!compiled)
      GLint infoLen = 0;
      glGetShaderiv ( shader, GL INFO LOG LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetShaderInfoLog ( shader, infoLen, NULL, infoLog );
         esLogMessage ( "Error compiling shader:\n%s\n", infoLog );
         free ( infoLog );
      glDeleteShader ( shader );
     return 0;
   }
```

```
return shader;
}
///
// Initialize the shader and program object
int Init ( ESContext *esContext )
{
   esContext->userData = malloc(sizeof(UserData));
   UserData *userData = esContext->userData;
   GLbyte vShaderStr[] =
      "attribute vec4 vPosition;
                                     \n"
      "void main()
                                     \n"
      "{
                                     \n"
          gl Position = vPosition;
                                    \n"
                                     \n";
   GLbyte fShaderStr[] =
      "precision mediump float;\n"\
      "void main()
                                                     \n"
      "{
         gl_FragColor = vec4 ( 1.0, 0.0, 0.0, 0.0 );\n"
   GLuint vertexShader;
   GLuint fragmentShader;
   GLuint programObject;
   GLint linked;
   // Load the vertex/fragment shaders
   vertexShader = LoadShader ( GL VERTEX SHADER, vShaderStr );
   fragmentShader = LoadShader ( GL_FRAGMENT_SHADER, fShaderStr );
   // Create the program object
   programObject = glCreateProgram ( );
   if ( programObject == 0 )
      return 0;
   glAttachShader ( programObject, vertexShader );
   glAttachShader ( programObject, fragmentShader );
   // Bind vPosition to attribute 0
   glBindAttribLocation ( programObject, 0, "vPosition" );
   // Link the program
   glLinkProgram ( programObject );
   // Check the link status
   glGetProgramiv ( programObject, GL_LINK_STATUS, &linked );
```

```
if (!linked)
     GLint infoLen = 0;
     glGetProgramiv ( programObject, GL_INFO_LOG_LENGTH, &infoLen );
     if (infoLen > 1)
        char* infoLog = malloc (sizeof(char) * infoLen );
        glGetProgramInfoLog ( programObject, infoLen, NULL, infoLog );
        esLogMessage ( "Error linking program:\n%s\n", infoLog );
        free ( infoLog );
     }
     glDeleteProgram ( programObject );
     return GL FALSE;
   }
   // Store the program object
   userData->programObject = programObject;
  glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
  return GL TRUE;
}
///
// Draw a triangle using the shader pair created in Init()
float incr = 0.0f;
void Draw ( ESContext *esContext )
  UserData *userData = esContext->userData;
  GLfloat vVertices[] = { 0.0f-incr, 0.5f-incr, 0.0f+incr,
                           -0.5f, -0.5f, 0.0f,
                           0.5f, -0.5f, 0.0f };
  incr += 0.01f;
   // Set the viewport
  glViewport ( 0, 0, esContext->width, esContext->height );
  // Clear the color buffer
  glClear ( GL COLOR BUFFER BIT );
  // Use the program object
  glUseProgram ( userData->programObject );
   // Load the vertex data
  glVertexAttribPointer ( 0, 3, GL FLOAT, GL FALSE, 0, vVertices );
  glEnableVertexAttribArray ( 0 );
```

```
glDrawArrays ( GL_TRIANGLES, 0, 3 );
}
#define IMG "cimg0135.jpg"
//#define IMG "hype.jpg"
void printState(OMX_HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "error elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
            perror("Stat'ing img file");
            return -1;
    return(st.st size);
}
unsigned int uWidth;
unsigned int uHeight;
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                          COMPONENT_T *component,
                                          OMX BUFFERHEADERTYPE *buff header,
                                          int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff_size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    }
```

```
r = OMX_EmptyThisBuffer(ilclient_get_handle(component),
                        buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    return r;
}
static void set image decoder input format(COMPONENT T *component) {
   // set input image format
   printf("Setting image decoder format\n");
   OMX IMAGE PARAM PORTFORMATTYPE imagePortFormat;
    //setHeader(&imagePortFormat, sizeof(OMX IMAGE PARAM PORTFORMATTYPE));
    memset(&imagePortFormat, 0, sizeof(OMX IMAGE PARAM PORTFORMATTYPE));
    imagePortFormat.nSize = sizeof(OMX IMAGE PARAM PORTFORMATTYPE);
    imagePortFormat.nVersion.nVersion = OMX VERSION;
    imagePortFormat.nPortIndex = 320;
    imagePortFormat.eCompressionFormat = OMX IMAGE CodingJPEG;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamImagePortFormat, &imagePortFormat);
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT_T **decodeComponent) {
    int err;
   err = ilclient_create_component(handle,
                                decodeComponent,
                                decodeComponentName,
                                ILCLIENT_DISABLE_ALL_PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT ENABLE OUTPUT BUFFERS
                                    */
                                );
    if (err == -1) {
       fprintf(stderr, "DecodeComponent create failed\n");
       exit(1);
    printState(ilclient_get_handle(*decodeComponent));
   err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
       exit(1);
    }
```

```
printState(ilclient_get_handle(*decodeComponent));
    // must be before we enable buffers
    set_image_decoder_input_format(*decodeComponent);
}
void setup_renderComponent(ILCLIENT_T *handle,
                              char *renderComponentName,
                              COMPONENT T **renderComponent) {
    int err;
   err = ilclient create component(handle,
                                renderComponent,
                                renderComponentName,
                                ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
void overlay gles() {
    ESContext esContext;
    UserData userData;
    //sleep(5);
    esInitContext ( &esContext );
    esContext.userData = &userData;
    esCreateWindow ( &esContext, "Hello Triangle", 1920, 1080, ES WINDOW RGB );
    if (!Init ( &esContext ) )
        return 0;
    esRegisterDrawFunc ( &esContext, Draw );
```

```
esMainLoop ( &esContext );
}
draw openmax image() {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    ILCLIENT T *handle;
    COMPONENT T *decodeComponent;
    COMPONENT T *renderComponent;
    FILE *fp = fopen(IMG, "r");
    int toread = get file size(IMG);
    OMX BUFFERHEADERTYPE *buff header;
    decodeComponentName = "image decode";
    renderComponentName = "video render";
    //sleep(5);
    bcm_host_init();
    handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
   if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
   ilclient set error callback(handle,
                               error_callback,
                               NULL);
   ilclient set eos callback(handle,
                             eos callback,
                             NULL);
   setup decodeComponent(handle, decodeComponentName, &decodeComponent);
   setup renderComponent(handle, renderComponentName, &renderComponent);
   // both components now in Idle state, no buffers, ports disabled
    // input port
    ilclient enable port buffers(decodeComponent, 320,
                                 NULL, NULL, NULL);
    ilclient enable port(decodeComponent, 320);
```

```
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
printState(ilclient_get_handle(decodeComponent));
// Read the first block so that the decodeComponent can get
// the dimensions of the image and call port settings
// changed on the output port to configure it
buff header =
    ilclient get input buffer(decodeComponent,
                              1 /* block */);
if (buff header != NULL) {
    read into buffer and empty(fp,
                               decodeComponent,
                               buff header,
                               &toread);
    // If all the file has been read in, then
    // we have to re-read this first block.
    // Broadcom bug?
    if (toread <= 0) {
        printf("Rewinding\n");
        // wind back to start and repeat
        fp = freopen(IMG, "r", fp);
        toread = get file size(IMG);
    }
}
// wait for first input block to set params for output port
err = ilclient_wait_for_event(decodeComponent,
                        OMX_EventPortSettingsChanged,
                        321, 0, 0, 1,
                        ILCLIENT_EVENT_ERROR | ILCLIENT_PARAMETER_CHANGED,
                        5);
if (err < 0) {
    fprintf(stderr, "No port settings changed\n");
printf("Port settings changed\n");
TUNNEL T tunnel;
set tunnel(&tunnel, decodeComponent, 321, renderComponent, 90);
if ((err = ilclient_setup_tunnel(&tunnel, 0, 0)) < 0) {</pre>
    fprintf(stderr, "Error setting up tunnel %X\n", err);
    exit(1);
} else {
   printf("Tunnel set up ok\n");
}
```


```
// enable the decode output ports
  OMX_SendCommand(ilclient_get_handle(decodeComponent),
                   OMX CommandPortEnable, 321, NULL);
   ilclient_enable_port(decodeComponent, 321);
   // enable the render output ports
   OMX SendCommand(ilclient get handle(renderComponent),
                   OMX CommandPortEnable, 90, NULL);
   */
   ilclient enable port(renderComponent, 90);
   // set both components to executing state
   err = ilclient change component state(decodeComponent,
                                          OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
   err = ilclient change component state(renderComponent,
                                          OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    // now work through the file
   while (toread > 0) {
        OMX ERRORTYPE r;
        // do we have a decode input buffer we can fill and empty?
        buff header =
            ilclient get input buffer(decodeComponent,
                                      320,
                                      1 /* block */);
        if (buff header != NULL) {
            read_into_buffer_and_empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        }
    ilclient wait for event(renderComponent,
                            OMX EventBufferFlag,
                            90, 0, OMX_BUFFERFLAG_EOS, 0,
                            ILCLIENT BUFFER FLAG EOS, 10000);
   printf("EOS on render\n");
}
```

// Okay to go back to processing data

```
int main(int argc, char** argv) {
    draw_openmax_image();
    overlay_gles();
    exit(0);
}
```

One of the changes is to let the coordinates of one of the triangle vertices change on each draw. The triangle acts as an overlay, with the image behind preserved on each change. I don't see how to make the overlay OpenGL ES surface transparent at all, though.

It looks like this:



The commands I used to build this (with considerable redundancy!) are as follows:

cc -g -Wall -pthread -I/usr/include/gtk-3.0 -I/usr/include/atk-1.0 -I/usr/include/at-spi2-atk/2.0 -I/usr/include/pango-1.0 -I/usr/include/gio-unix-2.0/ -I/usr/include/cairo -I/usr/include/gdk-pixbuf-2.0 -I/usr/include/glib-2.0 -I/usr/lib/arm-linux-gnueabihf/glib-2.0/include -I/usr/include/harfbuzz -I/usr/include/freetype2 -I/usr/include/pixman-1 -I/usr/include/libpng12 -I../../openGLES/Common/ -DSTANDALONE -D__STDC_CONSTANT_MACROS -D__STDC_LIMIT_MACROS -DTARGET_POSIX -D_LINUX -fPIC -DPIC -D_REENTRANT -D_LARGEFILE64_SOURCE -D_FILE_OFFSET_BITS=64 -U_FORTIFY_SOURCE -Wall -g -DHAVE_LIBOPENMAX=2 -DOMX -DOMX_SKIP64BIT -ftree-vectorize -pipe -DUSE_EXTERNAL_OMX -DHAVE_LIBBCM_HOST -DUSE_EXTERNAL_LIBBCM_HOST -DUSE_VCHIQ_ARM -Wno-psabi -I/opt/vc/include/ -I /opt/vc/include/IL -I/opt/vc/include/interface/vcos/pthreads -I/opt/vc/include/interface/vcos/ -I/opt/vc/include/interface/vmcs_host/linux -I./ -I/opt/vc/src/hello_pi/libs/ilclient -I/opt/vc/src/hello_pi/libs/vgfont -I/opt/vc/src/hello_pi/libs/ilclient -DRASPBERRY_PI -c -o il_render_image_gles_overlay.o il render image_gles_overlay.c

```
cc il_render_image_gles_overlay.o ../openGLES/Common/esUtil.o ../openGLES/Common/esTransform.o ../openGLES/Common/esShader.o ../openGLES/Common/esShapes.o -Wl,--whole-archive -lilclient -L/opt/vc/lib/ -lopenmaxil -lbcm_host -lvcos -lvchiq_arm -lpthread -lrt -L/opt/vc/src/hello_pi/libs/ilclient -L/opt/vc/src/hello_pi/libs/vgfont -Wl,--no-whole-archive -rdynamic -lavutil -lavcodec -lavformat -lavresample -lEGL -lGLESv2 -lm -lgtk-3 -lgdk-3 -latk-1.0 -lgio-2.0 -lpangocairo-1.0 -lgdk_pixbuf-2.0 -lcairo-gobject -lpango-1.0 -lcairo -lgobject-2.0 -lglib-2.0 -o il render image gles overlay
```

Drawing OpenGL ES on Top of an OpenMAX Video

The same basic techniques are applied to overlaying on top of a video, with the relatively minor complexity that both the video and the OpenGL ES rendering take place at the same time, requiring the use of threads. You can take il_render_video.c from Chapter 13 and combine this with the Hello Triangle.c program. You can place the Hello Triangle.c code in its own pthread, to run asynchronously with OpenMAX running in the main thread. It could be the other way around, of course.

The resulting program is il_render_video_gles_overlay.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <bcm host.h>
#include <ilclient.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include "esUtil.h"
#define IMG "/opt/vc/src/hello pi/hello video/test.h264"
pthread t tid;
typedef struct
    EGLDisplay display;
   EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL STATE T;
EGL_STATE_T state, *p_state = &state;
typedef struct
```

```
// Handle to a program object
   GLuint programObject;
} UserData;
///
// Create a shader object, load the shader source, and
// compile the shader.
GLuint LoadShader ( GLenum type, const char *shaderSrc )
{
   GLuint shader;
   GLint compiled;
   // Create the shader object
   shader = glCreateShader ( type );
   if ( shader == 0 )
        return 0;
   // Load the shader source
   glShaderSource ( shader, 1, &shaderSrc, NULL );
   // Compile the shader
   glCompileShader ( shader );
   // Check the compile status
   glGetShaderiv ( shader, GL_COMPILE_STATUS, &compiled );
   if (!compiled)
     GLint infoLen = 0;
      glGetShaderiv ( shader, GL_INFO_LOG_LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetShaderInfoLog ( shader, infoLen, NULL, infoLog );
         esLogMessage ( "Error compiling shader:\n%s\n", infoLog );
         free ( infoLog );
      }
      glDeleteShader ( shader );
      return 0;
   }
   return shader;
}
```

```
111
// Initialize the shader and program object
int Init ( ESContext *esContext )
  esContext->userData = malloc(sizeof(UserData));
  UserData *userData = esContext->userData;
   GLbyte vShaderStr[] =
      "attribute vec4 vPosition;
                                    \n"
     "void main()
                                    \n"
         gl_Position = vPosition; \n"
     "}
                                    \n";
   GLbyte fShaderStr[] =
      "precision mediump float;\n"\
      "void main()
                                                     \n"
                                                     \n"
       gl FragColor = vec4 ( 1.0, 0.0, 0.0, 0.0 );\n"
  GLuint vertexShader;
  GLuint fragmentShader;
  GLuint programObject;
  GLint linked;
   // Load the vertex/fragment shaders
   vertexShader = LoadShader ( GL VERTEX SHADER, vShaderStr );
   fragmentShader = LoadShader ( GL FRAGMENT SHADER, fShaderStr );
   // Create the program object
   programObject = glCreateProgram ( );
   if ( programObject == 0 )
     return 0;
   glAttachShader ( programObject, vertexShader );
  glAttachShader ( programObject, fragmentShader );
   // Bind vPosition to attribute 0
  glBindAttribLocation ( programObject, 0, "vPosition" );
   // Link the program
  glLinkProgram ( programObject );
   // Check the link status
  glGetProgramiv ( programObject, GL LINK STATUS, &linked );
   if (!linked)
     GLint infoLen = 0;
```

```
glGetProgramiv ( programObject, GL_INFO_LOG_LENGTH, &infoLen );
      if (infoLen > 1)
         char* infoLog = malloc (sizeof(char) * infoLen );
         glGetProgramInfoLog ( programObject, infoLen, NULL, infoLog );
         esLogMessage ( "Error linking program:\n%s\n", infoLog );
         free ( infoLog );
      }
      glDeleteProgram ( programObject );
      return GL FALSE;
   }
   // Store the program object
   userData->programObject = programObject;
   glClearColor ( 0.0f, 0.0f, 0.0f, 0.0f);
   return GL TRUE;
}
///
// Draw a triangle using the shader pair created in Init()
float incr = 0.0f;
void Draw ( ESContext *esContext )
{
   UserData *userData = esContext->userData;
   GLfloat vVertices[] = { 0.0f-incr, 0.5f-incr, 0.0f+incr,
                           -0.5f, -0.5f, 0.0f,
                            0.5f, -0.5f, 0.0f };
   incr += 0.01f;
   // Set the viewport
   glViewport ( 0, 0, esContext->width, esContext->height );
   // Clear the color buffer
   glClear ( GL_COLOR_BUFFER_BIT );
   // Use the program object
   glUseProgram ( userData->programObject );
   // Load the vertex data
   glVertexAttribPointer ( 0, 3, GL_FLOAT, GL_FALSE, 0, vVertices );
   glEnableVertexAttribArray ( 0 );
   glDrawArrays ( GL_TRIANGLES, 0, 3 );
}
```

```
void printState(OMX_HANDLETYPE handle) {
    // elided
char *err2str(int err) {
    return "error elided";
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing img file");
        return -1;
    return(st.st_size);
}
unsigned int uWidth;
unsigned int uHeight;
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX_ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff_header->pBuffer, 1, buff_size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
    printf("Read %d, %d still left\n", nread, *toread);
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff header->nFlags |= OMX BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    if (r != OMX_ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
```

```
}
    return r;
}
static void set video decoder input format(COMPONENT T *component) {
    int err;
    // set input video format
    printf("Setting video decoder format\n");
    OMX_VIDEO_PARAM_PORTFORMATTYPE videoPortFormat;
    memset(&videoPortFormat, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    videoPortFormat.nSize = sizeof(OMX_VIDEO_PARAM_PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
    videoPortFormat.nPortIndex = 130;
    videoPortFormat.eCompressionFormat = OMX VIDEO CodingAVC;
    err = OMX_SetParameter(ilclient_get_handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error setting video decoder format %s\n", err2str(err));
        return err;
    } else {
        printf("Video decoder format set up ok\n");
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
    err = ilclient create component(handle,
                                    decodeComponent,
                                    decodeComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT_ENABLE_INPUT_BUFFERS
                                    ILCLIENT ENABLE OUTPUT BUFFERS
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    err = ilclient_change_component_state(*decodeComponent,
                                          OMX StateIdle);
```

```
if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set video decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient_create_component(handle,
                                    renderComponent,
                                    renderComponentName,
                                    ILCLIENT_DISABLE_ALL_PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
void *overlay gles(void *args) {
    ESContext esContext;
    UserData userData;
    //sleep(10);
    esInitContext ( &esContext );
    esContext.userData = &userData;
    esCreateWindow ( &esContext, "Hello Triangle", 1920, 1080, ES WINDOW RGB );
    if ( !Init ( &esContext ) )
        return 0;
```


```
esRegisterDrawFunc ( &esContext, Draw );
   esMainLoop ( &esContext );
}
void draw openmax video(int argc, char** argv) {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    ILCLIENT_T *handle;
    COMPONENT T *decodeComponent;
    COMPONENT_T *renderComponent;
    FILE *fp; // = fopen(IMG, "r");
    int toread = get file size(IMG);
    OMX_BUFFERHEADERTYPE *buff_header;
    decodeComponentName = "video decode";
    renderComponentName = "video render";
    bcm host init();
    if (argc > 1) {
        fp = fopen(argv[1], "r");
    } else {
        fp =fopen(IMG, "r");
    if (fp == NULL) {
        fprintf(stderr, "Can't open file\n");
        exit(1);
    }
    handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
    if (OMX Init() != OMX ErrorNone) {
        ilclient_destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient set error callback(handle,
                                error_callback,
                                NULL);
    ilclient set eos callback(handle,
                              eos_callback,
                              NULL);
```

```
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
ilclient_enable_port_buffers(decodeComponent, 130,
                             NULL, NULL, NULL);
ilclient enable port(decodeComponent, 130);
err = ilclient_change_component_state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(decodeComponent));
// Read the first block so that the decodeComponent can get
// the dimensions of the video and call port settings
// changed on the output port to configure it
while (toread > 0) {
    buff header =
        ilclient get input buffer(decodeComponent,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            fp = freopen(IMG, "r", fp);
            toread = get_file_size(IMG);
        }
    }
    if (toread > 0 && ilclient_remove_event(decodeComponent,
                                            OMX EventPortSettingsChanged,
                                            131, 0, 0, 1) == 0) {
        printf("Removed port settings event\n");
        break;
    } else {
        printf("No portr settting seen yet\n");
```

```
// wait for first input block to set params for output port
    if (toread == 0) {
        // wait for first input block to set params for output port
        err = ilclient_wait_for_event(decodeComponent,
                                     OMX EventPortSettingsChanged,
                                     131, 0, 0, 1,
                                     ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                     2000);
        if (err < 0) {
            fprintf(stderr, "No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            break;
        }
    }
}
// set up the tunnel between decode and render ports
TUNNEL T tunnel;
set tunnel(&tunnel, decodeComponent, 131, renderComponent, 90);
if ((err = ilclient_setup_tunnel(&tunnel, 0, 0)) < 0) {</pre>
    fprintf(stderr, "Error setting up tunnel %X\n", err);
    exit(1);
} else {
    printf("Tunnel set up ok\n");
// Okay to go back to processing data
// enable the decode output ports
OMX SendCommand(ilclient get handle(decodeComponent),
                OMX CommandPortEnable, 131, NULL);
ilclient enable port(decodeComponent, 131);
// enable the render output ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX CommandPortEnable, 90, NULL);
ilclient enable port(renderComponent, 90);
// set both components to executing state
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
```

```
if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    err = ilclient_change_component_state(renderComponent,
                                           OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    }
    // now work through the file
    while (toread > 0) {
        OMX ERRORTYPE r;
        // do we have a decode input buffer we can fill and empty?
        buff header =
            ilclient get input buffer(decodeComponent,
                                       1 /* block */);
        if (buff header != NULL) {
            read_into_buffer_and_empty(fp,
                                        decodeComponent,
                                        buff header,
                                        &toread);
        }
    }
    ilclient wait for event(renderComponent,
                            OMX EventBufferFlag,
                            90, 0, OMX BUFFERFLAG EOS, 0,
                            ILCLIENT BUFFER FLAG EOS, 10000);
    printf("EOS on render\n");
}
int main(int argc, char** argv) {
    pthread create(&tid, NULL, overlay gles, NULL);
    draw openmax video(argc, argv);
    exit(0);
}
```

A snapshot (taken using raspi2png) is shown here:



Drawing OpenVG on Top of an OpenMAX Image

The same principle holds for drawing OpenVG rather than OpenGL ES overlaid on top of an OpenMAX image. You create a Dispmanx layer above the OpenMAX layer and draw into each. A program to draw an ellipse on top of an image is il render image vg overlay.c, as shown here:

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <assert.h>
#include <OMX Core.h>
#include <OMX Component.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
#include <bcm host.h>
#include <ilclient.h>
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
```

```
EGLConfig config;
} EGL_STATE_T;
EGL_STATE_T state, *p_state = &state;
void init egl(EGL STATE T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm host init();
    static const EGLint attribute list[] =
            EGL RED SIZE, 8,
            EGL_GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL RENDERABLE TYPE, EGL OPENVG BIT,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL_DEFAULT_DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    /* if we want all configs:
    EGLConfig *configs;
    eglGetConfigs(state->display, NULL, 0, &num configs);
    printf("EGL has %d configs\n", num configs);
    configs = calloc(num configs, sizeof *configs);
    eglGetConfigs(state->display, configs, num configs, &num configs);
    */
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute_list, &state->config, 1, &num_
    configs);
    assert(EGL_FALSE != result);
    // Choose the OpenGL ES API
    //result = eglBindAPI(EGL OPENGL ES API);
```

```
result = eglBindAPI(EGL_OPENVG_API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config, EGL NO CONTEXT,
                                       NULL);
    //context attributes);
                                       // breaks if we use this: context attributes);
    assert(state->context!=EGL_NO_CONTEXT);
}
void init_dispmanx(EGL_DISPMANX_WINDOW_T *nativewindow) {
    int32 t success = 0;
    uint32_t screen width;
    uint32_t screen_height;
    DISPMANX ELEMENT HANDLE T dispman element;
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX UPDATE HANDLE T dispman update;
    VC RECT T dst rect;
    VC_RECT_T src_rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst rect.width = screen width;
    dst rect.height = screen height;
    src_rect.x = 0;
    src rect.y = 0;
    src_rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman_update = vc_dispmanx_update_start( 0 );
    dispman element =
        vc_dispmanx_element_add(dispman_update, dispman_display,
                                 1/*layer*/, &dst rect, 0/*src*/,
                                 &src rect, DISPMANX PROTECTION NONE,
                                 0 /*alpha*/, 0/*clamp*/, 0/*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman_element;
```

```
nativewindow->width = screen_width;
    nativewindow->height = screen height;
    vc dispmanx update submit sync(dispman update);
   printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow, NULL );
    assert(state->surface != EGL_NO_SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL FALSE != result);
}
// setfill sets the fill color
void setfill(float color[4]) {
   VGPaint fillPaint = vgCreatePaint();
    vgSetParameteri(fillPaint, VG_PAINT_TYPE, VG_PAINT_TYPE_COLOR);
    vgSetParameterfv(fillPaint, VG PAINT COLOR, 4, color);
    vgSetPaint(fillPaint, VG FILL PATH);
    vgDestroyPaint(fillPaint);
}
// setstroke sets the stroke color and width
void setstroke(float color[4], float width) {
   VGPaint strokePaint = vgCreatePaint();
    vgSetParameteri(strokePaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(strokePaint, VG_PAINT_COLOR, 4, color);
    vgSetPaint(strokePaint, VG STROKE PATH);
    vgSetf(VG_STROKE_LINE_WIDTH, width);
    vgSeti(VG STROKE CAP STYLE, VG CAP BUTT);
   vgSeti(VG STROKE JOIN STYLE, VG JOIN MITER);
   vgDestroyPaint(strokePaint);
}
// Ellipse makes an ellipse at the specified location and dimensions, applying style
void Ellipse(float x, float y, float w, float h, float sw, float fill[4], float stroke[4]) {
   VGPath path = vgCreatePath(VG PATH FORMAT STANDARD, VG PATH DATATYPE F, 1.0f, 0.0f, 0,
0, VG_PATH_CAPABILITY_ALL);
   vguEllipse(path, x, y, w, h);
    setfill(fill);
    setstroke(stroke, sw);
    vgDrawPath(path, VG FILL PATH | VG STROKE PATH);
    vgDestroyPath(path);
}
```

```
void draw(){
    VGfloat color[4] = {0.4, 0.1, 1.0, 1.0};
    vgClear(0, 0, 1920, 1080);
    Ellipse(1920/2, 1080/2, 600, 400, 0, color, color);
    vgFlush();
}
void overlay vg()
    EGL DISPMANX WINDOW T nativewindow;
    init_egl(p_state);
    init dispmanx(&nativewindow);
    egl_from_dispmanx(p_state, &nativewindow);
    draw();
    eglSwapBuffers(p state->display, p state->surface);
    sleep(10);
    eglTerminate(p state->display);
    exit(0);
}
#define IMG "cimg0135.jpg"
void printState(OMX_HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
    return "error elided";
}
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
void error_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get file size(char *fname) {
    struct stat st;
    if (stat(fname, &st) == -1) {
            perror("Stat'ing img file");
            return -1;
    return(st.st size);
}
```

```
unsigned int uWidth;
unsigned int uHeight;
OMX_ERRORTYPE read_into_buffer_and_empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    printf("Read %d\n", nread);
    buff header->nFilledLen = nread;
    *toread -= nread;
    if (*toread <= 0) {
       printf("Setting EOS on input\n");
       buff_header->nFlags |= OMX_BUFFERFLAG EOS;
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                        buff header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   return r;
}
static void set image decoder input format(COMPONENT T *component) {
   // set input image format
   printf("Setting image decoder format\n");
   OMX IMAGE PARAM PORTFORMATTYPE imagePortFormat;
    //setHeader(&imagePortFormat, sizeof(OMX_IMAGE_PARAM_PORTFORMATTYPE));
    memset(&imagePortFormat, 0, sizeof(OMX IMAGE PARAM PORTFORMATTYPE));
    imagePortFormat.nSize = sizeof(OMX IMAGE PARAM PORTFORMATTYPE);
    imagePortFormat.nVersion.nVersion = OMX_VERSION;
    imagePortFormat.nPortIndex = 320;
    imagePortFormat.eCompressionFormat = OMX IMAGE CodingJPEG;
    OMX SetParameter(ilclient get handle(component),
                     OMX IndexParamImagePortFormat, &imagePortFormat);
}
void setup_decodeComponent(ILCLIENT_T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
```

```
err = ilclient_create_component(handle,
                                decodeComponent,
                                decodeComponentName,
                                ILCLIENT_DISABLE_ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                     /* |
                                     ILCLIENT ENABLE OUTPUT BUFFERS
                                );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set image decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                              char *renderComponentName,
                              COMPONENT T **renderComponent) {
    int err;
   err = ilclient_create_component(handle,
                                renderComponent,
                                renderComponentName,
                                ILCLIENT_DISABLE_ALL_PORTS
                                    /* |
                                    ILCLIENT ENABLE INPUT BUFFERS
                                );
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                           OMX_StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
```

```
printState(ilclient get handle(*renderComponent));
}
void draw openmax image() {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    ILCLIENT T *handle;
   COMPONENT T *decodeComponent;
    COMPONENT T *renderComponent;
    FILE *fp = fopen(IMG, "r");
    int toread = get file size(IMG);
    OMX BUFFERHEADERTYPE *buff header;
    decodeComponentName = "image decode";
    renderComponentName = "video render";
    bcm host init();
    handle = ilclient init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
   if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
   ilclient_set_error_callback(handle,
                               error callback,
                               NULL);
   ilclient_set_eos_callback(handle,
                             eos callback,
                             NULL);
   setup decodeComponent(handle, decodeComponentName, &decodeComponent);
   setup renderComponent(handle, renderComponentName, &renderComponent);
   // both components now in Idle state, no buffers, ports disabled
    // input port
    ilclient_enable_port_buffers(decodeComponent, 320,
                                 NULL, NULL, NULL);
    ilclient enable port(decodeComponent, 320);
   err = ilclient change component state(decodeComponent,
                                          OMX StateExecuting);
```

```
if (err < 0) {
     fprintf(stderr, "Couldn't change state to Executing\n");
     exit(1);
 printState(ilclient get handle(decodeComponent));
 // Read the first block so that the decodeComponent can get
 // the dimensions of the image and call port settings
 // changed on the output port to configure it
 buff header =
     ilclient get input buffer(decodeComponent,
                               1 /* block */);
 if (buff header != NULL) {
     read into buffer and empty(fp,
                                decodeComponent,
                                buff header,
                                &toread);
     // If all the file has been read in, then
     // we have to re-read this first block.
     // Broadcom bug?
     if (toread <= 0) {
         printf("Rewinding\n");
         // wind back to start and repeat
         fp = freopen(IMG, "r", fp);
         toread = get_file_size(IMG);
     }
 }
 // wait for first input block to set params for output port
 err = ilclient wait for event(decodeComponent,
                         OMX EventPortSettingsChanged,
                         321, 0, 0, 1,
                         ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                         5);
 if (err < 0) {
     fprintf(stderr, "No port settings changed\n");
 printf("Port settings changed\n");
 TUNNEL T tunnel;
 set tunnel(&tunnel, decodeComponent, 321, renderComponent, 90);
 if ((err = ilclient setup tunnel(&tunnel, 0, 0)) < 0) {
     fprintf(stderr, "Error setting up tunnel %X\n", err);
     exit(1);
 } else {
     printf("Tunnel set up ok\n");
 }
// Okay to go back to processing data
// enable the decode output ports
```

```
OMX SendCommand(ilclient get handle(decodeComponent),
                   OMX CommandPortEnable, 321, NULL);
   ilclient enable port(decodeComponent, 321);
   // enable the render output ports
   OMX SendCommand(ilclient get handle(renderComponent),
                   OMX CommandPortEnable, 90, NULL);
   */
   ilclient enable port(renderComponent, 90);
   // set both components to executing state
   err = ilclient change component state(decodeComponent,
                                          OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
   err = ilclient change component state(renderComponent,
                                          OMX StateExecuting);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    }
    // now work through the file
   while (toread > 0) {
        OMX ERRORTYPE r;
        // do we have a decode input buffer we can fill and empty?
        buff header =
            ilclient get input buffer(decodeComponent,
                                       320,
                                       1 /* block */);
        if (buff header != NULL) {
            read_into_buffer_and_empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        }
    ilclient wait for event(renderComponent,
                            OMX EventBufferFlag,
                            90, 0, OMX_BUFFERFLAG_EOS, 0,
                            ILCLIENT BUFFER FLAG EOS, 10000);
    printf("EOS on render\n");
}
int main(int argc, char** argv) {
```

```
draw_openmax_image();
  overlay_vg();
  sleep(100);

exit(0);
}
```

It looks like this:



Drawing OpenVG on Top of an OpenMAX Video

The same technique works again. You draw the video in one thread on one surface and the OpenVG in another thread on another surface.

This program draws a shrinking ellipse on top of an OpenMAX video. It is il_render_video_vg_ overlay.c.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>

#include <OMX_Core.h>
#include <OMX_Component.h>
#include <bcm_host.h>
#include <ilclient.h>

#include <assert.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
```

```
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
//#include "esUtil.h"
//#define IMG "cimg0135.jpg"
#define IMG "/opt/vc/src/hello_pi/hello_video/test.h264"
//#define IMG "/home/pi/timidity/short.mpg"
//#define IMG "small.ogv"
pthread t tid;
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL_STATE_T;
EGL STATE T state, *p state = &state;
typedef struct
   // Handle to a program object
   GLuint programObject;
} UserData;
void printState(OMX HANDLETYPE handle) {
    // elided
}
char *err2str(int err) {
   return "error elided";
void eos callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "Got eos event\n");
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
}
int get_file_size(char *fname) {
    struct stat st;
    if (stat(fname, \&st) == -1) {
        perror("Stat'ing img file");
        return -1;
    }
```

```
return(st.st_size);
}
unsigned int uWidth;
unsigned int uHeight;
OMX ERRORTYPE read into buffer and empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
    OMX ERRORTYPE r;
    int buff_size = buff_header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
    printf("Read %d, %d still left\n", nread, *toread);
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff_header->nFlags |= OMX_BUFFERFLAG_EOS;
    }
    r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff_header);
    if (r != OMX ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
    }
    return r;
}
static void set video decoder input format(COMPONENT T *component) {
    int err;
    // set input video format
    printf("Setting video decoder format\n");
    OMX VIDEO PARAM PORTFORMATTYPE videoPortFormat;
    memset(&videoPortFormat, 0, sizeof(OMX_VIDEO_PARAM_PORTFORMATTYPE));
    videoPortFormat.nSize = sizeof(OMX VIDEO PARAM PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
    videoPortFormat.nPortIndex = 130;
    videoPortFormat.eCompressionFormat = OMX VIDEO CodingAVC;
    err = OMX SetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error setting video decoder format %s\n", err2str(err));
        return err;
```

```
} else {
        printf("Video decoder format set up ok\n");
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
    err = ilclient create component(handle,
                                    decodeComponent,
                                    decodeComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT_ENABLE_OUTPUT_BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient_get_handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set video decoder input format(*decodeComponent);
}
void setup renderComponent(ILCLIENT T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient create component(handle,
                                    renderComponent,
                                    renderComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT_ENABLE_INPUT_BUFFERS
                                    );
    if (err == -1) {
```

```
fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    }
    printState(ilclient get handle(*renderComponent));
    err = ilclient change component state(*renderComponent,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
}
void init egl(EGL STATE T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm host init();
    static const EGLint attribute_list[] =
            EGL RED SIZE, 8,
            EGL_GREEN_SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL_SURFACE_TYPE, EGL_WINDOW_BIT,
            EGL SAMPLES, 1,
            EGL NONE
        };
    static const EGLint context attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL NONE
        };
    // get an EGL display connection
    state->display = eglGetDisplay(EGL_DEFAULT_DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute_list, &state->config, 1, &num_
    configs);
    assert(EGL FALSE != result);
    // Choose the OpenVG API
    result = eglBindAPI(EGL OPENVG API);
    assert(EGL_FALSE != result);
```

```
// create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config,
                                       NULL, // EGL_NO_CONTEXT,
                                       NULL);
                                       // breaks if we use this: context_attributes);
   assert(state->context!=EGL_NO_CONTEXT);
}
void init_dispmanx(EGL_DISPMANX_WINDOW_T *nativewindow) {
    int32 t success = 0;
    uint32 t screen width;
   uint32 t screen height;
   DISPMANX ELEMENT HANDLE T dispman element;
   DISPMANX DISPLAY HANDLE T dispman display;
   DISPMANX UPDATE HANDLE T dispman update;
   VC RECT T dst rect;
   VC_RECT_T src_rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen height);
   assert( success >= 0 );
    dst rect.x = 0;
   dst rect.y = 0;
    dst rect.width = screen width;
   dst rect.height = screen height;
    src_rect.x = 0;
    src rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src_rect.height = screen_height << 16;</pre>
    dispman display = vc dispmanx display open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
        vc_dispmanx_element_add(dispman_update, dispman_display,
                                 1 /*layer*/, &dst rect, 0 /*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0 /*clamp*/, 0 /*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman_element;
    nativewindow->width = screen width;
    nativewindow->height = screen height;
    vc_dispmanx_update_submit_sync(dispman_update);
```

```
printf("Got a Dispmanx window\n");
}
void egl_from_dispmanx(EGL_STATE_T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    static const EGLint attribute_list[] =
            EGL RENDER BUFFER, EGL SINGLE BUFFER,
            EGL NONE
        };
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow,
                                            NULL);
                                            //attribute list);
    assert(state->surface != EGL NO SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL_FALSE != result);
}
// setfill sets the fill color
void setfill(float color[4]) {
    VGPaint fillPaint = vgCreatePaint();
    vgSetParameteri(fillPaint, VG_PAINT_TYPE, VG_PAINT_TYPE_COLOR);
    vgSetParameterfv(fillPaint, VG_PAINT_COLOR, 4, color);
    vgSetPaint(fillPaint, VG FILL PATH);
    vgDestroyPaint(fillPaint);
}
// setstroke sets the stroke color and width
void setstroke(float color[4], float width) {
    VGPaint strokePaint = vgCreatePaint();
    vgSetParameteri(strokePaint, VG_PAINT_TYPE, VG_PAINT_TYPE_COLOR);
    vgSetParameterfv(strokePaint, VG PAINT COLOR, 4, color);
    vgSetPaint(strokePaint, VG STROKE PATH);
    vgSetf(VG STROKE LINE WIDTH, width);
    vgSeti(VG STROKE CAP STYLE, VG CAP BUTT);
    vgSeti(VG STROKE JOIN STYLE, VG JOIN MITER);
    vgDestroyPaint(strokePaint);
}
// Ellipse makes an ellipse at the specified location and dimensions, applying style
void Ellipse(float x, float y, float w, float h, float sw, float fill[4], float stroke[4]) {
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD, VG PATH DATATYPE F, 1.0f, 0.0f, 0,
0, VG_PATH_CAPABILITY_ALL);
    vguEllipse(path, x, y, w, h);
    setfill(fill);
    setstroke(stroke, sw);
```

```
vgDrawPath(path, VG_FILL_PATH | VG_STROKE_PATH);
    vgDestroyPath(path);
}
void draw() {
    EGL DISPMANX WINDOW T nativewindow;
    init egl(p state);
    init dispmanx(&nativewindow);
   egl from dispmanx(p_state, &nativewindow);
    vgClear(0, 0, 1920, 1080);
   VGfloat color[4] = {0.4, 0.1, 1.0, 1.0}; // purple
    float c = 1.0;
   float clearColor[4] = {c, c, c, 0.0}; // white transparent
   vgSetfv(VG CLEAR COLOR, 4, clearColor);
    vgClear(0, 0, 1920, 1080);
   vgSeti(VG BLEND MODE, VG BLEND SRC OVER);
    static float ht = 400;
   while (1) {
        vgClear(0, 0, 1920, 1080);
        Ellipse(1920/2, 1080/2, 600, ht--, 0, color, color);
        if (ht <= 0) {
           ht = 200;
        eglSwapBuffers(p state->display, p state->surface);
    assert(vgGetError() == VG_NO_ERROR);
   vgFlush();
   eglSwapBuffers(p state->display, p state->surface);
}
void *overlay vg(void *args) {
   draw();
void draw openmax video(int argc, char** argv) {
   int i;
   char *decodeComponentName;
   char *renderComponentName;
    int err;
   ILCLIENT T *handle;
   COMPONENT T *decodeComponent;
   COMPONENT_T *renderComponent;
    FILE *fp; // = fopen(IMG, "r");
    int toread = get file size(IMG);
   OMX_BUFFERHEADERTYPE *buff_header;
```

```
decodeComponentName = "video_decode";
renderComponentName = "video render";
bcm host init();
if (argc > 1) {
    fp = fopen(argv[1], "r");
} else {
    fp =fopen(IMG, "r");
if (fp == NULL) {
    fprintf(stderr, "Can't open file\n");
    exit(1);
handle = ilclient init();
if (handle == NULL) {
    fprintf(stderr, "IL client init failed\n");
    exit(1);
}
if (OMX Init() != OMX ErrorNone) {
    ilclient destroy(handle);
    fprintf(stderr, "OMX init failed\n");
    exit(1);
}
ilclient set error callback(handle,
                            error callback,
                            NULL);
ilclient set eos callback(handle,
                          eos callback,
                          NULL);
setup decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
ilclient_enable_port_buffers(decodeComponent, 130,
                             NULL, NULL, NULL);
ilclient enable port(decodeComponent, 130);
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(decodeComponent));
```

```
// Read the first block so that the decodeComponent can get
// the dimensions of the video and call port settings
// changed on the output port to configure it
while (toread > 0) {
    buff header =
        ilclient get input buffer(decodeComponent,
                                   1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            fp = freopen(IMG, "r", fp);
            toread = get_file_size(IMG);
        }
    }
    if (toread > 0 && ilclient remove event(decodeComponent,
                                            OMX EventPortSettingsChanged,
                                             131, 0, 0, 1) == 0) {
        printf("Removed port settings event\n");
        break:
    } else {
        printf("No portr settting seen yet\n");
    // wait for first input block to set params for output port
    if (toread == 0) {
        // wait for first input block to set params for output port
        err = ilclient_wait_for_event(decodeComponent,
                                     OMX EventPortSettingsChanged,
                                      131, 0, 0, 1,
                                      ILCLIENT_EVENT_ERROR | ILCLIENT_PARAMETER_CHANGED,
                                     2000);
        if (err < 0) {
            fprintf(stderr, "No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            break;
    }
}
```

```
// set up the tunnel between decode and render ports
TUNNEL T tunnel;
set tunnel(&tunnel, decodeComponent, 131, renderComponent, 90);
if ((err = ilclient setup tunnel(&tunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up tunnel %X\n", err);
    exit(1);
} else {
    printf("Tunnel set up ok\n");
}
// Okay to go back to processing data
// enable the decode output ports
OMX SendCommand(ilclient get handle(decodeComponent),
                OMX CommandPortEnable, 131, NULL);
ilclient enable port(decodeComponent, 131);
// enable the render output ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX CommandPortEnable, 90, NULL);
ilclient enable port(renderComponent, 90);
// set both components to executing state
err = ilclient change component state(decodeComponent,
                                      OMX_StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
err = ilclient change component state(renderComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
// now work through the file
while (toread > 0) {
    OMX ERRORTYPE r;
    // do we have a decode input buffer we can fill and empty?
    buff header =
        ilclient_get_input_buffer(decodeComponent,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   decodeComponent,
```

A snapshot is as follows:



Drawing Text on Top of an OpenMAX Video Using Pango

Drawing text can be made with any of the native OpenVG, Cairo, or Pango APIs. The easiest is probably Pango as it looks after many layout issues for you. In Chapter 18, you used Pango to lay out text on an OpenVG surface. That copies across to here, drawing Pango text onto an OpenVG surface, which is overlaid onto an OpenMAX surface playing a video.

The program il_render_video_pango_overlay.c draws a series of colored text lines on a video.

```
#include <stdio.h>
#include <stdlib.h>
#include <sys/stat.h>
#include <OMX Core.h>
#include <OMX_Component.h>
#include <bcm_host.h>
#include <ilclient.h>
#include <assert.h>
#include <EGL/egl.h>
#include <EGL/eglext.h>
#include <GLES2/gl2.h>
#include <VG/openvg.h>
#include <VG/vgu.h>
#include <gtk/gtk.h>
#define IMG "/opt/vc/src/hello_pi/hello_video/test.h264"
pthread t tid;
typedef struct
    EGLDisplay display;
    EGLSurface surface;
    EGLContext context;
    EGLConfig config;
} EGL_STATE_T;
EGL_STATE_T state, *p_state = &state;
typedef struct
   // Handle to a program object
   GLuint programObject;
} UserData;
void printState(OMX_HANDLETYPE handle) {
    // elided
char *err2str(int err) {
    return "error elided";
}
```

```
void eos_callback(void *userdata, COMPONENT_T *comp, OMX_U32 data) {
    fprintf(stderr, "Got eos event\n");
}
void error callback(void *userdata, COMPONENT T *comp, OMX U32 data) {
    fprintf(stderr, "OMX error %s\n", err2str(data));
int get file size(char *fname) {
   struct stat st;
    if (stat(fname, &st) == -1) {
        perror("Stat'ing img file");
        return -1;
   return(st.st_size);
}
unsigned int uWidth;
unsigned int uHeight;
OMX_ERRORTYPE read_into_buffer_and_empty(FILE *fp,
                                         COMPONENT T *component,
                                         OMX BUFFERHEADERTYPE *buff header,
                                         int *toread) {
   OMX ERRORTYPE r;
    int buff size = buff header->nAllocLen;
    int nread = fread(buff header->pBuffer, 1, buff size, fp);
    buff header->nFilledLen = nread;
    *toread -= nread;
   printf("Read %d, %d still left\n", nread, *toread);
    if (*toread <= 0) {
        printf("Setting EOS on input\n");
        buff_header->nFlags |= OMX_BUFFERFLAG_EOS;
   r = OMX EmptyThisBuffer(ilclient get handle(component),
                            buff header);
    if (r != OMX_ErrorNone) {
        fprintf(stderr, "Empty buffer error %s\n",
                err2str(r));
   return r;
}
static void set video decoder input format(COMPONENT T *component) {
    int err;
    // set input video format
    printf("Setting video decoder format\n");
```

```
OMX VIDEO PARAM PORTFORMATTYPE videoPortFormat;
    memset(&videoPortFormat, 0, sizeof(OMX VIDEO PARAM PORTFORMATTYPE));
    videoPortFormat.nSize = sizeof(OMX_VIDEO_PARAM_PORTFORMATTYPE);
    videoPortFormat.nVersion.nVersion = OMX VERSION;
    videoPortFormat.nPortIndex = 130;
    videoPortFormat.eCompressionFormat = OMX VIDEO CodingAVC;
    err = OMX SetParameter(ilclient get handle(component),
                           OMX IndexParamVideoPortFormat, &videoPortFormat);
    if (err != OMX ErrorNone) {
        fprintf(stderr, "Error setting video decoder format %s\n", err2str(err));
        return err;
    } else {
        printf("Video decoder format set up ok\n");
}
void setup decodeComponent(ILCLIENT T *handle,
                           char *decodeComponentName,
                           COMPONENT T **decodeComponent) {
    int err;
    err = ilclient create component(handle,
                                    decodeComponent,
                                    decodeComponentName,
                                    ILCLIENT_DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
                                    ILCLIENT ENABLE OUTPUT BUFFERS
                                    );
    if (err == -1) {
        fprintf(stderr, "DecodeComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    err = ilclient change component state(*decodeComponent,
                                          OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient get handle(*decodeComponent));
    // must be before we enable buffers
    set video decoder input_format(*decodeComponent);
}
```

```
void setup renderComponent(ILCLIENT T *handle,
                           char *renderComponentName,
                           COMPONENT T **renderComponent) {
    int err;
    err = ilclient create component(handle,
                                     renderComponent,
                                    renderComponentName,
                                    ILCLIENT DISABLE ALL PORTS
                                    ILCLIENT ENABLE INPUT BUFFERS
    if (err == -1) {
        fprintf(stderr, "RenderComponent create failed\n");
        exit(1);
    printState(ilclient get handle(*renderComponent));
    err = ilclient_change_component_state(*renderComponent,
                                           OMX StateIdle);
    if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    printState(ilclient_get_handle(*renderComponent));
}
void init_egl(EGL_STATE_T *state)
    EGLint num configs;
    EGLBoolean result;
    //bcm host init();
    static const EGLint attribute list[] =
            EGL_RED_SIZE, 8,
            EGL GREEN SIZE, 8,
            EGL BLUE SIZE, 8,
            EGL ALPHA SIZE, 8,
            EGL SURFACE TYPE, EGL WINDOW BIT,
            EGL SAMPLES, 1,
            EGL NONE
        };
    static const EGLint context_attributes[] =
            EGL CONTEXT CLIENT VERSION, 2,
            EGL_NONE
        };
```

```
// get an EGL display connection
    state->display = eglGetDisplay(EGL DEFAULT DISPLAY);
    // initialize the EGL display connection
    result = eglInitialize(state->display, NULL, NULL);
    // get an appropriate EGL frame buffer configuration
    result = eglChooseConfig(state->display, attribute list, &state->config, 1, &num
    configs);
    assert(EGL_FALSE != result);
    // Choose the OpenVG API
    result = eglBindAPI(EGL OPENVG API);
    assert(EGL FALSE != result);
    // create an EGL rendering context
    state->context = eglCreateContext(state->display,
                                       state->config,
                                       NULL, // EGL NO CONTEXT,
                                       NULL);
                                       // breaks if we use this: context attributes);
    assert(state->context!=EGL_NO_CONTEXT);
}
void init_dispmanx(EGL_DISPMANX_WINDOW_T *nativewindow) {
    int32 t success = 0;
    uint32 t screen width;
    uint32 t screen height;
    DISPMANX ELEMENT HANDLE T dispman element;
    DISPMANX DISPLAY HANDLE T dispman display;
    DISPMANX UPDATE HANDLE T dispman update;
    VC RECT T dst rect;
    VC RECT T src rect;
    bcm host init();
    // create an EGL window surface
    success = graphics get display size(0 /* LCD */,
                                         &screen width,
                                         &screen height);
    assert( success >= 0 );
    dst rect.x = 0;
    dst rect.y = 0;
    dst_rect.width = screen_width;
    dst rect.height = screen height;
    src_rect.x = 0;
    src rect.y = 0;
    src rect.width = screen width << 16;</pre>
    src rect.height = screen height << 16;</pre>
```

```
dispman display = vc_dispmanx_display_open( 0 /* LCD */);
    dispman update = vc dispmanx update start( 0 );
    dispman element =
       vc dispmanx element add(dispman update, dispman display,
                                1 /*layer*/, &dst rect, 0 /*src*/,
                                &src rect, DISPMANX PROTECTION NONE,
                                0 /*alpha*/, 0 /*clamp*/, 0 /*transform*/);
    // Build an EGL DISPMANX WINDOW T from the Dispmanx window
    nativewindow->element = dispman element;
    nativewindow->width = screen width;
    nativewindow->height = screen_height;
   vc dispmanx update submit sync(dispman update);
   printf("Got a Dispmanx window\n");
}
void egl from dispmanx(EGL STATE T *state,
                       EGL DISPMANX WINDOW T *nativewindow) {
    EGLBoolean result;
    static const EGLint attribute list[] =
            EGL RENDER BUFFER, EGL SINGLE BUFFER,
            EGL_NONE
        };
    state->surface = eglCreateWindowSurface(state->display,
                                            state->config,
                                            nativewindow.
                                            NULL);
                                            //attribute list);
    assert(state->surface != EGL NO SURFACE);
    // connect the context to the surface
    result = eglMakeCurrent(state->display, state->surface, state->surface, state->context);
    assert(EGL_FALSE != result);
}
// setfill sets the fill color
void setfill(float color[4]) {
   VGPaint fillPaint = vgCreatePaint();
   vgSetParameteri(fillPaint, VG PAINT TYPE, VG PAINT TYPE COLOR);
    vgSetParameterfv(fillPaint, VG PAINT COLOR, 4, color);
    vgSetPaint(fillPaint, VG FILL PATH);
   vgDestroyPaint(fillPaint);
}
// setstroke sets the stroke color and width
void setstroke(float color[4], float width) {
   VGPaint strokePaint = vgCreatePaint();
```

```
vgSetParameteri(strokePaint, VG_PAINT_TYPE, VG_PAINT_TYPE_COLOR);
    vgSetParameterfv(strokePaint, VG PAINT COLOR, 4, color);
    vgSetPaint(strokePaint, VG STROKE PATH);
    vgSetf(VG_STROKE_LINE_WIDTH, width);
    vgSeti(VG STROKE CAP STYLE, VG CAP BUTT);
    vgSeti(VG STROKE JOIN STYLE, VG JOIN MITER);
    vgDestroyPaint(strokePaint);
}
// Ellipse makes an ellipse at the specified location and dimensions, applying style
void Ellipse(float x, float y, float w, float h, float sw, float fill[4], float stroke[4]) {
    VGPath path = vgCreatePath(VG PATH FORMAT STANDARD, VG PATH DATATYPE F, 1.of, 0.of, 0,
o, VG PATH CAPABILITY ALL);
    vguEllipse(path, x, y, w, h);
    setfill(fill);
    setstroke(stroke, sw);
    vgDrawPath(path, VG FILL PATH | VG STROKE PATH);
    vgDestroyPath(path);
}
char *get markup text() {
    static int n = 0;
    int num texts = 6;
    gchar *texts[] = {
 "<span foreground=\"red\" font='96'></span>\
<span foreground=\"black\" font='96'>hello</span>",
         "<span foreground=\"red\" font='96'>h</span>\
<span foreground=\"black\" font='96'>ello</span>",
         "<span foreground=\"red\" font='96'>he</span>\
<span foreground=\"black\" font='96'>llo</span>",
         "<span foreground=\"red\" font='96'>hel</span>\
<span foreground=\"black\" font='96'>lo</span>",
         "<span foreground=\"red\" font='96'>hell</span>\
<span foreground=\"black\" font='96'>o</span>",
         "<span foreground=\"red\" font='96'>hello</span>\
<span foreground=\"black\" font='96'></span>"
    };
    return texts[n++ % num texts];
}
void pango() {
    int width = 500;
    int height = 200;
    cairo_surface_t *surface = cairo_image_surface_create (CAIRO_FORMAT_ARGB32,
                                                           width, height);
    cairo t *cr = cairo create(surface);
    // Pango marked up text, half red, half black
    gchar *markup text = get markup text();
    PangoAttrList *attrs;
```

```
gchar *text;
    pango parse markup (markup text, -1, 0, &attrs, &text, NULL, NULL);
    // draw Pango text
    PangoLayout *layout;
    PangoFontDescription *desc;
    cairo move to(cr, 30.0, 150.0);
    cairo_scale(cr, 1.0f, -1.0f);
    layout = pango cairo create layout (cr);
    pango layout set text (layout, text, -1);
    pango_layout_set_attributes(layout, attrs);
    pango cairo update layout (cr, layout);
    pango cairo show layout (cr, layout);
    int tex w = cairo image surface get width(surface);
    int tex h = cairo image surface get height(surface);
    int tex_s = cairo_image_surface_get_stride(surface);
    cairo surface flush(surface);
    cairo format t type =
        cairo image surface get format (surface);
    printf("Format is (0 is ARGB32) %d\n", type);
    unsigned char* data = cairo image surface get data(surface);
    PangoLayoutLine *layout line =
        pango layout get line(layout, 0);
    PangoRectangle ink rect;
    PangoRectangle logical rect;
    pango layout line get pixel extents (layout line,
                                         &ink rect,
                                         &logical rect);
    printf("Layout line rectangle is %d, %d, %d, %d\n",
           ink_rect.x, ink_rect.y, ink_rect.width, ink_rect.height);
    int left = 1920/2 - ink rect.width/2;
    vgWritePixels(data, tex_s,
                  //VG 1BGRA 8888,
                  VG sARGB 8888 ,
                  left, 300, tex w, tex h);
void draw()
    EGL_DISPMANX_WINDOW_T nativewindow;
    init egl(p state);
    init_dispmanx(&nativewindow);
    egl from dispmanx(p state, &nativewindow);
```

}

```
VGfloat color[4] = {0.4, 0.1, 1.0, 1.0}; // purple
    float c = 1.0;
    float clearColor[4] = {c, c, c, 0.0}; // white transparent
    vgSetfv(VG_CLEAR_COLOR, 4, clearColor);
    while (1) {
        vgClear(0, 0, 1920, 1080);
        pango();
        eglSwapBuffers(p state->display, p state->surface);
        sleep(1);
    }
    sleep(30);
    eglTerminate(p state->display);
    exit(0);
}
#if 0
void draw() {
    EGL DISPMANX WINDOW T nativewindow;
    init egl(p state);
    init dispmanx(&nativewindow);
    egl_from_dispmanx(p_state, &nativewindow);
    vgClear(0, 0, 1920, 1080);
    VGfloat color[4] = {0.4, 0.1, 1.0, 1.0}; // purple
    float c = 1.0;
    float clearColor[4] = {c, c, c, 0.0}; // white transparent
    vgSetfv(VG CLEAR COLOR, 4, clearColor);
    vgClear(0, 0, 1920, 1080);
    vgSeti(VG BLEND MODE, VG BLEND SRC OVER);
    static float ht = 400;
    while (1) {
        vgClear(0, 0, 1920, 1080);
        Ellipse(1920/2, 1080/2, 600, ht--, 0, color, color);
        if (ht <= 0) {
            ht = 200;
        eglSwapBuffers(p state->display, p state->surface);
    assert(vgGetError() == VG_NO_ERROR);
    vgFlush();
    eglSwapBuffers(p state->display, p state->surface);
}
```

```
#endif
void *overlay vg(void *args) {
    draw();
}
void draw_openmax_video(int argc, char** argv) {
    int i;
    char *decodeComponentName;
    char *renderComponentName;
    int err;
    ILCLIENT T *handle;
    COMPONENT_T *decodeComponent;
    COMPONENT T *renderComponent;
    FILE *fp; // = fopen(IMG, "r");
    int toread = get_file_size(IMG);
    OMX BUFFERHEADERTYPE *buff header;
    decodeComponentName = "video decode";
    renderComponentName = "video render";
    bcm host init();
    if (argc > 1) {
        fp = fopen(argv[1], "r");
    } else {
        fp =fopen(IMG, "r");
    if (fp == NULL) {
        fprintf(stderr, "Can't open file\n");
        exit(1);
    }
    handle = ilclient_init();
    if (handle == NULL) {
        fprintf(stderr, "IL client init failed\n");
        exit(1);
    }
    if (OMX Init() != OMX ErrorNone) {
        ilclient destroy(handle);
        fprintf(stderr, "OMX init failed\n");
        exit(1);
    }
    ilclient_set_error_callback(handle,
                                error callback,
                                NULL);
    ilclient_set_eos_callback(handle,
                              eos callback,
                              NULL);
```

```
setup_decodeComponent(handle, decodeComponentName, &decodeComponent);
setup renderComponent(handle, renderComponentName, &renderComponent);
// both components now in Idle state, no buffers, ports disabled
// input port
ilclient enable port buffers(decodeComponent, 130,
                             NULL, NULL, NULL);
ilclient enable port(decodeComponent, 130);
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Executing\n");
    exit(1);
printState(ilclient get handle(decodeComponent));
// Read the first block so that the decodeComponent can get
// the dimensions of the video and call port settings
// changed on the output port to configure it
while (toread > 0) {
    buff header =
        ilclient get input buffer(decodeComponent,
                                  1 /* block */);
    if (buff header != NULL) {
        read into buffer and empty(fp,
                                   decodeComponent,
                                   buff header,
                                   &toread);
        // If all the file has been read in, then
        // we have to re-read this first block.
        // Broadcom bug?
        if (toread <= 0) {
            printf("Rewinding\n");
            // wind back to start and repeat
            fp = freopen(IMG, "r", fp);
            toread = get file size(IMG);
        }
    }
    if (toread > 0 && ilclient remove event(decodeComponent,
                                            OMX EventPortSettingsChanged,
                                            131, 0, 0, 1) == 0) {
        printf("Removed port settings event\n");
        break;
    } else {
        printf("No portr settting seen yet\n");
    // wait for first input block to set params for output port
```

```
if (toread == 0) {
        // wait for first input block to set params for output port
        err = ilclient wait for event(decodeComponent,
                                     OMX_EventPortSettingsChanged,
                                     131, 0, 0, 1,
                                     ILCLIENT EVENT ERROR | ILCLIENT PARAMETER CHANGED,
                                     2000);
        if (err < 0) {
            fprintf(stderr, "No port settings change\n");
            //exit(1);
        } else {
            printf("Port settings changed\n");
            break;
    }
}
// set up the tunnel between decode and render ports
TUNNEL T tunnel;
set tunnel(&tunnel, decodeComponent, 131, renderComponent, 90);
if ((err = ilclient setup tunnel(&tunnel, 0, 0)) < 0) {
    fprintf(stderr, "Error setting up tunnel %X\n", err);
    exit(1);
} else {
    printf("Tunnel set up ok\n");
// Okay to go back to processing data
// enable the decode output ports
OMX_SendCommand(ilclient_get_handle(decodeComponent),
                OMX CommandPortEnable, 131, NULL);
ilclient_enable_port(decodeComponent, 131);
// enable the render output ports
OMX SendCommand(ilclient get handle(renderComponent),
                OMX CommandPortEnable, 90, NULL);
ilclient enable port(renderComponent, 90);
// set both components to executing state
err = ilclient change component state(decodeComponent,
                                      OMX StateExecuting);
if (err < 0) {
    fprintf(stderr, "Couldn't change state to Idle\n");
    exit(1);
err = ilclient change component state(renderComponent,
                                      OMX StateExecuting);
```

```
if (err < 0) {
        fprintf(stderr, "Couldn't change state to Idle\n");
        exit(1);
    }
    // now work through the file
    while (toread > 0) {
        OMX_ERRORTYPE r;
        // do we have a decode input buffer we can fill and empty?
        buff header =
            ilclient get input buffer(decodeComponent,
                                      1 /* block */);
        if (buff header != NULL) {
            read_into_buffer_and_empty(fp,
                                       decodeComponent,
                                       buff header,
                                       &toread);
        }
    }
    ilclient_wait_for_event(renderComponent,
                            OMX EventBufferFlag,
                            90, 0, OMX_BUFFERFLAG_EOS, 0,
                            ILCLIENT BUFFER FLAG EOS, 10000);
    printf("EOS on render\n");
}
int main(int argc, char** argv) {
    pthread create(&tid, NULL, overlay vg, NULL);
    draw openmax video(argc, argv);
    exit(0);
}
```

A snapshot looks like this:



Conclusion

This chapter looked at overlaying drawings and text on top of images and videos. A number of scenarios were dealt with, all using the concept of different layers at the Dispmanx level to implement them.

Index

■ A	Building programs
Advanced Audio Coding (AAC), 262	EGL initialization, 28-30 Makefile, 27
Application programming interface (API), 325 Audio and video rendering, 299–300	rendering context, 30–32
Audio_decode component, 221	■ C
output device, 214 PCM, 213–214	C99/C11 compilers, 10 Color codings, 157
Audio decoder, 300–322, 324 Audio formats, 204–213	Command-line parameter, 226
Audio port information audio_render, 95	Compile command, 226 CreateSimpleTexture2D, 63, 247, 251
coding, 95–97 fields, 93	D
MP3 files, 94 OMX_AUDIO_CODINGTYPE, 94 OMX_AUDIO_PARAM_PCMMODETYPE, 97 OMX_AUDIO_PARAM_PORTFORMATTYPE, 95 OMX_AUDIO_PORTDEFINITIONTYPE, 93 OMX_IndexParamAudioPcm, 97 OMX_PARAM_PORTDEFINITIONTYPE, 93-94 programs, 98-110 structure, 93 video_render, 111	Debian-derived systems, 263 Debugging, 261 Demuxer, 275 Dispmanx, 14 GPU accessing, 21-24 layers, 375-376 program, 21 doc/examples/decoding_encoding.cc program, 221
Audio stream rendering, 263–266, 268–275	■ E
Avconv, 221–226 av_dump_format, 266 av_find_best_stream, 235 av_read_frame, 265 AV_SAMPLE_FMT_FLTP, 265 AV_SAMPLE_FMT_S16P, 235 av_samples_alloc, 265	EGL, 14 drawing surface, 33–37 specification, 27 EGLClientBuffer, 246 EglCreateImageKHR, 246 EGLImage buffer, 253 esLoadTGA, 62 esUtil functions esCreateWindow, 43
Beethoven.mp3, 235, 244 Broadcom GPU components, 247 threads, 247	esCreateWildow, 45 esInitContext, 43 esMainLoop, 43 esRegisterDrawFunc, 43 fields, 43

© Jan Newmarch 2017 435

■ INDEX

esUtil functions (cont.) OS-dependent layers, 43 struct, 43 UserData, 46 X Window System, 43 Event handler callback, 122 F FFmpeg, 221–227, 229–239, 241–244, 263 FilledBuffer, 253	LibAV decoder, 226–227, 229–239, 241–244, 263–266, 300 libavcodec-extra, 235 Libraries Dispmanx, 15 EGL, 15 OpenGL ES, 16 OpenMAX, 15 OpenVG, 16
■ G	■ M, N
Garbage collection, 24 Java, 37 Khronos, 38 gcc Compile Flags, 11–12, 14 gcc version, 10	Mediainfo, 262, 266 Mp3 file decoding, 221–226 rendering, 226–227, 229–234 ID3 extensions, 234–239, 241–244 Multimedia files
■ H	Big Buck Bunny, 262 container files, 261
Hello_Triangle.c, 53 H.264 file decoding, 186–188, 190–193	decoding, 263–266 demuxing, 263 formats, 261
= 1	- 0
ID3 extensions, 234–239, 241–244 IL Client library building programs, 129 changing component state, 132–134 client creation, 131 debugging clients, 135–136 public functions, 130–131 waiting for events, 135 ilclient_set_fill_buffer_done_callback, 253, 255	OMX_AllocateBuffer, 138, 168, 207 OMX audio decoder, 300 OMX.broadcom.video_decode, 275 omxplayer, 261, 263, 280, 300 OMX_TIME_CONFIG_SCALETYPE, 280 OpenGL ES program, 7, 15, 246 animation esUtil, 71
il_enable_port_buffers, 207 il_ffmpeg_demux_render_audio_video.c, 301	invoking, 72 matrices, 71 uniform parameters, 72–77
■ J JPEG image, 157-158	API, 42 building programs, 41–42 colored triangle passing multiple attributes,
■ K	vertex shader, 58 squares drawing and other shapes, 59–62
Khronos Group EGL, 8 graphics and video, 7 OpenGL ES, 7–8 OpenMAX, 8 OpenVG, 8	varyings concept, 57 Dispmanx, 41 drawing, 51–52, 376–380, 382–383, 385–386 esUtil functions, 43–44, 46 files, 41 opaque red triangle drawing, 53–54, 56

OpenMAX video, 387-394, 396, 398	loaded to idle
program object, 50–51	components, 115
RPi, 41	nonworking program, 115–118
shaders	Makefile, 113
GPU, 47	mechanisms, 80
loading, 49	multithreaded processing model, 80
minimal fragment, 48	OMX_StateLoaded to OMX_StateIdle, 118
minimal vertex, 48	ports, 80, 119
shading language, 48	programming model, 80
Silicon Graphics, 42	specification, 5
surface, 375	state changes, 122, 124–128
textures, 247-248, 250-251, 253-255, 257-259	state transition diagram, 114
attributes and shaders, 63-64	transition to idle state, 122
coding, image drawing, 67-71	waitFor, client thread, 128
drawing, 65–66	wakeUp, event handler, 128
init function, 64	OpenMAX buffers, Raspberry Pi
mipmaps, 63	allocation, 138
object creation, 63	building programs, 137
TGA files, 62	components, 137
vertices, 46	EOS flag, 144
OpenMAX, 153, 226-227, 229-239,	IL client library, 138, 140–142
241-245, 252	image decoding, 146–148, 150–152
API, 14-15	port settings, 145
audio processing	sequence of actions, 143
audio formats, 204–213	video_decode, 138
building programs, 203	writing and reading
components, 204	OMX_EmptyThisBuffer, 142
broadcom, 80	OMX_FillBufferDone, 142
buffers, 80	Video Core/Posix threads, 143
coding, 119–121	OpenMAX video processing, 387–394, 396, 398
component states, 80, 113–114, 276	building programs, 181
audio port information, 93, 95–97, 99–111	H.264 File decoding, 186–188, 190–193
getting and setting parameters, 89	OpenVG, 408-418
getting port information, 90–92	Pango, 419-423, 425-431, 433
listcomponents, 84–86	video components, 181
Makefile, 85–86	video formats, 182–186
OMX.broadcom.visualisation, 83	OpenVG, 8, 15
OMX_ComponentNameEnum(), 84	building programs, 325
OMX_GetHandle(), 83, 87	Dispmanx and EGL, 326-330
OMX_GetRolesOfComponent, 84	drawing, 398–418
OMX_init(), 84	images
port information, 88–89	EGL context, 344
port types, 92	eglCreatePbufferFromClientBuffer, 345
Raspberry Pi, 86–87	image-user-to-surface transformation, 342
specification, 83	off-screen buffer image, 344
hComponent, 122	path, 345
idle to executing state, 122	pbuffer, 344
image	RGBA characteristics, 344
OpenGL ES surface, 376–380,	sources, 342
382-383, 385-386	stride, 341
OpenVG, 398-407	surface, 345
layers, 79	VGImage, memory data, 342
<i>y</i> -/ · -	

■ INDEX

OpenVG (cont.)	■ S
Mesa project, 326	
pink triangle, 331-336	Sample Makefiles
pipeline, 330	Dispmanx, 16
specification	EGL, 17
E-book readers, 326	OpenMAX, 17
games, 326	OpenVG, 18
low-level graphics device interface, 326	Screen capture, 25
portable mapping applications, 326	
scalable user interfaces, 326	■ T, U
SVG and Adobe Flash viewers, 325	– 1, 0
standard shapes, 337-341	Text processing, OpenVG
Output device, 214	building programs, 349
- mp,	displaying text, 349
= D O	drawing text
■ P, Q	Cairo, 350–354
Pango API, 419-423, 425-431, 433	complexities, 350
Pulse code modulated (PCM)	issues, 350
ADPCM data, 212, 214	Pango, 355-360
analog signals, 213	FreeType
avconv, 214	API reference, 361
description, 213	bitmap, 367
encoding, 214	font faces, 361-362
f32 and f64, 213	GPU, 361
functions, 215–220	Linux systems, 361
unencoded audio, 213	outline, 363, 365–366
pkg-config, 18–19	packages, 349
Posix threads, 127	paths and glyphs, 362–363
pthreads, 247	vgDrawpath, 366
•	glyph metrics, 371–372
= D	vgCreateFont, 368
■ R	vgDrawGlyphs, 368–371
Raspberry Pi (RPi)	Tunneling
building programs, 153	broadcom components, 159, 160
communication, 153	function, 161
CPU level, 3	IL client, 158
ELinux.org, 4	ilclient_setup_tunnel, 160
GPU programming, 4	image_decode, 160
image components, 153	proprietary communication, 158
image formats, 154–157	pseudo-code, 159, 161–162
JPEG Image, 157–158	rendering an image, 162–168
Linux system, 3	
Model B, 1	■ V
Pi Zero, 1	
programming style, 5	VCOS thread system, 128
rendering an image (without tunneling),	vgImageSubData, 342
168–169, 171, 173–174, 176–180	Video stream rendering
single-board computer, 1	with full speed, 275-277
Rendering an image	with scheduling
without tunneling, 168–169, 171,	behind-the-scenes, 280
173-174, 176-178, 180	64-bit timestamp, 284
with tunneling, 162, 164-168	clock component, 279, 282

clock setup, 280–281
code, 278–280
complete program, 284–287, 289–291, 293–299
dts and pts, 283
FFmpeg/LibAV, 281
field, 283
LibAV/FFmpeg, 283
numerator (num) and
denominator (den), 283
OMX timestamps, 284
OpenMAX components, 278

parameters, 280 pts values, 283 pts * timebase, 284 substantial layers, 277 tunnels, 281 xScale, 280 Vulkan graphics system, 42

■ **W, X, Y, Z**WAV header, 300