
Main Board (inside control box)



Ribbon Connector:

12v to switch	5v to pot
5v to pot	12v from switch
Gnd to pot	Gnd to pot
AN0 (fwd/rev)	AN1 (lt/rt)
5v to PB switch	Gnd to rdy ESC rdy LE
5v to pwr on LED	5v to ESC rdy LED
signal from PB switch	5v to LEAK LED
LCD0	5v to LCD
LCD1	
LCD2	
LCD3	
LCD4	
LCD5	
LCD6	
LCD7	