Joystick to ROV movement Diagram

Joystick movement during interrupt Normal Joystick Movement (push button depressed) (push button not depressed) **Forward** Surface Counter Clockwise Traverse Traverse Clockwise Right Rotation Left Rotation Dive Reverse