RISC-V REFERENCE

James Zhu <jameszhu@berkeley.edu>

RISC-V Instruction Set

Core Instruction Formats

31 27 26 25	24 20	19	15	14	12	11	7	6	0	
funct7	rs2	rs1		fun	ct3	1	rd	opcode		R-type
imm[11:	0]	rs1		fun	ct3	1	rd	opcode		I-type
imm[11:5]	rs2	rs1		fun	ct3	imm	1[4:0]	opcode		S-type
imm[12 10:5]	rs2	rs1		fun	ct3	imm[4:1 11]	opcode		B-type
imm[31:12]						1	rd	opcode		U-type
imm[20 10:1 11 19:12]						1	rd	opcode		J-type

RV32I Base Integer Instructions

Inst	Name	FMT	Opcode	funct3	funct7	Description (C)	Note
add	ADD	R	0110011	0x0	0x00	rd = rs1 + rs2	
sub	SUB	R	0110011	0x0	0x20	rd = rs1 - rs2	
xor	XOR	R	0110011	0x4	0x00	rd = rs1 ^ rs2	
or	OR	R	0110011	0x6	0x00	rd = rs1 rs2	
and	AND	R	0110011	0x7	0x00	rd = rs1 & rs2	
sll	Shift Left Logical	R	0110011	0x1	0x00	rd = rs1 << rs2	
srl	Shift Right Logical	R	0110011	0x5	0x00	rd = rs1 >> rs2	
sra	Shift Right Arith*	R	0110011	0x5	0x20	rd = rs1 >> rs2	msb-extends
slt	Set Less Than	R	0110011	0x2	0x00	rd = (rs1 < rs2)?1:0	
sltu	Set Less Than (U)	R	0110011	0x3	0x00	rd = (rs1 < rs2)?1:0	zero-extends
addi	ADD Immediate	I	0010011	0x0		rd = rs1 + imm	
xori	XOR Immediate	I	0010011	0x4		rd = rs1 ^ imm	
ori	OR Immediate	I	0010011	0x6		rd = rs1 imm	
andi	AND Immediate	I	0010011	0x7		rd = rs1 & imm	
slli	Shift Left Logical Imm	I	0010011	0x1	imm[5:11]=0x00	rd = rs1 << imm[0:4]	
srli	Shift Right Logical Imm	I	0010011	0x5	imm[5:11]=0x00	rd = rs1 >> imm[0:4]	
srai	Shift Right Arith Imm	I	0010011	0x5	imm[5:11]=0x20	rd = rs1 >> imm[0:4]	msb-extends
slti	Set Less Than Imm	I	0010011	0x2		rd = (rs1 < imm)?1:0	
sltiu	Set Less Than Imm (U)	I	0010011	0x3		rd = (rs1 < imm)?1:0	zero-extends
lb	Load Byte	I	0000011	0x0		rd = M[rs1+imm][0:7]	
lh	Load Half	I	0000011	0x1		rd = M[rs1+imm][0:15]	
lw	Load Word	I	0000011	0x2		rd = M[rs1+imm][0:31]	
lbu	Load Byte (U)	I	0000011	0x4		rd = M[rs1+imm][0:7]	zero-extends
lhu	Load Half (U)	I	0000011	0x5		rd = M[rs1+imm][0:15]	zero-extends
sb	Store Byte	S	0100011	0x0		M[rs1+imm][0:7] = rs2[0:7]	
sh	Store Half	S	0100011	0x1		M[rs1+imm][0:15] = rs2[0:15]	
SW	Store Word	S	0100011	0x2		M[rs1+imm][0:31] = rs2[0:31]	
beq	Branch ==	В	1100011	0x0		if(rs1 == rs2) PC += imm	
bne	Branch !=	В	1100011	0x1		if(rs1 != rs2) PC += imm	
blt	Branch <	В	1100011	0x4		if(rs1 < rs2) PC += imm	
bge	Branch ≥	В	1100011	0x5		if(rs1 >= rs2) PC += imm	
bltu	Branch < (U)	В	1100011	0x6		if(rs1 < rs2) PC += imm	zero-extends
bgeu	Branch \geq (U)	В	1100011	0x7		if(rs1 >= rs2) PC += imm	zero-extends
jal	Jump And Link	J	1101111			rd = PC+4; PC += imm	
jalr	Jump And Link Reg	I	1100111	0x0		rd = PC+4; PC = rs1 + imm	
lui	Load Upper Imm	U	0110111			rd = imm << 12	
auipc	Add Upper Imm to PC	U	0010111			rd = PC + (imm << 12)	
ecall	Environment Call	I	1110011	0x0	imm=0x0	Transfer control to OS	
ebreak	Environment Break	I	1110011	0x0	imm=0x1	Transfer control to debugger	

RISC-V Reference Card V0.1

Registers

Register	ABI Name	Description	Saver
x0	zero	Zero constant	_
x1	ra	Return address	Caller
x2	sp	Stack pointer	_
x3	gp	Global pointer	_
x4	tp	Thread pointer	Callee
x5-x7	t0-t2	Temporaries	Caller
x8	s0 / fp	Saved / frame pointer	Callee
x9	s1	Saved register	Callee
x10-x11	a0-a1	Fn args/return values	Caller
x12-x17	a2-a7	Fn args	Caller
x18-x27	s2-s11	Saved registers	Callee
x28-x31	t3-t6	Temporaries	Caller
f0-7	ft0-7	FP temporaries	Caller
f8-9	fs0-1	FP saved registers	Callee
f10-11	fa0-1	FP args/return values	Caller
f12-17	fa2-7	FP args	Caller
f18-27	fs2-11	FP saved registers	Callee
f28-31	ft8-11	FP temporaries	Caller