



ENGINEERING BULLETIN

Subject :	Expansion Valve Driver Board Programming procedure				
Released By:	PPP	Bulletin No.:	EB/15-16/02	Date:	15 th April, 15

We are releasing herewith procedure for Expansion valve driver board programming, which needs to be done once during new EVD Board installation / replacement .It can be referred by Manufacturing and service persons.

PROCEDURE:

- 1) Remove top cover of evd evolution.
- 2) Insert program key in the same slot.
- 3) Now Power on the evd evolution and wait for approx. for 10 to 15 seconds till initialization completes.
- 4) On Display ,press down button till display reaches to **END CONFIGURATION**
- 5) On same page, select YES by pressing down button and Press enter button.
- 6) After completing this, press **PRG** button & now display will show **PASSWORD** page. Now give the password (0022) by using up & down buttons.
- 7) Using Up/Down buttons go to the **2/11 VALVE**, select valve type (**CAREL, DANFOSS, ALCO, SPORLAN**) on this screen & press enter button.
- 8) Then under **3/11 MAIN REGULATION**, select **Analog positioned (0-10V)** on this screen & press enter button.
- 9) Then under **4/11 PROBE S2**, select **0-10V external signal** on this screen & press enter button.
- 10) Press **Esc** key to return to main screen.



KIRLOSKAR CHILLERS PRIVATE LIMITED

A Kirloskar Group Company

Enriching Lives

-
- 11) Turn Off the power supply, remove the program key & fit original top cover.
 - 12) Now to crosscheck correct programming, give Manual command to EXV (0 to 100%) from Display (PGD0/Touchscreen) & crosscheck EXV Closing/Opening by measuring 0 to 10 Volt output.