



KIRLOSKAR CHILLERS PRIVATE LIMITED

A Kirloskar Group Company

Enriching Lives

Document No : EB/17-18/08				
Document Name : Selection of measurement system in Screw Selection Software				
Prep. By : AHW	Chkd. By : SNM	Appd. By : SSN	Date : 28/11/17	Total Pages : 4

How to select measurement system

1. S-I System will be selected by default, to change it to I-P System refer step 2.



2. After clicking on Select Unit button, this window will pop up and you can change to "I-P System" by selecting "I-P System" and then clicking on "Save" Button.

