



KIRLOSKAR CHILLERS PRIVATE LIMITED

A Kirloskar Group Company

Enriching Lives

ENGINEERING SPECIFICATIONS

Document Name: Mechanical Cutout Settings for Centrifugal and Screw Chillers		
Document No: ESP-15-16-101	Revision: 01	Date: 08/04/15
Prepared By: PPP	Approved By: SSN	Sheet: 1 OF 2

Mechanical Cutout Settings

Sr. No.	Description	Function	Set point	
			Bar	PSI
1	Vane Open Switch	To indicate complete vanes open condition to controller	2	30
2	Vane Close Switch	To indicate complete vanes close condition to controller	2	30
3	Oil Pressure (OP) Cutout	To trip the chiller in case of insufficient oil pressure differential	4	60
4	HP Cutout	To trip the chiller in case of high condenser pressure	10.5	155
5	LP Cutout	To trip the chiller in case of low evaporator pressure	1.5	20
6	DP Switches for flow (Evap. and Cond)	To trip the chiller in case of insufficient water flow through heat exchangers	Refer procedure on sheet 2 of 2	

Notes

1. For any particular chiller, all above cutouts may or may not be applicable /provided. Corresponding cutouts from above chart should be referred, which are applicable to that specific order.
2. Do not refer Sr. No. 4 & 5 for WC chillers other than R-134a ,Heat pump and AC Chillers.(Contact engineering for the same, if required)
3. Sr. No. 1, 2 & 3 are applicable only for Centrifugal chillers however Sr. No. 4, 5 & 6 can be applicable for both centrifugal and screw chillers.
4. Sr.No. 6 can be applicable for all chiller series.



KIRLOSKAR CHILLERS PRIVATE LIMITED

A Kirloskar Group Company

Enriching Lives

ENGINEERING SPECIFICATIONS

Document Name: Mechanical Cutout Settings for Centrifugal and Screw Chillers		
Document No: ESP-15-16-101	Revision: 01	Date: 08/04/15
Prepared By: PPP	Approved By: SSN	Sheet: 2 OF 2

Procedure to set DP switches for flow(Evap and Cond)

Set the design water flow for evap. & cond. and note pressure drops across both heat exchangers. Ensure that pressure drop matches with values given in datasheet /software output within +/- 10% .If it's not matching within tolerance contact engineering.

Reduce water flow of both evap. & cond. up to 75 % of design flow. Note down these pressure drops of evap. & cond. on log sheet and set respective DP switch according to these pressure drop values at 75 %.

Note: Above procedure is to be followed for standard chiller with fixed flow design, if SO mentions *Variable flow design*, contact Engineering to set the Evaporator flow DP switch.