

ENGINEERING SPECIFICATIONS

Document Name: IO list for KWS Brine Single Circuit		
Document No: ESP-20-21-009	Revision: R03	Date: 28/02/2023
Prepared By: CGH		Sheet: 1
Updated By: CGH		Approved By: RDT

Analog Inputs	Main Board	U1	Suction Pressure Comp (4-20 mA)
		U2	Discharge Pressure Comp (4-20 mA)
		U3	Oil Feed Pressure (4-20 mA)
		U4	Evaporator Water In Temperature
		U5	Evaporator Water Out Temperature
		U6	Comp-1 Current (0-5 Vdc)
		U7	Sump Oil Temperature (HT)
		U8	Discharge Temperature
	Exp.Board A	B1	Suction Temperature
		B2	Liquid Line Temperature
		B3	Condenser Water In Temperature
		B4	Condenser Water Out Temperature
	Exp.Board B	B1	Economizer Out Temperature
		B2	Oil Feed Temperature (NTC)
		B3	Economizer Out Pressure
		B4	Evap Flow 4-20 mA

Digital Input	Main Board	ID1	Chiller ON/OFF Comp
		ID2	Voltage Protection Device / VFD Starter Fault
		ID3	Condenser Flow Switch
		ID4	Oil Level Switch
		ID5	Oil Flow Switch
		ID6	Winding Protection
		ID7	Evaporator Flow switch
		ID8	Transition OK Comp
		ID9	Emergency Stop
		ID10	=====Spare=====
		ID11	=====Spare=====
		ID12	=====Spare=====
		ID13	=====Spare=====
		ID14	=====Spare=====
	Exp. Board A	ID1	=====Spare=====
		ID2	Cooling Tower Feedback
		ID3	Chill Water pump Feedback
		ID4	Condenser Water Pump Feedback
	Exp. Board B	ID1	=====Spare=====
		ID2	=====Spare=====
		ID3	=====Spare=====
		ID4	=====Spare=====

ENGINEERING SPECIFICATIONS

Document Name: IO list for KWS Brine Single Circuit		
Document No: ESP-20-21-009	Revision: R03	Date: 28/02/2023
Prepared By: CGH		Sheet: 2
Updated By: CGH		Approved By: RDT

Digital Output	Main Board	NO1	=====Spare=====
		NO2	=====Spare=====
		NO3	LV Comp 1 100%
		NO4	=====Spare=====
		NO5	=====Spare=====
		NO6	=====Spare=====
		NO7	LV Comp 1 75%
		NO8	Compressor (Delta) /(SS) / VFD-Latch
		NO9	Compressor (Main)
		NO10	Oil Feed Solenoid
		NO11	Oil Heater
		NO12	LV Comp 1 50%
		NO13	Alarm
	Exp.Board A	NO1	Economizer (Optional)
		NO2	Liquid Injection Coil
		NO3	Evaporator Pump
		NO4	Condenser Pump
	Exp. Board B	NO1	=====Spare=====
		NO2	=====Spare=====
		NO3	=====Spare=====
		NO4	SOV Comp-1
Analog Output	Main Board	Y1	EXV Command
		Y2	Eco-EXV Command
		Y3	VFD Command
		Y4	Oil-EXV Command