Equipment Alarm Escalation and Work Orders

Document	Revision	Effective	Owner
SOP-OPS-003	2	2025-04-01	Northgate Distribution, Facilities

1. Purpose

This procedure sets response times for equipment alarms and explains how to open, update and close work orders in the CMMS.

2. Priority Levels

Priority	Definition	Response time	Who is notified
P1	Product at risk, safety hazard, or a line is down	Technician on site within 30 minutes, 24/7	On-call technician, shift lead, site maintenance manager
P2	Equipment degraded, failure likely within days	Within 4 hours during staffed shifts	On-call technician, shift lead
P3	Minor issue, no immediate impact	Next business day	Maintenance planner

3. Fault Code to Priority Map

Fault code	Equipment	Priority
E-21 with box temp above 38F, E-42	CU-400	P1
E-21 with normal box temp, E-30	CU-400	P2
DF-4, F-20	EV-220	P1
F-11	EV-220	P2
V-03, T-05, P-07	AC-75	P1
V-02	AC-75	P2
OL-2, TH-4	CD-900	P1 if the line is down, otherwise P2
OL-1, JM-3	CD-900	P3
C-12	BC-48	P1
C-01, C-20	BC-48	P2
E-14, F-31, C-33	Various	P3

4. Work Order Fields

- Device ID (for example D-114) and site code.
- Fault code and time first seen.
- Priority from Section 3.
- Actions taken, parts used, and readings before and after.
- Root cause, chosen from the CMMS list.

5. Escalation

If a P1 is not acknowledged in 15 minutes, the monitoring system calls the backup technician. If not resolved in 4 hours, the site maintenance manager notifies the regional engineering lead.

6. Site Codes

Code	Site
JOL	Joliet, IL
AUR	Aurora, CO
LAK	Lakeland, FL
STK	Stockton, CA
ALN	Allentown, PA