GHI Installation Guide

REVISION HISTORY			
NUMBER	DATE	DESCRIPTION	NAME

Contents

1	Prep	paring for GHI Install	1
	1.1	Prerequisites	1
	1.2	Operating System	2
		1.2.1 Set ulimits	2
		1.2.2 rsyslog configuration	2
	1.3	Memcached	3
		1.3.1 Install memcached and libmemcached	3
		1.3.2 Configure memcached	3
		1.3.2.1 Setup for RHEL 6 Nodes	3
		1.3.2.2 Setup for RHEL 7 Nodes	4
	1.4	GHI-ISHTAR	5
	1.5	Install GHI-ISHTAR	5
2	Spec	etrum Scale	6
	2.1	Install Spectrum Scale	6
	2.2	Configure Spectrum Scale	6
	2.3	Create SSH Trust	7
	2.4	Create a new GPFS Cluster	7
		2.4.1 Configure license	8
		2.4.2 Create NSD (Network Shared Disks) on main the GHI node only	8
		2.4.3 NSD Multipath	11
3	Db2		13
	3.1	Users and Groups	13
		3.1.1 Add hpssdmg with hpssuser tool	14
	3.2	Add hpssdmg to HPSS ACL on Core Server	15
	3.3	Set up GHI Tablespace on HPSS Core Server	16
		3.3.1 Database using Single Partition	16
		3.3.2 CREATE DATABASE PARTITION GROUP	17
		3.3.3 Configure Logging on the HPSS Core Server	18
	3.4	Install Db2 Client on all GHI Nodes	19
	3.5	Add Db2 Permanent License on all GHI Nodes	19

4	HPS	SS	22
	4.1	Verify HPSS rpms on all GHI NODES	22
	4.2	Configure HPSS Client	22
5	GHI	I Installation & Configuration	24
	5.1	Install GHI	24
		5.1.1 Configure GHI-ISHTAR	24
	5.2	GHI Users and Groups	25
	5.3	Configure GHI	25
	5.4	Create GHI Cluster	25
	5.5	Create Spectrum Scale file systems GHI will manage	26
	5.6	Create IOMs for each GHI Managed File systems	27
	5.7	Modify xinetd.conf for number of IOMs	27
	5.8	Information Lifecycle Management (ILM) Policies	28
6	Bacl	kup & Restore	29
	6.1	Backups	29
	6.2	Restore	30
7	GHI	I Conversions	31
	7.1	Conversion steps for 3.1.0 to 3.2.0	31
	7.2	Conversion steps for 3.0.1 to 3.1.0	31
	7.3	Conversion steps for 3.0.0 to 3.0.1	34
8	GHI	I Conversions	37
	8.1	Conversion steps for 3.1 to 3.2	37

Spectrum Scale HPSS Interface Release 3.0

May 2019

Copyright notification

Copyright © 1992-2019 International Business Machines Corporation, The Regents of the University of California, Los Alamos National Security, LLC, Lawrence Livermore National Security, LLC, Sandia Corporation, and UT-Battelle.

All rights reserved.

Portions of this work were produced by Lawrence Livermore National Security, LLC, Lawrence Livermore National Laboratory (LLNL) under Contract No. DE-AC52-07NA27344 with the U.S. Department of Energy (DOE); by the University of California, Lawrence Berkeley National Laboratory (LBNL) under Contract No. DE-AC02-05CH11231 with DOE; by Los Alamos National Security, LLC, Los Alamos National Laboratory (LANL) under Contract No. DE-AC52-06NA25396 with DOE; by Sandia Corporation, Sandia National Laboratories (SNL) under Contract No. DE-AC04-94AL85000 with DOE; and by UT-Battelle, Oak Ridge National Laboratory (ORNL) under Contract No. DE-AC05-00OR22725 with DOE. The U.S. Government has certain reserved rights under its prime contracts with the Laboratories.

DISCLAIMER

Portions of this software were sponsored by an agency of the United States Government. Neither the United States, DOE, The Regents of the University of California, Los Alamos National Security, LLC, Lawrence Livermore National Security, LLC, Sandia Corporation, UT-Battelle, nor any of their employees, makes any warranty, express or implied, or assumes any liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights.

Trademark usage

High Performance Storage System is a trademark of International Business Machines Corporation.

IBM is a registered trademark of International Business Machines Corporation.

IBM, DB2, DB2 Universal Database, AIX, pSeries, and xSeries are trademarks or registered trademarks of International Business Machines Corporation.

AIX and RISC/6000 are trademarks of International Business Machines Corporation.

UNIX is a registered trademark of the Open Group.

Linux is a registered trademark of Linus Torvalds in the United States and other countries.

Kerberos is a trademark of the Massachusetts Institute of Technology.

Java is a registered trademark of Oracle and/or its affiliates.

ACSLS is a trademark of Oracle and/or its affiliates.

Microsoft Windows is a registered trademark of Microsoft Corporation.

DST is a trademark of Ampex Systems Corporation.

Other brands and product names appearing herein may be trademarks or registered trademarks of third parties.

About this book

The Spectrum Scale (formerly GPFS) to HPSS Interface (GHI) Installation Guide is for use at system installation time. It outlines the steps required to install and configure a GHI system.

Conventions Used in This Document

Example commands that should be typed at a command line will be proceeded by a percent sign (%): % sample command

Example command output and example contents of ASCII files are presented in italic font: sample file line 1 sample file line 2

Any text preceded by a pound sign ('#') is considered comment lines: # This is a comment

A byte is an eight-bit data octet.

A kilobyte, KB, is 1024 bytes (2¹⁰ bytes).

A megabyte, MB, is 1,048,576 bytes (2²⁰ bytes).

A gigabyte, GB, is 1,073,741,824 bytes(2³⁰ bytes).

A terabyte, TB, is 1,099,511,627,776 bytes (2⁴⁰ bytes).

A petabyte, PB, is 1,125,899,906,842,624 bytes (2⁵⁰ bytes).

An exabyte, EB, is 1,152,921,504,606,846,976 bytes (2⁶⁰ bytes).

Chapter 1

Preparing for GHI Install

Prior to installing GHI, a series of planning meetings should have been conducted to discuss the customer's requirements in order to properly size and configure the GHI system. The planning process is not a subject of this Installation Guide and is done during the Proposal and/or System Engineering phase of the project. In addition, *refer to the GHI Management Guide* for planning considerations.

IBM recommends you install GHI on a Spectrum Scale cluster that has no other Hierarchical Storage Management (HSM) application running, for example, Tivoli Storage Manager (TSM). If another HSM managed file system is required, it must run on a separate cluster and be remotely mounted on the GHI managed cluster. GHI is dependent on timely Data Management Application Programming Interface (DMAPI) events from Spectrum Scale; therefore, there should not be two applications competing for events.

For systems installed with High Availability (HA) Core Server, it is critical to ensure that the required GHI components are installed on the backup or stand-by Core Server. These components include Db2 accounts creation and configuration, Db2 Server configuration and Independent Standalone HPSS TAR (ISHTAR).

GHI installation requires root or root-equivalent privileges, except where noted otherwise.

1.1 Prerequisites

Before installing GHI, review the GHI Release Notes on the HPSS Admin wiki for prerequisites, special notes, and possible known issues for the version you plan to install. The Release Notes define the software version of each prerequisite software:

- HPSS Core Server and Movers
- · Operating system
 - memcached
 - libmemcache
- Python not covered in this document
- IBM_db egg (Python support for Db2) not covered in this document
- Spectrum Scale
- Db2 Client
- HPSS Client
 - hpss-lib
 - hpss-lib-devel
- GHI-ISHTAR
- GHI

1.2 Operating System

1.2.1 Set ulimits

Note

Change the default soft and hard core size from "0" to "unlimited". This will allow GHI to create a core dump file for debug purposes. The default inode scan bucket size is 1000. Increase the max open file descriptors limit to 65536 in /etc/security/limits.d/19-hpss.conf on all systems that will run GHI. Reboot each node to validate each change is correct and persistent.

Example:

```
% vi /etc/security/limits.d/19-hpss.conf
                soft
#*
                        core
# *
                hard
                        rss
                                        10000
#@student
                hard
                        nproc
                                        20
                                        20
#@faculty
                soft
                        nproc
                                        50
#@faculty
                hard
                        nproc
                                        0
#ftp
                hard
                        nproc
#@student
                        maxlogins
               soft
                        core
                                        unlimited <- (add)
               hard
                                        unlimited <- (add)
                        core
               soft
                       nofile
                                        65536 <- (add)
               hard
                        nofile
                                        65536 <- (add)
```

Validate each change by running:

```
$ ulimit -a
```

1.2.2 rsyslog configuration

Note

We recommend suppressing repeat messages and turning rate limiting off

Sites must evaluate policies and configuration needs for their own systems and determine what works best for their own needs. The below is an example:

1. In /etc/rsyslog.conf update or add the following lines:

```
$SystemLogRateLimitInterval 0
$SystemLogRateLimitBurst 0
$IMUXSockRateLimitInterval 0
$IMJournalRateLimitInterval 0
$IMJournalRateLimitBurst 0
```

2. In /etc/systemd/journald.conf update or add the following lines:

```
RateLimitInterval=0
RateLimitBurst=0
Storage=volatile
Compress=no
MaxRetentionSec=5s
```

3. In /etc/rsyslog.d/hpss.conf update or add the following line:

```
$RepeatedMsgReduction off
```

4. Restart the services for changes to take effect

```
systemctl restart systemd-journald
systemctl restart rsyslog
```

1.3 Memcached

Memcached is an in-memory key-value store for small chunks of arbitrary data. Memcached allows applications to take memory from parts of the system where it has more than it needs and make it accessible to areas where applications have less than they need.

GHI uses memcached to reduce the load on the HPSS metadata. Memcached improves the performance of GHI full backups, GHI image backup verification, ghiverifyfs, and ghi_ls. Install the memcached and libmemcached-devel RPMs from the RHEL software distribution on each machine you want memcached to run to improve the above operations.

1.3.1 Install memcached and libmemcached

1. Read the Release Notes to check prerequisites for appropriate version to use

```
% yum list available | grep memcached
% yum install memcached
% yum install libmemcached
```

2. Verify the packages and versions have been properly installed

```
% rpm -qa | grep memcached
```

1.3.2 Configure memcached

1.3.2.1 Setup for RHEL 6 Nodes

• Create directory /var/hpss/ghi/etc and file memcached.conf

```
On each GHI node:
% mkdir /var/hpss/ghi/etc/
% vi /var/hpss/ghi/etc/memcached.conf
```

• Add the following lines to memcached.conf:

```
--POOL-MIN=4
--POOL-MAX=32
--SERVER=<ghi node name>:11211
--SERVER=<ghi node name>:11211
```

• Verify memcache's port number in file /etc/services. If the port is not 11211, then substitute the correct port number in its place.

• Create /etc/init/memcached.conf and add the lines below to the file.

```
stop on runlevel [012]
start on starting rc RUNLEVEL=[345]
respawn
exec /usr/bin/memcached -d -u root -m 1024
```

• Run the memcached command to start.

```
% memcached -d -u root -m 1024
```

This will start the server with 1024 MB of memory. Adjust to the desired cache size. The rule of thumb is that 10,000 items in the cache will use approximately 16MB.

1.3.2.2 Setup for RHEL 7 Nodes

• Run the following commands to enable, start, and status memcached.

```
% systemctl enable memcached.service
% systemctl start memcached.service
% systemctl status memcached.service
```

• Verify that memcached configuration files have been created.

```
% cd /usr/lib/systemd/system/
% ls | grep memcached
```

- If memcached.services does not exist, follow these steps below:
 - Create /usr/lib/systemd/system/memcached.service
 - Add the lines below to the file.

```
[Unit]
Description=Memcached
Before=httpd.service
After=network.target

[Service]
Type=simple
EnvironmentFile=-/etc/sysconfig/memcached
Restart=always
ExecStart=/usr/bin/memcached -u $USER -p $PORT -m $CACHESIZE -c $MAXCONN $OPTIONS

[Install]
WantedBy=multi-user.target
```

- Create the file /etc/sysconfig/memcached with contents:

```
PORT="11211"
USER="memcached"
MAXCONN="1024"
CACHESIZE="64"
OPTIONS=""
```

- Check status and, if necessary, disable, enable, reload, and restart memcached.service

```
% systemctl list-unit-files | grep memcached
% systemctl enable memcached.service
% systemctl daemon-reload
% systemctl restart memcached.service
% systemctl status memcached.service
```

1.4 GHI-ISHTAR

Before installing GHI-ISHTAR, verify that prerequisites hpss-lib, hpss-lib-devel, and hpss-clnt are installed.

```
% rpm -qa "hpss*"
```

• Install prerequisites if they are missing

```
% rpm -ivh hpss-lib-<version>*
% rpm -ivh hpss-lib-devel-<version>*
% rpm -ivh hpss-clnt-<version>*
```

After HPSS RPMs are installed, a message will appear letting the user know where the package directory is located. This directory path will be needed for the next step.

• Create /opt/hpss link to the directory where HPSS Client files are installed.

```
% ln -s /hpss_src/hpss-<version>* /opt/hpss
```

Example:

```
% ln -s /hpss_src/hpss-7.5.3.0-0.el7 /opt/hpss
```

1.5 Install GHI-ISHTAR

GHI-ISHTAR must be installed on all GHI IOM nodes. The GHI-ISHTAR RPM is compatible with GHI and is provided by IBM. Only the provided version should be used with GHI. Check the GHI Release Notes for the version of GHI-ISHTAR to install.

```
$ rpm -ivh ghi-ishtar*.rpm
```

Files for package ghi-ishtar installed under /var/hpss/hsi

Note

HPSS libraries must be installed on each GHI IOM node before GHI-ISHTAR can be installed.

Chapter 2

Spectrum Scale

2.1 Install Spectrum Scale

Contact your IBM Spectrum Scale customer support representative to obtain the Spectrum Scale software and install it according to instructions.

2.2 Configure Spectrum Scale

- 1. After Spectrum Scale is installed, make sure ssh or rsh is working between nodes in the cluster. If using ssh, be certain to complete additional configuration steps to allow for passwordless command execution (steps are covered in the Spectrum Scale documentation).
- 2. Enable threshold processing.

Check to see if the requested configuration attributes are set.

```
% mmlsconfig
% mmchconfig enablelowspaceevents=yes
```

3. Configure NSD Multipath.

If using multipath, follow the steps below to create NSDs.

- a. Create a /etc/multipath/bindings file. The file needs to match on all nodes using the NSD.
- b. Create an nsddevices script for NSD Device Discovery

```
% cp /usr/lpp/mmfs/samples/nsddevices.sample /var/mmfs/etc/nsddevices
```

c. Edit /var/mmfs/etc/nsddevices to look like the example below:

```
osName=$(/bin/uname -s)

if [[ $osName = Linux ]]
then
CONTROLLER_REGEX='mpath[a-z]+'
for dev in $( /bin/ls /dev/mapper | egrep $CONTROLLER_REGEX )
do

# dmm vs. generic is used by Spectrum Scale to prioritize internal order
# of searching through available disks, then later Spectrum Scale
# discards other disk device names that it finds that match as the
# same NSD device by a different path. For this reason,
# dmm vs. generic is an important distinction if you are not
```

```
# explicitly producing the entire and exclusive set of disks
# that Spectrum Scale should use, as output from this
# script (nsddevices) and exiting this script with a "return 0".
echo mapper/$dev dmm
echo mapper/$dev generic
done
fi

# To bypass the Spectrum Scale disk
# discovery (/usr/lpp/mmfs/bin/mmdevdiscover),
return 0
# To continue with the Spectrum Scale disk discovery steps,
return 1
```

d. Ensure this script is executable.

```
% chmod +x /var/mmfs/etc/nsddevices
```

e. Execute /var/mmfs/etc/nsddevices.

Example:

```
% /var/mmfs/etc/nsddevices
mapper/mpatha dmm
mapper/mpathb dmm
mapper/mpathc dmm
```

2.3 Create SSH Trust

After Spectrum Scale is installed, create ssh trust between all nodes in each direction in each node and between each node. Be certain to complete additional configuration steps to allow for passwordless command execution.

2.4 Create a new GPFS Cluster

Only on the main node run the command to create a GPFS cluster. Upon successful completion of the mmcrcluster command, the /var/mmfs/gen/mmsdrfs and the /var/mmfs/gen/mmfsNodeData files are created on each node in the cluster.

1. Run mmcrcluster * Example and output:

```
% mmcrcluster -n /var/hpss/ghi/gpfs_config/node.conf -p ghi_server1 \
-r /usr/bin/ssh -R /usr/bin/scp
```

2. Check that mmsdrfs and mmfsNodeData files are created and the output shows success and completion.

```
% cat /var/mmfs/gen/mmsdrfs
% cat /var/mmfs/gen/mmfsNodeData
```

Output:

```
mmcrcluster: Performing preliminary node verification ...
mmcrcluster: Processing quorum and other critical nodes ...
mmcrcluster: Finalizing the cluster data structures ...
mmcrcluster: Command successfully completed
mmcrcluster: Warning: Not all nodes have proper GPFS license designations.
mmcrcluster: Propagating the cluster configuration data to all affected nodes.
This is an asynchronous process.
```

2.4.1 Configure license

The mmchlicense command designates appropriate GPFS licenses. Run mmchlicense to accept and configure licenses.

```
% mmchlicense server --accept -N all
```

Output:

The following nodes will be designated as possessing server licenses:

```
ghi_server2.clearlake.ibm.com
ghi_server1.clearlake.ibm.com
```

2.4.2 Create NSD (Network Shared Disks) on main the GHI node only

• On the primary GHI Node, create NSD configuration file(s) for each disk.

```
% cd /var/hpss/ghi/gpfs_config
% touch nsd.StanzaFile nsd.StanzaFile2 ... nsd.StanzaFileX
% vi nsd.StanzaFile
```

• Add the following lines:

```
%nsd:
device=/dev/sdb
nsd=nsd1
servers=ghi_server1
usage=dataAndMetadata
% vi nsd.StanzaFile2
```

• Add the following lines:

```
%nsd:
device=/dev/sdc
nsd=nsd2
servers=ghi_server1
usage=dataAndMetadata
```

Note

Create a block for each resource. Include all GHI nodes that see the disk separated by a comma. For example, if two servers share a disk resource "servers=" value, the line will contain both hostnames like this: servers=<node1 shortname>,<node2 shortname>

• Create NSD stanzas file that uses the multipath aliases. For systems using multipath, skip this step if you are not using multipath. Edit /var/hpss/ghi/gpfs_config/nsd.StanzaFile and insert the lines below.

```
%nsd: device=/dev/mapper/mpatha
nsd=nsd1
servers=ghi_server1,ghi_server2
usage=dataAndMetadata
```

• Enable DMAPI on the Spectrum Scale file system.

```
% mmchfs <file system> -z Yes
```

• Run the mmcrnsd command to create network shared disk (NSD) servers The option "-F" specifies the file containing the NSD stanzas for the disks to be created. The option "-v no" specifies that the disks are to be created irrespective of their previous state.

```
% mmcrnsd -F /var/hpss/ghi/gpfs_config/nsd.StanzaFile -v no
mmcrnsd: Processing disk sdb
mmcrnsd: Propagating the cluster configuration data to all affected nodes.
This is an asynchronous process.

% mmcrnsd -F /var/hpss/ghi/gpfs_config/nsd.StanzaFile2 -v no
mmcrnsd: Processing disk sdc
mmcrnsd: Propagating the cluster configuration data to all affected nodes.
This is an asynchronous process.
```

· Create GPFS file system

First ensure all the GPFS nodes are active and then create the GPFS file system. Wait until the mmgetstate output shows that all nodes are active before issuing the mmcrfs command.

```
% mmgetstate -a

Node number Node name GPFS state

1 ghi_server1 active
2 ghi_server2 active
```

If the node state remains down, run *mmstartup -a* to start GPFS

If the node state remains down after mmstartup, check GPFS logs

If the node state is arbitrating, check GPFS logs

If the node needs to be recycled, run mmshutdown -a, and rerun mmstartup

Note

The GFPS log location is /var/mmfs/gen/mmfslog.

• Run mmcrfs to create the file system(s) with options to enable automount (-A yes), activate quotas automatically (-Q yes), enable DMAPI (-z yes), set blocksize (-B 256K), and specify disk to not belong to an existing file system (-v no).

```
% mmcrfs /ghi_server1_fs1 /dev/ghi_server1_fs1 -F /var/hpss/ghi/gpfs_config/nsd. \( \to \)
    StanzaFile \
-A yes -Q yes -z yes -B 256K -v no

% mmcrfs /ghi_server1_fs2 /dev/ghi_server1_fs2 -F /var/hpss/ghi/gpfs_config/nsd. \( \to \)
    StanzaFile2 \
-A yes -Q yes -z yes -B 256K -v no
```

GHI Installation Guide 10 / 39

Note

If the user plans on having a GPFS file system without a GHI file system for image restores, the "temp space" GPFS file system should have DMAPI set to no (-z no).

Sample Output:

```
The following disks of ghi_server1_fs2 will be formatted on node
ghi_server2.clearlake.ibm.com:
    nsd2: size 153600 MB

Formatting file system ...
Disks up to size 1.51 TB can be added to storage pool system.

Creating Inode File
Creating Allocation Maps

Creating Log Files
Clearing Inode Allocation Map

Clearing Block Allocation Map

Formatting Allocation Map for storage pool system

Completed creation of file system /dev/ghi_server1_fs2.

mmcrfs: Propagating the cluster configuration data to all
affected nodes. This is an asynchronous process.
```

Note

Use mmlsfs to list the file system attributes. For example, if you want to check if DMAPI is enabled on all GPFS file systems, run: mmlsfs all | grep DMAPI

Display the configuration data for a GPFS Cluster for each node
 Log in to main node:

```
% root@ghi_server1 /var/mmfs > mmlsconfig
```

```
Configuration data for cluster ghi_serverl.clearlake.ibm.com:

clusterName ghi_serverl.clearlake.ibm.com
clusterId 16335425671093415616
autoload no
dmapiFileHandleSize 32
minReleaseLevel 5.0.2.0
ccrEnabled yes
cipherList AUTHONLY
adminMode central

File systems in cluster ghi_serverl.clearlake.ibm.com:

/dev/ghi_serverl_fs1
/dev/ghi_serverl_fs2
```

Log in to all secondary nodes to check

```
% root@ghi_server2 /root > mmlsconfig
```

```
Configuration data for cluster ghi_server1.clearlake.ibm.com:

clusterName ghi_server1.clearlake.ibm.com
clusterId 16335425671093415616
autoload no
```

GHI Installation Guide 11 / 39

```
dmapiFileHandleSize 32
minReleaseLevel 5.0.2.0
ccrEnabled yes
cipherList AUTHONLY
adminMode central

File systems in cluster ghi_server1.clearlake.ibm.com:

/dev/ghi_server1_fs1
/dev/ghi_server1_fs2
```

2.4.3 NSD Multipath

1. Configure NSD Multipath.

If using multipath, follow the steps below to create NSDs.

- a. Create a /etc/multipath/bindings file. The file needs to match on all nodes using the NSD.
- b. Create an nsddevices script for NSD Device Discovery
 - % cp /usr/lpp/mmfs/samples/nsddevices.sample /var/mmfs/etc/nsddevices
- c. Edit /var/mmfs/etc/nsddevices to look like the example below:

```
osName=$(/bin/uname -s)
if [[ $osName = Linux ]]
then
CONTROLLER_REGEX='mpath[a-z]+'
for dev in $( /bin/ls /dev/mapper | egrep $CONTROLLER_REGEX )
# dmm vs. generic is used by Spectrum Scale to prioritize internal
# order of
# searching through available disks, then later Spectrum Scale
# discards other disk device names that it finds that match as the same
# NSD device by a different path. For this reason, dmm vs. generic is an
# important distinction if you are not explicitly producing the entire
# and exclusive set of disks that Spectrum Scale should use,
  as output from
# this script (nsddevices) and exiting this script with a "return 0".
echo mapper/$dev dmm
echo mapper/$dev generic
done
fi
if [[ $osName = AIX ]]
then:
# Add function to discover disks in the AIX environment.
# To bypass the Spectrum Scale disk discovery
# (/usr/lpp/mmfs/bin/mmdevdiscover),
# To continue with the Spectrum Scale disk discovery steps,
return 1
```

GHI Installation Guide 12 / 39

d. Ensure the script is executable.

Example:

```
% chmod +x /var/mmfs/etc/nsddevices
```

e. Execute /var/mmfs/etc/nsddevices.

Example:

```
# /var/mmfs/etc/nsddevices
mapper/mpatha dmm
mapper/mpathb dmm
mapper/mpathc dmm
```

f. Create NSD stanzas file that uses the multipath aliases. Edit /var/hpss/ghi/gpfs_config/nsd.StanzaFile and insert the lines.

```
%nsd: device=/dev/mapper/mpatha
nsd=nsd1
servers=ghi_server1,ghi_server2
usage=dataAndMetadata
```

- g. Continue with Creating NSDs.
- 2. Enable DMAPI on the Spectrum Scale file system.

```
% mmchfs <file system> -z Yes
```

GHI Installation Guide 13 / 39

Chapter 3

Db₂

3.1 Users and Groups

GHI needs three users (hpss, hpssdb, hpssdmg) and two groups (hpss, hpsssrvr) on all GHI nodes that will have the HPSS client installed. The user and group ID numbers created on the GHI nodes must match the corresponding user and group ID numbers on the HPSS Core Server. User IDs hpss and hpssdb should exist after the HPSS Core Server has been installed and configured. The user ID hpssdmg will need to be created on the HPSS Core Server using hpssuser.

• Use the system command id to verify the required users and groups exist.

```
% id <user>
% id -g <user>
```

User	Primary Group	Home Directory:
hpss	hpss	/var/hpss
hpssdb	hpssdb	/db2data/db2_hpssdb
hpssdmg	hpsssrvr	/var/hpssdmg

• If any of the above users or groups do not exist, use the **useradd** system command to add them.

The following shows the usage of the useradd command and an example adding hpssdb as a user and group:

```
% useradd -d <home directory> -g <group> -p password <user>
% useradd -d /db2data/db2_hpssdb -g 300 -p hpssdb hpssdb
```

Check to make sure Core Server and GHI nodes have matching entries for users hpss, hpssdb, and hpssdmg in the /etc/passwd and /etc/group files.

```
% cat /etc/passwd | grep hpss
hpss:x:300:300:HPSS User:/var/hpss:/bin/bash
hpssdba:x:301:301::/db2data/db2_hpssdb:/bin/bash
hpssdmg:x:1001:302::/var/hpssdmg:/bin/bash
% cat /etc/group | grep hpss
hpss:x:300:hpss,hpssdba
hpssdba:x:301:root
hpsssrvr:x:302:hpssdmg
```

The hpssdmg user in /etc/passwd is in the primary group of hpsssrvr. Also notice that in /etc/group hpssdmg is a secondary group to hpsssrvr. Make sure all Core and GHI nodes have the same configuration and passwords.

GHI Installation Guide 14 / 39

3.1.1 Add hpssdmg with hpssuser tool

• On the HPSS Core Server, use **hpssuser** to add user hpssdmg with **Unix Authentication**. Skip to the next bullet if your site uses **Kerberos Authentication**.

```
$ /opt/hpss/bin/hpssuser -add hpssdmg -unix -unixkeytab <keytab path>
User ID#: 1001
Primary group name: hpsssrvr
Enter password for hpssdmg: [hpssdmg]
Re-enter password to verify: [hpssdmg]
Full name: hpssdmg
Login shell: /bin/bash
Unix (local/system) home directory: /var/hpssdmg
[ adding unix user ]
[ added unix user ]
[ added unix keytab entry to '/var/hpss/etc/hpss.unix.keytab' ]
[ added unix keytab entry to '/var/hpss/etc/hpss.unix.keytab' ]
```

• On the HPSS Core Server, use **hpssuser** to add user hpssdmg with **Kerberos Authentication**. If your site uses Unix Authentication, go to the previous step.

```
$ /opt/hpss/bin/hpssuser -add hpssdmg -unix -krb -krbkeytab
/var/hpss/etc/hpss.keytab
User ID#: 1001
Primary group name: hpsssrvr
Enter password for hpssdmg: [hpssdmg]
Re-enter password to verify: [hpssdmg]
Full name: hpssdmg
Login shell: /bin/bash
Unix (local/system) home directory: /var/hpssdmg
[ adding unix user ]
[ added unix user ]
[ adding kerberos principal ]
INFO: Using kadmin.local for kerberos administrative actions
[ adding kerberos keytab entry to '/var/hpss/etc/hpss.keytab' ]
[ added kerberos keytab entry to '/var/hpss/etc/hpss.keytab' ]
[ added kerberos principal ]
```

• Check that hpssdmg has been added to /var/hpss/etc/passwd and to /var/hpss/etc/group under the group hpsssrvr. This step is valid only if you are using HPSS local password and group files. Otherwise, skip this step.

```
% cat /var/hpss/etc/passwd | grep hpssdmg
hpssdmg:x:1001:301:hpssdmg:/var/hpssdmg:/bin/bash
% cat /var/hpss/etc/group | grep hpssdmg
hpsssrvr:*:301:hpssmvr,hpsssd,hpssftp,hpssssm,hpsspvr,hpssgk,hpssmps,
hpssrait,hpsscore,hpsspvl,hpssfs,hpssls,hpssdmg
```

• Copy HPSS Core /var/hpss/etc/ to each GHI node with scp.

On the core:

```
% cd /var/hpss/etc
% tar -cvzf /tmp/etcnew.tar.gz ./
% scp /tmp/etcnew.tar.gz root@<GHI NODE>:/var/hpss
```

Move old /var/hpss/etc and make room for new one.
 On each GHI node:

GHI Installation Guide 15 / 39

```
% cd /var/hpss/
% mv etc etc.ori
% mkdir /var/hpss/etc
% cp /var/hpss/etcnew.tar.gz /var/hpss/etc
% cd /var/hpss/etc
% tar -xzvf etcnew.tar.gz
```

• Link /var/hpss/hpssdb to the hpssdb user's home directory. On each GHI Node:

```
$ ln -s /db2data/db2_hpssdb /var/hpss/hpssdb
```

3.2 Add hpssdmg to HPSS ACL on Core Server

Execute the HPSS ACL utility on your HPSS Core Server to add user hpssdmg, if necessary. Look at the output and choose the Account Validation Interface menu option. Next run the *show* command to determine if hpssdmg needs to be added. The order of ACL entries may differ from the following example:

```
% /opt/hpss/bin/hpss_server_acl
hsa> acl -t CORE

1) PVL Mount Notification Interface (v1) 007ff347-e533-1cc6-b22d-02608c2cedf4
2) Client Interface (v1) 32ba9692-4667-11d6-aa3a-0004ac49692b
3) Account Validation Interface (v1) 647f22a8-ale9-11d3-a739-000001341966
4) Realtime Monitor Interface (v1) 80c9a256-2f13-11d3-a0c8-000001341966
Select an interface
Choose an item by number (RET to cancel):
> 3
hsa> show
```

```
hsa> add user hpssdmg rwc
hsa> show
```

hsa> quit

GHI Installation Guide 16 / 39

3.3 Set up GHI Tablespace on HPSS Core Server

GHI should be configured to use the same Db2 storage group that is used in HPSS.



Important

GHI Tablespaces should be configured on HPSS Core Server only while the HPSS system is down. The actual configuration for Db2 should be determined during the system engineering planning phase of the deployment. The GHI Db2 mapping table has the potential to become very large and care should be taken in configuring Db2 to handle it.

Note

Repeat this section to set up the GHI tablespace on the HA Backup Core Server for proper failover operations.

3.3.1 Database using Single Partition

This configuration is performed only on the HPSS Core server while Db2 is running and HPSS servers are down.

- 1. Shut down all servers via HPSS GUI.
- 2. Find the number of partition(s)

As hpssdb user, the following shows there is only one partition.

```
% cat $HOME/sqllib/db2nodes.cfg
0 <core_server>.clearlake.ibm.com 0
```

3. Source the database profile.

```
% source ~hpssdb/sqllib/db2profile
```

4. Create the database.

This is the default example for a one partition and two storage paths file systems.

For systems that do not use the default, edit path partition names and storage path file systems to match your system configuration.

The following examples show path names and partition expressions usage:

```
% db2 "CREATE DATABASE HGHI ON \
\'/db2data/p0000/stg0001', \
\'/db2data/p0000/stg0002' \
DBPATH on '/db2data/db2_hpssdb'"

% db2 "CREATE DATABASE HGHI ON \
\'/db2data/p \$4N /stg0001\', \
\'/db2data/p \$4N /stg0002\' \
DBPATH ON '/db2data/db2_hpssdb'"
```

5. Modify the callback script to source the database profile. (DB2PROF)

```
% vim /opt/ghi/bin/hpssEventNotify
```

GHI Installation Guide 17 / 39

3.3.2 CREATE DATABASE PARTITION GROUP

1. Connect to the HGHI database.

```
% db2 CONNECT TO HGHI
```

2. For a single partition run the command:

```
% db2 "CREATE DATABASE PARTITION GROUP HPSS_GHI ON DBPARTITIONNUM (0)"
```

3. Check that a partition is created.

```
$ db2 list db partition groups
```

Example output:

- 3 record(s) selected.
 - 1. Create the bufferpool used for GHI DB table space.

```
% db2 "CREATE BUFFERPOOL SMALLTABLES \
   DATABASE PARTITION GROUP HPSS_GHI SIZE 1000 AUTOMATIC \
   PAGESIZE 4K"
```

2. Create the bufferpool used for GHI mapping tablespace.

```
% db2 "CREATE BUFFERPOOL bp32k \
   DATABASE PARTITION GROUP HPSS_GHI SIZE 1000 AUTOMATIC \
   PAGESIZE 32K"
```

- 3. Create Db2 tablespaces.
 - a. Create Db2 tablespace for GHIDB.

```
% db2 "CREATE LARGE TABLESPACE GHIDB \
IN DATABASE PARTITION GROUP HPSS_GHI \
PAGESIZE 4K \
MANAGED BY AUTOMATIC STORAGE \
AUTORESIZE YES \
INITIALSIZE 32M \
MAXSIZE NONE \
EXTENTSIZE 128 \
PREFETCHSIZE AUTOMATIC \
BUFFERPOOL "SMALLTABLES" \
OVERHEAD 7.500000 \
TRANSFERRATE 0.060000 \
NO FILE SYSTEM CACHING \
DROPPED TABLE RECOVERY ON \
DATA TAG NONE"
```

GHI Installation Guide 18 / 39

b. Create Db2 tablespace for GHIMAPPING.

```
% db2 "CREATE LARGE TABLESPACE GHIMAPPING
IN DATABASE PARTITION GROUP HPSS_GHI \
PAGESIZE 32K \
MANAGED BY AUTOMATIC STORAGE \
AUTORESIZE YES \
EXTENTSIZE 128 \
PREFETCHSIZE AUTOMATIC \
BUFFERPOOL BP32K \
DATA TAG NONE \
OVERHEAD 7.500000 \
TRANSFERRATE 0.060000 \
MAXSIZE NONE \
NO FILE SYSTEM CACHING \
DROPPED TABLE RECOVERY ON"
```

3.3.3 Configure Logging on the HPSS Core Server

• Grant user hpss access to the database.

```
% db2 "grant connect on database to user hpss"
% db2 "grant createtab on database to user hpss"
% db2 "grant dbadm on database to user hpss"
```

 Configure the primary logs, secondary logs, log archives, log file size, and number of logs similar to the standard of the HPSS databases.

```
% mkdir /db2data/p0000/db2_log/hghi
% db2 "update db cfg for hghi using NEWLOGPATH <primary_log_path> hghi"
% db2 "update db cfg for hghi using NEWLOGPATH '/db2data/p0000/db2_log/hghi'"
% mkdir /db2data/p0000/db2_logmirror/hghi
% db2 "update db cfg for hghi using MIRRORLOGPATH <secondary_log_path> hghi"
% db2 "update db cfg for hghi using MIRRORLOGPATH
'/db2data/db2 logmirror/hghi'"
% db2 "update db cfg for hghi using AUTO_MAINT off"
% db2 "update db cfg for hghi using AUTO_RUNSTATS off"
% db2 "update db cfg for hghi using AUTO_TBL_MAINT off"
% mkdir /db2data/p0000/db2_logarchive1/hghi
% db2 "update db cfg for hghi using LOGARCHMETH1 \
DISK:/ <primary_log_archive_path>/hghi/"
\$ db2 "update db cfg for hghi using LOGARCHMETH1 \setminus
DISK:/db2data/p0000/db2_logarchive1/hghi/"
% mkdir /db2data/p0000/db2_logarchive2/hghi
% db2 "update db cfg for hghi using LOGARCHMETH2 \
DISK:/<secondary_log_archive_path>/hghi/"
% db2 "update db cfg for hghi using LOGARCHMETH2 \
DISK:/db2data/p0000/db2_logarchive2/hghi/"
% db2 "update db cfg for hghi using LOGFILSIZ 25000"
% db2 "update db cfg for hghi using LOGPRIMARY 10"
% db2 "update db cfg for hghi using LOGSECOND -1"
```

GHI Installation Guide 19 / 39

Table 3.1: LOGBUFSZ

Machine Memory	LOGBUFSZ <table value=""></table>
< 16 GB RAM	4096
16 - 64 GB RAM	8192
> 64 GB RAM	16384

```
% db2 "update db cfg for hghi using LOGBUFSZ "
```

```
% db2 "update db cfg for hghi using DFT_QUERYOPT 2"
```

• Disconnect from the database.

% db2 disconnect all

3.4 Install Db2 Client on all GHI Nodes

Install the Db2 Client on each Spectrum Scale quorum node (all nodes which include "quorum" in the "Designation" column from the **mmlscluster** command). Follow the Db2 Command Reference document to install the server.

3.5 Add Db2 Permanent License on all GHI Nodes

Add a permanent license on each Spectrum Scale quorum node that has the Db2 client installed.

· Add License.

```
% cd /opt/ibm/db2/<version>/adm
% ./db2licm -a <path name to Db2 generic license file>/db2aese_c.lic
```

Note

The generic Db2 license file ("*/db2/license/db2ese.lic") can be found on the Db2 Installation CD or image. It can also be obtained by contacting your HPSS customer support representative.

Tip

Refer to the Db2 Command Reference document for more information on how to use the db2licm utility to manage the Db2 license. Create the Db2 database connection on the GHI Session nodes which should already have the Db2 client installed per the prerequisites.

• Create an instance as root.

```
% /opt/ibm/db2/<version>/instance/db2icrt -a CLIENT -s client -u hpssdb hpssdb
```

Source db2profile system wide to establish database environment.
 As root, add lines to aliases.sh.

GHI Installation Guide 20 / 39

```
$ su - root
$ vim /etc/profile.d/aliases.sh
. ~hpssdb/sqllib/db2profile
```

• Set DB2COMM.

As hpssdb

```
% su - hpssdb
% db2set DB2COMM=tcpip
```

• Verify that DB2COMM is set to topip

```
% db2set -all
[i] DB2COMM=TCPIP
[g] DB2SYSTEM=ghi_server1.clearlake.ibm.com
```

• Verify the local services in /etc/services file for Db2 support

As root, copy the Db2 service entries from the Core Server /etc/services file. The number of entries will differ based on configuration.

Example output:

```
# Local services
db2c_hpssdb 59999/tcp
DB2_hpssdba 60000/tcp
DB2_hpssdba_1 60001/tcp
DB2_hpssdba_2 60002/tcp
DB2_hpssdba_END 60003/tcp
```

• Catalog the database profile.

```
% db2 catalog tcpip node ghi_server2 remote <HPSS_Core_server> server 59999
DB20000I The CATALOG TCPIP NODE command completed successfully.
DB21056W Directory changes may not be effective until the directory cache is refreshed.
```

% db2 catalog tcpip node \$NODE remote \$HPSS_CORE server \$PORT

Where:

· Catalog the database hghi

GHI Installation Guide 21 / 39

```
% db2 catalog db hghi as hghi at node $NODE
```

\$ db2 catalog db hghi as hghi at node ghi_server2 Db20000I The CATALOG DATABASE command completed successfully. Db21056W Directory changes may not be effective until the directory cache is refreshed.

a. Verify that Db2 client can connect to the Db2 server on the HPSS core machine.

% /opt/hpss/bin/ghi_db_test --connect

GHI Installation Guide 22 / 39

Chapter 4

HPSS

The HPSS Core server must also be able to connect to the network configured for the Spectrum Scale configuration. For example, if the Spectrum Scale cluster is configured exclusively on a data network, HPSS must be able to connect to that data network, even if the Spectrum Scale nodes also have an additional network to connect to the HPSS Core Server.

4.1 Verify HPSS rpms on all GHI NODES

Verify that the following RPMs are installed on all the GHI nodes:

These should exist when GHI-ISHTAR was previously installed.

4.2 Configure HPSS Client

- 1. Set up /var/hpss/etc on GHI client machines.
 - a. Verify that /var/hpss/etc/* was copied from the HPSS Core Server to each GHI node.
 - b. Add HPSS_API_HOSTNAME=<long hostname> to /var/hpss/etc/env.conf
 - c. Add HPSS_PTHREAD_STACK=524288 to /var/hpss/etc/env.conf
- 2. Set up authentication.

Copy the HPSS PAM module (/etc/pam.d/hpss) from the HPSS Core Server to /etc/pam.d/hpss on all GHI nodes.

3. Set up links.

```
% /opt/ibm/db2 > ln -s /opt/ibm/db2/<version> /opt/ibm/db2/default
% /opt/hpss/db2 > ln -s /opt/ibm/db2/<version> /opt/hpss/db2/default
```

If using Kerberos authentication, copy /etc/krb5.conf from the HPSS Core Server to all GHI nodes.

1. Specify the *HPSS_NET_FAMILY*. Ensure that the HPSS client configuration has the correct HPSS_NET_FAMILY in /var/hpss/etc/env.conf. The default value is ipv4_only. Examples:

GHI Installation Guide 23 / 39

ipv6_only ipv4_only ipv6

GHI Installation Guide 24 / 39

Chapter 5

GHI Installation & Configuration

5.1 Install GHI

1. Install the following RPMs on all GHI nodes:

```
% rpm -ivh ghi-lib-*<architecture>.rpm
% rpm -ivh ghi-*<architecture>.rpm
```

GHI files will be installed under /hpss_src/ghi-*.architecture

1. Create a link at /opt/ghi to /hpss_src/ghi-<version>.<architecture>.+ GHI requires this link to exist to function properly.

```
% ln -s /hpss_src/ghi-<version>.<architecture> /opt/ghi
```

2. Verify that the following directories exist:

```
/opt/ghi
/opt/ghi/bin
/opt/ghi/lib
/usr/share/man/cat7
/var/hpss/ghi
/var/hpss/ghi/policy
/var/hpss/ghi/config
/var/hpss/ghi/config/templates
/var/hpss/hsi/bin
```

3. Create /var/hpss/ghi/etc directory

```
% mkdir /var/hpss/ghi/etc
```

5.1.1 Configure GHI-ISHTAR

1. Copy the htar.ksh wrapper script to /var/hpss/hsi/bin.

```
% cd /var/hpss/hsi/bin
% cp htar.ksh.template htar.ksh
% edit htar.ksh (Variables to modify are described with example below)
% /bin/chmod 755 htar.ksh
```

2. Modify the htar.ksh script to provide correct values for the following information:

GHI Installation Guide 25 / 39

Variable	Description	Example
TMPDIR	Location of the temporary files. The	export TMPDIR=/ <spectrum< td=""></spectrum<>
	amount of space required is based on	Scale_mount_point>/scratch/.ghi
	the size of an aggregate, plus	
	temporary files created for the data	
	files.	
DEFAULT_REALM	Realm name for location of the HPSS	if ["\$DEFAULT_REALM" = ""]; then
	Core server. This name must match	DEFAULT_REALM=core_server.clearlake.ibm.com
	what is set for "site name" in	fi
	/var/hpss/etc/site.conf from the Core	
	Server.	
HPSS_AUTH_METHOD	Set this variable for desired	export HPSS_AUTH_METHOD=unix
	authentication type <unix or<="" td=""><td></td></unix>	
	Kerberos>. This variable will	
	determine your keytab file to be used.	
HPSS_KEYTAB_PATH	Location of keytab. Set this variable	export HPSS_KEYTAB_PATH=
	when using UNIX authentication (ex.	/var/hpss/etc/hpssdmg.unix.keytab
	/var/hpss/etc/hpssdmg.unix.keytab).	
HPSS_HOSTNAME	Interface to be used for the data path.	export HPSS_HOSTNAME=ghi_server1

5.2 GHI Users and Groups

All authentication and authorization are done using the hpssdmg principal. The numeric IDs must match those on the HPSS Core Server, which may be obtained from the "/etc/passwd" file on your HPSS Core Server.

- 1. Verify hpssdmg User ID exists on each GHI node.
- 2. Verify Group ID hpsssrvr is set for hpssdmg.

If the user hpssdmg or group hpsssrvr do not exist, create them.

5.3 Configure GHI

GHI is configured using command-line tools. All of the GHI commands discussed in this section are fully documented in the GHI Management Guide.

These are the steps to configure GHI:

- 1. Create GHI cluster from the Spectrum Scale configuration.
- 2. Add Spectrum Scale file system for GHI to manage.
- 3. Add IOMs for each GHI managed Spectrum Scale file system.

5.4 Create GHI Cluster

Define the overall cluster configuration, including the nodes which will be known to GHI (not necessarily all nodes known to Spectrum Scale). This is accomplished via the ghicrcluster command. The ghicrcluster command must run on the session node that is designated as "Cluster manager node". Use mmlsmgr command to determine which node is the cluster manager.

GHI Installation Guide 26 / 39

In addition, Spectrum Scale must be running when defining the cluster configuration to GHI.

All nodes that are designated as quorum with the **mmlscluster** command must be listed after the cluster manager. This will allow GHI to assign them as a manager node in the case of a failover.

```
% ghicrcluster [-v] {--ppc_64 | --ppc_64le | --x86_64 <node>} ... <GHI_node> ..
% ghicrcluster -N [-v] {--ppc_64 | --ppc_64le | --x86_64 <node>} ... < ←
    nodelist_file>
```

Where:

```
<node> = This is the node the source code was compiled on (ghilscluster).
<GHI_node> | <nodelist_file> = Node list of machines from mmlscluster
which will have the designation of "manager" in the command mmlscluster.
```

The below command is an example.

```
% ghicrcluster -v --ppc_64 firefly firefly falcon
```

After ghicrcluster returns "Done.", restart Spectrum Scale and GHI.

```
% ghishutdown -G
% ghistartup -G
```

Note

If **ghicrcluster** fails during the configuration, retry the configuration step with the "-r" option after the errors from the failure are resolved (ghicrcluster -r [-v]).

5.5 Create Spectrum Scale file systems GHI will manage

Use the command **ghiaddfs** for each file system to be created, which may be issued from any node in the cluster. File systems to be defined must NOT be mounted in Spectrum Scale when the **ghiaddfs** command is issued. **ghiaddfs** will supply default values for the file system which can be updated or changed with the command **ghichfs**.

For each file system, the name and mount point are to be supplied by the user. The ports to be used by the associated SD and ED may also be user-supplied or left to their default values.

```
% ghiaddfs [-v] <FS_Name> [-c "# <comment>"] <Mount_Point> [<SD_Port> <ED_Port>]
```

GHI Installation Guide 27 / 39

Note

- <FS_Name> = The same as the Spectrum Scale configuration name.
- <Mount_Point> = The same as the Spectrum Scale configuration mount point.

 $\langle SD_Port \rangle = The default Scheduler Daemon port is 80x0, where x is the order in which file systems were configured. For example, 8010 for the first configured file system. GHI will assign a port if one is not specified.$

 $\langle ED_Port \rangle$ = The default Event Daemon Port is 80x1, where x is the order in which file systems were configured. For example, 8011 for the first configured file system. GHI will assign a port if one is not specified.

The below command is an example.

```
% ghiaddfs firefly /firefly
```

5.6 Create IOMs for each GHI Managed File systems

If you have multiple GHI nodes, you should create one IOM per GHI file system on each node. Each file system will use the same IOM port number across all nodes.

The default port selected for an IOM is 80*x*2, where x is the order in which the file system was configured (8012 for the first configured file system, 8022 for the second configured file system, etc.). For more details about ports, see the GHI Management Guide.

Refer to the GHI Management Guide for more details about ghiaddiom.

```
% ghiaddiom [-vd|D] <File System name> [-c "# <comment>"] <IOM Node> \
<active_on_session_node> <estimate_transfer_rate> <chunksize>
```

Where:

```
<File System name> = Name of the file system added with the ghiaddfs command.
<IOM Node> = Name of node the IOM will run.
<active_on_session_node> = Active state of the IOM on the manager session node.
<estimate_transfer_rate> = Estimated data transfer rate.
<chunksize> = maximum # of bytes to transfer per non-aggregate HPSS I/O request.
```

Example:

```
% ghiaddiom -v firefly firefly:8012 TRUE 1GB 1TB
```

5.7 Modify xinetd.conf for number of IOMs

Note

This setting should be adjusted whether using RHEL 6.X or RHEL 7.X

```
% vi /etc/xinetd.conf*
```

change cps = 50 10 to cps = <IOM Thread Pool Size * number of IOMs> 10

IOM Thread Pool Size can be obtained from ghilsfs <file system> --iotps

GHI Installation Guide 28 / 39

5.8 Information Lifecycle Management (ILM) Policies

GHI makes use of Spectrum Scale ILM policies. A policy is a plain-text file that describes files and directories to be included or excluded from processing. IBM provides templates which you may use as a starting point to configure custom policies. These templates can be found in the /var/hpss/ghi/policy directory. Below is a list of policy templates.

migrate.policy

This file can be placed in any directory in the system. The policy should have separate rules for aggregates and non-aggregates. The script, ghi migrate, gets invoked from the policy engine and requires a "-a" option to process aggregates.

reset_incomplete_migration.policy

Use this policy to reset files for which a migration was started but never completed. Such files will show as "[incompletely-migrated]" when listed with "ghi_ls -h". They are "migrated enough" such that Spectrum Scale will not select them to be re-migrated, and the migration-reset process will result in the files being set back to "un-migrated" so that Spectrum Scale will select them in the next applicable migration policy run. This file can be placed in any directory in the system.

recall.policy

The recall policy does not use a bulk size. The policy generates on list. That list is parsed into aggregates and non-aggregates. The recall policy file can be placed in any directory in the system.

tape_smart_migration.policy

This is an example used to migrate files in a tape smart manner. Files are migrated by HPSS file families and by path name. This policy can be used in combination with the –split-filelists-by-weight option for mmapplypolicy to generate file lists that contain elements with the same WEIGHT value.

backup_migration.policy

The migration policy will run a full Spectrum Scale scan and will attempt to migrate any files that are not stored currently in HPSS. The policy file should be updated to reflect the migration rules used for this file system. The policy should be able to select every file that has not been migrated to HPSS and exclude any file which should not be migrated. Verify that the backup migration policy matches what is being backed up in the backup_metadata.policy to ensure that files which have not been migrated are included in the metadata backup.

backup_metadata.policy

This policy is used by the Spectrum Scale SOBAR mmimgbackup command. Spectrum Scale file system namespace and file metadata are sent to GHI and HPSS.



Important

Do not change the backup_metadata policy without contacting IBM GHI support.

backup_error.policy

The backup error policy contains the rules that are used to validate the capture of a file system's metadata.



Important

Do not change the backup_error policy without contacting IBM GHI support.

threshold.policy

The Spectrum Scale ILM threshold policy provides the capability for GHI to space manage the Spectrum Scale file system. New and modified Spectrum Scale files are copied to HPSS on a periodic basis. When the Spectrum Scale file system reaches a predefined space threshold, the Spectrum Scale ILM threshold policy is executed to identify file candidates whose data can be removed from the file system. This file must be copied from the /var/hpss/ghi/policy directory to /var/hpss/ghi/policy/<file system> and modified to be file system specific. The script, ghi_migrate, is invoked from the policy engine requires a "-p" option to punch holes in the file system.

GHI Installation Guide 29 / 39

Chapter 6

Backup & Restore

6.1 Backups

To backup a Spectrum Scale file system, use the GHI ghi_backup command line interface. The backup interface uses the Spectrum Scale mmimgbackup command, which uses the ILM policy management engine.

GHI backups use the Spectrum Scale snapshot feature to take a point-in-time image of the file system. When running a backup:

- 1. A snapshot of the Spectrum Scale namespace is saved after the backup migration policy and any other running migration policies have completed.
- 2. The state of each of the files is saved.

Each file system to be backed up uses its own copy of each of the following backup policy templates that reside in the /var/h-pss/ghi/policy directory:

backup_migration.policy:

The backup migration policy contains the migration rules for the Spectrum Scale file system to be backed up. The rules can migrate files as aggregates or non-aggregates. The rules must select all the files to be backed up.

backup_metadata.policy:

The backup metadata policy contains the rules that previous GHI versions need to capture a file system's metadata. The new image backup feature does not require a metadata policy for metadata backup. The metadata is contained in the image generated by Spectrum Scale as part of the backup process.

backup_error.policy:

The backup error policy contains the rules that are used to validate the capture of the file system's metadata.

Tip

IBM recommends running a daily backup. Checking the backup logs daily to correct any errors is a good practice to ensure successful backups. The GHI backup option is image. Full non-image backup is deprecated. Details of backup is provided in the GHI Management Guide.

Most sites create a crontab entry to run a daily backup.

```
ghi_backup <filesys> <type> [-E <Fsets> [-U <user_args>]] | [-U] [<user_args>]
qhi_backup <filesys> <type> [-E -F <List of Fsets> [-U <user_args>]]
```

Where:

GHI Installation Guide 30 / 39

```
type = one of the backup type:
image = image backup using Spectrum Scale SOBAR capability.
Fsets = filesets which need not be linked-in, either space-separated
List of Fsets or -F space-separated list of files containing list
of filesets user_args = args to be passed to policy.
```

Example command:

```
% ghi_backup firefly image
```

6.2 Restore

Refer to Backup and Recovery in the GHI Management Guide for more restore details.

GHI Installation Guide 31 / 39

Chapter 7

GHI Conversions

Note: Make sure that for any version you upgrade to, you read through all instructions from the version you are upgrading from up until the version you are installing.

7.1 Conversion steps for 3.1.0 to 3.2.0

Note

The conversion process will use RPMs for GHI 3.2.0.

1. Modify the callback script to source the database profile on all GHI nodes. (DB2PROF)

% vim /opt/ghi/bin/hpssEventNotify

7.2 Conversion steps for 3.0.1 to 3.1.0

Note

The conversion process will use RPMs for GHI 3.1.0.

• Shutdown GHI.

% ghishutdown -g

• Verify all non-IOM GHI processes are not in the process list

```
% ps -ef | grep ghi | grep -v ghi_iom
```

Note

If any GHI processes remain in the list use kill -9 <pid> to shut them down.

• Unmount the file system

GHI Installation Guide 32 / 39

```
% mmumount <file system> -a
```

· Remove old GHI RPMs

```
% rpm -qa | grep ghi - List installed RPMs
% rpm -e <ghi_rpms installed from above>
% rpm -qa | grep ghi - Verify no GHI RPMs are installed
```

• Install new GHI 3.1.0 RPMs

Note

RPMs deployed will vary. Contact GHI support rep before installing.

```
% cd <path to GHI 3.1.0 RPMs> % rpm -ivh ghi-3.1.0.0-0.<arch>, ghi-lib-3.1.0.0-0.<arch>, ghi-ishtar-5.1.2.0-0.<arch>
```

• Run ghiupdate

```
% ghiupdate -vT --<OS arch> <all nodes listed in ghilsnodes> - It is recommended to use ←
    the -T option first.

% ghiupdate -v --<OS arch> <all nodes listed in ghilsnodes>
```

- Make sure the directory where GHI is installed is linked to /opt/ghi.
- Delete and recreate the mmcallbacks so they use the /opt/ghi/bin path. For example, if the mmcallbacks are:

You should do the following to re-add the callbacks for the /opt/ghi directory.

Delete the callbacks with:

```
% mmdelcallback hpssCBstartup
% mmdelcallback hpssCBthreshold
```

and add them back for /opt/ghi with:

```
% mmaddcallback hpssCBstartup --command /opt/ghi/bin/hpssEventNotify --event startup, \( \to \)
    clusterManagerTakeover,preShutdown --parms "%clusterName %eventName %clusterManager.ip \( \to \)
    %myNode.ip"

% mmaddcallback hpssCBthreshold --command /opt/ghi/bin/hpssCBthreshold --event \( \to \)
    noDiskSpace,lowDiskSpace --parms "%eventName %fsName"
```

GHI Installation Guide 33 / 39

• Delete and read the IOMs so they are configured for the new location under the /opt/ghi directory. The following instructions can help achieve this:

· List all IOMs

```
% ghilsiom <file system>
```

You can use this to see the current IOM configuration info.

· Delete all IOMs

```
% ghideliom <file system> <IOM node>:<port #>
```

Use this on each IOM node you want recreated on the file system

• Add all IOMs

```
% ghiaddiom <file system> <IOM node>:<port #> <asn value> <etr value> <chunk size>
```

where <asn value> = the value indicated earlier for the "Active Session Node" in the ghilsiom output <etr value> = the value indicated earlier for the "Estimated Transfer Rate" in the ghilsiom output <chunk size> = the value indicated earlier for the "Transfer Chunk Size" in the ghilsiom output Repeat the above for each IOM and port in ghilsiom

· Restart ghi

```
% ghishutdown -g
% ghistartup -g
```

- The new IOM should be usable and you can confirm the change by running ghilsiom <file system>.
- You may wish to update your path to include /opt/ghi/bin so that the ghi executables can be found without specifying the path.
- The files installed by the GHI RPM that specify GHI paths will use /opt/ghi instead of /opt/hpss. However, for any policy files containing GHI paths that already exist on the system that are not replaced by the GHI RPM, these will need to be updated so paths containing /opt/hpss are changed to /opt/ghi.
- Old libraries must be removed

As part of upgrading to versions of GHI 3.1.0 or higher from GHI 3.0.1 or older, sites should remove the GHI files from the HPSS directory. These include the ghi* files under /opt/hpss/bin and /opt/hpss/lib, but also these files under /opt/hpss/lib:

```
HPSSModule.so
libhpssghi.so
libhpssghi_base.so
```

Note

GHI will attempt to create a link in libhpssghi_restore.so in /opt/hpss/lib. Spectrum Scale continues to link with that location for handling image restores. The libhpssghi_restore.so file should be removed.

and these files under /opt/hpss/bin:

GHI Installation Guide 34 / 39

```
db2db.py
dmapishell
hpssAddCallbacks
hpssCBthreshold
hpssEventNotify
hpss_krb5_rmxcred
hpssdelete
hpsslist
hpssmigrate
hpssmigrate
hpssrecall
lsghi
lsgpfs
```

• Policy files must be updated to reflect the new install location

Also, customers will have to update **all policy files** on all their nodes manually to reflect /opt/ghi/bin instead of /opt/hpss/bin. Until this is done, migrations, recalls, and stages will not work.

7.3 Conversion steps for 3.0.0 to 3.0.1

Note

The conversion process will use RPMs for GHI 3.0.1.

· Shutdown GHI.

```
% ghishutdown -g
```

• Verify all non-IOM GHI processes are not in the process list

```
% ps -ef | grep ghi | grep -v ghi_iom
```

Note

If any GHI processes remain in the list use kill -9 <pid> to shut them down.

• Unmount the file system

```
% mmumount <file system> -a
```

• Remove old GHI RPMs

```
% rpm -qa | grep ghi - List installed RPMs
% rpm -e <ghi_rpms installed from above>
% rpm -qa | grep ghi - Verify no GHI RPMs are installed
```

• Install new GHI 3.0.1 RPMs

Note

RPMs deployed will vary. Contact GHI support rep before installing.

GHI Installation Guide 35 / 39

```
% cd <path to GHI 3.0.1 RPMs>
% rpm -ivh ghi-3.0.1.0-0.<arch>, ghi-lib-3.0.1.0-0.<arch>, ghi-ishtar-5.1.2.0-0.< ←
    arch>
```

· Run ghiupdate

```
% ghiupdate -vT --<0S arch> <all nodes listed in ghilsnodes> - It is recommended \ \hookleftarrow to use the -T option first.
```

- Convert the GHI garbage collection table on each file system. This step should be run for all file systems; the conversion of file system tables can be executed in parallel.
 - For each file system, modify /var/hpss/ghi/templates/ghimodifygc.ddl by replacing the template info (<GC_FILESYSTEM>) with your file system name throughout the file (e.g. if your file system name is "foo", the table name should be "GC_FOO").

```
% cat /var/hpss/ghi/templates/ghimodifygc.ddl
```

% ghiupdate -v --<OS arch> <all nodes listed in ghilsnodes>

```
connect to hghi;
ALTER TABLE HPSS."GC_FOO_FS1"
ADD COLUMN INODE
BIGINT NOT NULL DEFAULT 0
ADD COLUMN IGEN
INTEGER NOT NULL DEFAULT 0;
reorg table HPSS."GC_CANAAN_FS1";
```

- Run the modified ghimodifygc.ddl.

```
% db2 -svtf ghimodifygc.ddl
```

· Start new GHI

```
% ghistartup -g
```

• Verify that PM, CM, MD processes are running.

```
% ps -ef | grep ghi
```

• Mount GHI managed File Systems

```
% mmmount <file system> -a
```

· Verify SD, ED, and then IOMs are active

```
% tail /<file system>/scratch/mon/<mon_sd.out | mon_iom.out>
```

Note

The Pin Conversion process converts DMAPI PIN attributes into timestamp values for all file systems. If GPFS is restored using a backup prior to this conversion, the unconverted DMAPI PIN attributes will be restored as well, and it will be necessary to rerun these steps to convert the PIN attribute values again.

GHI Installation Guide 36 / 39

- Convert the DMAPI PIN attributes into timestamp values for all file systems
 - List all pinned files using the following policy:

* Apply the above policy

```
% ghiapplypolicy <file system> -P <above template file> -I defer
```

- Generate a file list for all pinned files and convert them:

- Generate a file list for all unpinned files (files which were previously pinned, but were later unpinned using the ghi_pin tool) and convert them:

```
% cat <path/to/scratch/.ghi>/list.files_unpinned | cut -d' ' -f7 > /tmp/ ←
    unpinned_files
% ghi_pin -u -f /tmp/unpinned_files
```

Validate that all attributes have been migrated by listing the pinned files and comparing row counts - they should match. If
not, list the pinned files again and rerun the ghi_pin tool against the resulting list.

```
% ghiapplypolicy -P /var/hpss/ghi/policy/pin_time_list.policy -I defer
% wc -l <path/to/scratch/.ghi>/list.files_pinned </path/to/scratch/.ghi>/list. 
files_pinned_time
1000 <path/to/scratch/.ghi>/list.files_pinned
1000 <path/to/scratch/.ghi>/list.files_pinned_time
```

Note

It could take up to ten minutes for ED to connect to SD and fifteen minutes for the IOMs to connect to the ED. If after twenty minutes things are still not connecting, contact your GHI support rep.

GHI Installation Guide 37 / 39

Chapter 8

GHI Conversions

8.1 Conversion steps for 3.1 to 3.2

Note

The conversion process will use RPMs for GHI 3.2.

• Shutdown GHI.

```
% ghishutdown -g
```

• Verify all non-IOM GHI processes are not in the process list

```
% ps -ef | grep ghi | grep -v ghi_iom
```

Note

If any GHI processes remain in the list use kill -9 <pid> to shut them down.

• Unmount the file system

```
% mmumount <file system> -a
```

• Remove old GHI RPMs

```
% rpm -qa | grep ghi - List installed RPMs
% rpm -e <ghi_rpms installed from above>
% rpm -qa | grep ghi - Verify no GHI RPMs are installed
```

• Install new GHI 3.2 RPMs

Note

RPMs deployed will vary. Contact GHI support rep before installing.

GHI Installation Guide 38 / 39

- Run ghiupdate
 - $\mbox{\%}$ ghiupdate -vT --<OS arch> <all nodes listed in ghilsnodes> It is recommended $\ \ \mbox{\leftarrow}$ to use the -T option first.
 - % ghiupdate -v --<OS arch> <all nodes listed in ghilsnodes>
- Create Indexes on the GHI Mapping tables for each file system. These steps should be run for all file systems; the conversion of the system tables can be executed in parallel.
 - For each file system, source the db2 database.
 - % source <hpssdb user home>/sqllib/db2profile
 - Create the HPSS path index.
 - % db2 "CREATE INDEX HPSSIDX ON MAPPING_<FS>_BASE (HPSSPATH)"
 - Create the GPFS path index.
 - % db2 "CREATE INDEX GPFSIDX ON MAPPING_<FS>_BASE (GPFSPATH)"
 - Create the Inode index.
 - % db2 "CREATE INDEX INODEIDX ON MAPPING_<FS>_BASE (INODE)"
 - Update statistics in the system catalog for the GHI mapping base table.
 - % db2 "RUNSTATS ON TABLE MAPPING_<FS>_BASE AND SAMPLE DETAILED INDEXES ALL"
 - Remove any cached SQL statements.
 - % db2 "FLUSH PACKAGE CACHE DYNAMIC"
 - Check if the mapping table needs to be reorganized.
 - % db2 "REORGCHK CURRENT STATISTICS ON TABLE MAPPING_<FS>_BASE"
- Create a new index on the GHI Garbage Collection table for each file system. This step should be run for all file systems; the conversion of the system tables can be executed in parallel.
 - For each file system, source the db2 database.
 - % source <hpssdb user home>/sqllib/db2profile
 - Create the SOID Index for the GC table.
 - % db2 "CREATE INDEX GC_<FS>_SOID_INDEX ON GC_<FS> (SOID)"
- · Start new GHI
 - % ghistartup -g
- Verify that PM, CM, MD processes are running.
 - % ps -ef | grep ghi
- Mount GHI managed File Systems
 - % mmmount <file system> -a

GHI Installation Guide 39 / 39

```
AND path_name NOT LIKE '%/%.snapshot%' RULE 'Default' SET POOL 'system'
```

- Generate a file list for all unpinned files (files which were previously pinned, but were later unpinned using the ghi_pin tool) and convert them:

```
% cat <path/to/scratch/.ghi>/list.files_unpinned | cut -d' ' -f7 > /tmp/ ← unpinned_files
% ghi_pin -u -f /tmp/unpinned_files
```

- Validate that all attributes have been migrated by listing the pinned files and comparing row counts - they should match. If not, list the pinned files again and rerun the ghi_pin tool against the resulting list.

```
% ghiapplypolicy -P /var/hpss/ghi/policy/pin_time_list.policy -I defer
% wc -l <path/to/scratch/.ghi>/list.files_pinned </path/to/scratch/.ghi>/list. ←
   files_pinned_time
1000 <path/to/scratch/.ghi>/list.files_pinned
1000 <path/to/scratch/.ghi>/list.files_pinned_time
```

Note

It could take up to ten minutes for ED to connect to SD and fifteen minutes for the IOMs to connect to the ED. If after twenty minutes things are still not connecting, contact your GHI support rep.