# 3、机器人键盘控制

### 1、程序启动

成功安装好Rosmaster库以及编译工作空间通过后,我们可以输入以下指令来启动小车键盘控制,以本公司Rosmaster-X3麦克纳姆轮子为例,终端输入,

#### #底层驱动

ros2 run yahboomcar\_bringup Mcnamu\_driver\_X3

#### #键盘控制

ros2 run yahboomcar\_ctrl yahboom\_keyboard

## 2、按键说明

#### 方向控制

[i] 或 [l]	[linear, 0]	[u] 或 [U]	[linear, angular]
[,]	[-linear, 0]	[0] 或[0]	【linear, -angular】
【j】或【J】	[0, angular]	[m]或[M]	[- linear, - angular]
【I】或【L】	[0, -angular]	[.]	【 - linear, angular】


#### 速度控制

按键	速度变化	按键	速度变化
[q]	线速度和角速度都增加10%	[z]	线速度和角速度都减少10%
[w]	仅线速度增加10%	[x]	仅线速度减少10%
[e]	仅角速度增加10%	[c]	仅角速度减少10%
[t]	线速度X轴/Y轴方向切换	[s]	停止键盘控制

## 3、节点通讯图

输入以下指令查看节点通讯图,

ros2 run rqt\_graph rqt\_graph



### 4、源码解析

键盘控制只能控制小车的运动控制,因此,只有一个/cmd\_vel速度发布者,

```
self.pub = self.create_publisher(Twist,'cmd_vel',1)
```

程序还定义了两个字典来检测键盘的字母按下时候的变化,

```
moveBindings = {
'i': (1, 0),
'o': (1, -1),
'j': (0, 1),
'1': (0, -1),
'u': (1, 1),
',': (-1, 0),
'.': (-1, 1),
'm': (-1, -1),
'I': (1, 0),
'0': (1, -1),
'J': (0, 1),
'L': (0, -1),
'U': (1, 1),
'M': (-1, -1),
}
speedBindings = {
'Q': (1.1, 1.1),
'Z': (.9, .9),
'W': (1.1, 1),
'X': (.9, 1),
'E': (1, 1.1),
'c': (1, .9),
'q': (1.1, 1.1),
'z': (.9, .9),
'w': (1.1, 1),
'x': (.9, 1),
'e': (1, 1.1),
'c': (1, .9),
}
```

进入while循环,程序会读取键盘按下的值,然后进行一层一层的判断,

```
key = yahboom_keyboard.getKey()
if key=="t" or key == "T": xspeed_switch = not xspeed_switch
elif key == "s" or key == "S":
...
if key in moveBindings.keys():
...
elif key in speedBindings.keys():
...
```

最后,根据多层的判断,赋值给twist.linear.x、twist.linear.y、twist.angular.z然后发布出去。

```
if xspeed_switch: twist.linear.x = speed * x
else: twist.linear.y = speed * x
twist.angular.z = turn * th
if not stop: yahboom_keyboard.pub.publish(twist)
if stop:yahboom_keyboard.pub.publish(Twist())
```

详细代码参考: ~/driver\_ws/src/yahboomcar\_ctrl/yahboomcar\_ctrl/yahboom\_keyboard.py。