
CLASSIFICATION CHANGED TO the lossified

BY AUTHORITY OF Br. Ass

ON 10/13/55 BY Dan M. Loice HISTORICAL

ILLUSTRATED ASSEMBLY BREAKDOWN









E	XPLOD	ED V	/IEW		4		7	20					Page 2
1	MAJOR	ASS	EMBL	IE:	S		•		· · · · · · · · · · · · · · · · · · ·	•	÷	ě	3
F	OWER	PLAI	NT	*		::::	:*s	•22	*3	*8		*	4, 5
(COCKPI	T PA	NELS	5		31.275		100	•	₫a		*	6
(COCKPI	Τ.		٠		٠	•	ē		•			7,8
I	EADIN	G ED	GE			-	8	•				3	9
F	RONT	SECT	ION		٠		400	•	*	*			10, 11
1	AFT SEC	CTIO	Ν.			0.00	**	¥ē.		*			12
1	RAILIN	G ED	GE	•	•		*0	•	*				13
F	PROP. 1	NACE	LLE	•	•	70:0	*6	*	*	*	*		14
1	MPENI	NAGE	Ξ.		127		:55	*:	*:	* 5	*	*	15
,	KIN PA	ANEL	S .	٠.		*88	58	100	25	*		œ	16

This booklet has been prepared by the Publications Section of the Engineering Department. It is designed to be used as a ready reference for major assembly

to be used as a ready reference for major assembly numbers of the airplane by all departments of our company.


January 1, 1945.


F. N. Dickerman

CHANCE VOUGHT AIRCRAFT

DIVISION OF UNITED AIRCRAFT . STRATFORD, CONN.

EXPLODED VIEW





Body Erection	CV3-200000
Body Assembly	CV3-200001
Tail Contour Lines	CV3-100201
Wing Contour Lines	CV3-200201
Wing Contour Lines	CV3-222201
Aft Section Unit	CV3-231001
Droppable Tank Installation	CV3-327000
Inboard Profile	CV3-400000
Three Point Plan Hoisting, Towing & Tie Down Diagram	CV3-400775
Interior Decalcomanias	CV3-400980
Exterior Decalcomanias	CV3-400981
lacking Diggram	CV3-400998
General Arrangement—Fighter	CV3-401000
Catapult Arrangement	CV3-401002
Catapult Arrangement	CV3-401003
Identification Subcontractors Plates	CV3-401004
Sealing Diagram	CV3-401006
Spotting Diagram	CV3-401007
Lubricating Diagram	CV3-401998
Lubricating Diagram	CV3-404999
Cockpit Illumination	CV3-425997
Cockpit Illumination	CV3-425999
Bomb Installation	CV3-440500
50 Cal. Gun Installation	CV3-452000
50 Cal. Blast Tube Adapter Installation	
Gun Bore Sighting Diagram	CV3-452998
Armament Installation	CV3-452999
20 MM Gun Installation	CV3-453000
Fixed Blast Tube Installation	
20 MM Blast Tube Adapter Installation	
Armor Arrangement	CV3 450008
Hoisting Sling Installation	
Radio Installation Identification Installation	CV2 491500
Radio Installation Rigging	CV3-481999





POWER PLANT


Removable Power Plant Instal	CV3-300500
Domoughla Davis Dl. (11 to 11)	CV3-300501-1
Demand I D. Di e II i Di	CV3-300301-1
	CV3-300501-2
Engine Electrical Box Installation	CV3-425410
Removable Diaphragm Installation .	CV3-302100
Exhaust Collector Installation	CV3-315100
Rear Engine Mount Installation	CV3-300600
Carburetor Air Intake Duct Instal	CV3-302600
Engine	P&W R-2000-2
Engine Gear Box Assembly LH	CV3-317001-3
Engine Gear Box Assembly RH	CV3-317001-4
Shaft Installation	CV3-317001-5
Intercooler Cooling Air Flap Assembly	
Engine Cooling Exit Air Flap Assembly	CV2 210501
Inner Cowl Assembly	
Intercooler Air Duct Installation	CV3-226750
	CV3-227000
Inboard Engine Air Duct Installation .	CV3-227400
Power Plant Installation	CV3-300000
Power Plant Lines	CV3-300201
Engine Controls Instal—Power Plant .	CV3-301000
Propeller Pitch Control Installation .	CV3-301300
GB Oil Cooler Ent. Air Duct Instal	CV3-302080
Engine Diaphragm Air Seal	CV3-302160
Removable Diaphragm Support	
Channel	CV3-302161
Diaphragm Upper Remov. Shoulder	0.0000.
Instal	CV3-302170
Instal	C 7 3 - 3 0 2 1 7 0
Instal	CV3-302200
Instal	
Inb'd Fixed Diaphragm Instal.—LH	
	CV3-302320
Inb'd Eng. Baffle Seal Instal.—	
—LH Fixed	CV3-302270-1
Inb'd Eng. Baffle Seal Instal.—	
	CV3-302270-2
Removable Engine Baffle Seal Instal	CV3-302270-3
Intercooler Installation	CV3-302300
	CV3-302401
Turbo & Intercooler Air Duct Vane	
Instal.	CV3-302420
Turbo & Intercooler Air Duct Instal.	CV3-302430
w moreovier All Duci install, .	C 7 3-302430

Intercooler Cooling Air Duct Instal.	CV3-302500
Intercooler to Carb. Air Duct Instal.	CV3-302530
Turbo to Intercooler Air Duct Instal.	CV3-302650
Generator Cooling Blast Tube Instal.	CV3-302680
Eng. Oil Cooler Entrance Air Duct	
Assem	CV3-302701
Engine Gear Box Fairing Installation .	CV3-302800
Intercooler Exit Air Duct Installation .	CV3-302900
Air Intake Blower Installation	CV3-303000
Blower Drive Shaft Installation	CV3-303070
Engine & Turbo Lubricating System .	CV3-307500
Eng. & Turbo Oil Cooler Support	
Instal.	CV3-307150
Eng. & Turbo Lubricating System	
	CV3-307202

Eng. & Turbo Lubricating System	
Elbow	CV3-307204
Engine & Turbo Oil Tank Installation .	CV3-307600
Eng. & Turbo Lubricating System—	0.000
Diagram	CV3-307998
Gear Boxes Lubricating System—	0,000,,,0
Nacelle	CV3-308000
Gear Boxes Oil Cooler Installation	CV3-308100
Gear Boxes Oil Drain Installation	CV3-308200
Gear Boxes Oil Tank Installation	CV3-308300
Gear Boxes Oiling Diagram	CV3-308996
Gear Boxes Lubricating System—	
Diagram	CV3-308998
Turbo Installation	CV3-309000
Exhaust System Ducts Installation	CV3-315200
Turbo Exhaust Tail Pipe Assembly	CV3-315301
Gear Boxes Installation	CV3-317001
Engine Gear Boxes Connecting Shaft	CV3-317301
Fuel System Installation	CV3-325000
Water Injection Tank Installation	CV3-325500
Water Injection System Main Fuel Tank Pressurization System	CV3-325600
Fuel System—Diagram	CV3-325900 CV3-325998
Self-Sealing Main Fuel Tank Instal.	CV3-325998
occurry mann for funk mann.	C10-020000








Cockpit Assembly		CV3-222001
Cabin Control Installation	405	CV3-225200
- Cabin Track Installation	10	CV3-222550
-Armor Panel—Top	-	CV3-222500
Cabin Fairing Assembly LH		CV3-222301
-Water Filler Door Installation	•27	
Oil Filler Door Installation		
Cabin Fairing Assembly RH		
Removable Panel Assembly		
Overturn Structure Installation	200 200	
Bulkhead Armor—Sta15		CV3-222801
Cockpit Armor Cowl Installation		
Windshield Access Door Installation		CV3-223250
Bullet Proof Glass Installation		CV3-223300
Removable Panel Assembly—Aft		
- Pilot's Armor Installation—Lower .		CV3-222100
Pilot's Seat Installation		
-Windshield Installation		CV3-223000
Nose Dome Installation		CV3-222600
Hydraulic System—Cockpit		
Compressed Air Lines Installation		CV3-402900-1
Fixed Gun Sight Installation		
Gun Camera Installation		
Electrical System		
Gun Switch Box Installation		
- Approach Light Installation		
		CV3-423630
Camera & Approach Light Bracket		CV2 425070
	- 51	CV3-4238/U
Armor Installation—Vertical		
Defroster Installation	(*)	CV3-472200







Cockpit General Arrangement	CV3-200999
Main Instrument Board Installation	CV3-411000
Writing Pad Installation	CV3-400075
Electrical System Panel	CV3-425200
Pedal & Brake Installation	CV3-404000
Center Aux. Board Supporting Bracket	
Installation	CV3-411100
Map Case Installation	CV3-400300
Foot Trough Installation	CV3-224900
Throttle Control Installation	CV3-301200
Mixture Control Installation	CV3-301100
Tow Target Installation	CV3-400200
Chartboard Holder Installation	CV3-400250
Relief Tube Installation	CV3-400500
Head Rest Installation	CV3-400550
Arm Rest Installation	CV3-400580
Pilot's Seat Equipment	CV3-400600
Shoulder Harness Release Installation	CV3-400671
Cockpit Cover Installation	CV3-400700
Compressed Air Cylinder Installation	CV3-402090
Ailayator Control—Stick & Rod Instal.	
Control Stick Support Installation LH	CV3-224700
Control Stick Support Installation RH	CV3-224750
Oxygen Equipment Installation	CV3-450000
Pedal & Support Assem.—	0,0 .0000
Brake & Rudder	CV3-404010
Fixed Equipment Instrument Installation	
Electrical System Box Installation	CV3-425330
Oxygen System Support Installation	CV3-450150
Oxygen System Support Installation .	C10-430130
Oxygen Cylinder Regulator Support	CV3-450160
Installation	CV3-455000
Fire Extinguisher Installation	CV3-472000
Ventilator Installation	C 7 3-47 2000















Engine Access Panel Assembly—Lower CV3-209161 Engine Access Panel Assembly—Upper CV3-209171 Aft Gun Access Door Instal.—Lower LH CV3-209300 Aft Gun Access Door Instal.—Lower RH CV3-209320 Fwd. Gun Access Panel—Lower LH . CV3-209351 Fwd. Gun Access Panel—Lower RH . CV3-209371 Ammunition Door Support Installation CV3-209450 Inboard Access Panel—Lower LH . . . CV3-209550 Inboard Access Panel-Lower RH CV3-209570 CV3-209650 Outboard Access Panel—Lower Turbo Access Panel—Lower . CV3-209700 CV3-210300 Tie Rod Installation—Beam Sta. 150.7 CV3-210450 Eng. Cooling Air Exit Flaps Sup't Instal. CV3-210500


Oil Cooler Flap Installation	CV3-210600
Center Section Skeleton Installation .	CV3-211200
Frame—Sta. 53.8—Lower	CV3-211350
Frame—Sta. 150.7—Upper	CV3-211400
Interframe Tube Instal.—Sta. 136.45	CV3-211530
Frame-Sta. 136.45-Lower	CV3-211550
Upper Frame Instal.—Sta. 103.9 Inb'd	CV3-211600-6
Upper Frame Instal.—Sta. 103.9	
—Outb'd	CV3-211600-7
Interframe Tube Instal.—Sta. 104	CV3-211658
Interframe Tube Instal.—Sta. 122	CV3-211762
Pylon Installation	CV3-440750
Amm. Feed Chute Sup't-50 Cal. LH	CV3-452530
Amm. Feed Chute Sup't—50 Cal. RH	CV3-452540











 Rudder Installation
 CV3-107001

 Fin Installation
 CV3-105001

 Fin Fairing Installation
 CV3-232500-1

 Stability Flap Installation
 CV3-238001

 Ailavator Installation
 CV3-109001

 Tab Assembly
 CV3-109501

 Balance Assembly—Inboard
 CV3-109821

 Balance Assembly—Outboard
 CV3-109811

 Ailavator Tab Control Installation
 CV3-406800

EMPENNAGE

