

JD Retail Product Care Guide

Document Version: 1.0

Last Updated: 20 July 2026

Product Care Guide

Proper care helps maintain the quality, appearance, and lifespan of your products. Customers should always follow the manufacturer's care instructions provided on the product label. Different product categories require different care methods.

Footwear Care

To keep your footwear in excellent condition:

- Clean shoes regularly using a soft brush or damp cloth.
 - Remove dirt immediately after use.
 - Avoid machine washing unless specifically recommended by the manufacturer.
 - Allow shoes to air dry naturally at room temperature.
 - Do not place footwear near radiators or direct heat sources.
 - Apply a suitable shoe protector spray before first use.
 - For suede or nubuck footwear, use a specialist suede brush and cleaner.
-

Clothing Care

Before washing clothing:

- Read the care label carefully.
- Wash garments inside out where possible.
- Separate light and dark colours.
- Use a mild detergent.
- Avoid excessive bleach unless specified on the care label.
- Do not overload the washing machine.

Recommended Washing Temperatures

Product Type Recommended Temperature

Sportswear 30°C

Hoodies 30°C

Product Type Recommended Temperature

T-Shirts	30°C
Shorts	30°C
Joggers	30°C

Drying Instructions

For best results:

- Air dry garments whenever possible.
- Avoid tumble drying unless permitted on the care label.
- Do not expose clothing to prolonged direct sunlight while drying.

Proper drying helps prevent shrinkage and colour fading.

Leather Product Care

Leather footwear and accessories should be maintained by:

- Wiping with a soft cloth.
 - Using an approved leather cleaner.
 - Applying leather conditioner periodically.
 - Avoiding excessive exposure to water.
-

Waterproof Products

Waterproof footwear and jackets require additional maintenance.

Recommendations include:

- Clean using a damp cloth.
 - Avoid fabric softeners.
 - Reapply waterproof treatment when necessary.
 - Allow products to dry naturally.
-

Sports Accessories

Backpacks, caps and sports accessories should be:

- Cleaned according to the manufacturer's instructions.

- Stored in a cool, dry place.
 - Checked regularly for signs of wear or damage.
-

Storage Recommendations

Store products:

- In a cool, dry environment.
- Away from direct sunlight.
- Away from excessive moisture.

Footwear should be stored using shoe trees or tissue paper to help maintain its shape.

Product Inspection

Regularly inspect products for:

- Loose stitching
- Sole wear
- Broken zips
- Damaged laces
- Fabric tears

Addressing minor issues early can help prevent further damage.

Warranty Information

Selected products may be covered by a manufacturer's warranty against manufacturing defects.

The warranty does **not** cover:

- Normal wear and tear
- Incorrect washing or cleaning
- Accidental damage
- Misuse
- Improper storage
- Unauthorised repairs

Customers should retain proof of purchase when making a warranty claim.

Reporting Product Faults

If you believe a product has developed a manufacturing fault:

- Contact Customer Support as soon as possible.
- Provide photographs where appropriate.
- Include proof of purchase.
- Return the product for inspection if requested.

Each claim is assessed individually.

Sustainability

To help extend the life of your products:

- Wash garments only when necessary.
- Use lower washing temperatures where appropriate.
- Repair minor damage where possible.
- Donate or recycle unwanted clothing.
- Recycle packaging responsibly.

Following these practices helps reduce environmental impact.

Customer Support

Email: support@jdretaildemo.com

Phone: +44 800 555 1000

Support Hours:

Monday – Friday

9:00 AM – 6:00 PM