

IPv4-Schema
Fgz. Nr: 4736-118



Fahrzeugnummer: 4736-118				Fzg. ID: 146				Wagen: A - 100					
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	73	120	120				
	e1-0	Überw. Kamera A7	5	Access	172	18	201	10	10	y	5.0		
	e1-1	Überw. Kamera A2	5	Access	172	18	201	11	11	y	5.0		
	e1-2	Überw. Kamera A1	5	Access	172	18	201	12	12	y	5.0		
	e1-3	Überw. Kamera A5	5	Access	172	18	201	13	13	y	5.0		
	e1-4	Überw. Kamera A9	5	Access	172	18	201	14	14	y	5.0		
	e1-5	AFZ A1	8	Access	172	20	73	5	5	y	10.0		
	e1-6	AFZ A2	8	Access	172	20	73	6	6	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle A1	9	Access	172	20	201	5	5	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A5	90	Access	-	-	-	-	-				
	e1-13	Future use box A6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A1	3	Access	172	17	201	25	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	201	26	26				
	e2-0	Bildschirm A7	3	Access	172	17	201	50	50				
	e2-1	Bildschirm A5	3	Access	172	17	201	51	51				
	e2-2	Bildschirm A1	3	Access	172	17	201	52	52				
	e2-3	Bildschirm A3	3	Access	172	17	201	53	53				
e2-4	ADU A	9	Access	172	20	201	3	3					
e2-5	Audio Amp. A1	9	Access	172	20	201	21	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera A8	5	Access	172	18	201	15	15	y	5.0		
	e1-1	Überw. Kamera A4	5	Access	172	18	201	16	16	y	5.0		
	e1-2	Überw. Kamera A3	5	Access	172	18	201	17	17	y	5.0		
	e1-3	Überw. Kamera A6	5	Access	172	18	201	18	18	y	5.0		
	e1-4	Überw. Kamera A10	5	Access	172	18	201	19	19	y	5.0		
	e1-5	AFZ A3	8	Access	172	20	73	7	7	y	10.0		
	e1-6	AFZ A4	8	Access	172	20	73	8	8	y	10.0		
	e1-7	NVR A	5	Access	172	18	201	5	5				
	e1-8	Sprechstelle A2	9	Access	172	20	201	6	6	y	7.5		
	e1-9	Sprechstelle A1R	9	Access	172	20	201	5	5	y	7.5		Redundanz A1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A2	90	Access	-	-	-	-	-				
	e1-13	Future use box A4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A2	3	Access	172	17	201	27	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	201	28	28				
	e2-0	Bildschirm A8	3	Access	172	17	201	54	54				
	e2-1	Bildschirm A6	3	Access	172	17	201	55	55				
	e2-2	Bildschirm A2	3	Access	172	17	201	56	56				
	e2-3	Bildschirm A4	3	Access	172	17	201	57	57				
e2-4				-	-	-	-	-					
e2-5	Audio Amp. A2	9	Access	172	20	201	22	22					
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera A1	5	Access	172	18	201	80	80	y	5.0		
	e1-1	Rücksehkamera A2	5	Access	172	18	201	81	81	y	5.0		
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4	Firewall	2	Trunk	172	17	73	1	1		Kein DHCP Statische Konfiguration STADLER		
			3		172	17	201	1					
			5		172	18	201	1					
			6		172	19	73	1					
			7		172	19	201	1					
			8		172	20	73	1					
			9		172	20	201	1					
	e1-5		12		172	22	73	1					
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle A2R	9	Access	172	20	201	6	6	y	7.5		Redundanz A2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A1	90	Access	-	-	-	-	-				
	e1-13	Future use box A3	90	Access	-	-	-	-	-				
e1-14	Frontanzeige A	3	Access	172	17	201	23	23					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU AR	9	Access	172	20	201	3	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	121	121				
	e1-0	Überw. Kamera C7	5	Access	172	18	201	20	20	y	5.0		
	e1-1	Überw. Kamera C2	5	Access	172	18	201	21	21	y	5.0		
	e1-2	Überw. Kamera C1	5	Access	172	18	201	22	22	y	5.0		
	e1-3	Überw. Kamera C5	5	Access	172	18	201	23	23	y	5.0		
	e1-4	Überw. Kamera C9	5	Access	172	18	201	24	24	y	5.0		
	e1-5	AFZ C1	8	Access	172	20	73	9	9	y	10.0		
	e1-6	AFZ C2	8	Access	172	20	73	10	10	y	10.0		
	e1-7	AFZ C5	8	Access	172	20	73	11	11	y	10.0		
	e1-8	Sprechstelle C1	9	Access	172	20	201	7	7	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C1	3	Access	172	17	201	29	29				
e1-15	Seitenanzeige C3	3	Access	172	17	201	30	30					
e2-0	Bildschrim C7	3	Access	172	17	201	58	58					
e2-1	Bildschrim C5	3	Access	172	17	201	59	59					
e2-2	Bildschrim C1	3	Access	172	17	201	60	60					
e2-3	Bildschrim C3	3	Access	172	17	201	61	61					
e2-4	Bildschrim C	3	Access	172	17	201	62	62					
e2-5	Audio Amp. C1	9	Access	172	20	201	23	23					
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera C8	5	Access	172	18	201	25	25	y	5.0		
	e1-1	Überw. Kamera C4	5	Access	172	18	201	26	26	y	5.0		
	e1-2	Überw. Kamera C3	5	Access	172	18	201	27	27	y	5.0		
	e1-3	Überw. Kamera C6	5	Access	172	18	201	28	28	y	5.0		
	e1-4	Überw. Kamera C10	5	Access	172	18	201	29	29	y	5.0		
	e1-5	AFZ C3	8	Access	172	20	73	12	12	y	10.0		
	e1-6	AFZ C4	8	Access	172	20	73	13	13	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle C2	9	Access	172	20	201	8	8	y	7.5		
	e1-9	Sprechstelle C1R	9	Access	172	20	201	7	7	y	7.5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C2	90	Access	-	-	-	-	-				
	e1-13	Future use box C4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C2	3	Access	172	17	201	31	31				
e1-15	Seitenanzeige C4	3	Access	172	17	201	32	32					
e2-0	Bildschrim C8	3	Access	172	17	201	63	63					
e2-1	Bildschrim C6	3	Access	172	17	201	64	64					
e2-2	Bildschrim C2	3	Access	172	17	201	65	65					
e2-3	Bildschrim C4	3	Access	172	17	201	66	66					
e2-4	Bildschrim C11	3	Access	172	17	201	67	67					
e2-5	Audio Amp. C2	9	Access	172	20	201	24	24					
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera C1	5	Access	172	18	201	82	82	y	5.0		
	e1-1	Rücksehkamera C2	5	Access	172	18	201	83	83	y	5.0		
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle C2R	9	Access	172	20	201	8	8	y	7.5		Redundanz C2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C1	90	Access	-	-	-	-	-				
	e1-13	Future use box C3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	201	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	201	30	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	201	31	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	201	32	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	201	33	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	201	34	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	73	14	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	73	15	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	73	16	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	201	10	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	201	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	201	34	34				
	e2-0	Bildschirm D7	3	Access	172	17	201	68	68				
	e2-1	Bildschirm D5	3	Access	172	17	201	69	69				
e2-2	Bildschirm D1	3	Access	172	17	201	70	70					
e2-3	Bildschirm D3	3	Access	172	17	201	71	71					
e2-4	Bildschirm D	3	Access	172	17	201	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	201	25	25					
D2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	201	35	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	201	36	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	201	37	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	201	38	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	201	39	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	73	17	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	73	18	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	201	11	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	201	10	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	201	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	201	36	36				
	e2-0	Bildschirm D8	3	Access	172	17	201	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	201	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	201	75	75				
e2-3	Bildschirm D4	3	Access	172	17	201	76	76					
e2-4	Bildschirm D11	3	Access	172	17	201	77	77					
e2-5	Audio Amp. D2	9	Access	172	20	201	26	26					
D3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	201	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	201	84	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	201	85	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	201	11	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
	e0-2				-	-	-	-	-	-					
	e0-3				-	-	-	-	-	-					
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	73	123	123						
	e1-0	Überw. Kamera E7	5	Access	172	18	201	40	40	y	5.0				
	e1-1	Überw. Kamera E2	5	Access	172	18	201	41	41	y	5.0				
	e1-2	Überw. Kamera E1	5	Access	172	18	201	42	42	y	5.0				
	e1-3	Überw. Kamera E5	5	Access	172	18	201	43	43	y	5.0				
	e1-4	Überw. Kamera E9	5	Access	172	18	201	44	44	y	5.0				
	e1-5	AFZ E1	8	Access	172	20	73	19	19	y	10.0				
	e1-6	AFZ E2	8	Access	172	20	73	20	20	y	10.0				
	e1-7	AFZ E5	8	Access	172	20	73	21	21	y	10.0				
	e1-8	Sprechstelle E1	9	Access	172	20	201	12	12	y	7.5				
	e1-9					-	-	-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	201	13	13	y	7.5				
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	201	16	16	y	7.5			Redundanz WC	
	e1-12	Future use box E5	90	Access		-	-	-	-	-	-				
	e1-13	Future use box E7	90	Access		-	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	201	37	37						
	e1-15	Seitenanzeige E3	3	Access	172	17	201	38	38						
	E2	e2-0	Bildschirm E7	3	Access	172	17	201	78	78					
		e2-1	Bildschirm E5	3	Access	172	17	201	79	79					
		e2-2	Bildschirm E1	3	Access	172	17	201	80	80					
e2-3		Bildschirm E3	3	Access	172	17	201	81	81						
e2-4		Bildschirm E	3	Access	172	17	201	82	82						
e2-5		Audio Amp. E1	9	Access	172	20	201	27	27						
e0-0		FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
e0-1		FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
e0-2					-	-	-	-	-	-					
e0-3					-	-	-	-	-	-					
e0-4		Access point E2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0			
e0-5					-	-	-	-	-	-					
e1-0		Überw. Kamera E8	5	Access	172	18	201	45	45	y	5.0				
e1-1		Überw. Kamera E4	5	Access	172	18	201	46	46	y	5.0				
e1-2		Überw. Kamera E3	5	Access	172	18	201	47	47	y	5.0				
e1-3		Überw. Kamera E6	5	Access	172	18	201	48	48	y	5.0				
e1-4					-	-	-	-	-	-					
e1-5		AFZ E3	8	Access	172	20	73	22	22	y	10.0				
e1-6		AFZ E4	8	Access	172	20	73	23	23	y	10.0				
e1-7		AFZ E6	8	Access	172	20	73	24	24	y	10.0				
e1-8		Sprechstelle E2	9	Access	172	20	201	14	14	y	7.5				
e1-9		Sprechstelle E1R	9	Access	172	20	201	12	12	y	7.5			Redundanz E1	
e1-10		Sprechstelle PRM E2	9	Access	172	20	201	15	15	y	7.5				
e1-11		Sprechstelle PRM E1R	9	Access	172	20	201	13	13	y	7.5			Redundanz E1	
e1-12		Future use box E2	90	Access	-	-	-	-	-	-	-				
e1-13	Future use box E4	90	Access	-	-	-	-	-	-	-					
e1-14	Seitenanzeige E2	3	Access	172	17	201	39	39							
e1-15	Seitenanzeige E4	3	Access	172	17	201	40	40							
E3	e2-0	Bildschirm E8	3	Access	172	17	201	83	83						
	e2-1	Bildschirm E6	3	Access	172	17	201	84	84						
	e2-2	Bildschirm E2	3	Access	172	17	201	85	85						
	e2-3	Bildschirm E4	3	Access	172	17	201	86	86						
	e2-4	Bildschirm E11	3	Access	172	17	201	87	87						
	e2-5	Audio Amp. E2	9	Access	172	20	201	28	28						
	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-					
	e0-2				-	-	-	-	-	-					
	e0-3				-	-	-	-	-	-					
	e0-4	Access point E3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0			
	e0-5				-	-	-	-	-	-					
	e1-0	Rücksehkamera E1	5	Access	172	18	201	86	86	y	5.0				
	e1-1	Rücksehkamera E2	5	Access	172	18	201	87	87	y	5.0				
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0			
	e1-3				-	-	-	-	-	-					
	e1-4				-	-	-	-	-	-					
	e1-5				-	-	-	-	-	-					
	e1-6				-	-	-	-	-	-					
	e1-7				-	-	-	-	-	-					
	e1-8				-	-	-	-	-	-					
	e1-9	Sprechstelle E2R	9	Access	172	20	201	14	14	y	7.5			Redundanz E2	
	e1-10	Sprechstelle PRM WC	9	Access	172	20	201	16	16	y	7.5				
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	201	15	15	y	7.5			Redundanz E2	
	e1-12	Future use box E1	90	Access	-	-	-	-	-	-	-				
e1-13	Future use box E3	90	Access	-	-	-	-	-	-	-					
e1-14				-	-	-	-	-	-	-					
e1-15				-	-	-	-	-	-	-					
e2-0	Energiezähler E	12	Access	172	22	73	3	3							
e2-1				-	-	-	-	-	-	-					
e2-2				-	-	-	-	-	-	-					
e2-3				-	-	-	-	-	-	-					
e2-4				-	-	-	-	-	-	-					
e2-5				-	-	-	-	-	-	-					

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-2				-	-	-	-	-	-										
	e0-3				-	-	-	-	-	-										
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e0-5	Service FIS / CCTV	2	Access	172	17	73	124	124											
	e1-0	Überw. Kamera F7	5	Access	172	18	201	49	49	y	5.0									
	e1-1	Überw. Kamera F2	5	Access	172	18	201	50	50	y	5.0									
	e1-2	Überw. Kamera F1	5	Access	172	18	201	51	51	y	5.0									
	e1-3	Überw. Kamera F5	5	Access	172	18	201	52	52	y	5.0									
	e1-4	Überw. Kamera F9	5	Access	172	18	201	53	53	y	5.0									
	e1-5	AFZ F1	8	Access	172	20	73	25	25	y	10.0									
	e1-6	AFZ F2	8	Access	172	20	73	26	26	y	10.0									
	e1-7	AFZ F5	8	Access	172	20	73	27	27	y	10.0									
	e1-8	Sprechstelle F1	9	Access	172	20	201	17	17	y	7.5									
	e1-9				-	-	-	-	-	-										
	e1-10				-	-	-	-	-	-										
	e1-11				-	-	-	-	-	-										
	e1-12	Future use box F5	90	Access	-	-	-	-	-	-										
	e1-13	Future use box F6	90	Access	-	-	-	-	-	-										
e1-14	Seitenanzeige F1	3	Access	172	17	201	41	41												
e1-15	Seitenanzeige F3	3	Access	172	17	201	42	42												
F2	e2-0	Bildschirm F7	3	Access	172	17	201	88	88											
	e2-1	Bildschirm F5	3	Access	172	17	201	89	89											
	e2-2	Bildschirm F1	3	Access	172	17	201	90	90											
	e2-3	Bildschirm F3	3	Access	172	17	201	91	91											
	e2-4	Bildschirm F	3	Access	172	17	201	92	92											
	e2-5	Audio Amp. F1	9	Access	172	20	201	29	29											
	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-2				-	-	-	-	-	-										
	e0-3				-	-	-	-	-	-										
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e0-5	reserved			-	-	-	-	-	-										
	e1-0	Überw. Kamera F8	5	Access	172	18	201	54	54	y	5.0									
	e1-1	Überw. Kamera F4	5	Access	172	18	201	55	55	y	5.0									
	e1-2	Überw. Kamera F3	5	Access	172	18	201	56	56	y	5.0									
	e1-3	Überw. Kamera F6	5	Access	172	18	201	57	57	y	5.0									
	e1-4	Überw. Kamera F10	5	Access	172	18	201	58	58	y	5.0									
	e1-5	AFZ F3	8	Access	172	20	73	28	28	y	10.0									
	e1-6	AFZ F4	8	Access	172	20	73	29	29	y	10.0									
	e1-7				-	-	-	-	-	-										
e1-8	Sprechstelle F2	9	Access	172	20	201	18	18	y	7.5										
e1-9	Sprechstelle FIR	9	Access	172	20	201	17	17	y	7.5										
e1-10				-	-	-	-	-	-											
e1-11				-	-	-	-	-	-											
e1-12	Future use box F2	90	Access	-	-	-	-	-	-											
e1-13	Future use box F4	90	Access	-	-	-	-	-	-											
e1-14	Seitenanzeige F2	3	Access	172	17	201	43	43												
e1-15	Seitenanzeige F4	3	Access	172	17	201	44	44												
F3	e2-0	Bildschirm F8	3	Access	172	17	201	93	93											
	e2-1	Bildschirm F6	3	Access	172	17	201	94	94											
	e2-2	Bildschirm F2	3	Access	172	17	201	95	95											
	e2-3	Bildschirm F	3	Access	172	17	201	96	96											
	e2-4	Bildschirm F11	3	Access	172	17	201	97	97											
	e2-5	Audio Amp. F2	9	Access	172	20	201	30	30											
	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-2				-	-	-	-	-	-										
	e0-3				-	-	-	-	-	-										
	e0-4	Access point F3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e0-5	reserved			-	-	-	-	-	-										
	e1-0	Rücksehkamera F1	5	Access	172	18	201	88	88	y	5.0									
	e1-1	Rücksehkamera F2	5	Access	172	18	201	89	89	y	5.0									
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e1-3				-	-	-	-	-	-										
	e1-4				-	-	-	-	-	-										
	e1-5				-	-	-	-	-	-										
	e1-6				-	-	-	-	-	-										
	e1-7				-	-	-	-	-	-										
e1-8				-	-	-	-	-	-											
e1-9	Sprechstelle F2R	9	Access	172	20	201	18	18	y	7.5								Redundanz F2		
e1-10				-	-	-	-	-	-											
e1-11				-	-	-	-	-	-											
e1-12	Future use box F1	90	Access	-	-	-	-	-	-											
e1-13	Future use box F3	90	Access	-	-	-	-	-	-											
e1-14				-	-	-	-	-	-											
e1-15				-	-	-	-	-	-											
e2-0				-	-	-	-	-	-											
e2-1				-	-	-	-	-	-											
e2-2				-	-	-	-	-	-											
e2-3				-	-	-	-	-	-											
e2-4				-	-	-	-	-	-											
e2-5				-	-	-	-	-	-											

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	73	125	125					
	e1-0	Überw. Kamera B7	5	Access	172	18	201	59	59	y	5.0			
	e1-1	Überw. Kamera B2	5	Access	172	18	201	60	60	y	5.0			
	e1-2	Überw. Kamera B1	5	Access	172	18	201	61	61	y	5.0			
	e1-3	Überw. Kamera B5	5	Access	172	18	201	62	62	y	5.0			
	e1-4	Überw. Kamera B9	5	Access	172	18	201	63	63	y	5.0			
	e1-5	AFZ B1	8	Access	172	20	73	30	30	y	10.0			
	e1-6	AFZ B2	8	Access	172	20	73	31	31	y	10.0			
	e1-7				-	-	-	-	-					
	e1-8	Sprechstelle B1	9	Access	172	20	201	19	19	y	7.5			
	e1-9				-	-	-	-	-					
	e1-10				-	-	-	-	-					
	e1-11	ZFR R	2	Access	172	17	73	2	2					
	e1-12	Future use box B5	90	Access	-	-	-	-	-					
	e1-13	Future use box B6	90	Access	-	-	-	-	-					
	e1-14	Seitenanzeige B1	3	Access	172	17	201	45	45					
	e1-15	Seitenanzeige B3	3	Access	172	17	201	46	46					
	e2-0	Bildschrim B7	3	Access	172	17	201	98	98					
	e2-1	Bildschrim B5	3	Access	172	17	201	99	99					
	e2-2	Bildschrim B1	3	Access	172	17	201	100	100					
	e2-3	Bildschrim B3	3	Access	172	17	201	101	101					
	e2-4	ADU B	9	Access	172	20	201	4	4					
	e2-5	Audio Amp. B1	9	Access	172	20	201	31	31					
	B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
		e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-2					-	-	-	-	-					
e0-3					-	-	-	-	-					
e0-4		Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e0-5		reserved			-	-	-	-	-					
e1-0		Überw. Kamera B8	5	Access	172	18	201	64	64	y	5.0			
e1-1		Überw. Kamera B4	5	Access	172	18	201	65	65	y	5.0			
e1-2		Überw. Kamera B3	5	Access	172	18	201	66	66	y	5.0			
e1-3		Überw. Kamera B6	5	Access	172	18	201	67	67	y	5.0			
e1-4		Überw. Kamera B10	5	Access	172	18	201	68	68	y	5.0			
e1-5		AFZ B3	8	Access	172	20	73	32	32	y	10.0			
e1-6		AFZ B4	8	Access	172	20	73	33	33	y	10.0			
e1-7		NVR B	5	Access	172	18	201	6	6					
e1-8		Sprechstelle B2	9	Access	172	20	201	20	20	y	7.5			
e1-9		Sprechstelle B1R	9	Access	172	20	201	19	19	y	7.5			
e1-10					-	-	-	-	-					
e1-11					-	-	-	-	-					
e1-12		Future use box B2	90	Access	-	-	-	-	-					
e1-13		Future use box B4	90	Access	-	-	-	-	-					
e1-14		Seitenanzeige B2	3	Access	172	17	201	47	47					
e1-15		Seitenanzeige B4	3	Access	172	17	201	48	48					
e2-0		Bildschrim B8	3	Access	172	17	201	102	102					
e2-1		Bildschrim B6	3	Access	172	17	201	103	103					
e2-2		Bildschrim B2	3	Access	172	17	201	104	104					
e2-3		Bildschrim B4	3	Access	172	17	201	105	105					
e2-4					-	-	-	-	-					
e2-5		Audio Amp. B2	9	Access	172	20	201	32	32					
B3		e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
		e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-	-					
	e1-0	Rücksehkamera B1	5	Access	172	18	201	90	90	y	5.0			
	e1-1	Rücksehkamera B2	5	Access	172	18	201	91	91	y	5.0			
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e1-3				-	-	-	-	-					
	e1-4				-	-	-	-	-					
	e1-5				-	-	-	-	-					
	e1-6				-	-	-	-	-					
	e1-7				-	-	-	-	-					
	e1-8				-	-	-	-	-					
	e1-9	Sprechstelle B2R	9	Access	172	20	201	20	20	y	7.5		Redundanz B2	
	e1-10				-	-	-	-	-					
	e1-11	ZFR	2	Access	172	17	73	2	2					
	e1-12	Future use box B1	90	Access	-	-	-	-	-					
	e1-13	Future use box B3	90	Access	-	-	-	-	-					
	e1-14	Frontanzeige B	3	Access	172	17	201	24	24					
	e1-15				-	-	-	-	-					
	e2-0				-	-	-	-	-					
	e2-1				-	-	-	-	-					
	e2-2				-	-	-	-	-					
	e2-3				-	-	-	-	-					
	e2-4	ADU BR	9	Access	172	20	201	4	4					
	e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					
	Firewall		2	N/A	172	17	73	126	126				IP festgehalten fuer die RCU.	
			3	N/A	172	17	201	126	126				Diese ist mit der Firewall verbunden.	
		9	N/A	172	20	201	126	126				Anforderung von STADLER		