

IPv4-Schema
Fgz. Nr: OEGB (250)



Fahrzeugnummer:			OEGB-BENCH	Fzg ID: 250				Wagen:			A - 100		
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	125	120	120				
	e1-0	Überw. Kamera A7	5	Access	172	18	253	10	10	y	5,0		
	e1-1	Überw. Kamera A2	5	Access	172	18	253	11	11	y	5,0		
	e1-2	Überw. Kamera A1	5	Access	172	18	253	12	12	y	5,0		
	e1-3	Überw. Kamera A5	5	Access	172	18	253	13	13	y	5,0		
	e1-4	Überw. Kamera A9	5	Access	172	18	253	14	14	y	5,0		
	e1-5	AFZ A1	8	Access	172	20	125	5	5	y	10,0		
	e1-6	AFZ A2	8	Access	172	20	125	6	6	y	10,0		
	e1-7				-	-	-	-	-	-			
	e1-8	Sprechstelle A1	9	Access	172	20	253	5	5	y	7,5		
	e1-9	Sprechstelle A3R	9	Access	172	20	253	41	41	y	7,5		
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box A5	90	Access	-	-	-	-	-	-			
	e1-13	Future use box A6	90	Access	-	-	-	-	-	-			
	e1-14	Seitenanzeige A1	3	Access	172	17	253	25	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	253	26	26				
	e2-0	Bildschirm A7	3	Access	172	17	253	50	50				
	e2-1	Bildschirm A5	3	Access	172	17	253	51	51				
	e2-2	Bildschirm A1	3	Access	172	17	253	52	52				
	e2-3	Bildschirm A3	3	Access	172	17	253	53	53				
e2-4	ADU A	9	Access	172	20	253	3	3					
e2-5	Audio Amp. A1	9	Access	172	20	253	21	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Überw. Kamera A8	5	Access	172	18	253	15	15	y	5,0		
	e1-1	Überw. Kamera A4	5	Access	172	18	253	16	16	y	5,0		
	e1-2	Überw. Kamera A3	5	Access	172	18	253	17	17	y	5,0		
	e1-3	Überw. Kamera A6	5	Access	172	18	253	18	18	y	5,0		
	e1-4	Überw. Kamera A10	5	Access	172	18	253	19	19	y	5,0		
	e1-5	AFZ A3	8	Access	172	20	125	7	7	y	10,0		
	e1-6	AFZ A4	8	Access	172	20	125	8	8	y	10,0		
	e1-7	NVR A	5	Access	172	18	253	5	5				
	e1-8	Sprechstelle A2	9	Access	172	20	253	6	6	y	7,5		
	e1-9	Sprechstelle A1R	9	Access	172	20	253	5	5	y	7,5		Redundanz A1
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box A2	90	Access	-	-	-	-	-	-			
	e1-13	Future use box A4	90	Access	-	-	-	-	-	-			
	e1-14	Seitenanzeige A2	3	Access	172	17	253	27	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	253	28	28				
	e2-0	Bildschirm A8	3	Access	172	17	253	54	54				
	e2-1	Bildschirm A6	3	Access	172	17	253	55	55				
	e2-2	Bildschirm A2	3	Access	172	17	253	56	56				
	e2-3	Bildschirm A4	3	Access	172	17	253	57	57				
e2-4				-	-	-	-	-	-				
e2-5	Audio Amp. A2	9	Access	172	20	253	22	22					
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Rücksehkamera A1	5	Access	172	18	253	80	80	y	5,0		
	e1-1	Rücksehkamera A2	5	Access	172	18	253	81	81	y	5,0		
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-	-			
	e1-4	Firewall	2	Trunk	172	17	125	1	1			Kein DHCP Statische Konfiguration STADLER	
			3		172	17	253	1					
			5		172	18	253	1					
			6		172	19	125	1					
			7		172	19	253	1					
			8		172	20	125	1					
			9		172	20	253	1					
			12		172	22	125	1					
	e1-5				-	-	-	-	-	-			
	e1-6				-	-	-	-	-	-			
	e1-7				-	-	-	-	-	-			
	e1-8	Sprechstelle A1R	9	Access	172	20	253	5	5	y	7,5		Redundanz A1
	e1-9	Sprechstelle A2R	9	Access	172	20	253	6	6	y	7,5		Redundanz A2
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box A1	90	Access	-	-	-	-	-	-			
	e1-13	Future use box A3	90	Access	-	-	-	-	-	-			
	e1-14	Frontanzeige A	3	Access	172	17	253	23	23				
	e1-15				-	-	-	-	-	-			
	e2-0	Bildschirm A9	3	Access	172	17	253	106	106				
e2-1	Bildschirm A10	3	Access	172	17	253	107	107					
e2-2				-	-	-	-	-	-				
e2-3	Sitzplatzreservierung A	6	Access	172	19	125	10	10					
e2-4	ADU AR	9	Access	172	20	253	3	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

G1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	253	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	125	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	253	30	30	y	5,0		
	e1-1	Überw. Kamera D2	5	Access	172	18	253	31	31	y	5,0		
	e1-2	Überw. Kamera D1	5	Access	172	18	253	32	32	y	5,0		
	e1-3	Überw. Kamera D5	5	Access	172	18	253	33	33	y	5,0		
	e1-4	Überw. Kamera D9	5	Access	172	18	253	34	34	y	5,0		
	e1-5	AFZ D1	8	Access	172	20	125	14	14	y	10,0		
	e1-6	AFZ D2	8	Access	172	20	125	15	15	y	10,0		
	e1-7	AFZ D5	8	Access	172	20	125	16	16	y	10,0		
	e1-8	Sprechstelle D1	9	Access	172	20	253	10	10	y	7,5		
	e1-9	Sprechstelle D3R	9	Access	172	20	253	43	43	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	253	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	253	34	34				
	e2-0	Bildschirm D7	3	Access	172	17	253	68	68				
	e2-1	Bildschirm D5	3	Access	172	17	253	69	69				
	e2-2	Bildschirm D1	3	Access	172	17	253	70	70				
	e2-3	Bildschirm D3	3	Access	172	17	253	71	71				
e2-4	Bildschirm D	3	Access	172	17	253	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	253	25	25					
G2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	253	35	35	y	5,0		
	e1-1	Überw. Kamera D4	5	Access	172	18	253	36	36	y	5,0		
	e1-2	Überw. Kamera D3	5	Access	172	18	253	37	37	y	5,0		
	e1-3	Überw. Kamera D6	5	Access	172	18	253	38	38	y	5,0		
	e1-4	Überw. Kamera D10	5	Access	172	18	253	39	39	y	5,0		
	e1-5	AFZ D3	8	Access	172	20	125	17	17	y	10,0		
	e1-6	AFZ D4	8	Access	172	20	125	18	18	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	253	11	11	y	7,5		
	e1-9	Sprechstelle D1R	9	Access	172	20	253	10	10	y	7,5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	253	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	253	36	36				
	e2-0	Bildschirm D8	3	Access	172	17	253	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	253	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	253	75	75				
	e2-3	Bildschirm D4	3	Access	172	17	253	76	76				
	e2-4	Bildschirm D11	3	Access	172	17	253	77	77				
e2-5	Audio Amp. D2	9	Access	172	20	253	26	26					
G3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	253	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	253	84	84	y	5,0		
	e1-1	Rücksehkamera D2	5	Access	172	18	253	85	85	y	5,0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3	Überw. Kamera D11	5	Access	172	18	253	69	69	y	5,0		
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	253	11	11	y	7,5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Bildschirm D9	3	Access	172	17	253	110	110				
	e2-1	Bildschirm D10	3	Access	172	17	253	111	111				
	e2-2				-	-	-	-	-				
	e2-3	Sitzplatzreservierung D	6	Access	172	19	125	12	12				
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	125	123	123				
	e1-0	Überw. Kamera E7	5	Access	172	18	253	40	40	y	5,0		
	e1-1	Überw. Kamera E2	5	Access	172	18	253	41	41	y	5,0		
	e1-2	Überw. Kamera E1	5	Access	172	18	253	42	42	y	5,0		
	e1-3	Überw. Kamera E5	5	Access	172	18	253	43	43	y	5,0		
	e1-4	Überw. Kamera E9	5	Access	172	18	253	44	44	y	5,0		
	e1-5	AFZ E1	8	Access	172	20	125	19	19	y	10,0		
	e1-6	AFZ E2	8	Access	172	20	125	20	20	y	10,0		
	e1-7	AFZ E5	8	Access	172	20	125	21	21	y	10,0		
	e1-8	Sprechstelle E1	9	Access	172	20	253	12	12	y	7,5		
	e1-9					-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	253	13	13	y	7,5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	253	16	16	y	7,5		Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-				
	e1-13	Future use box E7	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	253	37	37				
	e1-15	Seitenanzeige E3	3	Access	172	17	253	38	38				
	e2-0	Bildschirm E7	3	Access	172	17	253	78	78				
	e2-1	Bildschirm E5	3	Access	172	17	253	79	79				
	e2-2	Bildschirm E1	3	Access	172	17	253	80	80				
e2-3	Bildschirm E3	3	Access	172	17	253	81	81					
e2-4	ADU E	9	Access	172	20	253	2	2					
e2-5	Audio Amp. E1	9	Access	172	20	253	27	27					
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	253	45	45	y	5,0		
	e1-1	Überw. Kamera E4	5	Access	172	18	253	46	46	y	5,0		
	e1-2	Überw. Kamera E3	5	Access	172	18	253	47	47	y	5,0		
	e1-3	Überw. Kamera E6	5	Access	172	18	253	48	48	y	5,0		
	e1-4	Überw. Kamera E10	5	Access	172	18	253	70	70	y	5,0		
	e1-5	AFZ E3	8	Access	172	20	125	22	22	y	10,0		
	e1-6	AFZ E4	8	Access	172	20	125	23	23	y	10,0		
	e1-7	AFZ E6	8	Access	172	20	125	24	24	y	10,0		
	e1-8	Sprechstelle E2	9	Access	172	20	253	14	14	y	7,5		
	e1-9	Sprechstelle E1R	9	Access	172	20	253	12	12	y	7,5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	253	15	15	y	7,5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	253	13	13	y	7,5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	253	39	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	253	40	40				
	e2-0	Bildschirm E8	3	Access	172	17	253	83	83				
	e2-1	Bildschirm E6	3	Access	172	17	253	84	84				
	e2-2	Bildschirm E2	3	Access	172	17	253	85	85				
e2-3	Bildschirm E4	3	Access	172	17	253	86	86					
e2-4	Bildschirm E11	3	Access	172	17	253	87	87					
e2-5	Audio Amp. E2	9	Access	172	20	253	28	28					
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	253	86	86	y	5,0		
	e1-1	Rücksehkamera E2	5	Access	172	18	253	87	87	y	5,0		
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	253	14	14	y	7,5		Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	253	16	16	y	7,5		
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	253	15	15	y	7,5		Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Bildschirm E9	3	Access	172	17	253	112	112				
	e2-1	Bildschirm E10	3	Access	172	17	253	113	113				
	e2-2	Fahrausweiseinrichtung		Access	-	-	-	-	-				Reserviert
e2-3	Sitzplatzreservierung E	6	Access	172	19	125	13	13					
e2-4	ADU ER	9	Access	172	20	253	2	2				Redundanz E	
e2-5	Energiezähler F	12	Access	172	22	125	3	3					

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	125	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	253	59	59	y	5,0		
	e1-1	Überw. Kamera B2	5	Access	172	18	253	60	60	y	5,0		
	e1-2	Überw. Kamera B1	5	Access	172	18	253	61	61	y	5,0		
	e1-3	Überw. Kamera B5	5	Access	172	18	253	62	62	y	5,0		
	e1-4	Überw. Kamera B9	5	Access	172	18	253	63	63	y	5,0		
	e1-5	AFZ B1	8	Access	172	20	125	30	30	y	10,0		
	e1-6	AFZ B2	8	Access	172	20	125	31	31	y	10,0		
	e1-7	Sprechstelle B4	9	Access	172	20	253	44	44	y	7,5		
	e1-8	Sprechstelle B1	9	Access	172	20	253	19	19	y	7,5		
	e1-9	Sprechstelle B3R	9	Access	172	20	253	45	45	y	7,5		Redundanz B3
	e1-10					-	-	-	-	-			
	e1-11	ZFR R	2	Access	172	17	125	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B1	3	Access	172	17	253	45	45				
	e1-15	Seitenanzeige B3	3	Access	172	17	253	46	46				
	e2-0	Bildschrim B7	3	Access	172	17	253	98	98				
	e2-1	Bildschrim B5	3	Access	172	17	253	99	99				
	e2-2	Bildschrim B1	3	Access	172	17	253	100	100				
e2-3	Bildschrim B3	3	Access	172	17	253	101	101					
e2-4	ADU B	9	Access	172	20	253	4	4					
e2-5	Audio Amp. B1	9	Access	172	20	253	31	31					
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	253	64	64	y	5,0		
	e1-1	Überw. Kamera B4	5	Access	172	18	253	65	65	y	5,0		
	e1-2	Überw. Kamera B3	5	Access	172	18	253	66	66	y	5,0		
	e1-3	Überw. Kamera B6	5	Access	172	18	253	67	67	y	5,0		
	e1-4	Überw. Kamera B10	5	Access	172	18	253	68	68	y	5,0		
	e1-5	AFZ B3	8	Access	172	20	125	32	32	y	10,0		
	e1-6	AFZ B4	8	Access	172	20	125	33	33	y	10,0		
	e1-7	NVR B	5	Access	172	18	253	6	6				
	e1-8	Sprechstelle B2	9	Access	172	20	253	20	20	y	7,5		
	e1-9	Sprechstelle B1R	9	Access	172	20	253	19	19	y	7,5		
	e1-10	Sprechstelle B5R	9	Access	172	20	253	46	46	y	7,5		Redundanz B5
	e1-11	Sprechstelle B3	9	Access	172	20	253	45	45	y	7,5		
	e1-12	Future use box B2	90	Access	-	-	-	-	-				
	e1-13	Future use box B4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B2	3	Access	172	17	253	47	47				
	e1-15	Seitenanzeige B4	3	Access	172	17	253	48	48				
	e2-0	Bildschrim B8	3	Access	172	17	253	102	102				
	e2-1	Bildschrim B6	3	Access	172	17	253	103	103				
	e2-2	Bildschrim B2	3	Access	172	17	253	104	104				
e2-3	Bildschrim B4	3	Access	172	17	253	105	105					
e2-4					-	-	-	-	-				
e2-5	Audio Amp. B2	9	Access	172	20	253	32	32					
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera B1	5	Access	172	18	253	90	90	y	5,0		
	e1-1	Rücksehkamera B2	5	Access	172	18	253	91	91	y	5,0		
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7	Sprechstelle B5	9	Access	172	20	253	46	46	y	7,5		
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle B2R	9	Access	172	20	253	20	20	y	7,5		Redundanz B2
	e1-10	Sprechstelle B1R	9	Access	172	20	253	19	19	y	7,5		Redundanz B1
	e1-11	ZFR	2	Access	172	17	125	2	2				
	e1-12	Future use box B1	90	Access	-	-	-	-	-				
	e1-13	Future use box B3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige B	3	Access	172	17	253	24	24				
	e1-15				-	-	-	-	-				
	e2-0	Bildschirm B9	3	Access	172	17	253	116	116				
	e2-1	Bllldschirm B10	3	Access	172	17	253	117	117				
	e2-2				-	-	-	-	-				
e2-3	Sitzplatzreservierung B	6	Access	172	19	125	15	15					
e2-4	ADU BR	9	Access	172	20	253	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					
Firewall		2		N/A	172	17	125	126	126			IP festgehalten fuer die RCU.	
		3		N/A	172	17	253	126	126			Diese ist mit der Firewall verbunden.	
		9		N/A	172	20	253	126	126			Anforderung von STADI ER	