WI-001 Sample Work Instruction

Demo file for Tulip connector function file outputs. Not a real procedure.

Assemble bracket kit

1. Confirm the part number on the traveler matches the kit label.
2. Place the bracket on the fixture with the slot facing up.
3. Insert four M5 screws and hand-tighten in a cross pattern.
4. Torque each screw to 4.5 Nm with the calibrated driver.
5. Apply the inspection sticker and scan the serial number.