

- SLIDE THE OLEO SPACER (MG02-101)
- SLIDE THE ASSEMBLED OLEO STRUT INTO THE UPPER MAIN GEAR WELDMENT.
- INSTALL "O" RING (MG02-124) ONTO THE LOWER OLEO SLEEVE AND "O" RING (MG02-123) INTO THE OLEO SLEEVE.
- SLIDE THE ASSEMBLED LOWER OLEO SLEEVE OVER THE OLEO STRUT AND INTO THE UPPER MAIN GEAR WELDMENT.
- INSTALL THE 2" SNAP RING (MG02-110) ** CAUTION ** THIS SNAP RING HOLDS THE PRESSURIZED OLEO TOGETHER, THE SNAP RING MUST BE SEATED CORRECTLY. IF NOT. THE OLEO MAY BLAST APART WHEN THE AIRCRAFT WEIGHT IS OFF THE LANDING GEAR. (AFTER TAKEOFF).
- TO SERVICE THE STRUT, REMOVE THE OLEO VALVE, COLLAPSE THE STRUT UNTIL IT STOPS. ATTACH ONE END OF A HOSE TO THE VALVE FITTING, THE OTHER END IMMERSED IN A CAN OF MIL-5606 HYDRA. FLUID (OR EQUAL). EXTEND THE STRUT TO FULL EXTENSION, HYDRA, FLUID WILL BE DRAWN INTO THE STRUT.
- EXTEND AND COLLAPSE THE STRUT SEVERAL TIMES UNTIL THERE ARE NO AIR BUBBLES IN THE CAN. WITH STRUT COLLAPSED. EXTEND UNTIL 1" OF STRUT IS VISIBLE, REMOVE HOSE AND REINSERT THE OLEO VALVE FITTING.
- EXTEND THE STRUT AND REPLACE THE OLEO VALVE. PRESSURIZE THE STRUT WITH NITROGEN OR COMPRESSED AIR TO 165 TO 185 PSI.
- -WITH THE WEIGHT OFF THE GEAR, CHECK THE PRESSURE AND ADD AIR IF NECESSARY.

