```
int main (void){
                               //Example 1
  char num string[12];
  long num;
setup HW;
if(watch_dog_reset == 1)watch_dog_reset = 0; else
String_to_PC_Basic("Enter number at keyboard\r\n");
Num_string_from_KBD_Local(num_string);
Char_to_PC_Basic('\t');
num = Askii_to_binary_Local(num_string);
Int_to_PC_Basic(num/2);
newline_Basic();
SW_reset;
return 1;}
int main (void){
                                //Example 2
  char num_string[12];
  long num = 2;
  long old_num = 2;
setup_HW;
String_to_PC_Basic("Multiply number by 2 and enter it\r\n");
String_to_PC_Basic("2\r\n");
while(1){
Num_string_from_KBD_Local(num_string);
num = Askii to binary Local(num string);
if(num == old num * 2)
{newline_Basic();old_num = num;}
else Char_to_PC_Basic('?');
SW reset;
return 1;}
```