```
#include "Local subroutines.c"
unsigned int PRN;
unsigned char PRN_counter;
int main (void)
                                 //Example 13
 {int T1_period = 15;
 char direction;
 char seg_counter;
  setup_HW;
 I2C_Tx_any_segment_clear_all();
 PRN_counter = 0;
 PRN = PRN_16bit_GEN (0, &PRN_counter);
  direction=1;
 while(1){
     direction ^= 1;
   seg_counter=0;
 PRN = update_display
 (T1_period, direction, seg_counter, PRN);
 if(switch_1_down);
 else T1_period = Adjust_T1_period(T1_period);}}
                               //Example 14
int main (void)
{ unsigned int PRN;
 unsigned char PRN_counter;
  setup_HW;
 wdt_enable(WDTO_30MS);
 PRN counter = 0;
 PRN = PRN_16bit_GEN (0, &PRN_counter);
 while (1)
  { PRN = PRN_16bit_GEN (PRN, &PRN_counter);
    I2C_Tx_2_integers(PRN, (PRN << ((PRN % 2) + 1)));</pre>
    Timer_T0_10mS_delay_x_m(10);
  }}
```