```
int main (void)
                      //Example 1
 { unsigned int PORT 1;
  setup_HW;
    PORT_1 = 1;
  for (int m = 0; m <= 15; m++)
  { I2C_Tx_2_integers(PORT_1, PORT_1);
    Timer_T0_10mS_delay_x_m(12);
   PORT_1 = PORT_1 << 1;
   }
 SW_reset; }
int main (void) //Example 2
 { unsigned int PORT_1;
  setup HW;
  wdt_enable(WDTO_30MS);
    PORT_1 = 1;
  for (int m = 0; m <= 15; m++)
  { I2C_Tx_2_integers(PORT_1, PORT_1);
    Timer_T0_10mS_delay_x_m(12);
   PORT_1 = PORT_1 << 1;
  }
 while(1); }
    int main (void)
                       //Example 3
  { unsigned int PORT_1;
  setup_HW;
 wdt_enable(WDTO_30MS);
 PORT_1 = 1;
  for (int m = 0; m <= 15; m++)
  { I2C_Tx_2_integers
  (PORT_1 << m, PORT_1 << m);
   Timer_T0_10mS_delay_x_m(12);
   }
for (int m = 14; m; m--)
{ I2C_Tx_2_integers
(PORT_1 << m, PORT_1 << m);
   Timer_T0_10mS_delay_x_m(12);
 while(1); }
```