```
int main (void)
                                 //Example 3
 { long number = 1;
                                 //Print out a column of numbers
  long number_old = 1;
  setup HW;
 wdt_enable(WDTO_120MS);
 while(switch_1_down)wdr();
  for(int m = 2; m < 11; m++){</pre>
  Int_to_PC_Basic(number);
 newline_Basic();
number = (number_old * 10) + m;
number_old = number;}
while(switch_1_up)wdr();
 while(switch_1_down);
  return 1;}
 int main (void)
                                      //Example 4
  { int i = 0;
                                     //Print out a column of numbers
  long number = 123456789;
  long number_old = 123456789;
  char s[12];
  setup_HW;
  wdt_enable(WDTO_120MS);
 while(switch_1_down)wdr();
  for(int m = 2; m < 11; m++){
Int_to_PC_Basic(number);
newline_Basic();
number = number_old / 10;
number_old = number;}
while(switch_1_up)wdr();
 while(switch_1_down);
  return 1;}
```