

Column #33, November 1997 by Jon Williams:

# It's Time to Get Real Using the Dallas Semiconductor 1302

Have you ever stopped to consider how much of our life is governed by clocks? A bunch. We get up at a given time. We go to work at a given time. We finish work at a given time. Our favorite television and radio programs start and stop at a given time. Wow! Just think how out of sync our society would be without clocks.

A software real-time clock is not a practical exercise when it comes to the BASIC Stamp. Even if one succeeded in implementing the clock function, without interrupts, it's not likely that the Stamp could handle any additional control. It would be too difficult to keep the software clock in sync. It's on occasions like these — when software really isn't the answer — that we turn to external hardware. Thankfully, there are choices. And PBASIC makes them easy to use.

Before we get to hardware specifics, let's talk about time and how to deal with it in a microcontroller. When we refer to time, we're concerned with the hours, minutes, and the appropriate side of noon (AM or PM). This can be a headache to deal with in software. For example, if the time was 11:45 AM and we wanted to add 20 minutes, we'd have to add the 20 to the 45, notice that we went passed 60, carry to the hours variable, check that we went from AM to PM, blah, blah, blah. What a hassle! There is an easier way.

## Column #33: It's Time to Get Real Using the Dallas Semiconductor 1302 - Part 1

## Just a minute, please ....

I once worked for a large irrigation company, and was involved with many teams that designed and built sprinkler timers. Sprinkler timers deal with time on two levels: 1) when to start the sprinklers, and 2) how long the sprinklers should run. It's interesting to note that no matter what the scope of the irrigation controller — from those you can buy at garden centers for residential use, to the big, computerized irrigation systems used on golf courses — time was always dealt with as a single variable. Conversion routines are used to interface with people.

Life for the Stamp would be quite a lot easier if it only had to deal with one variable for the time instead of three. We move from three variables to one by converting the hours, minutes, and AM/PM to minutes. Now you let the Stamp deal with time as a value between zero (12:00 AM) and 1439 (11:59 PM).

It's a reasonably simple matter to convert between this raw time format and something we humans can live with.

This month, we're going to demonstrate how to deal with real-time by building something that most of us use every day: an alarm clock. We'll use an external RTC chip and take advantage of the LCD interface we covered last month. This project should give you a firm grounding in time-based control, and teach you a math trick or two along the way.

## The Dallas Semiconductor DS1302

For our alarm clock, we'll be using the DS1302 from Dallas Semiconductor. This eight-pin DIP keeps track of seconds, minutes, hours (with an AM/PM indicator, if running in 12-hour mode), date of month, month, day of week, and year with leap year compensation valid up to 2100. As a bonus, the DS1302 contains 31 bytes of RAM that we can use as we please. And for projects that use main's power, the DS1302 also contains a trickle-charging circuit that can charge a back-up battery.

Connecting to the Stamp is very straight-forward. The DS1302 uses the same three-wire interface as the DS1620 thermometer (Apr. '95) and the DS1267 digital pot (Aug. '96). This allows us to take advantage of the BS2's SHIFTOUT and SHIFTIN commands. To write a value to the DS1302, we'll send (SHIFTOUT) the register address first, then the data for that register. The LSB of the address determines whether the operation is a write (0) or a read (1). To read from the DS1302, we send the address, then immediately read back (SHIFTIN) the register value.




Figure 33.1: DS1302 hookup diagram

For our project, we'll share the clock and data lines with a 74HC595 shift register. This cuts down the number of Stamp pins required to implement the alarm clock. For details on using the 74HC595 with an LCD, please refer to the Oct. '97 issue (More LCDs ...).

## Time format conversion

In order to keep our interface with the DS1302 simple, we'll use it in the 24-hour mode. In this mode, we don't have to fuss with the AM/PM indicator. (If you want to know how, download DS1302.BS2 from my FTP directory.) For a 12-hour display, we'll deduce AM/PM mathematically.

Another compelling reason to use our raw time format is that the DS1302 stores its registers in BCD (binary coded decimal). In case you haven't dealt with BCD before, here it is in a nutshell: BCD is a method of storing a value between zero and 99 in a byte-sized variable. The ones digit occupies the lower nibble, the tens digit the upper.

Neither nibble of a BCD byte is allowed to have a value greater than nine. Thankfully, the BS2 allows nibble-sized variables and, more importantly, it allows variables to be overlaid. We discussed this technique back in the Aug. '97 issue (PBASIC Programming With Style) and now we're going to use it.

If you study the variables section of Program Listing 33.1, you'll see that we've defined each time element as a byte, then overlaid the tens and ones nibbles. These overlaid nibble definitions do not occupy any more memory in the Stamp. With these definitions, converting the time from the DS1302 to our raw format takes just one line of code:

```
rawTime = (hr10 * 600) + (hr01 * 60) + (mn10 * 10) + mn01
```

Get a pencil and paper, and do it longhand. What you'll find is that the result is always a value between zero and 1439. Keep in mind that we're using 24-hour mode, so the hours value is always between zero and 23.

Converting back is just a bit trickier but, once you get the hang of it, you'll find the technique very useful. The key to this conversion routine is the modulus operator (//). The modulus operator returns the remainder of a division. For example, 5 // 2 (read "five mod two") returns one.

Here's the code to convert from our raw (minutes) format to the BCD values required by the DS1302:

```
hr10 = rawTime / 600
hr01 = rawTime // 600 / 60
mn10 = rawTime // 60 / 10
mn01 = rawTime // 10
```

This first line is easy. Since there are 600 minutes in 10 hours, we simply divide by 600 to get the tens value. Remember that the Stamp uses integer mathematics — the result of a division will always be a whole number. Getting the ones digit of the hours means dividing by 60 since there are 60 minutes in one hour. But first, we've got to get rid of the tens. This is where the modulus operator helps us. Since the Stamp does math from left to right, we first mod the raw value by 600. This step gets rid of the tens of hours. Now we

can divide by 60 to get the ones.

Getting the minutes works in the same fashion. First, we mod the raw time by 60 to get rid of all the hours, then we divide by 10 to get the tens digit. The final step is getting to the ones minutes, so we mod the raw time by 10. You'll notice that this technique does not modify the value of the rawTime variable.

Since the nibble variables are overlaid with the time register variables, our BCD bytes are ready to SHIFTOUT to the DS1302. Pretty nifty, isn't it? Unless you've used this technique before, you may not be entirely comfortable with the modulus operator. That's okay, everything gets easier with time (no pun intended). Again, I suggest that you work through the steps with a pencil and paper so that you have a firm grasp of the technique.

## **Setting the Clock**

The modulus operator exhibits a behavior that can be very useful: keeping a variable within a range. The result of x // y will always fall between zero and y-1. And, unlike the MIN and MAX operators, the modulus operator causes the result to wrap around. This table will give you a quick idea of how it works:

```
0 // 3 = 0  
1 // 3 = 1  
2 // 3 = 2  
3 // 3 = 0  
- Notice the wrap around  
4 // 3 = 1
```

We'll take advantage of this behavior in our time setting routine. Based on the user input, we'll either add one or 60 (an hour) to our raw time and then mod by 1440. This will keep the time between 0 and 1439 and handle the rollover for us. Without the modulus operator, we'd be forced to use a convoluted IF-THEN construct and test for values. No, thank you.

There is one last modulus trick I'd like to share with you before we move on to our clock circuit and software. In the description above, and in the clock we present here, we're simply adding time and rolling over. But what if we wanted to add another input to this project that told the Stamp to subtract time? How would we handle that?

Hang on, this gets a bit gory .... What you'll do to subtract from the raw time is to add the modulus value (1440) minus the amount you want to subtract. So, to subtract a minute, you'll actually add 1439 to the raw time and then apply the modulus of 1440. For example, to subtract an hour from the raw time, you'll add 1380, then apply the modulus

## Column #33: It's Time to Get Real Using the Dallas Semiconductor 1302 - Part 1

of 1440. This technique takes advantage of the wrap-around behavior of the modulus operator. To perform a subtraction, we simply wrap around something less than a full "turn." Let's go through one to see how this works:

- 8:00 PM (20:00) has a raw time value of 1200
- Subtract one minute:
  - -1200 + (1440 1) = 2639
  - 2639 // 1440 = 1199
  - $-\{1200 1 = 1199\}$
- Subtract an hour:
  - -1200 + (1440 60) = 2580
  - 2580 // 1440 = 1140
  - $\{1200 60 = 1140\}$

At first, this may look like a lot of work. Please trust me when I tell you that it isn't. These modulus operator tricks will streamline your programs, saving valuable EEPROM space for other code. And it's always a good idea to write efficient code, even when the program is "small." Save yourself a possible rewrite — you never know when a small program will grow into a monster.

## Our alarm clock

Now that we've introduced the DS1302 and thoroughly covered the modulus operator, the rest of our alarm clock project is a breeze. My design goal was to use no more than eight of the BS2's I/O pins for the time-keeping and display elements. Four of these pins are used to communicate with the DS1302 and the 74HC595. The rest are used for time-setting buttons and the alarm enable.

To set the clock, press and hold the SET button, then press either the MINUTES or HOURS button to change the time. The BUTTON command debounces the inputs and, with the auto-repeat feature, allows us to change the time quickly by holding either of the time-set buttons. The state of the Time/Alarm input determines which value is displayed and changed. The software is simplified by using an array to hold the raw time values and using the Time/Alarm input as a pointer into the array. When we send the new time to the clock, the seconds value is always reset to zero.

You'll notice that I cheated a bit with the alarm. From a software standpoint, the alarm is always active. This keeps the program simple. The alarm is disabled by opening a switch

connected to the alarm pin. We check for an alarm by comparing the current time with the alarm time. This comparison is done inside a loop so that we can activate the alarm pin for any number of minutes we choose (AlrmOut constant) without worrying about crossing midnight.

For alarm outputs shorter than one minute, you can modify the code and use the seconds value returned from the DS1302.

Okay, it's up to you now. Download the DS1302 documentation from Dallas Semiconductor, get out your breadboards, and build the clock. Once you've got it working, you might want to challenge yourself with adding features. How about a second alarm? How about adding everyone's favorite: a snooze button? And why not add another switch to determine the direction (add or subtract) of the hours and minutes time-set buttons? Next month, we'll talk about some possible solutions to these problems.

#### Time for the BS1?

I can imagine that some BS1 users are feeling just a bit slighted, and I certainly understand. While it is possible to connect the DS1302 to the Stamp 1, the process uses up a lot of code space and doesn't make room for many features. But don't give up, there is another solution. Tune in next month and I'll show you how to build a BS1-based alarm clock with a couple of serial modules. Until then, feel free to use DS1302.BAS from my FTP directory if you'd like to experiment with the DS1302.

```
' Program Listing 33.1
' Stamp Applications: Nuts & Volts, November 1997
' ----[ Title ]-----
' File..... BS2CLOCK.BS2
' Purpose... Stamp II-based Alarm Clock
' Author.... Jon Williams
' E-mail.... jonwms@aol.com
' WWW..... http://members.aol.com/jonwms
' Started... 20 SEP 97
' Updated... 27 SEP 97
' ----[ Program Description ]-----
^{\prime} This program demonstrates basic timekeeping functions using the DS1302
' from Dallas Semiconductor. In order to minimize the number of I/O pins
' used, a 74HC595 is used to send data to an LCD. The DS1302 and 74HC595
' share the Dio and Clock lines.
' ----[ Revision History ] -----
' 26 SEP 97 : Timekeeping functions complete
' 27 SEP 97 : Alarm function complete
' I/O Pin Definitions
' ========
             8
9
10
Dio CON Clk CON
                                ' DS1302.6, 74HC595.14
                              ' DS1302.7, 74HC595.11
                                ' 74HC595.12
CS 595 CON
CS 1302 CON
              11
                                ' DS1302.5
SetHr CON
SetMn CON
              12
              13
TmAlrm VAR
            In14
          In14
Out15
Alarm VAR
' =========
' DS1302 Registers
' =========
WrSc CON $80
                                ' write seconds
RdSc CON $81
                                ' read seconds
```

Page 372 • The Nuts and Volts of BASIC Stamps (Volume 1)

```
WrMn CON
             $82
RdMn CON
              $83
WrHr CON
             $84
RdHr CON $85
CWPr CON $8E
                                   ' write protect register
WPr1 CON
              $80
                                    ' set write protect
                                   ' clear write protect
WPr0 CON $00
WrBrst CON $BE
                                    ' write burst of data
RdBrst CON
             $BF
                                   ' read burst of data
           $C0
$C1
WrRam CON
                                    ' RAM address control
RdRam CON
T24hr CON
              0
                                    ' 24 hour clock mode
T12hr CON
                                    ' 12 hour clock mode
              1
AM
       CON
              0
PM
      CON
              1
AlrmLen CON 1
                                    ' length of alarm (in minutes)
' ==========
' LCD control characters
' =========
            $01
                                    ' clear the LCD
ClrLCD CON
CrsrHm CON $02
                                    ' move cursor to home position
CrsrLf CON $10
                                    ' move cursor left
           $14
$18
$1C
$80
CrsrRt CON
                                    ' move cursor right
DispLf CON
                                   ' shift displayed chars left
DispRt CON
                                   ' shift displayed chars right
                                   ' Display Data RAM control
DDRam CON
CGRam CON
                                   ' Char Gen RAM control
             $40
' ----[ Variables ]-------------
addr VAR
            Byte
                                   ' DS1302 address to read/write
ioByte VAR
             Byte
secs VAR Byte
sc10 VAR secs.HIGHNIB
sc01 VAR secs.LOWNIB
mins VAR Byte
mn10 VAR mins.HIGHNIB
mn01 VAR mins.LOWNIB
hrs VAR Byte
hr10 VAR hrs.HIGHNIB
hr01 VAR hrs.LOWNIB
```

```
ampm VAR hrs.Bit5
tMode VAR hrs.Bit7
                                      0 = AM, 1 = PM
                                    0 = 24, 1 = 12
rawTime VAR Word(2)
                                     ' raw storage of time values
work VAR Word
                                     ' work variable for display output
oldSc VAR Byte apChar VAR Byte
                                     ' previous seconds value
                                     "A" (65) or "P" (80)
char VAR Byte
temp VAR Byte
lcd_E VAR temp.Bit2
lcd_RS VAR temp.Bit3
                                ' character to send to LCD
' work variable for LCD routine
' LCD Enable pin
' Register Select (1 = char)
                                     ' Register Select (1 = char)
butn VAR Byte alrmX VAR Bit
                                    ' BUTTON workspace variable
' ----[ Initialization ]------
Init: DirH = %10001110
       addr = CWPr
                                   ' clear write protect register
       ioByte = WPr0
       GOSUB RTCout
                                 ' set the display flag
' put clock in 24-hour mode
' preset alarm to 6:00 AM
       oldSc = $99
       tMode = T24Hr
       rawTime(0) = 360
                                    set time to 12:00 AM
       GOSUB SetRTm
' Initialize the LCD (Hitachi HD44780 controller)
LCDini: PAUSE 500
                                      ' let the LCD settle
       char = %0011
                                      ' 8-bit mode
       GOSUB LCDcmd
       PAUSE 5
       GOSUB LCDcmd
       GOSUB LCDcmd
                                     ' put in 4-bit mode
       char = %0010
       GOSUB LCDcmd
                           ' disp on, crsr off, blink off
       char = %00001100
       GOSUB LCDcmd
       char = %00000110
                                     ' inc crsr, no disp shift
       GOSUB LCDcmd
       char = ClrLCD
       GOSUB LCDcmd
```

Page 374 • The Nuts and Volts of BASIC Stamps (Volume 1)

```
' ----[ Main Code ]------
Start: GOSUB GetTm
       IF secs = oldSc THEN ChkHr
       GOSUB ShowTm
ChkHr: BUTTON SetHr,0,150,10,butn,0,ChkMn ' is Set Hours pressed?
                                           ' yes, get the clock
       GOSUB GetTm
       rawTime(TmAlrm) = rawTime(TmAlrm)+60//1440
                                            ' skip 1302 set for alarm
       IF TmAlrm = 0 THEN NoSet1
       GOSUB SetRTm
                                            ' set new time
NoSet1: GOSUB ShowTm
                                            ' display the change
       PAUSE 100
                                            ' pause between changes
                                            ' still pressed?
       GOTO ChkHr
ChkMn: BUTTON SetMn,0,150,10,butn,0,ChAlrm ' is Set Mins pressed?
       GOSUB GetTm
       rawTime(TmAlrm) = rawTime(TmAlrm)+1//1440
       IF TmAlrm = 0 THEN NoSet2
       GOSUB SetRTm
NoSet2: GOSUB ShowTm
      PAUSE 100
       GOTO ChkMn
ChAlrm: IF AlrmLen = 0 THEN Start
                                           ' skip if no alarm length
       alrmX = 0
                                           ' assume no alarm
       FOR temp = 0 TO (AlrmLen-1) ' check for length of al work = rawTime(0)+temp//1440 ' calculate alarm range
                                           ' check for length of alarm
         IF rawTime(1) <> work THEN NoAlrm ' is time in range?
NoAlrm: NEXT
      Alarm = alrmX
                                            ' output the alarm state
       GOTO Start
                                            ' start all over
' ----[ Subroutines ] ---------
' send a byte (ioByte) to the DS1302 location specified by addr
RTCout: HIGH CS_1302
' get a byte (ioByte) from the DS1302 location specified by addr
RTCin: HIGH CS 1302
       SHIFTOUT Dio,Clk,LSBFIRST,[addr]
       SHIFTIN Dio, Clk, LSBPRE, [ioByte]
       LOW CS_1302
```

```
RETURN
' convert raw time format to BCD bytes for DS1302
SetRTm: hr10 = rawTime(1) / 600
       hr01 = rawTime(1) // 600 / 60
       mn10 = rawTime(1) // 60 / 10
       mn01 = rawTime(1) // 10
       secs = $00
' use burst mode to set the clock and calendar
 -- do not remove the third SHIFTOUT line
' -- you must send 8 bytes for data to be written in burst mode
SetTm: HIGH CS 1302
       addr = WrBrst
       temp = 0
       SHIFTOUT Dio, Clk, LSBFIRST, [addr]
       SHIFTOUT Dio, Clk, LSBFIRST, [secs, mins, hrs]
       SHIFTOUT Dio, Clk, LSBFIRST, [temp, temp, temp, temp]
       LOW CS_1302
       RETURN
' use burst mode to the grab time (hrs, mins & secs)
GetTm: HIGH CS 1302
       addr = RdBrst
       SHIFTOUT Dio, Clk, LSBFIRST, [addr]
       SHIFTIN Dio, Clk, LSBPRE, [secs, mins, hrs]
       LOW CS 1302
       rawTime(1) = ((hr10 \& %11)*600) + (hr01*60) + (mn10*10) + mn01
       RETURN
' Send command to the LCD
LCDcmd: lcd RS = 0
                                     ' command mode
       GOTO LCDout
' Write ASCII char to LCD
LCDwr: lcd RS = 1
                                      ' character mode
LCDout: temp.HIGHNIB = char.HIGHNIB ' get high nibble
       lcd_E = 1
       SHIFTOUT Dio, Clk, MSBFIRST, [temp]
       PULSOUT CS_595, 1
       lcd E = 0
                                      ' drop Enable line low
       SHIFTOUT Dio, Clk, MSBFIRST, [temp]
       PULSOUT CS_595, 1
       temp.HIGHNIB = char.LOWNIB ' get low nibble
```

Page 376 • The Nuts and Volts of BASIC Stamps (Volume 1)

```
lcd_E = 1
       SHIFTOUT Dio, Clk, MSBFIRST, [temp]
       PULSOUT CS_595, 1
       lcd E = 0
       SHIFTOUT Dio, Clk, MSBFIRST, [temp]
       PULSOUT CS 595, 1
       RETURN
' Show time in LCD
' -- the time displayed is controlled by the position
' -- of the TmAlrm switch input
ShowTm: char = DDRam+$02
                                    ' move to third position in LCD
      GOSUB LCDcmd
      work = rawTime(TmAlrm)
                                   ' get the raw time
                                    ' extract (decimal) hours
      hrs = work / 60
       mins = work // 60
                                    ' extract (decimal) minutes
      IF TmAlrm = 1 THEN STO
      secs = 0
                                    ' show zero seconds if alarm
      apChar = "A"
ST0:
      IF hrs > 0 THEN ST1
      hrs = 12
                                    ' zero hours --> 12 AM
      GOTO ST3
ST1:
      IF hrs > 11 THEN ST2
      GOTO ST3
ST2:
      apChar = "P"
       IF hrs = 12 THEN ST3
      hrs = hrs-12
                                    ' 13 - 23 --> 1 - 11 PM
                                    ' get hours, convert to ASCII
ST3:
      char = hrs DIG 1+48
      IF char <> "0" THEN ST4
      char = " "
                                    ' remove leading zero
ST4:
      GOSUB LCDwr
                                    ' write hours.tens
      char = hrs DIG 0+48
      GOSUB LCDwr
                                    ' write hours.ones
       char = ":"
       GOSUB LCDwr
       char = mins DIG 1+48
       GOSUB LCDwr
       char = mins DIG 0+48
       GOSUB LCDwr
       char = ":"
       GOSUB LCDwr
       char = sc10+48
       GOSUB LCDwr
```

# Column #33: It's Time to Get Real Using the Dallas Semiconductor 1302 - Part 1